

Programming Guide

ZPL II
ZBI 2
Set-Get-Do
Mirror
WML



ZEBRA

© 2018 ZIH Corp. All rights reserved. ZEBRA and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners.

Information in this document is subject to change without notice.

For further information regarding legal and proprietary statements, please go to:

COPYRIGHTS: www.zebra.com/copyright

WARRANTY: www.zebra.com/warranty

END USER LICENSE AGREEMENT: www.zebra.com/eula

SOFTWARE: www.zebra.com/linkoslegal

Terms of Use

Proprietary Statement This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries (“Zebra Technologies”). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

Product Improvements Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

Liability Disclaimer Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

Limitation of Liability In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Contents

Contents	3	^BK ANSI Codabar Bar Code	96
Functional List of ZPL Commands	15	^BL LOGMARS Bar Code	98
Alphabetical List of ZBI Commands	19	^BM MSI Bar Code	100
Alphabetical List of Set/Get/Do Commands	21	^BO Aztec Bar Code Parameters	102
About This Document	27	^BP Plessey Bar Code	104
Contact Zebra	28	^BQ QR Code Bar Code	106
Introduction	28	^BR GS1 Databar	113
Who Should Use This Document	28	^BS UPC/EAN Extensions	115
How This Document Is Organized	29	^BT TLC39 Bar Code	118
ZPL Commands	31	^BU UPC-A Bar Code	120
Basic ZPL Exercises and Examples	32	^BX Data Matrix Bar Code	122
Allowed Characters in File Names	41	^BY Bar Code Field Default	126
^A Scalable/Bitmapped Font	42	^BZ POSTAL Bar Code	127
^A@ Use Font Name to Call Font	44	^CC ~CC Change Caret	129
^B0 Aztec Bar Code Parameters	46	^CD ~CD Change Delimiter	130
^B1 Code 11 Bar Code	48	^CF Change Alphanumeric Default Font	131
^B2 Interleaved 2 of 5 Bar Code	50	^CI Change International Font/Encoding	132
^B3 Code 39 Bar Code	52	^CM Change Memory Letter Designation	136
^B4 Code 49 Bar Code	56	^CN Cut Now	138
^B5 Planet Code bar code	60	^CO Cache On	139
^B7 PDF417 Bar Code	61	^CP Remove Label	141
^B8 EAN-8 Bar Code	64	^CT ~CT Change Tilde	142
^B9 UPC-E Bar Code	66	^CV Code Validation	143
^BA Code 93 Bar Code	68	^CW Font Identifier	145
^BB CODABLOCK Bar Code	72	~DB Download Bitmap Font	147
^BC Code 128 Bar Code (Subsets A, B, and C)	76	~DE Download Encoding	149
^BD UPS MaxiCode Bar Code	87	^DF Download Format	151
^BE EAN-13 Bar Code	89	~DG Download Graphics	152
^BF MicroPDF417 Bar Code	91	~DN Abort Download Graphic	155
^BI Industrial 2 of 5 Bar Codes	93	~DS Download Intellifont (Scalable Font)	156
^BJ Standard 2 of 5 Bar Code	95	~DT Download Bounded TrueType Font	157
		~DU Download Unbounded TrueType Font	158
		~DY Download Objects	159
		~EG Erase Download Graphics	162
		^FB Field Block	163
		^FC Field Clock	166

^FD Field Data	167	~JQ Terminate Zebra BASIC Interpreter	244
^FH Field Hexadecimal Indicator	168	~JR Power On Reset	245
^FL Font Linking	170	^JS Sensor Select	246
^FM Multiple Field Origin Locations	172	~JS Change Backfeed Sequence	247
^FN Field Number	175	^JT Head Test Interval	248
^FO Field Origin	176	^JU Configuration Update	249
^FP Field Parameter	177	^JW Set Ribbon Tension	250
^FR Field Reverse Print	178	~JX Cancel Current Partially Input Format	251
^FS Field Separator	179	^JZ Reprint After Error	252
^FT Field Typeset	180	~KB Kill Battery (Battery Discharge Mode)	253
^FV Field Variable	182	^KD Select Date and Time Format (for Real Time Clock)	254
^FW Field Orientation	183	^KL Define Language	255
^FX Comment	185	^KN Define Printer Name	256
^GB Graphic Box	186	^KP Define Password	257
^GC Graphic Circle	188	^KV Kiosk Values	258
^GD Graphic Diagonal Line	189	^LF List Font Links	262
^GE Graphic Ellipse	190	^LH Label Home	263
^GF Graphic Field	191	^LL Label Length	264
^GS Graphic Symbol	193	^LR Label Reverse Print	265
~HB Battery Status	194	^LS Label Shift	266
~HD Head Diagnostic	195	^LT Label Top	267
^HF Host Format	196	^MA Set Maintenance Alerts	268
^HG Host Graphic	197	^MC Map Clear	270
^HH Configuration Label Return	198	^MD Media Darkness	271
~HI Host Identification	199	^MF Media Feed	272
~HM Host RAM Status	200	^MI Set Maintenance Information Message	273
~HQ Host Query	201	^ML Maximum Label Length	274
~HS Host Status Return	207	^MM Print Mode	275
^HT Host Linked Fonts List	210	^MN Media Tracking	277
~HU Return ZebraNet Alert Configuration	211	^MP Mode Protection	278
^HV Host Verification	212	^MT Media Type	280
^HW Host Directory List	213	^MU Set Units of Measurement	281
^HY Upload Graphics	215	^MW Modify Head Cold Warning	282
^HZ Display Description Information	216	^NC Select the Primary Network Device	283
^ID Object Delete	217	~NC Network Connect	284
^IL Image Load	219	^ND Change Network Settings	285
^IM Image Move	220	^NI Network ID Number	287
^IS Image Save	221	~NR Set All Network Printers Transparent	288
~JA Cancel All	223	^NS Change Wired Networking Settings	289
^JB Initialize Flash Memory	224	~NT Set Currently Connected Printer Transparent	290
~JB Reset Optional Memory	225	^PA Advanced Text Properties	291
~JC Set Media Sensor Calibration	226	^PF Slew Given Number of Dot Rows	292
~JD Enable Communications Diagnostics	227	^PH ~PH Slew to Home Position	293
~JE Disable Diagnostics	228	~PL Present Length Addition	294
~JF Set Battery Condition	229	^PM Printing Mirror Image of Label	295
~JG Graphing Sensor Calibration	230	^PN Present Now	296
^JH Early Warning Settings	231	^PO Print Orientation	297
^JI Start ZBI (Zebra BASIC Interpreter)	234	^PP ~PP Programmable Pause	298
~JI Start ZBI (Zebra BASIC Interpreter)	236	^PQ Print Quantity	299
^JJ Set Auxiliary Port	237	~PR Applicator Reprint	300
~JL Set Label Length	239	^PR Print Rate	301
^JM Set Dots per Millimeter	240	~PS Print Start	303
~JN Head Test Fatal	241	^PW Print Width	304
~JO Head Test Non-Fatal	242	~RO Reset Advanced Counters	305
~JP Pause and Cancel Format	243		

^SC Set Serial Communications 306
~SD Set Darkness 307
^SE Select Encoding Table 308
^SF Serialization Field (with a Standard ^FD String) . . 309
^SI Set Sensor Intensity 312
^SL Set Mode and Language (for Real-Time Clock) . . 313
^SN Serialization Data 315
^SO Set Offset (for Real-Time Clock) 317
^SP Start Print 318
^SQ Halt ZebraNet Alert 319
^SR Set Printhead Resistance 320
^SS Set Media Sensors 321
^ST Set Date and Time (for Real-Time Clock) 323
^SX Set ZebraNet Alert 324
^SZ Set ZPL Mode 326
~TA Tear-off Adjust Position 327
^TB Text Blocks 328
^TO Transfer Object 329
~WC Print Configuration Label 331
^WD Print Directory Label 332
~WQ Write Query 333
^XA Start Format 339
^XB Suppress Backfeed 340
^XF Recall Format 341
^XG Recall Graphic 342
^XS Set Dynamic Media Calibration 343
^XZ End Format 344
^ZZ Printer Sleep 345

ZPL RFID Commands 347

RFID Command Overview 348
Printer and Firmware Compatibility 349
^HL or ~HL Return RFID Data Log to Host 353
^HR Calibrate RFID Tag Position 354
^RA Read AFI or DSFID Byte 361
^RB Define EPC Data Structure 362
^RE Enable/Disable E.A.S. Bit 364
^RF Read or Write RFID Format 365
^RI Get RFID Tag ID 369
^RL Lock/Unlock RFID Tag Memory 370
^RM Enable RFID Motion 372
^RN Detect Multiple RFID Tags in Encoding Field . . . 373
^RQ Quick Write EPC Data and Passwords 374
^RR Specify RFID Retries for a Block or Enable Adaptive
Antenna Selection 376
^RS Set Up RFID Parameters 378
^RT Read RFID Tag 383
^RU Read Unique RFID Chip Serialization 385
~RV Report RFID Encoding Results 387
^RW Set RF Power Levels for Read and Write 388
^RZ Set RFID Tag Password and Lock Tag 392
^WF Encode AFI or DSFID Byte 395
^WT Write (Encode) Tag 396
^WV Verify RFID Encoding Operation 398

ZPL Wireless Commands 401

^KC Set Client Identifier (Option 61) 402
^NB Search for Wired Print Server during
Network Boot 403
^NN Set SNMP 404
^NP Set Primary/Secondary Device 405
^NT Set SMTP 406
^NW Set Web Authentication Timeout Value 407
^WA Set Antenna Parameters 408
^WE Set WEP Mode 409
^WI Change Wireless Network Settings 411
^WL Set LEAP Parameters 412
~WL Print Network Configuration Label 413
^WP Set Wireless Password 414
^WR Set Transmit Rate 415
~WR Reset Wireless Radio Card and Print Server . . . 416
^WS Set Wireless Radio Card Values 417
^WX Configure Wireless Securities 419

ZBI Commands 427

Introduction to Zebra Basic Interpreter (ZBI) 428
Command and Function Reference Format 429
Section Organization 430
Editing Commands 431
NEW 433
REM 434
! (EXCLAMATION MARK) 435
LIST 436
AUTONUM 437
RENUM 438
ECHO 439
Running and Debugging Commands 439
RUN 441
CTRL-C 442
RESTART 443
STEP 444
DEBUG 445
TRACE 446
BREAK 447
ADDBREAK 448
DELBREAK 449
ZPL 450
Base Types and Expressions 450
LET 454
Control and Flow 459
IF Statements 461
DO Loops 462
FOR Loops 463
GOTO/GOSUB 464
SUB 465
EXIT 466
END 467
Input and Output 467
OPEN 469
CLOSE 470
DATAREADY 471
SERVERSOCKET 472
SERVERCLOSE 473
CLIENTSOCKET 474

ACCEPT	475	FIND	551
INPUT	476	Time and Date Functions	552
PRINT	477	DATE\$	554
OUTBYTE	478	TIME\$	555
INBYTE	479	DATE	556
READ	480	TIME	557
WRITE	481	Set/Get/Do Interactions	557
SEARCHTO\$	482	SETVAR	558
File System	488	GETVAR\$	559
STORE	490	Example Programs	559
LOAD	491		
DIR	492	SGD Printer Commands	571
DELETE	493	Overview	572
Comma Separated Values (CSV)	493	Command Structure	573
CSVLOAD	494	JSON (JavaScript Object Notation)	574
CSVSTORE	496	alerts.add	577
TXLOAD	497	alerts.conditions	578
TXTSTORE	498	alerts.configured	579
Events	498	alerts.destinations	580
REGISTEREVENT	504	alerts.http.authentication.add	581
UNREGISTEREVENT	506	alerts.http.authentication.entries	583
HANDLEEVENT	507	alerts.http.authentication.remove	584
TRIGGEREVENT	509	alerts.http.logging.clear	585
Systems	509	alerts.http.logging.entries	586
ISERROR	511	alerts.http.logging.max_entries	587
ISWARNING	512	alerts.http.proxy	588
SLEEP	513	alerts.tracked_settings.clear_log	589
SETERR	514	alerts.tracked_settings.log_tracked	590
CLRERR	515	alerts.tracked_settings.max_log_entries	591
ON ERROR	516	alerts.tracked_sgds.log	592
AUXPORT_STEALPIN	517	alerts.tracked_sgds.max_log_entries	593
AUXPORT_SETPIN	518	alerts.tracked_sgds.zbi_notified	594
AUXPORT_GETPIN	519	apl.enable	595
AUXPORT_RELEASEPIN	520	apl.framework_version	596
String Functions	520	apl.version	597
LCASE\$	521	appl.link_os_version	598
CHR\$	522	appl.option_board_version	599
LTRIM\$	523	appl.bootblock	600
REPEAT\$	524	appl.date	601
RTRIM\$	525	appl.name	602
SPLIT	526	capture.channel1.count	603
SPLITCOUNT	530	capture.channel1.data.mime	604
UCASE\$	531	capture.channel1.data.raw	605
EXTRACT\$	532	capture.channel1.delimiter	606
ORD	534	capture.channel1.max_length	607
POS	535	capture.channel1.port	608
LEN	536	CISDFCRC16	609
Math Functions	536	Download Files	609
STR\$	537	comm.baud	611
MAX	538	comm.halt	612
MIN	539	comm.pnp_option	613
MAXNUM	540	comm.type	614
MOD	541	comm.parity	615
VAL	542	comm.stop_bits	616
INTTOHEX\$	543	cradle.comm.baud	617
HEXTOINT	544	cradle.comm.handshake	618
Array Functions	544	cutter.clean_cutter	619
REDIM	546	device.applicator.data_ready	620
INSERTROW	547	device.applicator.end_print	621
DELROW	548	device.applicator.feed	622
ROWSIZE	549	device.applicator.media_out	623
COLUMNSIZE	550		

device.applicator.pause	624	device.slot_2	689
device.applicator.reprint	625	device.super_host_status	690
device.applicator.rfid_void	626	device.syslog.clear_log	691
device.applicator.ribbon_low	627	device.syslog.configuration	692
device.applicator.ribbon_out	628	device.syslog.enable	694
device.applicator.service_required	629	device.syslog.entries	695
device.applicator.start_print	630	device.syslog.log_max_file_size	696
device.bluetooth_installed	631	device.syslog.save_local_file	697
device.command_override.active	632	device.applicator.data_ready_activation	698
device.command_override.add	633	device.applicator.error_on_pause	699
device.command_override.clear	634	device.applicator.start_print_mode	700
device.command_override.list	635	device.applicator.voltage	701
device.company_contact	636	device.unique_id	702
device.configuration_number	637	device.unpause	703
device.cpcl_synchronous_mode	638	device.uptime	704
device.cutter_installed	639	device.user_p1	705
device.download_connection_timeout	640	device.user_p2	706
device.epi_legacy_mode	641	device.user_vars.set_range	707
device.feature.bluetooth_le	643	device.user_vars.create	708
device.feature.mcr	644	device.xml.enable	710
device.feature.nfc	645	device.feature.lighted_arrows	711
device.feature.ribbon_cartridge	646	device.light.ribbon_path_brightness	712
device.friendly_name	647	device.light.media_path_brightness	713
device.frontpanel.feedenabled	648	display.backlight	714
device.frontpanel.key_press	649	display.backlight_on_time	715
device.frontpanel.line1	650	display.batch_counter	716
device.frontpanel.line2	651	display.language	717
device.frontpanel.xml	652	display.load_card	718
device.host_identification	653	display.password.level	719
device.host_status	654	display.root_wml	720
device.idle_display_format	657	display.text	721
device.idle_display_value	658	file.capture_response.destination	722
device.internal_wired_setting_location	659	head.resolution.in_dpi	723
device.jobs_print	660	ezpl.head_close_action	724
device.languages	661	ezpl.label_length_max	725
device.light.cover_open_brightness	662	ezpl.label_sensor	726
device.light.head_open_brightness	663	ezpl.manual_calibration	727
device.location	664	ezpl.media_type	728
device.ltu_installed	665	ezpl.power_up_action	729
device.orientation	666	ezpl.print_method	730
device.pause	667	ezpl.print_width	731
device.pnp_option	668	ezpl.reprint_mode	732
device.pmcu.revision	669	ezpl.take_label	733
device.position.accuracy	670	ezpl.tear_off	734
device.position.altitude	671	file.delete	735
device.position.latitude	672	file.dir	736
device.position.longitude	673	file.dir_format	737
device.print_2key	674	file.type	738
device.print_reprogram_2key	675	file.run	739
device.product_name_submodel	676	formats.cancel_all	740
device.prompted_network_reset	677	head.darkness_switch_enable	741
device.reset	678	head.darkness_switch	743
device.restore_defaults	679	head.element_test	744
device.rewinder_installed	680	head.latch	745
device.save_2key	681	input.capture	746
device.sensor_select	682	interface.network.active.arp_interval	747
device.serial_number.option_board_date	683	interface.network.active.cable_type	748
device.serial_numbers.control_panel_date	684	interface.network.active.dhcp_received_host_name	749
device.serial_numbers.mlb_date	685	interface.network.active.gateway	750
device.serial_numbers.processor	686	interface.network.active.ip_addr	751
device.set_clock_to_build_date	687	interface.network.active.mac_addr	752
device.slot_1	688	interface.network.active.mac_raw	753

interface.network.active.netmask	754	netmanage.avalanche.interval_update	819
interface.network.active.protocol	755	netmanage.avalanche.model_name	820
interface.network.active.protocol_error	756	netmanage.avalanche.set_property	821
interface.network.active.rx_errors	757	netmanage.avalanche.startup_update	822
interface.network.active.rx_packets	758	netmanage.avalanche.tcp_connection_timeout	823
interface.network.active.server_address	759	netmanage.avalanche.terminal_id	824
interface.network.active.protocol_error	760	netmanage.avalanche.text_msg.beep	825
interface.network.active.speed	761	netmanage.avalanche.text_msg.display	826
interface.network.active.tx_errors	762	netmanage.avalanche.text_msg.print	827
interface.network.active.tx_packets	763	netmanage.avalanche.udp_timeout	828
interface.network.active.wins_addr	764	netmanage.error_code	829
interface.network.settings_require_reset	765	netmanage.state_code	830
ip.firewall.whitelist_in	766	netmanage.status_code	831
ip.https.enable	768	odometer.cut_marker_count	832
ip.https.port	769	odometer.headclean	833
ip.ping_gateway_interval	770	odometer.headnew	834
ip.pop3.print_body	771	odometer.label_dot_length	835
ip.pop3.print_headers	772	odometer.media_marker_count	836
ip.pop3.save_attachments	773	odometer.media_marker_count1	837
ip.pop3.verbose_headers	774	odometer.media_marker_count2	838
ip.tls.enable	775	odometer.retracts_count	839
ip.tls.port	777	odometer.rfid.valid_resetable	840
ip.tls.port_json_config	778	odometer.rfid.void_resetable	841
log.reboot.code	779	odometer.total_cuts	842
log.reboot.codes	780	odometer.total_print_length	843
log.reboot.reason	781	odometer.total_label_count	844
log.reboot.report	782	odometer.user_label_count	845
mcr.crypt.enabled	783	odometer.user_label_count[1 2]	846
mcr.cancel	784	odometer.latch_open_count	847
mcr.crypt.key_mgmt	785	parallel_port.mode	848
mcr.crypt.algorithm	786	parallel_port.present	849
mcr.out	787	power.average_current	851
mcr.revision	788	power.battery_led_blink_rate	852
media.bar_location	789	power.battery_led_enable	853
media.cartridge.part_number	790	power.battery_led_off_duration	854
media.cut_now	791	power.battery_led_on_duration	855
media.darkness_mode	792	power.battery_replacement_cyclecount_threshold	856
media.draft_mode	793	power.dtr_power_off	857
media.feed_skip	794	power.energy_star.enable	859
media.media_low.external	795	power.energy_star.timeout	861
media.media_low.warning	796	power.label_queue.shutdown	862
media.part_number	797	power.power_on_mode	863
media.present.cut_amount	798	power.shutdown	864
media.present.eject	799	print.tone	865
media.present.length_addition	800	print.troubleshooting_label_print	866
media.present.loop_length	801	rfid.adaptive_antenna	867
media.present.loop_length_max	802	rfid.antenna_sweep	868
media.present.cut_margin	803	DNP - rfid.calibration_maximum_power	869
media.present.present_timeout	804	rfid.country_code	870
media.present.present_type	805	rfid.enable	871
media.printmode	806	rfid.error.response	872
media.speed	808	rfid.hop_table_version	873
media.serial_number	809	rfid.position.program	874
memory.flash_free	810	rfid.reader_1.antenna_port	876
memory.flash_size	811	rfid.reader_1.power.read	879
memory.ram_free	812	rfid.reader_1.power.write	880
memory.ram_size	813	rfid.reader_1.power.single_power	881
netmanage.avalanche.agent_addr	814	rfid.reader_1.firmware_version	882
netmanage.avalanche.available_agent	815	rfid.reader_1.hardware_version	883
netmanage.avalanche.available_port	816	rfid.reader_1.model	884
netmanage.avalanche.encryption_type	817	rfid.recipe_version	885
netmanage.avalanche.interval	818	rfid.region_code	886

rfid.tag.calibrate	887	zbi.control.run	953
rfid.tag.data	888	zbi.control.step	954
rfid.tag.read.content	889	zbi.control.terminate	955
rfid.tag.read.execute	890	zbi.control.variable_name	956
rfid.tag.read.result_line1	891	zbi.control.variable_value	957
rfid.tag.read.result_line2	892	zbi.enable	958
rfid.tag.read.result_line1_alternate	893	zbi.key	959
rfid.tag.read.result_line2_alternate	894	zbi.last_error	960
rfid.tag.test	895	zbi.program_list	961
rfid.tag.test.content	896	zbi.reseller_key	962
rfid.tag.test.execute	897	zbi.revision	963
rfid.tag.test.result_line1	898	zbi.running_program_name	964
rfid.tag.test.result_line2	899	zbi.start_info.execute	965
rfid.tag.type	900	zbi.start_info.file_name	966
ribbon.serial_number	903	zbi.start_info.memory_alloc	967
ribbon.part_number	904	zbi.state	968
rtc.timezone	905	zpl.caret	969
sensor.cover_open	907	zpl.control_character	970
sensor.paper_supply	908	zpl.delimiter	971
sensor.peeler	909	zpl.label_length	972
sensor.self_adjusting_enable	911	zpl.left_position	973
usb.device.device_id_string	912	zpl.system_error	974
usb.device.device_unique_id	913	zpl.system_status	976
usb.device.device_version	914	zpl.zpl_mode	979
usb.device.manufacturer_string	915	zpl.zpl_override	980
usb.device.product_id	916	zpl.relative_darkness	981
usb.device.product_string	917		
usb.device.serial_string	918		
usb.device.vendor_id	919		
usb.halt	920		
usb.host.fn_field_data	921		
usb.host.fn_last_field	922		
usb.host.hid_count	923		
usb.host.keyboard_input	924		
usb.host.lock_out	925		
usb.host.mass_storage_count	926		
usb.host.read_list	927		
usb.host.read_list_print_delay	928		
usb.host.template_list	929		
usb.host.template_print_amount	930		
usb.host.write_list	931		
usb.mirror.appl_path	932		
usb.mirror.auto	933		
usb.mirror.enable	934		
usb.mirror.enabled	935		
usb.mirror.error_retry	936		
usb.mirror.feedback.auto	937		
usb.mirror.feedback.odometer	938		
usb.mirror.feedback.path	939		
usb.mirror.fetch	940		
usb.mirror.last_error	941		
usb.mirror.last_time	942		
usb.mirror.path	943		
usb.mirror.reset_delay	944		
usb.mirror.success	945		
usb.mirror.success_time	946		
zbi.control.add_breakpoint	947		
zbi.control.break	948		
zbi.control.clear_breakpoints	949		
zbi.control.delete_breakpoint	950		
zbi.control.line_number	951		
zbi.control.restart	952		
		SGD Wired Commands	983
		Overview	985
		Command Structure	986
		external_wired.check	987
		external_wired.ip.addr	988
		external_wired.ip.arp_interval	989
		external_wired.ip.default_addr_enable	990
		external_wired.ip.dhcp.cid_all	991
		external_wired.ip.dhcp.cid_enable	992
		external_wired.ip.dhcp.cid_prefix	993
		external_wired.ip.dhcp.cid_suffix	994
		external_wired.ip.dhcp.cid_type	995
		external_wired.ip.gateway	996
		external_wired.ip.netmask	997
		external_wired.ip.port	998
		external_wired.ip.protocol	999
		external_wired.ip.timeout.enable	1000
		external_wired.ip.timeout.value	1001
		external_wired.ip.v6.addr	1002
		external_wired.ip.v6.gateway	1003
		external_wired.ip.v6.prefix_length	1004
		external_wired.mac_addr	1005
		external_wired.mac_raw	1006
		internal_wired.8021x.password	1007
		internal_wired.8021x.peap.validate_server_certificate	1008
		internal_wired.8021x.peap.anonymous_identity	1009
		internal_wired.8021x.private_key_password	1010
		internal_wired.8021x.security	1011
		internal_wired.8021x.ttls_tunnel	1012
		internal_wired.8021x.username	1013
		internal_wired.activity_led	1014
		internal_wired.auto_switchover	1015
		internal_wired.enable	1016
		internal_wired.installed	1017
		internal_wired.ip.addr	1018

internal_wired.ip.arp_interval	1019	ip.dhcp.auto_provision_enable	1082
internal_wired.ip.default_addr_enable	1020	ip.dhcp.cache_ip	1083
internal_wired.ip.dhcp.arp_verify	1021	ip.dhcp.cid_all	1084
internal_wired.ip.dhcp.cache_ip	1022	ip.dhcp.cid_enable	1085
internal_wired.ip.dhcp.cid_all	1023	ip.dhcp.cid_prefix	1086
internal_wired.ip.dhcp.cid_enable	1024	ip.dhcp.cid_suffix	1087
internal_wired.ip.dhcp.cid_prefix	1025	ip.dhcp.cid_type	1088
internal_wired.ip.dhcp.cid_suffix	1026	ip.dhcp.cid_value	1089
internal_wired.ip.dhcp.cid_type	1027	ip.dhcp.enable	1090
internal_wired.ip.dhcp.lease.last_attempt	1028	ip.dhcp.lease.last_attempt	1091
internal_wired.ip.dhcp.lease.length	1029	ip.dhcp.lease.server	1092
internal_wired.ip.dhcp.lease.server	1030	ip.dhcp.lease.time_left	1093
internal_wired.ip.dhcp.lease.time_left	1031	ip.dhcp.ntp.enable	1094
internal_wired.ip.dhcp.option12	1032	ip.dhcp.ntp.received_servers	1095
internal_wired.ip.dhcp.option12_format	1033	ip.dhcp.option12	1096
internal_wired.ip.dhcp.option12_value	1034	ip.dhcp.option12_format	1097
internal_wired.ip.dhcp.requests_per_session	1035	ip.dhcp.option12_value	1098
internal_wired.ip.dns.servers	1036	ip.dhcp.request_timeout	1099
internal_wired.ip.gateway	1037	ip.dhcp.requests_per_session	1100
internal_wired.ip.netmask	1038	ip.dhcp.session_interval	1101
internal_wired.ip.port	1039	ip.dhcp.user_class_id	1102
internal_wired.ip.port_alternate	1040	ip.dhcp.vendor_class_id	1103
internal_wired.ip.port_json_config	1041	ip.dns.domain	1104
internal_wired.ip.protocol	1042	ip.dns.servers	1105
internal_wired.ip.timeout.enable	1043	ip.ftp.enable	1106
internal_wired.ip.timeout.value	1044	ip.ftp.execute_file	1107
internal_wired.ip.wins.addr	1045	ip.ftp.request_password	1108
internal_wired.ip.wins.permanent_source	1046	ip.gateway	1109
internal_wired.mac_addr	1047	ip.http.admin_name	1110
internal_wired.mac_raw	1048	ip.http.admin_password	1111
		ip.http.custom_link_name	1112
		ip.http.custom_link_url	1113
		ip.http.enable	1114
		ip.http.faq_url	1115
		ip.http.port	1116
		ip.lpd.enable	1117
		ip.mac_raw	1118
		ip.mirror.appl_path	1119
		ip.mirror.auto	1120
		ip.mirror.error_retry	1121
		ip.mirror.feedback.auto	1122
		ip.mirror.feedback.freq	1123
		ip.mirror.feedback.odometer	1124
		ip.mirror.feedback.path	1125
		ip.mirror.fetch	1126
		ip.mirror.freq	1127
		ip.mirror.freq_hours	1128
		ip.mirror.interface	1129
		ip.mirror.last_error	1130
		ip.mirror.last_time	1131
		ip.mirror.mode	1132
		ip.mirror.password	1133
		ip.mirror.path	1134
		ip.mirror.reset_delay	1135
		ip.mirror.server	1136
		ip.mirror.success	1137
		ip.mirror.success_time	1138
		ip.mirror.username	1139
		ip.mirror.version	1140
		ip.netmask	1141
		ip.ntp.enable	1142
		ip.ntp.log	1143
SGD Wireless Commands	1051		
Overview	1052		
Command Structure	1053		
bluetooth.address	1054		
bluetooth.afh_map	1055		
bluetooth.afh_map_curr	1056		
bluetooth.afh_mode	1057		
bluetooth.authentication	1058		
bluetooth.bluetooth_pin	1059		
bluetooth.clear_bonding_cache	1060		
bluetooth.date	1061		
bluetooth.discoverable	1062		
bluetooth.enable	1063		
bluetooth.enable_reconnect	1064		
bluetooth.friendly_name	1065		
bluetooth.json_config_channel_enable	1066		
bluetooth.le.controller_mode	1067		
bluetooth.le.minimum_security	1068		
bluetooth.local_name	1069		
bluetooth.minimum_security_mode	1070		
bluetooth.radio_auto_baud	1071		
bluetooth.radio_version	1072		
bluetooth.short_address	1073		
bluetooth.version	1074		
card.mac_addr	1075		
card.inserted	1076		
ip.active_network	1077		
ip.addr	1078		
ip.arp_interval	1079		
ip.bootp.enable	1080		
ip.dhcp.arp_verify	1081		

ip.ntp.servers	1144	wlan.authentication_error	1212
ip.pop3.enable	1145	wlan.available	1213
ip.pop3.password	1146	wlan.allowed_band	1214
ip.pop3.poll	1147	wlan.adhocautomode	1215
ip.pop3.server_addr	1148	wlan.adhocchannel	1216
ip.pop3.username	1149	wlan.associated	1217
ip.port	1150	wlan.auth_type	1218
ip.port_alternate	1151	wlan.bssid	1219
ip.port_json_config	1152	wlan.channel	1220
ip.port_single_conn	1153	wlan.channel_mask	1221
ip.port_single_conn_idle_timeout	1154	wlan.country_code	1222
ip.primary_network	1155	wlan.current_tx_rate	1223
ip.smtp.domain	1156	wlan.enable	1224
ip.smtp.enable	1157	wlan.encryption_index	1225
ip.smtp.server_addr	1158	wlan.encryption_key[1 2 3 4]1	1226
ip.snmp.get_community_name	1159	wlan.encryption_mode	1227
ip.snmp.set_community_name	1160	wlan.essid	1228
ip.snmp.trap_community_name	1161	wlan.firmware_version	1229
ip.snmp.enable	1162	wlan.ip.addr	1230
ip.tcp.enable	1163	wlan.ip.arp_interval	1231
ip.telnet.enable	1164	wlan.ip.default_addr_enable	1232
ip.tcp.nagle_algorithm	1165	wlan.ip.dhcp.arp_verify	1233
ip.udp.enable	1166	wlan.ip.dhcp.cache_ip	1234
weblink.cloud_connect.enable	1167	wlan.ip.dhcp.cid_all	1235
weblink.enable	1168	wlan.ip.dhcp.cid_enable	1236
weblink.ip.conn[1 2].authentication.add	1169	wlan.ip.dhcp.cid_prefix	1237
weblink.ip.conn[1 2].authentication.entries	1171	wlan.ip.dhcp.cid_suffix	1238
weblink.ip.conn[1 2].authentication.remove	1172	wlan.ip.dhcp.cid_type	1239
weblink.ip.conn[1 2].location	1173	wlan.ip.dhcp.lease.last_attempt	1240
weblink.ip.conn[1 2].num_connections	1174	wlan.ip.dhcp.lease.length	1241
weblink.ip.conn[1 2].maximum_simultaneous_connections	1175	wlan.ip.dhcp.lease.server	1242
weblink.ip.conn[1 2].proxy	1176	wlan.ip.dhcp.lease.time_left	1243
weblink.ip.conn[1 2].retry_interval	1178	wlan.ip.dhcp.option12	1244
weblink.ip.conn[1 2].test.location	1179	wlan.ip.dhcp.option12_format	1245
weblink.ip.conn[1 2].test.retry_interval	1181	wlan.ip.dhcp.option12_value	1246
weblink.ip.conn[1 2].retry_interval_random_max	1182	wlan.ip.dhcp.request_timeout	1247
weblink.ip.conn[1 2].test.test_on	1184	wlan.ip.dhcp.requests_per_session	1248
weblink.logging.clear	1185	wlan.ip.dhcp.session_interval	1249
weblink.logging.entries	1186	wlan.ip.dns.servers	1250
weblink.logging.max_entries	1187	wlan.ip.gateway	1251
weblink.printer_reset_required	1188	wlan.ip.netmask	1252
weblink.restore_defaults	1189	wlan.ip.port	1253
weblink.zebra_connector.authentication.add	1190	wlan.ip.port_alternate	1254
weblink.zebra_connector.authentication.entries	1192	wlan.ip.port_json_config	1255
weblink.zebra_connector.authentication.remove	1193	wlan.ip.protocol	1256
weblink.zebra_connector.enable	1194	wlan.ip.timeout.enable	1257
weblink.zebra_connector.proxy	1195	wlan.ip.timeout.value	1258
weblink.zebra_connector.version	1197	wlan.ip.wins.addr	1259
wlan.11ac.80mhz_enable	1199	wlan.ip.wins.permanent_source	1260
wlan.11d.enable	1200	wlan.keep_alive.enable	1261
wlan.11n.20mhz_only	1201	wlan.keep_alive.timeout	1262
wlan.11n.aggregation	1202	wlan.kerberos.kdc	1263
wlan.11n.greenfield	1203	wlan.kerberos.mode	1264
wlan.11n.rifs	1204	wlan.kerberos.password	1265
wlan.11n.short_gi_40mhz	1205	wlan.kerberos.realm	1266
wlan.11n.short_gi_20mhz	1206	wlan.kerberos.username	1267
wlan.8021x.enable	1207	wlan.leap_mode	1268
wlan.8021x.validate_peap_server_certificate	1208	wlan.leap_password	1269
wlan.active_channels	1209	wlan.leap_username	1270
wlan.adhoc_last_channel	1210	wlan.mac_addr	1271
wlan.authenticated	1211	wlan.mac_raw	1272
		wlan.operating_mode	1273

wlan.password	1274
wlan.permitted_channels	1275
wlan.poor_signal_threshold	1276
wlan.preamble	1277
wlan.private_key_password	1278
wlan.region_code	1279
wlan.roam.interchannel_delay	1280
wlan.roam.interval	1281
wlan.roam.max_chan_scan_time	1282
wlan.roam.max_fail	1283
wlan.roam.rssi	1284
wlan.roam.signal	1285
wlan.rts_cts_enabled	1286
wlan.security	1287
wlan.signal_noise	1294
wlan.signal_quality	1295
wlan.signal_strength	1296
wlan.station_name	1297
wlan.tx_power	1298
wlan.tx_rate	1299
wlan.user_channel_list	1300
wlan.username	1301
wlan.waveagent.enable	1302
wlan.waveagent.udp_port	1303
wlan.wep.auth_type	1304
wlan.wep.index	1305
wlan.wep.key1	1306
wlan.wep.key2	1307
wlan.wep.key3	1308
wlan.wep.key4	1309
wlan.wpa.psk	1310
wlan.wep.key_format	1311
wlan.wpa.timecheck	1315
wlan.wpa.wpa_version	1316

Zebra Code Pages 1317

Zebra Code Page 850 — Latin Character Set	1317
Zebra Code Page 1250 — Central and Eastern European Latin Character Set	1320
Zebra Code Page 1252— Latin Character Set	1322
Zebra Code Page 1253 — Modern Greek Character Set	1324
Zebra Code Page 1254 — Turkish Character Set	1326
Zebra Code Page 1255 — Hebrew Character Set	1328

ASCII 1331

ASCII Code Chart	1332
------------------	------

Fonts and Bar Codes 1335

Standard Printer Fonts	1336
Proportional and Fixed Spacing	1338
Scalable Versus Bitmapped Fonts	1339
Font Matrices	1341
Bar Codes	1343

Mod 10 and Mod 43 Check Digits 1349

Mod 10 Check Digit	1349
Mod 43 Check Digit	1350

Error Detection Protocol 1353

Introduction	1355
Request Packet Formats from the Host Computer	1356
Response From the Zebra Printer	1358

ZB64 Encoding and Compression 1365

Introduction to B64 and Z64	1366
B64 and Z64 Encoding	1367

Field Interactions 1369

Normal Orientation	1370
Rotated Orientation	1371
Bottom Up Orientation	1372
Inverted Orientation	1373

Real Time Clock 1375

Control Panel Programming	1376
RTC General Information	1378
ZPL II Samples	1383

ZBI Character Set 1389

Character Set	1389
---------------	------

SGD Command Support 1393

Printer and Firmware Compatibility	1393
------------------------------------	------

Firmware Features 1435

Firmware x.17	1435
Firmware x.16	1436
Firmware x.15	1437
Firmware x.14	1439

Mirror 1443

Mirror Overview	1444
Professional Services for Mirror Configuration	1445
Requirements	1445
How Mirror Works	1447
Creating ZPL Files for Use in the "<update-root>/files" Directory	1449
Configuration	1452
The Feedback.get File	1452
How to Set Up and Use Mirror	1455
Troubleshooting	1457

Wireless Markup Language (WML) 1461

WML Overview	1462
WML Details	1463
Supported Printers	1464
Professional Services for WML Content Creation	1465
WML Tags	1466
Using WML	1467
WML Examples	1472
Troubleshooting Scenarios	1480

Using Weblink 1483

- When Should Weblink be Used? 1483
- Configuring Weblink 1484
- SSL/TLS Certificate Errors 1487
- Other Typical Errors 1489
- Troubleshooting 1490
- HTTP Messages 1491

- HTTP POST Alerts 1493**
 - Configuring Alerts
 - Where the Alert Destination is HTTP POST 1493
 - How to Parse via PHP 1495
 - Basic Configuration 1495
 - Enabling Logging 1497
 - Navigating the Log Output 1498
 - Understanding Errors in the Alerts HTTP Log 1498
 - Troubleshooting 1498
 - HTTP Messages 1499

- Advanced Techniques 1501**
 - Special Effects for Print Fields 1502
 - Serialized Data 1502
 - Variable Data 1503
 - Stored Formats 1503
 - Control Commands 1504
 - Changing Delimiters and Command Prefixes 1508
 - Communication Diagnostics Commands 1509
 - Graphic Commands 1509
 - Memory, Flash Cards, and Font Cards 1513

- Glossary 1519**

Functional List of ZPL Commands

Abort Download Graphic	155	Display Description Information	216
Advanced Text Properties	291	Download Bitmap Font	147
ANSI Codabar Bar Code	96	Download Bounded TrueType Font	157
Applicator Reprint	300	Download Encoding	149
Aztec Bar Code Parameters	102	Download Files	609
Aztec Bar Code Parameters	46	Download Format	151
Bar Code Field Default	126	Download Graphics	152
Battery Status	194	Download Intellifont (Scalable Font)	156
Cache On	139	Download Objects	159
Calibrate RFID Tag Position	354	Download Unbounded TrueType Font	158
Cancel All	223	EAN-13 Bar Code	89
Cancel Current Partially Input Format	251	EAN-8 Bar Code	64
Change Alphanumeric Default Font	131	Early Warning Settings	231
Change Backfeed Sequence	247	Enable Communications Diagnostics	227
Change Caret	129	Enable RFID Motion	372
Change Delimiter	130	Enable/Disable E.A.S. Bit	364
Change International Font/Encoding	132	Encode AFI or DSFID Byte	395
Change Memory Letter Designation	136	End Format	344
Change Network Settings	285	Erase Download Graphics	162
Change Tilde	142	Field Block	163
Change Wired Networking Settings	289	Field Clock	166
Change Wireless Network Settings	411	Field Data	167
CODABLOCK Bar Code	72	Field Hexadecimal Indicator	168
Code 11 Bar Code	48	Field Number	175
Code 128 Bar Code (Subsets A, B, and C)	76	Field Orientation	183
Code 39 Bar Code	52	Field Origin	176
Code 49 Bar Code	56	Field Parameter	177
Code 93 Bar Code	68	Field Reverse Print	178
Code Validation	143	Field Separator	179
Comment	185	Field Typeset	180
Configuration Label Return	198	Field Variable	182
Configuration Update	249	Font Identifier	145
Configure Wireless Securities	419	Font Linking	170
Cut Now	138	Get RFID Tag ID	369
Data Matrix Bar Code	122	Graphic Box	186
Define EPC Data Structure	362	Graphic Circle	188
Define Language	255	Graphic Diagonal Line	189
Define Password	257	Graphic Ellipse	190
Define Printer Name	256	Graphic Field	191
Detect Multiple RFID Tags in Encoding Field	373	Graphic Symbol	193
Disable Diagnostics	228	Graphing Sensor Calibration	230

GS1 Databar	113	Printer Sleep	345
Halt ZebraNet Alert	319	Printing Mirror Image of Label	295
Head Diagnostic	195	Programmable Pause	298
Head Test Fatal	241	QR Code Bar Code	106
Head Test Interval	248	Quick Write EPC Data and Passwords	374
Head Test Non-Fatal	242	Read AFI or DSFID Byte	361
Host Directory List	213	Read or Write RFID Format	365
Host Format	196	Read RFID Tag	383
Host Graphic	197	Read Unique RFID Chip Serialization	385
Host Identification	199	Recall Format	341
Host Linked Fonts List	210	Recall Graphic	342
Host Query	201	Remove Label	141
Host RAM Status	200	Report RFID Encoding Results	387
Host Status Return	207	Reprint After Error	252
Host Verification	212	Reset Advanced Counters	305
Image Load	219	Reset Optional Memory	225
Image Move	220	Reset Wireless Radio Card and Print Server	416
Image Save	221	Return RFID Data Log to Host	353
Industrial 2 of 5 Bar Codes	93	Return ZebraNet Alert Configuration	211
Initialize Flash Memory	224	Scalable/Bitmapped Font	42
Interleaved 2 of 5 Bar Code	50	Search for Wired Print Server during	
Kill Battery (Battery Discharge Mode)	253	Network Boot	403
Kiosk Values	258	Select Date and Time Format (for Real Time Clock)	254
Label Home	263	Select Encoding Table	308
Label Length	264	Select the Primary Network Device	283
Label Reverse Print	265	Sensor Select	246
Label Shift	266	Serialization Data	315
Label Top	267	Serialization Field (with a Standard ^FD String)	309
List Font Links	262	Set All Network Printers Transparent	288
Lock/Unlock RFID Tag Memory	370	Set Antenna Parameters	408
LOGMARS Bar Code	98	Set Auxiliary Port	237
Map Clear	270	Set Battery Condition	229
Maximum Label Length	274	Set Client Identifier (Option 61)	402
Media Darkness	271	Set Currently Connected Printer Transparent	290
Media Feed	272	Set Darkness	307
Media Tracking	277	Set Date and Time (for Real-Time Clock)	323
Media Type	280	Set Dots per Millimeter	240
MicroPDF417 Bar Code	91	Set Dynamic Media Calibration	343
Mode Protection	278	Set Label Length	239
Modify Head Cold Warning	282	Set LEAP Parameters	412
MSI Bar Code	100	Set Maintenance Alerts	268
Multiple Field Origin Locations	172	Set Maintenance Information Message	273
Network Connect	284	Set Media Sensor Calibration	226
Network ID Number	287	Set Media Sensors	321
Object Delete	217	Set Mode and Language (for Real-Time Clock)	313
Pause and Cancel Format	243	Set Offset (for Real-Time Clock)	317
PDF417 Bar Code	61	Set Primary/Secondary Device	405
Planet Code bar code	60	Set Printhead Resistance	320
Plessey Bar Code	104	Set RF Power Levels for Read and Write	388
POSTAL Bar Code	127	Set RFID Tag Password and Lock Tag	392
Power On Reset	245	Set Ribbon Tension	250
Present Length Addition	294	Set Sensor Intensity	312
Present Now	296	Set Serial Communications	306
Print Configuration Label	331	Set SMTP	406
Print Directory Label	332	Set SNMP	404
Print Mode	275	Set Transmit Rate	415
Print Network Configuration Label	413	Set Units of Measurement	281
Print Orientation	297	Set Up RFID Parameters	378
Print Quantity	299	Set Web Authentication Timeout Value	407
Print Rate	301	Set WEP Mode	409
Print Start	303	Set Wireless Password	414
Print Width	304	Set Wireless Radio Card Values	417

Set ZebraNet Alert	324	Terminate Zebra BASIC Interpreter	244
Set ZPL Mode	326	Text Blocks	328
Slew Given Number of Dot Rows	292	TLC39 Bar Code	118
Slew to Home Position	293	Transfer Object	329
Specify RFID Retries for a Block or Enable Adaptive Antenna Selection	376	UPC/EAN Extensions	115
Standard 2 of 5 Bar Code	95	UPC-A Bar Code	120
Start Format	339	UPC-E Bar Code	66
Start Print	318	Upload Graphics	215
Start ZBI (Zebra BASIC Interpreter)	234	UPS MaxiCode Bar Code	87
Start ZBI (Zebra BASIC Interpreter)	236	Use Font Name to Call Font	44
Suppress Backfeed	340	Verify RFID Encoding Operation	398
Tear-off Adjust Position	327	Write (Encode) Tag	396
		Write Query	333

Alphabetical List of ZBI Commands

! (EXCLAMATION MARK)	435	ISERROR	511
ACCEPT	475	ISWARNING	512
ADDBREAK	448	LCASE\$	521
AUTONUM	437	LEN	536
AUXPORT_GETPIN	519	LET	454
AUXPORT_RELEASEPIN	520	LIST	436
AUXPORT_SETPIN	518	LOAD	491
AUXPORT_STEALPIN	517	LTRIM\$	523
BREAK	447	MAX	538
CHR\$	522	MAXNUM	540
CLIENTSOCKET	474	MIN	539
CLOSE	470	MOD	541
CLRERR	515	NEW	433
COLUMNSIZE	550	ON ERROR	516
CSVLOAD	494	OPEN	469
CSVSTORE	496	ORD	534
CTRL-C	442	OUTBYTE	478
DATAREADY	471	POS	535
DATE	556	PRINT	477
DATE\$	554	READ	480
DEBUG	445	REDIM	546
DELBREAK	449	REGISTEREVENT	504
DELETE	493	REM	434
DELROW	548	RENUM	438
DIR	492	REPEAT\$	524
DO Loops	462	RESTART	443
ECHO	439	ROWSIZE	549
END	467	RTRIM\$	525
EXIT	466	RUN	441
EXTRACT\$	532	SEARCHTO\$	482
FIND	551	SERVERCLOSE	473
FOR Loops	463	SERVERSOCKET	472
GETVAR\$	559	SETERR	514
GOTO/GOSUB	464	SETVAR	558
HANDLEEVENT	507	SLEEP	513
HEXTOINT	544	SPLIT	526
IF Statements	461	SPLITCOUNT	530
INBYTE	479	STEP	444
INPUT	476	STORE	490
INSERTROW	547	STR\$	537
INTTOHEX\$	543	SUB	465

TIME	557
TIMES	555
TRACE	446
TRIGGEREVENT	509
TXLOAD	497
TXSTORE	498
UCASE\$	531
UNREGISTEREVENT	506
VAL	542
WRITE	481
ZPL	450

Alphabetical List of Set/Get/Do Commands

alerts.add	577	bluetooth.minimum_security_mode	1070
alerts.conditions	578	bluetooth.radio_auto_baud	1071
alerts.configured	579	bluetooth.radio_version	1072
alerts.destinations	580	bluetooth.short_address	1073
alerts.http.authentication.add	581	bluetooth.version	1074
alerts.http.authentication.entries	583	capture.channel1.count	603
alerts.http.authentication.remove	584	capture.channel1.data.mime	604
alerts.http.logging.clear	585	capture.channel1.data.raw	605
alerts.http.logging.entries	586	capture.channel1.delimiter	606
alerts.http.logging.max_entries	587	capture.channel1.max_length	607
alerts.http.proxy	588	capture.channel1.port	608
alerts.tracked_settings.clear_log	589	card.inserted	1076
alerts.tracked_settings.log_tracked	590	card.mac_addr	1075
alerts.tracked_settings.max_log_entries	591	CISDFCRC16	609
alerts.tracked_sgds.log	592	comm.baud	611
alerts.tracked_sgds.max_log_entries	593	comm.halt	612
alerts.tracked_sgds.zbi_notified	594	comm.parity	615
apl.enable	595	comm.pnp_option	613
apl.framework_version	596	comm.stop_bits	616
apl.version	597	comm.type	614
appl.bootblock	600	cradle.comm.baud	617
appl.date	601	cradle.comm.handshake	618
appl.link_os_version	598	cutter.clean_cutter	619
appl.name	602	device.applicator.data_ready	620
appl.option_board_version	599	device.applicator.data_ready_activation	698
bluetooth.address	1054	device.applicator.end_print	621
bluetooth.afh_map	1055	device.applicator.error_on_pause	699
bluetooth.afh_map_curr	1056	device.applicator.feed	622
bluetooth.afh_mode	1057	device.applicator.media_out	623
bluetooth.authentication	1058	device.applicator.pause	624
bluetooth.bluetooth_pin	1059	device.applicator.reprint	625
bluetooth.clear_bonding_cache	1060	device.applicator.rfid_void	626
bluetooth.date	1061	device.applicator.ribbon_low	627
bluetooth.discoverable	1062	device.applicator.ribbon_out	628
bluetooth.enable	1063	device.applicator.service_required	629
bluetooth.enable_reconnect	1064	device.applicator.start_print	630
bluetooth.friendly_name	1065	device.applicator.start_print_mode	700
bluetooth.json_config_channel_enable	1066	device.applicator.voltage	701
bluetooth.le.controller_mode	1067	device.bluetooth_installed	631
bluetooth.le.minimum_security	1068	device.command_override.active	632
bluetooth.local_name	1069	device.command_override.add	633

device.command_override.clear	634	device.syslog.save_local_file	697
device.command_override.list	635	device.unique_id	702
device.company_contact	636	device.unpause	703
device.configuration_number	637	device.uptime	704
device.cpcl_synchronous_mode	638	device.user_p1	705
device.cutter_installed	639	device.user_p2	706
device.download_connection_timeout	640	device.user_vars.create	708
device.epl_legacy_mode	641	device.user_vars.set_range	707
device.feature.bluetooth_le	643	device.xml.enable	710
device.feature.lighted_arrows	711	display.backlight	714
device.feature.mcr	644	display.backlight_on_time	715
device.feature.nfc	645	display.batch_counter	716
device.feature.ribbon_cartridge	646	display.language	717
device.friendly_name	647	display.load_card	718
device.frontpanel.feedenabled	648	display.password.level	719
device.frontpanel.key_press	649	display.root_wml	720
device.frontpanel.line1	650	display.text	721
device.frontpanel.line2	651	DNP - rfid.calibration_maximum_power	869
device.frontpanel.xml	652	external_wired.check	987
device.host_identification	653	external_wired.ip.addr	988
device.host_status	654	external_wired.ip.arp_interval	989
device.idle_display_format	657	external_wired.ip.default_addr_enable	990
device.idle_display_value	658	external_wired.ip.dhcp.cid_all	991
device.internal_wired_setting_location	659	external_wired.ip.dhcp.cid_enable	992
device.jobs_print	660	external_wired.ip.dhcp.cid_prefix	993
device.languages	661	external_wired.ip.dhcp.cid_suffix	994
device.light.cover_open_brightness	662	external_wired.ip.dhcp.cid_type	995
device.light.head_open_brightness	663	external_wired.ip.gateway	996
device.light.media_path_brightness	713	external_wired.ip.netmask	997
device.light.ribbon_path_brightness	712	external_wired.ip.port	998
device.location	664	external_wired.ip.protocol	999
device.ltu_installed	665	external_wired.ip.timeout.enable	1000
device.orientation	666	external_wired.ip.timeout.value	1001
device.pause	667	external_wired.ip.v6.addr	1002
device.pmcu.revision	669	external_wired.ip.v6.gateway	1003
device.pnp_option	668	external_wired.ip.v6.prefix_length	1004
device.position.accuracy	670	external_wired.mac_addr	1005
device.position.altitude	671	external_wired.mac_raw	1006
device.position.latitude	672	ezpl.head_close_action	724
device.position.longitude	673	ezpl.label_length_max	725
device.print_2key	674	ezpl.label_sensor	726
device.print_reprogram_2key	675	ezpl.manual_calibration	727
device.product_name_submodel	676	ezpl.media_type	728
device.prompted_network_reset	677	ezpl.power_up_action	729
device.reset	678	ezpl.print_method	730
device.restore_defaults	679	ezpl.print_width	731
device.rewinder_installed	680	ezpl.reprint_mode	732
device.save_2key	681	ezpl.take_label	733
device.sensor_select	682	ezpl.tear_off	734
device.serial_number.option_board_date	683	file.capture_response.destination	722
device.serial_numbers.control_panel_date	684	file.delete	735
device.serial_numbers.mlb_date	685	file.dir	736
device.serial_numbers.processor	686	file.dir_format	737
device.set_clock_to_build_date	687	file.run	739
device.slot_1	688	file.type	738
device.slot_2	689	formats.cancel_all	740
device.super_host_status	690	head.darkness_switch	743
device.syslog.clear_log	691	head.darkness_switch_enable	741
device.syslog.configuration	692	head.element_test	744
device.syslog.enable	694	head.latch	745
device.syslog.entries	695	head.resolution.in_dpi	723
device.syslog.log_max_file_size	696	input.capture	746

interface.network.active.arp_interval	747	ip.addr	1078
interface.network.active.cable_type	748	ip.arp_interval	1079
interface.network.active.dhcp_received_host_name	749	ip.bootp.enable	1080
interface.network.active.gateway	750	ip.dhcp.arp_verify	1081
interface.network.active.ip_addr	751	ip.dhcp.auto_provision_enable	1082
interface.network.active.mac_addr	752	ip.dhcp.cache_ip	1083
interface.network.active.mac_raw	753	ip.dhcp.cid_all	1084
interface.network.active.netmask	754	ip.dhcp.cid_enable	1085
interface.network.active.protocol	755	ip.dhcp.cid_prefix	1086
interface.network.active.protocol_error	756	ip.dhcp.cid_suffix	1087
interface.network.active.protocol_error	760	ip.dhcp.cid_type	1088
interface.network.active.rx_errors	757	ip.dhcp.cid_value	1089
interface.network.active.rx_packets	758	ip.dhcp.enable	1090
interface.network.active.server_address	759	ip.dhcp.lease.last_attempt	1091
interface.network.active.speed	761	ip.dhcp.lease.server	1092
interface.network.active.tx_errors	762	ip.dhcp.lease.time_left	1093
interface.network.active.tx_packets	763	ip.dhcp.ntp.enable	1094
interface.network.active.wins_addr	764	ip.dhcp.ntp.received_servers	1095
interface.network.settings_require_reset	765	ip.dhcp.option12	1096
internal_wired.8021x.password	1007	ip.dhcp.option12_format	1097
internal_wired.8021x.peap.anonymous_identity	1009	ip.dhcp.option12_value	1098
internal_wired.8021x.peap.validate_server_certificate	1008	ip.dhcp.request_timeout	1099
internal_wired.8021x.private_key_password	1010	ip.dhcp.requests_per_session	1100
internal_wired.8021x.security	1011	ip.dhcp.session_interval	1101
internal_wired.8021x.ttls_tunnel	1012	ip.dhcp.user_class_id	1102
internal_wired.8021x.username	1013	ip.dhcp.vendor_class_id	1103
internal_wired.activity_led	1014	ip.dns.domain	1104
internal_wired.auto_switchover	1015	ip.dns.servers	1105
internal_wired.enable	1016	ip.firewall.whitelist_in	766
internal_wired.installed	1017	ip.ftp.enable	1106
internal_wired.ip.addr	1018	ip.ftp.execute_file	1107
internal_wired.ip.arp_interval	1019	ip.ftp.request_password	1108
internal_wired.ip.default_addr_enable	1020	ip.gateway	1109
internal_wired.ip.dhcp.arp_verify	1021	ip.http.admin_name	1110
internal_wired.ip.dhcp.cache_ip	1022	ip.http.admin_password	1111
internal_wired.ip.dhcp.cid_all	1023	ip.http.custom_link_name	1112
internal_wired.ip.dhcp.cid_enable	1024	ip.http.custom_link_url	1113
internal_wired.ip.dhcp.cid_prefix	1025	ip.http.enable	1114
internal_wired.ip.dhcp.cid_suffix	1026	ip.http.faq_url	1115
internal_wired.ip.dhcp.cid_type	1027	ip.http.port	1116
internal_wired.ip.dhcp.lease.last_attempt	1028	ip.https.enable	768
internal_wired.ip.dhcp.lease.length	1029	ip.https.port	769
internal_wired.ip.dhcp.lease.server	1030	ip.lpd.enable	1117
internal_wired.ip.dhcp.lease.time_left	1031	ip.mac_raw	1118
internal_wired.ip.dhcp.option12	1032	ip.mirror.appl_path	1119
internal_wired.ip.dhcp.option12_format	1033	ip.mirror.auto	1120
internal_wired.ip.dhcp.option12_value	1034	ip.mirror.error_retry	1121
internal_wired.ip.dhcp.requests_per_session	1035	ip.mirror.feedback.auto	1122
internal_wired.ip.dns.servers	1036	ip.mirror.feedback.freq	1123
internal_wired.ip.gateway	1037	ip.mirror.feedback.odometer	1124
internal_wired.ip.netmask	1038	ip.mirror.feedback.path	1125
internal_wired.ip.port	1039	ip.mirror.fetch	1126
internal_wired.ip.port_alternate	1040	ip.mirror.freq	1127
internal_wired.ip.port_json_config	1041	ip.mirror.freq_hours	1128
internal_wired.ip.protocol	1042	ip.mirror.interface	1129
internal_wired.ip.timeout.enable	1043	ip.mirror.last_error	1130
internal_wired.ip.timeout.value	1044	ip.mirror.last_time	1131
internal_wired.ip.wins.addr	1045	ip.mirror.mode	1132
internal_wired.ip.wins.permanent_source	1046	ip.mirror.password	1133
internal_wired.mac_addr	1047	ip.mirror.path	1134
internal_wired.mac_raw	1048	ip.mirror.reset_delay	1135
ip.active_network	1077	ip.mirror.server	1136

ip.mirror.success	1137	media.present.loop_length_max	802
ip.mirror.success_time	1138	media.present.present_timeout	804
ip.mirror.username	1139	media.present.present_type	805
ip.mirror.version	1140	media.printmode	806
ip.netmask	1141	media.serial_number	809
ip.ntp.enable	1142	media.speed	808
ip.ntp.log	1143	memory.flash_free	810
ip.ntp.servers	1144	memory.flash_size	811
ip.ping_gateway_interval	770	memory.ram_free	812
ip.pop3.enable	1145	memory.ram_size	813
ip.pop3.password	1146	netmanage.avalanche.available_port	816
ip.pop3.poll	1147	netmanage.avalanche.startup_update	822
ip.pop3.print_body	771	netmanage.avalanche.agent_addr	814
ip.pop3.print_headers	772	netmanage.avalanche.available_agent	815
ip.pop3.save_attachments	773	netmanage.avalanche.encryption_type	817
ip.pop3.server_addr	1148	netmanage.avalanche.interval	818
ip.pop3.username	1149	netmanage.avalanche.interval_update	819
ip.pop3.verbose_headers	774	netmanage.avalanche.model_name	820
ip.port	1150	netmanage.avalanche.set_property	821
ip.port_alternate	1151	netmanage.avalanche.tcp_connection_timeout	823
ip.port_json_config	1152	netmanage.avalanche.terminal_id	824
ip.port_single_conn	1153	netmanage.avalanche.text_msg.beep	825
ip.port_single_conn_idle_timeout	1154	netmanage.avalanche.text_msg.display	826
ip.primary_network	1155	netmanage.avalanche.text_msg.print	827
ip.smtp.domain	1156	netmanage.avalanche.udp_timeout	828
ip.smtp.enable	1157	netmanage.error_code	829
ip.smtp.server_addr	1158	netmanage.state_code	830
ip.snmp.enable	1162	netmanage.status_code	831
ip.snmp.get_community_name	1159	odometer.cut_marker_count	832
ip.snmp.set_community_name	1160	odometer.headclean	833
ip.snmp.trap_community_name	1161	odometer.headnew	834
ip.tcp.enable	1163	odometer.label_dot_length	835
ip.tcp.nagle_algorithm	1165	odometer.latch_open_count	847
ip.telnet.enable	1164	odometer.media_marker_count	836
ip.tls.enable	775	odometer.media_marker_count1	837
ip.tls.port	777	odometer.media_marker_count2	838
ip.tls.port_json_config	778	odometer.retracts_count	839
ip.udp.enable	1166	odometer.rfid.valid_resetable	840
log.reboot.code	779	odometer.rfid.void_resetable	841
log.reboot.codes	780	odometer.total_cuts	842
log.reboot.reason	781	odometer.total_label_count	844
log.reboot.report	782	odometer.total_print_length	843
mcr.cancel	784	odometer.user_label_count	845
mcr.crypt.algorithm	786	odometer.user_label_count[1 2]	846
mcr.crypt.enabled	783	parallel_port.mode	848
mcr.crypt.key_mgmt	785	parallel_port.present	849
mcr.out	787	power.average_current	851
mcr.revision	788	power.battery_led_blink_rate	852
media.bar_location	789	power.battery_led_enable	853
media.cartridge.part_number	790	power.battery_led_off_duration	854
media.cut_now	791	power.battery_led_on_duration	855
media.darkness_mode	792	power.battery_replacement_cyclecount_threshold	856
media.draft_mode	793	power.dtr_power_off	857
media.feed_skip	794	power.energy_star.enable	859
media.media_low.external	795	power.energy_star.timeout	861
media.media_low.warning	796	power.label_queue.shutdown	862
media.part_number	797	power.power_on_mode	863
media.present.cut_amount	798	power.shutdown	864
media.present.cut_margin	803	print.tone	865
media.present.eject	799	print.troubleshooting_label_print	866
media.present.length_addition	800	rfid.adaptive_antenna	867
media.present.loop_length	801	rfid.antenna_sweep	868

rfid.country_code	870	usb.mirror.feedback.path	939
rfid.enable	871	usb.mirror.fetch	940
rfid.error.response	872	usb.mirror.last_error	941
rfid.hop_table_version	873	usb.mirror.last_time	942
rfid.position.program	874	usb.mirror.path	943
rfid.reader_1.antenna_port	876	usb.mirror.reset_delay	944
rfid.reader_1.firmware_version	882	usb.mirror.success	945
rfid.reader_1.hardware_version	883	usb.mirror.success_time	946
rfid.reader_1.model	884	weblink.cloud_connect.enable	1167
rfid.reader_1.power.read	879	weblink.enable	1168
rfid.reader_1.power.single_power	881	weblink.ip.conn[1 2].authentication.add	1169
rfid.reader_1.power.write	880	weblink.ip.conn[1 2].authentication.entries	1171
rfid.recipe_version	885	weblink.ip.conn[1 2].authentication.remove	1172
rfid.region_code	886	weblink.ip.conn[1 2].location	1173
rfid.tag.calibrate	887	weblink.ip.conn[1 2].maximum_simultaneous_	
rfid.tag.data	888	connections	1175
rfid.tag.read.content	889	weblink.ip.conn[1 2].num_connections	1174
rfid.tag.read.execute	890	weblink.ip.conn[1 2].proxy	1176
rfid.tag.read.result_line1	891	weblink.ip.conn[1 2].retry_interval	1178
rfid.tag.read.result_line1_alternate	893	weblink.ip.conn[1 2].retry_interval_random_max	1182
rfid.tag.read.result_line2	892	weblink.ip.conn[1 2].test.location	1179
rfid.tag.read.result_line2_alternate	894	weblink.ip.conn[1 2].test.retry_interval	1181
rfid.tag.test	895	weblink.ip.conn[1 2].test.test_on	1184
rfid.tag.test.content	896	weblink.logging.clear	1185
rfid.tag.test.execute	897	weblink.logging.entries	1186
rfid.tag.test.result_line1	898	weblink.logging.max_entries	1187
rfid.tag.test.result_line2	899	weblink.printer_reset_required	1188
rfid.tag.type	900	weblink.restore_defaults	1189
ribbon.part_number	904	weblink.zebra_connector.authentication.add	1190
ribbon.serial_number	903	weblink.zebra_connector.authentication.entries	1192
rtc.timezone	905	weblink.zebra_connector.authentication.remove	1193
sensor.cover_open	907	weblink.zebra_connector.enable	1194
sensor.paper_supply	908	weblink.zebra_connector.proxy	1195
sensor.peeler	909	weblink.zebra_connector.version	1197
sensor.self_adjusting_enable	911	wlan.11ac.80mhz_enable	1199
usb.device.device_id_string	912	wlan.11d.enable	1200
usb.device.device_unique_id	913	wlan.11n.20mhz_only	1201
usb.device.device_version	914	wlan.11n.aggregation	1202
usb.device.manufacturer_string	915	wlan.11n.greenfield	1203
usb.device.product_id	916	wlan.11n.rifs	1204
usb.device.product_string	917	wlan.11n.short_gi_20mhz	1206
usb.device.serial_string	918	wlan.11n.short_gi_40mhz	1205
usb.device.vendor_id	919	wlan.8021x.enable	1207
usb.halt	920	wlan.8021x.validate_peap_server_certificate	1208
usb.host.fn_field_data	921	wlan.active_channels	1209
usb.host.fn_last_field	922	wlan.adhoc_last_channel	1210
usb.host.hid_count	923	wlan.adhocautomode	1215
usb.host.keyboard_input	924	wlan.adhocchannel	1216
usb.host.lock_out	925	wlan.allowed_band	1214
usb.host.mass_storage_count	926	wlan.associated	1217
usb.host.read_list	927	wlan.auth_type	1218
usb.host.read_list_print_delay	928	wlan.authenticated	1211
usb.host.template_list	929	wlan.authentication_error	1212
usb.host.template_print_amount	930	wlan.available	1213
usb.host.write_list	931	wlan.bssid	1219
usb.mirror.appl_path	932	wlan.channel	1220
usb.mirror.auto	933	wlan.channel_mask	1221
usb.mirror.enable	934	wlan.country_code	1222
usb.mirror.enabled	935	wlan.current_tx_rate	1223
usb.mirror.error_retry	936	wlan.enable	1224
usb.mirror.feedback.auto	937	wlan.encryption_index	1225
usb.mirror.feedback.odometer	938	wlan.encryption_key[1 2 3 4]1	1226

wlan.encryption_mode	1227	wlan.roam.rssi	1284
wlan.essid	1228	wlan.roam.signal	1285
wlan.firmware_version	1229	wlan.rts_cts_enabled	1286
wlan.ip.addr	1230	wlan.security	1287
wlan.ip.arp_interval	1231	wlan.signal_noise	1294
wlan.ip.default_addr_enable	1232	wlan.signal_quality	1295
wlan.ip.dhcp.arp_verify	1233	wlan.signal_strength	1296
wlan.ip.dhcp.cache_ip	1234	wlan.station_name	1297
wlan.ip.dhcp.cid_all	1235	wlan.tx_power	1298
wlan.ip.dhcp.cid_enable	1236	wlan.tx_rate	1299
wlan.ip.dhcp.cid_prefix	1237	wlan.user_channel_list	1300
wlan.ip.dhcp.cid_suffix	1238	wlan.username	1301
wlan.ip.dhcp.cid_type	1239	wlan.waveagent.enable	1302
wlan.ip.dhcp.lease.last_attempt	1240	wlan.waveagent.udp_port	1303
wlan.ip.dhcp.lease.length	1241	wlan.wep.auth_type	1304
wlan.ip.dhcp.lease.server	1242	wlan.wep.index	1305
wlan.ip.dhcp.lease.time_left	1243	wlan.wep.key_format	1311
wlan.ip.dhcp.option12	1244	wlan.wep.key1	1306
wlan.ip.dhcp.option12_format	1245	wlan.wep.key2	1307
wlan.ip.dhcp.option12_value	1246	wlan.wep.key3	1308
wlan.ip.dhcp.request_timeout	1247	wlan.wep.key4	1309
wlan.ip.dhcp.requests_per_session	1248	wlan.wpa.psk	1310
wlan.ip.dhcp.session_interval	1249	wlan.wpa.timecheck	1315
wlan.ip.dns.servers	1250	wlan.wpa.wpa_version	1316
wlan.ip.gateway	1251	zbi.control.add_breakpoint	947
wlan.ip.netmask	1252	zbi.control.break	948
wlan.ip.port	1253	zbi.control.clear_breakpoints	949
wlan.ip.port_alternate	1254	zbi.control.delete_breakpoint	950
wlan.ip.port_json_config	1255	zbi.control.line_number	951
wlan.ip.protocol	1256	zbi.control.restart	952
wlan.ip.timeout.enable	1257	zbi.control.run	953
wlan.ip.timeout.value	1258	zbi.control.step	954
wlan.ip.wins.addr	1259	zbi.control.terminate	955
wlan.ip.wins.permanent_source	1260	zbi.control.variable_name	956
wlan.keep_alive.enable	1261	zbi.control.variable_value	957
wlan.keep_alive.timeout	1262	zbi.enable	958
wlan.kerberos.kdc	1263	zbi.key	959
wlan.kerberos.mode	1264	zbi.last_error	960
wlan.kerberos.password	1265	zbi.program_list	961
wlan.kerberos.realm	1266	zbi.reseller_key	962
wlan.kerberos.username	1267	zbi.revision	963
wlan.leap_mode	1268	zbi.running_program_name	964
wlan.leap_password	1269	zbi.start_info.execute	965
wlan.leap_username	1270	zbi.start_info.file_name	966
wlan.mac_addr	1271	zbi.start_info.memory_alloc	967
wlan.mac_raw	1272	zbi.state	968
wlan.operating_mode	1273	zpl.caret	969
wlan.password	1274	zpl.control_character	970
wlan.permitted_channels	1275	zpl.delimiter	971
wlan.poor_signal_threshold	1276	zpl.label_length	972
wlan.preamble	1277	zpl.left_position	973
wlan.private_key_password	1278	zpl.relative_darkness	981
wlan.region_code	1279	zpl.system_error	974
wlan.roam.interchannel_delay	1280	zpl.system_status	976
wlan.roam.interval	1281	zpl.zpl_mode	979
wlan.roam.max_chan_scan_time	1282	zpl.zpl_override	980
wlan.roam.max_fail	1283		

About This Document

This section provides an overview of the entire document, contact information, and details on document structure and organization.

Contents

Contact Zebra	28
Introduction	28
Who Should Use This Document.	28
How This Document Is Organized	29

Contact Zebra

To contact Zebra or for technical support, visit www.zebra.com/contact.

Introduction

This guide is the unabridged, alphabetical reference of programming commands supported in the firmware. This includes all ZPL commands and SGD commands.



Important • These are important points to note when using ZPL and SGD commands:

- ZPL and SGD commands should be sent to the printer as separate files.
- Certain settings can be controlled by both ZPL and SGD. Configuration changes made in ZPL can affect configuration changes made in SGD.

Firmware You can get the printer's firmware version by printing out a configuration label. For instructions to do so, see your printer's user guide.



Note • For firmware upgrades go to: www.zebra.com.



Important • These are important points to note when using a Zebra G-Series printer:

- You can send instructions to the printer using multiple programming languages: EPL, ZPL, or SGD. EPL and ZPL commands configure the printer, print labels, and get device status information. SGD commands set and get configuration details. These three languages can be used without the need to send the printer instructions to switch from one language to another.
- EPL, ZPL, and SGD commands must be sent to the printer as separate files. They cannot be used together in one format, or set of commands. For example, if you send a series of SGD commands to the printer and they are followed by a printable format, this needs to be done using separate files.

Many text editors and word processors can recreate most examples in this guide in ASCII format. However, for other encodings such as Unicode, a text editor such as Microsoft Notepad is needed.

If there are any terms used in this guide that you need clarification on, see the [Glossary](#) on page 1519.

Who Should Use This Document

This Programming Guide is for programmers who are familiar working with programming languages.

How This Document Is Organized

The Programming Guide is set up as follows:

Section	Description
About This Document	Provides a high-level overview about this guide and Zebra Programming Language (ZPL).
ZPL Commands	Provides an alphabetical, detailed description of each ZPL command.
ZPL RFID Commands	Provides an alphabetical, detailed description of each ZPL RFID command, and some examples of how to use them.
ZPL Wireless Commands	Provides new and modified ZPL commands for the wireless print server.
ZBI Commands	Provides details about the Zebra Basic Interpreter, its commands, descriptions, formats, and parameters.
SGD Printer Commands	Provides a high-level overview of printer setting Set / Get / Do (SGD) commands.
SGD Wired Commands	Provides a high-level overview of the wired Set / Get / Do (SGD) commands.
SGD Wireless Commands	Provides a high-level overview of the wireless Set / Get / Do (SGD) commands.
Appendixes	The appendixes include: Zebra Code Pages ASCII Fonts and Bar Codes Mod 10 and Mod 43 Check Digits Error Detection Protocol ZB64 Encoding and Compression Field Interactions Real Time Clock ZBI Character Set SGD Command Support Firmware Features Mirror Wireless Markup Language (WML) Using Weblink HTTP POST Alerts Advanced Techniques
Glossary	Glossary of terms.

ZPL Commands

This section contains the complete alphabetical listing of ZPL II commands.

The first paragraph(s) provides an explanation of how the command is used, what it is capable of, and any defining characteristics it has.

The format explains how the command is syntactically arranged and what parameters it contains. For example, the **^B8** command prints a EAN-8 bar code. The format of the **^B8** command is: **^B8o,h,f,g**. It is arranged with the caret symbol (^), the command code (**B8**), and the parameters and are replaced with supported values.

In the parameters table, if a command has values that can be defined to make its function more specific, these are outlined as parameters.

Still using the **^B8** example, the **h** parameter is defined as:

h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
---	---

If the command has no parameters – for example **~JA** (Cancel All) – the parameter heading is removed, indicating that the format of the command (**~JA**) is acceptable ZPL II code.



Example: When the command is best clarified in context, an example of the ZPL II code is provided. Text indicating exact code entered is printed in an easily recognizable Courier font. An example of code using the **^B8** command looks like this:

```
^XA
^F050,50
^B8N,100,Y,N
^FD1234567^FS
^XZ
```

Notice that the **^B8** parameter letters have been replaced with real values that apply to the command. In this example **N,100,Y,N** have been entered.

A Comments section (if used) will show notes that are of value to a programmer, warnings of potential command interactions, or command-specific information that should be taken into consideration.



Example:

This command works only when the printer is idle, or This command is ignored if a value exceeds the parameter limits.

Comments are also included next to parameters if they apply directly to a particular setting.

Basic ZPL Exercises and Examples

The purpose of these exercises is to introduce basic ZPL commands to novice ZPL users.

Make sure this checklist is complete:

- Load the printer with labels that are big enough to give you ample space to work with.
- Print a configuration label (CANCEL test).
- Look at the configuration label and make sure that the **LEFT POSITION** is set to **000** and **LABEL TOP** is set to **000**.
- Determine the printer's resolution. It is listed on the configuration label. **8/MM** = 200 dpi, **12/MM** = 300 dpi and **24/MM** = 600 dpi.

Tips

These are some tips when using ZPL:

- Use the DOS text editor to write ZPL files.
- Save the file as a **.txt** file and copy it to the printer from DOS command line.

Before you begin

Some things that are important to understand before you begin are:

- 200 dpi means the resolution of the printhead is 200 dots per inch. If you program the printer to draw a line 100 dots long that equals a half inch. 100 dots on a 300 dpi printer prints a line 1/3 inch long.
- The home position that all your coordinates are referencing is at the left-hand trailing edge of the label as the label comes out of the printer. (There are some exceptions to this.)

Exercises

The exercises start simple and gradually progress to give you an opportunity to try a variety of commonly used ZPL commands. Not all commands are covered, but this should be a good core of commands to learn. Some commands may not be supported due to the firmware version in your printer.

Exercise 1 This exercise shows you how to specify a location for an entered name.


1. Print your name on the label.

2. Start by printing just your name on the label. Use this format as a model:



Important • Your name goes where you see `xxxxxxxxxxx` in the second line of code.

3. Send this format to the printer:



1	Every format starts with the ^XA command
2	^FO (field origin) command
3	^FS (field separator) command
4	Every format ends with the ^XZ command
5	^FD (field data) command

4. When the label prints correctly, alter the first number after the **^FOx**. See how that change affects the print position. Alter the second number after the **^FO50, x** and see how that the print position.

Font instruction

^ADN

- Alter the numbers after the **^ADN, x, x** command.
 - 18,10 is the smallest size you can make the **D** font.
 - The first number is the height of the font in dots. The second number is the width in dots.
 - You can use direct multiples up to ten times that size as a maximum.



Example: 180,100 is the largest you can make the **D** font.

- 25,18 would not be a valid size. The printer rounds to the next recognizable size.
- Check the font matrices tables for other fonts to try. See *Fonts and Bar Codes on page 1335*.
 - Try the zero scalable font **^A0N, x, x**.
This font is scalable, and you can choose any height and width.

Rotation Commands

- Change **^ADN** to **^ADR**, and then **^ADI**, and then **^ADB**.
See how the print position changes.
- Add more fields.

3. Add two more fields to print directly under your name using the **^ADN, 36, 20** font and size:
Your street address
Your city, state, zip
4. You must add two more lines of code that start off with:
^XA
^F050,50^ADN,36,20^FDxxxxxxxxxxxx^FS
^FO (fill in the rest)
^FO (fill in the rest)
^XZ

Make sure all these fields print in the same font and size and left side of fields has same vertical alignment.

Your name
1200 W Main Street
Anytown, IL 60061

Special Effects commands

The Graphic Box or **^GB** command or is used in some of the speical effects commands.

Reverse Printing a Field

1. Write the following format and send to the printer:
^XA
^PR1
^F0100,100
^GB70,70,70,,3^FS
^F0200,100
^GB70,70,70,,3^FS
^F0300,100
^GB70,70,70,,3^FS
^F0400,100
^GB70,70,70,,3^FS
^F0107,110^CF0,70,93
^FR^FDREVERSE^FS
^XZ
2. To see the effects, remove:
^FR^FDREVERSE^FS
3. To see the effects, try removing one of the **^GB** lines of code.

Label Reverse Print

1. Write the following format and send to the printer:
^XA^LRY
^F0100,50
^GB195,203,195^FS
^F0180,110^CFG
^FDLABEL^FS
^F0130,170
^FDREVERSE^FS
^XZ
2. To see the effects, remove:
^GB195,203,195^FS

Mirror Image of Label

1. Write the following format and send to the printer:
^XA^PMY
^F0100,100
^CFG
^FDMIRROR^FS
^F0100,160
^FDIMAGE^FS
^XZ
2. To see the effects, in the first line of code change ^PMY to ^PMN.

Print Orientation

1. Write the following format and send to the printer:
^XA^CFD
^POI
^LH330,10
^F050,50
^FDZEBRA TECHNOLOGIES^FS
^F050,75
^FDVernon Hills, IL^FS
^XZ
2. To see the effects, in the second line of code change ^POI to ^PON.

Exercise 2 Boxes and lines

1. Use the address format from [Exercise 1](#).
2. Add this new line to your existing format:
`^F050,200^GB200,200,2^FS`
 This prints a box one wide by one inch long and the thickness of the line is 2 dots.
3. Reposition and resize the square so that it goes around the name and address uniformly.
4. Print a line by adding:
`^F050,300^GB400,1,4,^FS`
 This prints a horizontal line two inches wide by 4 dots thick.
5. Print a vertical line using this code:
`^F0100,50^GB1,400,4^FS`

Exercise 3 Bar codes — ^B3 code 39 bar code

1. Write the following format and send to the printer:
`^XA`
`^F050,50^B3N,N,100,Y,N^FD123456^FS`
`^XZ`
2. Try changing each of the parameters in the `^B3` string so you can see the effects.
`^B3o,e,h,f,g`
`^BY`



Important • For valid parameter choices, see `^B3` [on page 52](#).

3. Insert the `^BY` command just before the `^B3` to see how the narrow bar width can be altered.
`^F050,50^BY2^B3..etc ^BYx`, acceptable values for x are 1 through 10
4. Alter the ratio of the narrow to wide bar.
`^F050,50^BY2,3^B3..etc ^BY2,x` acceptable values for x are 2.1 through 3 in .1 increments
5. Print out a `^B3` bar code with the interpretation line on top of the bar code and the bar code rotated 90 degrees.
6. Add a `^PQ` just before the `^XZ` to print several labels.
`^PQ4`
`^XZ`
`^PR` Print rate (in inches per second)

7. Add a **^PR** command after the **^XA** at the beginning of the format to change the print rate (print speed).
^XA
^PR4 then try **^PR6** **^PRx** acceptable values for x are 2 through 12 (check printer specs)
 See how the print speed affects the print quality of the bar code. You may need to increase the printer darkness setting at higher print speeds.

Exercise 4 ^SN — Serial Number command

1. Send this format to the printer:
^XA
^F0100,100^ADN,36,20^SN001,1,Y^FS
^PQ3
^XZ
 To vary the **^SNv,n,z** to exercise increment/decrement and leading zeros functions, consult this guide.
 If your serial number contains alpha and numeric characters, you can increment or decrement a specific segment of the data even if it is in the middle, as this sample sequence shows:
ABCD1000EFGH, ABCD1001EFGH, ABCD1002EFGH

2. Send this file to the printer and to see how it increments the serial number. The **^SF** command can also work with alpha characters.
^XA
^F0100,100^ADN,36,20^FDABCD1000EFGH^SF%%%ddd%%%,10000^FS
^PQ15
^XZ

Notice how the field data character position aligns with the **^SF** data string:

^	F	D	A	B	C	D	1	0	0	0	E	F	G	H
^	S	F	%	%	%	%	d	d	d	d	%	%	%	%
										1	0	0	0	0
										2	0	0	0	0
										3	0	0	0	0

And on through...

							1	0	1	4	0	0	0	0
--	--	--	--	--	--	--	----------	----------	----------	----------	----------	----------	----------	----------

The last label prints **ABCD1014EFGH**.

The **%** is placed in positions that you do not want to increment or decrement,
d = decimal, **10000** = increment value.

For more details on **^SF**, see **^SF** on page 309.

Exercise 5 Saving a template to memory. **^IS** and image save and image load.



Note • This exercise helps you troubleshoot your code against the errors you see on your labels.

1. Send this format to the printer:

```

^XA
^F020,30^GB750,1100,4^FS
^F020,30^GB750,200,4^FS
^F020,30^GB750,400,4^FS
^F020,30^GB750,700,4^FS
^F020,226^GB325,204,4^FS
^F030,40^ADN,36,20^FDShip to:^FS
^F030,260^ADN,18,10^FDPart number #^FS
^F0360,260^ADN,18,10^FDDescription:^FS
^F030,750^ADN,36,20^FDFrom:^FS
^ISR:SAMPLE.GRF^FS
^XZ
  
```

2. Send this format:

```

^XA
^ILR:SAMPLE.GRF^FS
^F0150,125^ADN,36,20^FDAcme Printing^FS
^F060,330^ADN,36,20^FD14042^FS
^F0400,330^ADN,36,20^FDScrew^FS
^F070,480^BY4^B3N,,200^FD12345678^FS
^F0150,800^ADN,36,20^FDMacks Fabricating^FS
^XZ
  
```


In this way the template only needs to be sent one time to the printer's memory. Subsequent formats can be sent recalling the template and merging variable data into the template. In this exercise, the file was saved in the printers **R**: memory, which is volatile.

Exercise 6 **^DF** and **^XF** — Download format and recall format

Similar concept to **^IS** and **^IL** command. **^IS** and **^IL** processes faster in the printer than **^DF** and **^XF**.

This is how the **^DF** and **^XF** format structure produces a label similar to the **^IS**/**^IL** sample you just tried.

Figure 1 • Download and Recall Format



1	Download format code
2	Recall format call that generates the generated label in Figure 1 .

Exercise 7 Asian and Unicode Encodings



This exercise works in printers with firmware version V60.14, V50.14, or later.

In each of the following examples, the format is saved in the corresponding encoding before being sent down to the printer and the ZPL script was made in Microsoft Notepad, a basic text editor. The characters were inserted from the character map in Windows or typed from the keyboard.

➔ **Example:** This is an example of using an Asian encoding, such as UHANGUL, with ASCII text. Using the **CI26** command tells the printer to recognize any byte less than 7F as ASCII text and every byte above as the first byte of UHANGUAL encoding:

ZPL II CODE	GENERATED LABEL
<pre>^XA^Cw1, B:ANMDK.TTF ^SEB:UHANGUL.DAT^CI26 ^FO100,100^A1, 50, 50^FDASCII 한국어 ^FS ^XZ</pre>	ASCII한국어

➔ **Example:** This is an example of using the Unicode encoding, UTF-8:

ZPL II CODE
<pre>^XA^Cw1, ANMDJ.TTF^CI28 ^FO100, 50^A1, 30, 30^FDENGLISH/日本語/한국어/简体中文/繁体中文^FS ^XZ</pre>

GENERATED LABEL
ENGLISH/日本語/한국어/简体中文/繁体中文

Allowed Characters in File Names

Files on the internal printer drives (R:, E:, etc.) can be created or accessed using several different commands (for example, ^DF, ^XF, ^TO, etc.). The names of the file can contain ONLY the characters shown in Table 1.

Shaded areas indicate characters which cannot be used. The command and control characters (normally ^ and ~) cannot be used unless the control characters are changed to something else using the ^CC ~CC ZPL command.

Table 1 •

Char.	DEC	OCT	HEX
(sp)	32	0040	0x20
!	33	0041	0x21
"	34	0042	0x22
#	35	0043	0x23
\$	36	0044	0x24
%	37	0045	0x25
&	38	0046	0x26
'	39	0047	0x27
(40	0050	0x28
)	41	0051	0x29
*	42	0052	0x2a
+	43	0053	0x2b
,	44	0054	0x2c
-	45	0055	0x2d
.	46	0056	0x2e
/	47	0057	0x2f
0	48	0060	0x30
1	49	0061	0x31
2	50	0062	0x32
3	51	0063	0x33
4	52	0064	0x34
5	53	0065	0x35
6	54	0066	0x36
7	55	0067	0x37
8	56	0070	0x38
9	57	0071	0x39
:	58	0072	0x3a
;	59	0073	0x3b
<	60	0074	0x3c
=	61	0075	0x3d
>	62	0076	0x3e
?	63	0077	0x3f

Char.	DEC	OCT	HEX
@	64	0100	0x40
A	65	0101	0x41
B	66	0102	0x42
C	67	0103	0x43
D	68	0104	0x44
E	69	0105	0x45
F	70	0106	0x46
G	71	0107	0x47
H	72	0110	0x48
I	73	0111	0x49
J	74	0112	0x4a
K	75	0113	0x4b
L	76	0114	0x4c
M	77	0115	0x4d
N	78	0116	0x4e
O	79	0117	0x4f
P	80	0120	0x50
Q	81	0121	0x51
R	82	0122	0x52
S	83	0123	0x53
T	84	0124	0x54
U	85	0125	0x55
V	86	0126	0x56
W	87	0127	0x57
X	88	0130	0x58
Y	89	0131	0x59
Z	90	0132	0x5a
[91	0133	0x5b
\	92	0134	0x5c
]	93	0135	0x5d
^	94	0136	0x5e
_	95	0137	0x5f

Char.	DEC	OCT	HEX
`	96	0140	0x60
a	97	0141	0x61
b	98	0142	0x62
c	99	0143	0x63
d	100	0144	0x64
e	101	0145	0x65
f	102	0146	0x66
g	103	0147	0x67
h	104	0150	0x68
i	105	0151	0x69
j	106	0152	0x6a
k	107	0153	0x6b
l	108	0154	0x6c
m	109	0155	0x6d
n	110	0156	0x6e
o	111	0157	0x6f
p	112	0160	0x70
q	113	0161	0x71
r	114	0162	0x72
s	115	0163	0x73
t	116	0164	0x74
u	117	0165	0x75
v	118	0166	0x76
w	119	0167	0x77
x	120	0170	0x78
y	121	0171	0x79
z	122	0172	0x7a
{	123	0173	0x7b
	124	0174	0x7c
}	125	0175	0x7d
~	126	0176	0x7e
(del)	127	0177	0x7f

^A – Scalable/Bitmapped Font

The ^A command specifies the font to use in a text field. ^A designates the font for the current ^FD statement or field. The font specified by ^A is used only once for that ^FD entry. If a value for ^A is not specified again, the default ^CF font is used for the next ^FD entry.


Format:	
Parameter	Details
f = font name	Values: A through Z, and 0 to 9 Any font in the printer (downloaded, EPROM, stored fonts, fonts A through Z and 0 to 9).
o = field orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: the last accepted ^FW value or the ^FW default
h = Character Height (in dots)	Scalable Values: 10 to 32000 Default: last accepted ^CF Bitmapped Values: multiples of height from 1 to 10 times the standard height, in increments of 1 Default: last accepted ^CF
w = width (in dots)	Scalable Values: 10 to 32000 Default: last accepted ^CF Bitmapped Values: multiples of width from 1 to 10 times the standard width, in increments of 1 Default: last accepted ^CF



Important • Parameter **f** is required. If **f** is omitted it defaults to the last value of the ^CF command.


Scalable Font Command

➔ **Example:** This is an example of a scalable font command:

ZPL II Code	Generated Label
^XA	
^F050,50	
^A0,32,25	
^FDZEBRA^FS	
^F050,150	
^A0,32,25	
^FDPROGRAMMING^FS	
^F050,250	
^A0,32,25^FDLANGUAGE^FS	

Bitmap Font Command

➔ **Example:** This is an example of a bitmap font command:

ZPL II Code	Generated Label
^XA	
^F050,50	
^ADN,36,20	
^FDZEBRA^FS	
^F050,150	
^ADN,36,20	
^FDPROGRAMMING^FS	
^F050,250	
^ADN,36,20^FDLANGUAGE^FS	

For reference, see [Standard Printer Fonts on page 1336](#), [Zebra Code Page 850 — Latin Character Set on page 1317](#), [Fonts and Bar Codes on page 1335](#), and [ASCII on page 1331](#).

Comments Fonts are built using a matrix that defines standard height-to-width ratios. If you specify only the height or width value, the standard matrix for that font automatically determines the other value. If the value is not given or a 0 (zero) is entered, the height or width is determined by the standard font matrix.



This command interacts with the justification parameters of ^FO and ^FT and with the field direction parameter of ^FP. For output and examples, see [Field Interactions on page 1369](#).

^A@ – Use Font Name to Call Font


The ^A@ command uses the complete name of a font, rather than the character designation used in ^A. Once a value for ^A@ is defined, it represents that font until a new font name is specified by ^A@.

Format: ^A@o,h,w,d:f.x	
Parameter	Details
o = field orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotates 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: N or the last ^FW value</p>
h = character height (in dots)	<p>Default: Specifies magnification by w (character width) or the last accepted ^CF value. Uses the base height if none is specified.</p> <ul style="list-style-type: none"> • Scalable The value is the height in dots of the entire character block. Magnification factors are unnecessary, because characters are scaled. • Bitmapped The value is rounded to the nearest integer multiple of the font's base height, then divided by the font's base height to give a magnification nearest limit.
w = width (in dots)	<p>Default: Specifies magnification by h (height) or the last accepted ^CF value. Specifies the base width is used if none is specified.</p> <ul style="list-style-type: none"> • Scalable The value is the width in dots of the entire character block. Magnification factors are unnecessary, because characters are scaled. • Bitmapped The value rounds to the nearest integer multiple of the font's base width, then divided by the font's base width to give a magnification nearest limit.
d = drive location of font	<p>Values: R:, E:, B:, and A: Default: R:</p>
f = font name	<p>Values: any valid font Default: if an invalid or no name is entered, the default set by ^CF is used. If no font has been specified in ^CF, font A is used.</p> <p>The font named carries over on all subsequent ^A@ commands without a font name.</p>
x = extension	<p>Values:</p> <ul style="list-style-type: none"> .FNT = font .TTF = TrueType Font .TTE = TrueType Extension



.TTE is only supported in firmware version V60.14.x, V50.14.x, or later.

➔ **Example:** This example identifies the purpose of each line of code for this label:

ZPL II Code	Generated Label
1→ ^XA	
2→ ^A2N,50,50,B:CYRI_UB.FNT	
3→ ^F0100,100	
4→ ^FDZebra Printer Fonts^FS	
5→ ^A2N,40,40	
6→ ^F0100,150	
7→ ^FDThis uses B:CYRI_UB.FNT^FS	
8→ ^XZ	

1	Starts the label format.
2	Searches non-volatile printer memory (B:) for CYRI_UB.FNT. When the font is found, the ^A@ command sets the print orientation to normal and the character size to 50 dots by 50 dots.
3	Sets the field origin at 100,100.
4	Prints the field data, <i>Zebra Printer Fonts</i> on the label.
5	Calls the font again and character size is decreased to 40 dots by 40 dots.
6	Sets the new field origin at 100,150.
7	Prints the field data, <i>This uses the B:CYRI_UB.FNT</i> on the label.
8	Ends the label format.

For reference, see [Zebra Code Page 850 — Latin Character Set](#) on page 1317, [Fonts and Bar Codes](#) on page 1335, and [ASCII](#) on page 1331.

^B0 – Aztec Bar Code Parameters

The ^B0 command creates a two-dimensional matrix symbology made up of square modules arranged around a bulls-eye pattern at the center.




Note • The Aztec bar code works with firmware version V60.13.0.11A and V50.13.2 or later.

Format: ^B0a,b,c,d,e,f,g

Parameters	Details
a = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: current ^FW value</p>
b = magnification factor	<p>Values: 1 to 10</p> <p>Default:</p> <ul style="list-style-type: none"> 1 on 150 dpi printers 2 on 200 dpi printers 3 on 300 dpi printers 6 on 600 dpi printers
c = extended channel interpretation code indicator	<p>Values:</p> <ul style="list-style-type: none"> Y = if data contains ECICs N = if data does not contain ECICs <p>Default: N</p>
d = error control and symbol size/type indicator	<p>Values:</p> <ul style="list-style-type: none"> 0 = default error correction level 01 to 99 = error correction percentage (minimum) 101 to 104 = 1 to 4-layer compact symbol 201 to 232 = 1 to 32-layer full-range symbol 300 = a simple Aztec "Rune" <p>Default: 0</p>
e = menu symbol indicator	<p>Values:</p> <ul style="list-style-type: none"> Y = if this symbol is to be a menu (bar code reader initialization) symbol N = if it is not a menu symbol <p>Default: N</p>
f = number of symbols for structured append	<p>Values: 1 through 26</p> <p>Default: 1</p>
g = optional ID field for structured append	<p>The ID field is a text string with 24-character maximum</p> <p>Default: no ID</p>



Example: This is an example of the ^B0 command:

ZPL II CODE	GENERATED LABEL
<pre data-bbox="428 310 894 569">^XA ^B0R,7,N,0,N,1,0 ^FD 7. This is testing label 7^FS ^XZ</pre>	

^B1 – Code 11 Bar Code

The ^B1 command produces the Code 11 bar code, also known as USD-8 code. In a Code 11 bar code, each character is composed of three bars and two spaces, and the character set includes 10 digits and the hyphen (-).

- ^B1 supports print ratios of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.




Important • If additional information about the Code 11 bar code is required, go to www.aimglobal.org.

Format: ^B1o,e,h,f,g

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: <i>current ^FW value</i>
e = check digit	Values: Y = 1 digit N = 2 digits Default: N
h = bar code height (in dots)	Values: 1 to 32000 Default: Value set by ^BY
f = print interpretation line	Values: Y = yes N = no Default: Y
g = print interpretation line above code	Values: Y = yes N = no Default: N



Example: This is an example of the Code 11 bar code:

ZPL II CODE	CODE 11 BAR CODE											
<pre> ^XA ^FO100,100^BY3 ^B1N,N,150,Y,N ^FD123456^FS ^XZ </pre>	 <p>△12345611△</p>											
CODE 11 BAR CODE CHARACTERS												
<table style="margin: 0 auto; border: none;"> <tr> <td style="padding: 0 10px;">0</td> <td style="padding: 0 10px;">1</td> <td style="padding: 0 10px;">2</td> <td style="padding: 0 10px;">3</td> <td style="padding: 0 10px;">4</td> <td style="padding: 0 10px;">5</td> <td style="padding: 0 10px;">6</td> <td style="padding: 0 10px;">7</td> <td style="padding: 0 10px;">8</td> <td style="padding: 0 10px;">9</td> <td style="padding: 0 10px;">-</td> </tr> </table> <p style="margin-top: 10px;">Internal Start/Stop Character:△</p> <p style="margin-top: 5px;"><i>When used as a stop character:</i></p> <ul style="list-style-type: none"> △ is used with 1 check digit △ is used with 2 check digits 		0	1	2	3	4	5	6	7	8	9	-
0	1	2	3	4	5	6	7	8	9	-		

^B2 – Interleaved 2 of 5 Bar Code

The ^B2 command produces the Interleaved 2 of 5 bar code, a high-density, self-checking, continuous, numeric symbology.

Each data character for the Interleaved 2 of 5 bar code is composed of five elements: five bars or five spaces. Of the five elements, two are wide and three are narrow. The bar code is formed by interleaving characters formed with all spaces into characters formed with all bars.

- ^B2 supports print ratios of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.




Important • If additional information about the Interleaved 2 of 5 bar code is required, go to www.aimglobal.org.

Format: ^B2o,h,f,g,e,j

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: Y = yes N = no Default: Y
g = print interpretation line above code	Values: Y = yes N = no Default: N
e = calculate and print Mod 10 check digit	Values: Y = yes N = no Default: N



Example: This is an example of an Interleaved 2 of 5 bar code:

ZPL II CODE					INTERLEAVED 2 OF 5 BAR CODE														
<pre> ^XA ^FO100,100^BY3 ^B2N,150,Y,N,N ^FD123456^FS ^XZ </pre>					 123456														
INTERLEAVED 2 OF 5 BAR CODE CHARACTERS																			
0		1		2		3		4		5		6		7		8		9	
Start/Stop (internal)																			

Comments The total number of digits in an Interleaved 2 of 5 bar code must be even. The printer automatically adds a leading 0 (zero) if an odd number of digits is received.

The Interleaved 2 of 5 bar code uses the Mod 10 check-digit scheme for error checking. For more information on Mod 10 check digits, see [Mod 10 Check Digit on page 1349](#).

^B3 – Code 39 Bar Code

The Code 39 bar code is the standard for many industries, including the U.S. Department of Defense. It is one of three symbologies identified in the American National Standards Institute (ANSI) standard MH10.8M-1983. Code 39 is also known as USD-3 Code and 3 of 9 Code.

Each character in a Code 39 bar code is composed of nine elements: five bars, four spaces, and an inter-character gap. Three of the nine elements are wide; the six remaining elements are narrow.

- ^B3 supports print ratios of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.
- Code 39 automatically generates the start and stop character (*).
- Asterisk (*) for start and stop character prints in the interpretation line, if the interpretation line is turned on.
- Code 39 is capable of encoding the full 128-character ASCII set.




Important • If additional information about the Code 39 bar code is required, go to www.aimglobal.org.

Format: ^B3o,e,h,f,g


Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
e = Mod-43 check digit	Values: Y = yes N = no Default: N
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: Y = yes N = no Default: Y
g = print interpretation line above code	Values: Y = yes N = no Default: N

➔ **Example 1:** This is an example of a Code 39 bar code:

ZPL II CODE	CODE 39 BAR CODE																																												
<pre> ^XA ^FO100,100^BY3 ^B3N,N,100,Y,N ^FD123ABC^FS ^XZ </pre>	 <p style="text-align: center;">*123ABC*</p>																																												
CODE 39 BAR CODE CHARACTERS																																													
<table style="width: 100%; border: none;"> <tr> <td style="width: 10%;"></td> <td style="width: 10%;">0</td> <td style="width: 10%;">1</td> <td style="width: 10%;">2</td> <td style="width: 10%;">3</td> <td style="width: 10%;">4</td> <td style="width: 10%;">5</td> <td style="width: 10%;">6</td> <td style="width: 10%;">7</td> <td style="width: 10%;">8</td> <td style="width: 10%;">9</td> </tr> <tr> <td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td><td>K</td> </tr> <tr> <td>L</td><td>M</td><td>N</td><td>O</td><td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td> </tr> <tr> <td>W</td><td>X</td><td>Y</td><td>Z</td><td>-</td><td>.</td><td>\$</td><td>/</td><td>+</td><td>%</td><td>Space</td> </tr> </table>			0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	-	.	\$	/	+	%	Space
	0	1	2	3	4	5	6	7	8	9																																			
A	B	C	D	E	F	G	H	I	J	K																																			
L	M	N	O	P	Q	R	S	T	U	V																																			
W	X	Y	Z	-	.	\$	/	+	%	Space																																			

Comments Extended ASCII is a function of the scanner, not of the bar code. Your scanner must have extended ASCII enabled for this feature to work. To enable extended ASCII in the Code 39, you must first encode +\$ in your ^FD statement. To disable extended ASCII, you must encode -\$ in your ^FD statement.

➔ **Example 2:** This example encodes a carriage return with line feed into a Code 39 bar code:

ZPL II CODE	GENERATED LABELS
<pre> ^XA ^FO20,20 ^B3N,N,100,Y ^FDTEST+\$\$M\$J-\$^FS ^XZ </pre>	 <p style="text-align: center;">*TEST+\$\$M\$J-\$*</p>

Full ASCII Mode for Code 39

Code 39 can generate the full 128-character ASCII set using paired characters as shown in these tables:

Table 2 •

ASCII	Code 39	ASCII	Code 39
SOH	\$A	SP	Space
STX	\$B	!	/A
ETX	\$C	"	/B
EOT	\$D	#	/C
ENQ	\$E	\$	/D
ACK	\$F	%	/E
BEL	\$G	&	/F
BS	\$H	'	/G
HT	\$I	(/H
LF	\$J)	/I
VT	\$K	*	/J
FF	\$L	++	/K
CR	\$M	,	/L
SO	\$N	-	-
SI	\$O	.	.
DLE	\$P	/	/O
DC1	\$Q	0	0
DC2	\$R	1	1
DC3	\$S	2	2
DC4	\$T	3	3
NAK	\$U	4	4
SYN	\$V	5	5
ETB	\$W	6	6
CAN	\$X	7	7
EM	\$Y	8	8
SUB	\$Z	9	9
ESC	%A	:	/Z
FS	%B	;	%F
FS	%C	<	%G
RS	%D	=	%H
US	%E	>	%I
		?	%J

Table 3 •

ASCII	Code 39	ASCII	Code 39
@	%V	'	%W
A	A	a	+A
B	B	b	+B
C	C	c	+C
D	D	d	+D
E	E	e	+E
F	F	f	+F
G	G	g	+G
H	H	h	+H
I	I	i	+I
J	J	j	+J
K	K	k	+K
L	L	l	+L
M	M	m	+M
N	N	n	+N
O	O	o	+O
P	P	p	+P
Q	Q	q	+Q
R	R	r	+R
S	S	s	+S
T	T	t	+T
U	U	u	+U
V	V	v	+V
W	W	w	+W
X	X	x	+X
Y	Y	y	+Y
Z	Z	z	+Z
[%K	{	%P
\	%L		%Q
]	%M	}	%R
^	%N	~	%S
_	%O	DEL	%T, %X

^B4 – Code 49 Bar Code

The ^B4 command creates a multi-row, continuous, variable-length symbology capable of encoding the full 128-character ASCII set. It is ideally suited for applications requiring large amounts of data in a small space.

The code consists of two to eight rows. A row consists of a leading quiet zone, four symbol characters encoding eight code characters, a stop pattern, and a trailing quiet zone. A separator bar with a height of one module separates each row. Each symbol character encodes two characters from a set of Code 49 characters.

- ^B4 has a fixed print ratio.
- Rows can be scanned in any order.



Important • For additional information about the Code 49 bar code is required, go to www.aimglobal.org.

Format: ^B4o,h,f,m

Parameters	Details
o = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: current ^FW value</p>
h = height multiplier of individual rows	<p>Values: 1 to height of label</p> <p>Default: value set by ^BY</p> <p>This number multiplied by the module equals the height of the individual rows in dots. 1 is not a recommended value.</p>
f = print interpretation line	<p>Values:</p> <ul style="list-style-type: none"> N = no line printed A = print interpretation line above code B = print interpretation line below code <p>Default: N</p> <p>When the field data exceeds two rows, expect the interpretation line to extend beyond the right edge of the bar code symbol.</p>
m = starting mode	<p>Values:</p> <ul style="list-style-type: none"> 0 = Regular Alphanumeric Mode 1 = Multiple Read Alphanumeric 2 = Regular Numeric Mode 3 = Group Alphanumeric Mode 4 = Regular Alphanumeric Shift 1 5 = Regular Alphanumeric Shift 2 A = Automatic Mode. The printer determines the starting mode by analyzing the field data. <p>Default: A</p>



Example 1: This is an example of a Code 49 bar code:


ZPL II CODE	CODE 49 BAR CODE
<pre>^XA ^FO150,100^BY3 ^B4N,20,A,A ^FD12345ABCDE^FS ^XZ</pre>	 <p>12345ABCDE</p>

Table 4 •

Field Data Set	Unshifted Character Set	Shift 1 Character Set	Shift 2 Character Set
0	0	,	
1	1	ESC	;
2	2	FS	<
3	3	GS	=
4	4	RS	>
5	5	US	?
6	6	!	@
7	7	"	[
8	8	#	\
9	9	&]
A	A	SOH	a
B	B	STX	b
C	C	ETX	c
D	D	EOT	d
E	E	ENQ	e
F	F	ACK	f
G	G	BEL	g
H	H	BS	h
I	I	HT	i
J	J	LF	j
K	K	VT	k
L	L	FF	l
M	M	CR	m
N	N	SO	n
O	O	SI	o
P	P	DLE	p
Q	Q	DC1	q
R	R	DC2	r
S	S	DC3	s
T	T	DC4	t
U	U	NAK	u
V	V	SYN	v
W	W	ETB	w
X	X	CAN	x
Y	Y	EM	y
Z	Z	SUB	z
-	-	(␣
.	.)	␣
SPACE	SPACE	Null	DEL
\$	\$	*	{
/	/	,	
++	++	:	}
%	%	reserved	~
< (Shift 1)			
> (Shift 2)			
: (N.A.)			
; (N.A.)			
? (N.A.)			
= (Numeric Shift)			

Code 49 Shift 1 and 2 Character Substitutions

Code 49 Field Data Character Set

The ^FD data sent to the printer when using starting modes 0 to 5 is based on the Code 49 Internal Character Set. This is shown in the first column of the Code 49 table on the previous page. These characters are Code 49 control characters:

: ; < = > ?

Valid field data must be supplied when using modes 0 to 5. Shifted characters are sent as a two-character sequence of a shift character followed by a character in the unshifted character set.



Example 2: To encode a lowercase **a**, send **a >** (Shift 2) followed by an uppercase **A**. If interpretation line printing is selected, a lowercase *a* prints in the interpretation line. This reflects what the output from the scanner reads. Code 49 uses uppercase alphanumeric characters only.

If an invalid sequence is detected, the Code 49 formatter stops interpreting field data and prints a symbol with the data up to the invalid sequence. These are examples of invalid sequences:

- Terminating numeric mode with any characters other than 0 to 9 or a Numeric Space.
- Starting in Mode 4 (Regular Alphanumeric Shift 1) and the first field data character is not in the Shift 1 set.
- Starting in Mode 5 (Regular Alphanumeric Shift 2) and the first field data character is not in the Shift 2 set.
- Sending Shift 1 followed by a character not in the Shift 1 set.
- Sending Shift 2 followed by a character not in the Shift 2 set.
- Sending two Shift 1 or Shift 2 control characters.

Advantages of Using the Code 49 Automatic Mode

Using the default (Automatic Mode) completely eliminates the need for selecting the starting mode or manually performing character shifts. The Automatic Mode analyzes the incoming ASCII string, determines the proper mode, performs all character shifts, and compacts the data for maximum efficiency.

Numeric Mode is selected or shifted only when five or more continuous digits are found. Numeric packaging provides no space advantage for numeric strings consisting of fewer than eight characters.

^B5 – Planet Code bar code

The ^B5 command is supported in all printers as a resident bar code.



Note • Accepted bar code characters are 0 - 9.

Format: ^B5o,h,f,g

Parameters	Details
o = orientation code	Values: N = normal R = rotated I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 9999 Default: value set by ^BY
f = interpretation line	Values: N = no Y = yes Default: N
g = determines if the interpretation line is printed above the bar code	Values: N = no Y = yes Default: N



Example: This is an example of a Planet Code bar code:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO150,100^BY3 ^B5N,100,Y,N ^FD12345678901^FS ^XZ </pre>	

^B7 – PDF417 Bar Code

The ^B7 command produces the PDF417 bar code, a two-dimensional, multirow, continuous, stacked symbology. PDF417 is capable of encoding over 1,000 characters per bar code. It is ideally suited for applications requiring large amounts of information at the time the bar code is read.

The bar code consists of three to 90 stacked rows. Each row consists of start and stop patterns and symbol characters called *code-words*. A code-word consists of four bars and four spaces. A three code-word minimum is required per row.

The PDF417 bar code is also capable of using the structured append option (^FM), which allows you to extend the field data limitations by printing multiple bar codes. For more information on using structured append, see [^FM on page 172](#).


- PDF417 has a fixed print ratio.
- Field data (^FD) is limited to 3K of character data.

Format: ^B7o,h,s,c,r,t



Parameters	Details
o = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: current ^FW value</p>
h = bar code height for individual rows (in dots)	<p>Values: 1 to height of label</p> <p>Default: value set by ^BY</p> <p>This number multiplied by the module equals the height of the individual rows in dots. If this number is not specified, the overall bar code height, divided by the number of rows, equals the height of the individual rows in dots, where the overall bar code height is defined by the ^BY command. 1 is not a recommended value.</p>
s = security level	<p>Values: 1 to 8 (error detection and correction)</p> <p>Default: 0 (error detection only)</p> <p>This determines the number of error detection and correction code-words to be generated for the symbol. The default level provides only error detection without correction. Increasing the security level adds increasing levels of error correction and increases the symbol size.</p>
c = number of data columns to encode	<p>Values: 1 to 30</p> <p>Default: 1:2 (row-to-column aspect ratio)</p> <p>You can specify the number of code-word columns giving control over the width of the symbol.</p>
r = number of rows to encode	<p>Values: 3 to 90</p> <p>Default: 1:2 (row-to-column aspect ratio)</p> <p>You can specify the number of symbol rows giving control over the height of the symbol. For example, with no row or column values entered, 72 code-words would be encoded into a symbol of six columns and 12 rows. Depending on code-words, the aspect ratio is not always exact.</p>

Parameters	Details
t = truncate right row indicators and stop pattern	Values: N = no truncation Y = perform truncation Default: N

→ **Example 1:** This is an example of a PDF417 bar code:

ZPL II CODE	PDF417 BAR CODE
<pre> ^XA ^BY2,3 ^FO10,10^B7N,5,5,,83,N ^FDZebra Technologies Corporation strives to be the expert supplier of innovative solutions to speciality demand labeling and ticketing problems of business and government. We will attract and retain the best people who will understand our customer's needs and provide them with systems, hardware, software, consumables and service offering the best value, high quality, and reliable performance, all delivered in a timely manner. ^FS^XZ </pre>	

→ **Example 2:** This is an example of a PDF417 without and with truncation selected:


PDF417 without Truncation being selected

PDF417 with Truncation being selected



Example 3: This example shows the ^B7 command used with field hex (^FH) characters:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO50,50^BY3,3.0^B7N,8,5,7,21,N ^FH ^FD[>_1E06_1DP12345678_1DQ160 _1D1JUN123456789A2B4C6D8E_1D20LA6-987 _1D21L54321_ZES_1D15KG1155 _1DBSC151208_1D7Q10GT_1E_04^FS ^XZ </pre>	

Comments Noted in this bulleted list:

- If both columns and rows are specified, their product must be less than 928.
- No symbol is printed if the product of columns and rows is greater than 928.
- No symbol is printed if total code-words are greater than the product of columns and rows.
- Serialization is not allowed with this bar code.
- The truncation feature can be used in situations where label damage is not likely. The right row indicators and stop pattern is reduced to a single module bar width. The difference between a non truncated and a truncated bar code is shown in the previous examples.

Special Considerations for ^BY When Using PDF417

When used with ^B7, the parameters for the ^BY command are:

w = module width (in dots)

Values: 2 to 10

Default: 2

r = ratio

Fixed Value: 3 (ratio has no effect on PDF417)

h = height of bars (in dots)

Values: 1 to 32000

Default: 10

PDF417 uses this only when row height is not specified in the ^B7 h parameter.

Special Considerations for ^FD When Using PDF417

The character set sent to the printer with the ^FD command includes the full ASCII set, except for those characters with special meaning to the printer.

See [Zebra Code Page 850 — Latin Character Set on page 1317](#), [^CC ~CC on page 129](#), and [^CT ~CT on page 142](#).

- CR and LF are also valid characters for all ^FD statements. This scheme is used:
 \& = carriage return/line feed
 \\ = backslash (\)
- ^CI13 must be selected to print a backslash (\).

^B8 – EAN-8 Bar Code

The ^B8 command is the shortened version of the EAN-13 bar code. EAN is an acronym for European Article Numbering. Each character in the EAN-8 bar code is composed of four elements: two bars and two spaces.

- ^B8 supports a fixed ratio.
- Field data (^FD) is limited to exactly seven characters. ZPL II automatically pads or truncates on the left with zeros to achieve the required number of characters.
- When using JAN-8 (Japanese Article Numbering), a specialized application of EAN-8, the first two non-zero digits sent to the printer are always 49.




Important • If additional information about the EAN-8 bar code is required, go to www.aimglobal.org.

Format: ^B8o,h,f,g

Parameters	Details
o = orientation	<p>Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees</p> <p>Default: current ^FW value</p>
h = bar code height (in dots)	<p>Values: 1 to 32000 Default: value set by ^BY</p>
f = print interpretation line	<p>Values: N = no Y = yes</p> <p>Default: Y</p>
g = print interpretation line above code	<p>Values: N = no Y = yes</p> <p>Default: N</p>



Example: This is an example of an EAN-8 bar code:

ZPL II CODE					EAN-8 BAR CODE				
<pre> ^XA ^F0100,100^BY3 ^B8N,100,Y,N ^FD1234567^FS ^XZ </pre>									
EAN-8 BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9

^B9 – UPC-E Bar Code

The ^B9 command produces a variation of the UPC symbology used for number system 0. It is a shortened version of the UPC-A bar code, where zeros are suppressed, resulting in codes that require less printing space. The 6 dot/mm, 12 dot/mm, and 24 dot/mm printheads produce the UPC and EAN symbologies at 100 percent of their size. However, an 8 dot/mm printhead produces the UPC and EAN symbologies at a magnification factor of 77 percent.

Each character in a UPC-E bar code is composed of four elements: two bars and two spaces. The ^BY command must be used to specify the width of the narrow bar.

- ^B9 supports a fixed ratio.
- Field data (^FD) is limited to exactly 10 characters, requiring a five-digit manufacturer's code and five-digit product code.
- When using the zero-suppressed versions of UPC, you must enter the full 10-character sequence. ZPL II calculates and prints the shortened version.




Important • If additional information about the UPC-E bar code is required, go to www.aimglobal.org.

Format: ^B9,h,f,g,e

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N
e = print check digit	Values: N = no Y = yes Default: Y



Example: This is an example of a UPC-E bar code:

ZPL II CODE					UPC-E BAR CODE				
<pre> ^XA ^FO150,100^BY3 ^B9N,100,Y,N,Y ^FD1230000045^FS ^XZ </pre>									
UPC-E BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9

Rules for Proper Product Code Numbers

- If the last three digits in the manufacturer's number are 000, 100, or 200, valid product code numbers are 00000 to 00999.
- If the last three digits in the manufacturer's number are 300, 400, 500, 600, 700, 800, or 900, valid product code numbers are 00000 to 00099.
- If the last two digits in the manufacturer's number are 10, 20, 30, 40, 50, 60, 70, 80, or 90, valid product code numbers are 00000 to 00009.
- If the manufacturer's number does not end in zero (0), valid product code numbers are 00005 to 00009.

^BA – Code 93 Bar Code

The ^BA command creates a variable length, continuous symbology. The Code 93 bar code is used in many of the same applications as Code 39. It uses the full 128-character ASCII set. ZPL II, however, does not support ASCII control codes or escape sequences. It uses the substitute characters shown below.

Control Code	ZPL II Substitute
Ctrl \$	&
Ctrl %	'
Ctrl /	(
Ctrl +)

Each character in the Code 93 bar code is composed of six elements: three bars and three spaces. Although invoked differently, the human-readable interpretation line prints as though the control code has been used.

- ^BA supports a fixed print ratio.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.




Important • If additional information about the Code 93 bar code is required, go to www.aimglobal.org.

Format: ^BAo,h,f,g,e

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N
e = print check digit	Values: N = no Y = yes Default: N



Example: This is an example of a Code 93 bar code:

ZPL II CODE		CODE 93 BAR CODE																							
<pre> ^XA ^FO100,75^BY3 ^BAN,100,Y,N,N ^FD12345ABCDE^FS ^XZ </pre>			<p>012345ABCDE0</p>																						
CODE 93 BAR CODE CHARACTERS																									
0	1	2	3	4	5	6	7	8	9																
A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
		-	.	\$	/	+	%	&	'	()											
SPACE																									
<p>□ Denotes an internal start/stop character that must precede and follow every bar code message.</p>																									

Comments All control codes are used in pairs. Code 93 is also capable of encoding the full 128-character ASCII set.

Full ASCII Mode for Code 93

Code 93 can generate the full 128-character ASCII set using paired characters as shown in the following tables.

Table 5 •

ASCII	Code 93	ASCII	Code 93
NUL	'U	SP	Space
SOH	&A	!	(A
STX	&B	"	(B
ETX	&C	#	(C
EOT	&D	\$	(D
ENQ	&E	%	(E
ACK	&F	&	(F
BEL	&G	'	(G
BS	&H	((H
HT	&I)	(I
LF	&J	*	(J
VT	&K	++	++
FF	&L	,	(L
CR	&M	-	-
SO	&N	.	.
SI	&O	/	/
DLE	&P	0	0
DC1	&Q	1	1
DC2	&R	2	2
DC3	&S	3	3
DC4	&T	4	4
NAK	&U	5	5
SYN	&V	6	6
ETB	&W	7	7
CAN	&X	8	8
EM	&Y	9	9
SUB	&Z	:	(Z
ESC	'A	;	'F
FS	'B	<	'G
FS	'C	=	'H
RS	'D	>	'I
US	'E	?	'J

Table 6 •

ASCII	Code 93	ASCII	Code 93
@	'V	'	'W
A	A	a)A
B	B	b)B
C	C	c)C
D	D	d)D
E	E	e)E
F	F	f)F
G	G	g)G
H	H	h)H
I	I	i)I
J	J	j)J
K	K	k)K
L	L	l)L
M	M	m)M
N	N	n)N
O	O	o)O
P	P	p)P
Q	Q	q)Q
R	R	r)R
S	S	s)S
T	T	t)T
U	U	u)U
V	V	v)V
W	W	w)W
X	X	x)X
Y	Y	y)Y
Z	Z	z)Z
['K	{	'P
\	'L		'Q
]	'M	}	'R
^	'N	~	'S
_	'O	DEL	'T

^BB – CODABLOCK Bar Code

The ^BB command produces a two-dimensional, multirow, stacked symbology. It is ideally suited for applications that require large amounts of information.

Depending on the mode selected, the code consists of one to 44 stacked rows. Each row begins and ends with a start and stop pattern.

- CODABLOCK A supports variable print ratios.
- CODABLOCK E and F support only fixed print ratios.



Important • If additional information about the CODABLOCK bar code is required, go to www.aimglobal.org.


Format: ^BB`o,h,s,c,r,m`

Parameters	Details
<code>o</code> = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: N</p>
<code>h</code> = bar code height for individual rows (in dots)	<p>Values: 2 to 32000</p> <p>Default: 8</p> <p>This number, multiplied by the module, equals the height of the individual row in dots.</p>
<code>s</code> = security level	<p>Values:</p> <ul style="list-style-type: none"> N = no Y = yes <p>Default: Y</p> <p>Security level determines whether symbol check-sums are generated and added to the symbol. Check sums are never generated for single-row symbols. This can be turned off only if parameter <code>m</code> is set to A.</p>
<code>c</code> = number of characters per row (data columns)	<p>Values: 2 to 62 characters</p> <p>This is used to encode a CODABLOCK symbol. It gives the you control over the width of the symbol.</p>

Parameters	Details
r = number of rows to encode	<p>Values: for CODABLOCK A: 1 to 22 for CODABLOCK E and F: 2 to 4</p> <ul style="list-style-type: none">• If values for c and r are not specified, a single row is produced.• If a value for r is not specified, and c exceeds the maximum range, a single row equal to the field data length is produced.• If a value for c is not specified, the number of characters per row is derived by dividing the field data by the value of r.• If the s parameter is set to the default of Y, then the checksum characters that are included count as two data characters . <p>For example, if c = 6, r is set to 3 and s is set to N, then up to 18 characters can be used (6 x 3). However, if s is set to Y, then only 16 character can be used.</p> <ul style="list-style-type: none">• If the data field contains primarily numeric data, fewer than the specified rows might be printed. If the field data contains several shift and code-switch characters, more than the specified number of rows might be printed.
m = mode	<p>Values: A, E, F CODABLOCK A uses the Code 39 character set. CODABLOCK F uses the Code 128 character set. CODABLOCK E uses the Code 128 character set and automatically adds FNC1.</p> <p>Default: F</p>



Example: This is an example of a CODABLOCK bar code:

ZPL II CODE	CODABLOCK BAR CODE
<pre> ^XA ^BY2,3 ^FO10,10^BBN,30,,30,44,E ^FDZebra Technologies Corporation strives to be the expert supplier of innovative solutions to speciality demand labeling and ticketing problems of business and government. We will attract and retain the best people who will understand our customer's needs and provide them with systems, hardware, software, consumables and service offering the best value, high quality, and reliable performance, all delivered in a timely manner.^FS ^XZ </pre>	

Special Considerations for the ^BY Command When Using ^BB

The parameters for the ^BYw,r,h command, when used with a ^BB code, are as follows:

w = module width (in dots)

Values: 2 to 10 (CODABLOCK A only)

Default: 2

r = ratio

Fixed Value: 3 (ratio has no effect on CODABLOCK E or F)

h = height of bars (in dots)

Values: 1 to 32,32000

Default: 10

CODABLOCK uses this as the overall symbol height only when the row height is not specified in the ^BB h parameter.

Special Considerations for ^FD Character Set When Using ^BB

The character set sent to the printer depends on the mode selected in parameter m.

CODABLOCK A: CODABLOCK A uses the same character set as Code 39. If any other character is used in the ^FD statement, either no bar code is printed or an error message is printed (if ^CV is active).

CODABLOCK E: The Automatic Mode includes the full ASCII set except for those characters with special meaning to the printer. Function codes or the Code 128 Subset A <nu1> character can be inserted using of the ^FH command.

<fnc1> = 80 hex	<fnc3> = 82 hex
<fnc2> = 81 hex	<fnc4> = 83 hex
<nul> = 84 hex	

For any other character above 84 hex, either no bar code is printed or an error message is printed (if ^CV is active).

CODABLOCK F: CODABLOCK F uses the full ASCII set, except for those characters with special meaning to the printer. Function codes or the Code 128 Subset A <nul> character can be inserted using of the ^FH command.

<fnc1> = 80 hex	<fnc3> = 82 hex
<fnc2> = 81 hex	<fnc4> = 83 hex
<nul> = 84 hex	

^BC – Code 128 Bar Code (Subsets A, B, and C)

The ^BC command creates the Code 128 bar code, a high-density, variable length, continuous, alphanumeric symbology. It was designed for complexly encoded product identification.

Code 128 has three subsets of characters. There are 106 encoded printing characters in each set, and each character can have up to three different meanings, depending on the character subset being used. Each Code 128 character consists of six elements: three bars and three spaces.

- ^BC supports a fixed print ratio.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.




Important • If additional information about the Code 128 bar code is required, go to www.aimglobal.org.

Format: ^BCo,h,f,g,e,m

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: Y (yes) or N (no) Default: Y The interpretation line can be printed in any font by placing the font command before the bar code command.
g = print interpretation line above code	Values: Y (yes) or N (no) Default: N
e = UCC check digit	Values: Y (turns on) or N (turns off) Mod 103 check digit is always there. It cannot be turned on or off. Mod 10 and 103 appear together with e turned on. Default: N

Parameters	Details
m = mode	<p>Values:</p> <p>N = no selected mode</p> <p>U = UCC Case Mode</p> <ul style="list-style-type: none"> • More than 19 digits in ^FD or ^SN are eliminated. • Fewer than 19 digits in ^FD or ^SN add zeros to the right to bring the count to 19. This produces an invalid interpretation line. <p>A = Automatic Mode This analyzes the data sent and automatically determines the best packing method. The full ASCII character set can be used in the ^FD statement — the printer determines when to shift subsets. A string of four or more numeric digits causes an automatic shift to Subset C.</p> <p>D = UCC/EAN Mode (x.11.x and newer firmware) This allows dealing with UCC/EAN with and without chained application identifiers. The code starts in the appropriate subset followed by FNC1 to indicate a UCC/EAN 128 bar code. The printer automatically strips out parentheses and spaces for encoding, but prints them in the human-readable section. The printer automatically determines if a check digit is required, calculate it, and print it. Automatically sizes the human readable.</p> <p>Default: N</p>

➔ **Example 1:** This is an example of a Code 128 bar code:

ZPL II CODE	CODE 128 BAR CODE
<pre> ^XA ^FO100,100^BY3 ^BCN,100,Y,N,N ^FD123456^FS ^XZ </pre>	

Code 128 Subsets

The Code 128 character subsets are referred to as Subset A, Subset B, and Subset C. A subset can be selected in these ways:

- A special Invocation Code can be included in the field data (^FD) string associated with that bar code.
- The desired Start Code can be placed at the beginning of the field data. If no Start Code is entered, Subset B are used.

To change subsets within a bar code, place the Invocation Code at the appropriate points within the field data (^FD) string. The new subset stays in effect until changed with the Invocation Code. For example, in Subset C, >7 in the field data changes the Subset to A.

Table 7 shows the Code 128 Invocation Codes and Start Characters for the three subsets.

Table 7 • Code 128 Invocation Characters

Invocation Code	Decimal Value	Subset A Character	Subset B Character	Subset C Character
><	62			
>0	30	>	>	
>=	94		~	
>1	95	USQ	DEL	
>2	96	FNC 3	FNC 3	
>3	97	FNC 2	FNC 2	
>4	98	SHIFT	SHIFT	
>5	99	CODE C	CODE C	
>6	100	CODE B	FNC 4	CODE B
>7	101	FNC 4	CODE A	CODE A
>8	102	FNC 1	FNC 1	FNC 1
Start Characters				
>9	103	Start Code A	(Numeric Pairs give Alpha/Numerics)	
>:	104	Start Code B	(Normal Alpha/Numeric)	
>;	105	Start Code C	(All numeric (00 - 99))	



Table 8 shows the character sets for Code 128:

Table 8 •


Value	Code A	Code B	Code C	Value	Code A	Code B	Code C
0	SP	SP	00	53	U	U	53
1	!	!	01	54	V	V	54
2	"	"	02	55	W	W	55
3	#	#	03	56	X	X	56
4	\$	\$	04	57	Y	Y	57
5	%	%	05	58	Z	Z	58
6	&	&	06	59	[[59
7	'	'	07	60	\	\	60
8	((08	61]]	61
9))	09	62	^	^	62
10	*	*	10	63	-	-	63
11	+	+	11	64	NUL	.	64
12	,	,	12	65	SOH	a	65
13	-	-	13	66	STX	b	66
14	.	.	14	67	ETX	c	67
15	/	/	15	68	EOT	d	68
16	0	0	16	69	ENQ	e	69
17	1	1	17	70	ACK	f	70
18	2	2	18	71	BEL	g	71
19	3	3	19	72	BS	h	72
20	4	4	20	73	HT	i	73
21	5	5	21	74	LF	j	74
22	6	6	22	75	VT	k	75
23	7	7	23	76	FF	l	76
24	8	8	24	77	CR	m	77
25	9	9	25	78	SO	n	78
26	:	:	26	79	SI	o	79
27	;	;	27	80	DLE	p	80
28	<	<	28	81	DC1	q	81
29	=	=	29	82	DC2	r	82
30	>	>	30	83	DC3	s	83
31	?	?	31	84	DC4	t	84
32	@	@	32	85	NAK	u	85
33	A	A	33	86	SYN	v	86
34	B	B	34	87	ETB	w	87
35	C	C	35	88	CAN	x	88
36	D	D	36	89	EM	y	89
37	E	E	37	90	SUB	z	90
38	F	F	38	91	ESC	{	91
39	G	G	39	92	FS		92
40	H	H	40	93	GS	}	93
41	I	I	41	94	RS	~	94
42	J	J	42	95	US	DEL	95
43	K	K	43	96	FNC3	FNC3	96
44	L	L	44	97	FNC2	FNC2	97
45	M	M	45	98	SHIFT	SHIFT	98
46	N	N	46	99	Code C	Code C	99
47	O	O	47	100	Code B	FNC4	Code B
48	P	P	48	101	FNC4	Code A	Code A
49	Q	Q	49	102	FNC1	FNC1	FNC1
50	R	R	50	103		START (Code A)	
51	S	S	51	104		START (Code B)	
52	T	T	52	105		START (Code C)	



Example 2: Figures A and B are examples of identical bar codes, and Figure C is an example of switching from Subset C to B to A, as follows:



Because Code 128 Subset B is the most commonly used subset, ZPL II defaults to Subset B if no start character is specified in the data string.



How ^BC Works Within a ZPL II Script

^XA – the first command starts the label format.

^FO100,75 – the second command sets the field origin at 100 dots across the x-axis and 75 dots down the y-axis from the upper-left corner.

^BCN,100,Y,N,N – the third command calls for a Code 128 bar code to be printed with no rotation (N) and a height of 100 dots. An interpretation line is printed (Y) below the bar code (N). No UCC check digit is used (N).

^FDCODE128^FS (Figure A) **^FD>:CODE128^FS** (Figure B) – the field data command specifies the content of the bar code.

^XZ – the last command ends the field data and indicates the end of the label.

The interpretation line prints below the code with the UCC check digit turned off.

The **^FD** command for Figure A does not specify any subset, so Subset B is used. In Figure B, the **^FD** command specifically calls Subset B with the **>**: Start Code. Although ZPL II defaults to Code B, it is good practice to include the Invocation Codes in the command.

Code 128 – Subset B is programmed directly as ASCII text, except for values greater than 94 decimal and a few special characters that must be programmed using the invocation codes. Those characters are:

^ > ~





Example 3: Code 128 – Subsets A and C

Code 128, Subsets A and C are programmed in pairs of digits, 00 to 99, in the field data string. For details, see [Table 7 on page 78](#).

In Subset A, each pair of digits results in a single character being encoded in the bar code; in Subset C, characters are printed as entered. Figure E below is an example of Subset A (>9 is the Start Code for Subset A).

Nonintegers programmed as the first character of a digit pair (D2) are ignored. However, nonintegers programmed as the second character of a digit pair (2D) invalidate the entire digit pair, and the pair is ignored. An extra unpaired digit in the field data string just before a code shift is also ignored.

Figure D and Figure E below are examples of Subset C. Notice that the bar codes are identical. In the program code for Figure F, the *D* is ignored and the 2 is paired with the 4.



The UCC/EAN-128 Symbology

The symbology specified for the representation of Application Identifier data is UCC/EAN-128, a variant of Code 128, exclusively reserved to EAN International and the Uniform Code Council (UCC).



Note • It is not intended to be used for data to be scanned at the point of sales in retail outlets.

UCC/EAN-128 offers several advantages. It is one of the most complete, alphanumeric, one-dimensional symbologies available today. The use of three different character sets (A, B and C), facilitates the encoding of the full 128 ASCII character set. Code 128 is one of the most compact linear bar code symbologies. Character set C enables numeric data to be represented in a double density mode. In this mode, two digits are represented by only one symbol character saving valuable space. The code is concatenated. That means that multiple AIs and their fields may be combined into a single bar code. The code is also very reliable. Code 128 symbols use two independent self-checking features which improves printing and scanning reliability.

UCC/EAN-128 bar codes always contain a special non-data character known as function 1 (FNC 1), which follows the start character of the bar code. It enables scanners and processing software to auto-discriminate between UCC/EAN-128 and other bar code symbologies, and subsequently only process relevant data.

The UCC/EAN-128 bar code is made up of a leading quiet zone, a Code 128 start character A, B, or C, a FNC 1 character, Data (Application Identifier plus data field), a symbol check character, a stop character, and a trailing quiet zone.


UCC/EAN, UCC/128 are a couple of ways you'll hear someone refer to the code. This just indicates that the code is structured as dictated by the application identifiers that are used.

SSCC (Serial Shipping Container Code) formatted following the data structure layout for Application Identifier 00. See [Table 9, UCC/EAN Application Identifier on page 85](#). It could be 00 which is the SSCC code. The customer needs to let us know what application identifiers are used for their bar code so we can help them.

There are several ways of writing the code to print the code to Application Identifier '00' structure.

Using N for the mode (m) parameter


→ **Example 1:** This example shows with application identifier 00 structure:

ZPL II CODE	N FOR THE M PARAMETER
<pre> ^XA ^FO90,200^BY4 ^BCN,256,Y,N,Y,N ^FD>;>80012345123451234512^FS ^XZ </pre>	 <p>00123451234512345120</p>

- '>;>8' sets it to subset C, function 1
- '00' is the application identifier followed by '17 characters', the check digit is selected using the 'Y' for the (e) parameter to automatically print the 20th character.
- you are not limited to 19 characters with mode set to N

Using U for the mode (m) parameter

➔ **Example 1:** The example shows the application identifier 00 format:


ZPL II CODE	U FOR THE M PARAMETER
<pre> ^XA ^FO90,200 ^BY4^BC,256,Y,N,,U ^FD0012345123451234512^FS ^XZ </pre>	

UCC Case Mode

- Choosing **U** selects UCC Case mode. You will have exactly 19 characters available in **^FD**.
- Subset C using FNC1 values are automatically selected.
- Check digit is automatically inserted.

Using D for the mode (m) parameter

➔ **Example 1:** This example shows application identifier 00 format ((x.11.x or later):


ZPL II CODE	D FOR THE M PARAMETER
<pre> ^XA ^FO50,200^BCN,150,Y,N,,D ^FD(00)10084423 7449200940^FS ^XZ </pre>	

(0 at end of field data is a bogus character that is inserted as a place holder for the check digit the printer will automatically insert.

- Subset C using FNC1 values are automatically selected.
- Parentheses and spaces can be in the field data. '00' application identifier, followed by 17 characters, followed by bogus check digit place holder.
- Check digit is automatically inserted. The printer will automatically calculate the check digit and put it into the bar code and interpretation line.
- The interpretation line will also show the parentheses and spaces but will strip them out from the actual bar code.

Printing the Interpretation Line


➔ **Example 1:** This example shows printing the interpretation in a different font with firmware x.11.x or later:

ZPL II CODE	INTERPRETATION LINE
<pre> ^XA ^FO50,200 ^A0N,40,30^BCN,150,Y,N,Y ^FD>;>80012345123451234512^FS ^XZ </pre>	

The font command (**^A0N,40,30**) can be added and changed to alter the font and size of the interpretation line.

With firmware version later than x.10.x

- A separate text field needs to be written.
- The interpretation line needs to be turned off.
- **^A0N,50,40** is the font and size selection for the separate text field.
- You have to make sure you enter the correct check digit in the text field.
- Creating a separate text field allows you to format the interpretation line with parentheses and spaces.

ZPL II CODE	FIRMWARE OLDER THAN X.10.X
<pre> ^XA ^FO25,25 ^BCN,150,N,N,Y ^FD>;>80012345123451234512^FS ^FO100,190 ^A0N,50,40 ^FD(00) 1 2345123 451234512 0^FS ^XZ </pre>	

Application Identifiers — UCC/EAN APPLICATION IDENTIFIER

An Application Identifier is a prefix code used to identify the meaning and the format of the data that follows it (data field).

There are AIs for identification, traceability, dates, quantity, measurements, locations, and many other types of information.

For example, the AI for batch number is 10, and the batch number AI is always followed by an alphanumeric batch code not to exceed 20-characters.

The UCC/EAN Application Identifiers provide an open standard that can be used and understood by all companies in the trading chain, regardless of the company that originally issued the codes.

Table 9 • UCC/EAN Application Identifier

Data Content	AI	Plus The Following Data Structure
Serial Shipping Container Code (SSCC)	00	exactly 18 digits
Shipping Container Code	01	exactly 14 digits
Batch Numbers	10	up to 20 alpha numerics
Production Date (YYMMDD)	11	exactly 6 digits
Packaging Date (YYMMDD)	13	exactly 6 digits
Sell By Date (YYMMDD)	15	exactly 6 digits
Expiration Date (YYMMDD)	17	exactly 6 digits
Product Variant	20	exactly 2 digits
Serial Number	21	up to 20 alpha numerics
HIBCC Quantity, Date, Batch and Link	22	up to 29 alpha numerics
Lot Number	23 ^a	up to 19 alpha numerics
Quantity Each	30	
Net Weight (Kilograms)	310 ^b	exactly 6 digits
Length, Meters	311 ^b	exactly 6 digits
Width or Diameter (Meters)	312 ^b	exactly 6 digits
Depths (Meters)	313 ^b	exactly 6 digits
Area (Sq. Meters)	314 ^b	exactly 6 digits
Volume (Liters)	315 ^b	exactly 6 digits
Volume (Cubic Meters)	316 ^b	exactly 6 digits
Net Weight (Pounds)	320 ^b	exactly 6 digits
Customer PO Number	400	up to 29 alpha numerics
Ship To (Deliver To) Location Code using EAN 13 or DUNS Number with leading zeros	410	exactly 13 digits
Bill To (Invoice To) Location Code using EAN 13 or DUNS Number with leading zeros	411	exactly 13 digits
Purchase from	412	exactly 13 digits
Ship To (Deliver To) Postal Code within single postal authority	420	up to 9 alpha numerics
Ship To (Deliver To) Postal Code with 3-digit ISO Country Code Prefix	421	3 digits plus up to 9 alpha numerics
Roll Products - width, length, core diameter, direction and splices	8001	exactly 14 digits
Electronic Serial number for cellular mobile phone	8002	up to 20 alpha numerics

a. Plus one digit for length indication.

b. Plus one digit for decimal point indication.



Note • Table 9 is a partial table showing the application identifiers. For more current and complete information, search the Internet for **UCC Application Identifier**.

For date fields that only need to indicate a year and month, the day field is set to **00**.

Chaining several application identifiers (firmware x.11.x or later)

The FNC1, which is invoked by **>8**, is inserted just before the AI's so that the scanners reading the code sees the FNC1 and knows that an AI follows.



Example 1: This is an example with the mode parameter set to **A** (automatic):

```
^XA
^BY2,2.5,193
^F033,400
^BCN,,N,N,N,A
^FD>;>80204017773003486100008535>8910001>837252^FS
^FT33,625^AEN,0,0^FD(02)04017773003486(10)0008535(91)0001(37)2
52^FS
^XZ
```



Example 2: This is an example with the mode parameter set to **U**:

```
^XA
^BY3,2.5,193
^F033,200
^BCN,,N,N,N,U
^FD>;>80204017773003486>8100008535>8910001>837252^FS
^FT33,455^A0N,30,30^FD(02)04017773003486(10)0008535(91)0001(37)
252^FS
^XZ
```



Example 3: This is an example with the mode parameter set to **D***:

```
^XA
^PON
^LH0,0
^BY2,2.5,145
^F0218,343
^BCB,,Y,N,N,D
^FD(91)0005886>8(10)0000410549>8(99)05^FS
^XZ
```

D* — When trying to print the last Application Identifier with an odd number of characters, a problem existed when printing EAN128 bar codes using Mode D. The problem was fixed in firmware version V60.13.0.6.

^BD – UPS MaxiCode Bar Code

The ^BD command creates a two-dimensional, optically read (not scanned) code. This symbology was developed by UPS (United Parcel Service).

Notice that there are no additional parameters for this code and it does not generate an interpretation line. The ^BY command has no effect on the UPS MaxiCode bar code. However, the ^CV command can be activated.

Format: ^BDm,n,t

Parameters	Details
m = mode	Values: 2 = structured carrier message: numeric postal code (U.S.) 3 = structured carrier message: alphanumeric postal code (non-U.S.) 4 = standard symbol, secretary 5 = full EEC 6 = reader program, secretary Default: 2
n = symbol number	Values: 1 to 8 can be added in a structured document Default: 1
t = total number of symbols	Values: 1 to 8, representing the total number of symbols in this sequence Default: 1



Example: This is an example of UPS MAXICODE - MODE 2 bar code:

ZPL II CODE	UPS MAXICODE - MODE 2
<pre> ^XA ^FO50,50 ^CVY ^BD^FH^FD001840152382802 []>_1E01_1D961Z00004951_1DUPSN_ 1D_06X610_1D159_1D1234567_1D1/1_ 1D_1DY_1D634 ALPHA DR_ 1DPITTSBURGH_1DPA_1E_04^FS ^FO30,300^A0,30,30^FMode2^FS ^XZ </pre>	

Special Considerations for ^FD when Using ^BD

The ^FD statement is divided into two parts: a high priority message (**hpm**) and a low priority message (**lpm**). There are two types of high priority messages. One is for a U.S. Style Postal Code; the other is for a non-U.S. Style Postal Code. The syntax for either of these high priority messages must be exactly as shown or an error message is generated.

Format: ^FD <hpm><lpm>

Parameters	Details
<p><hpm> = high priority message (applicable only in Modes 2 and 3)</p>	<p>Values: 0 to 9, except where noted</p> <p>U.S. Style Postal Code (Mode 2)</p> <p><hpm> = aaabbbccccdddd</p> <p>aaa = three-digit class of service</p> <p>bbb = three-digit country zip code</p> <p>cccc = five-digit zip code</p> <p>dddd = four-digit zip code extension (if none exists, four zeros (0000) must be entered)</p> <p>non-U.S. Style Postal Code (Mode 3)</p> <p><hpm> = aaabbbcccccc</p> <p>aaa = three-digit class of service</p> <p>bbb = three-digit country zip code</p> <p>cccc = six-digit zip code (A through Z or 0 to 9)</p>
<p><lpm> = low priority message (only applicable in Modes 2 and 3)</p>	<p>GS is used to separate fields in a message (0x1D). RS is used to separate format types (0x1E). EOT is the end of transmission characters.</p> <p>Message Header []>RS</p> <p>Transportation Data</p> <p>Format Header01GS96</p> <p>Tracking Number*<tracking number></p> <p>SCAC*GS<SCAC></p> <p>UPS Shipper NumberGS<shipper number></p> <p>Julian Day of PickupGS<day of pickup></p> <p>Shipment ID NumberGS<shipment ID number></p> <p>Package n/xGS<n/x></p> <p>Package WeightGS<weight></p> <p>Address ValidationGS<validation></p> <p>Ship to Street AddressGS<street address></p> <p>Ship to CityGS<city></p> <p>Ship to StateGS<state></p> <p>RSRS</p> <p>End of MessageEOT</p> <p>(* Mandatory Data for UPS)</p>

Comments

- The formatting of <hpm> and <lpm> apply only when using Modes 2 and 3. Mode 4, for example, takes whatever data is defined in the ^FD command and places it in the symbol.
- UPS requires that certain data be present in a defined manner. When formatting MaxiCode data for UPS, always use uppercase characters. When filling in the *fields* in the <lpm> for UPS, follow the data size and types specified in *Guide to Bar Coding with UPS*.
- If you do not choose a mode, the default is Mode 2. If you use non-U.S. Postal Codes, you probably get an error message (invalid character or message too short). When using non-U.S. codes, use Mode 3.
- ZPL II doesn't automatically change your mode based on the zip code format.
- When using special characters, such as GS, RS, or EOT, use the ^FH command to tell ZPL II to use the hexadecimal value following the underscore character (_).

^BE – EAN-13 Bar Code

The ^BE command is similar to the UPC-A bar code. It is widely used throughout Europe and Japan in the retail marketplace.

The EAN-13 bar code has 12 data characters, one more data character than the UPC-A code. An EAN-13 symbol contains the same number of bars as the UPC-A, but encodes a 13th digit into a parity pattern of the left-hand six digits. This 13th digit, in combination with the 12th digit, represents a country code.

- ^BE supports fixed print ratios.
- Field data (^FD) is limited to exactly 12 characters. ZPL II automatically truncates or pads on the left with zeros to achieve the required number of characters.
- When using JAN-13 (Japanese Article Numbering), a specialized application of EAN-13, the first two non-zero digits sent to the printer must be 49.



Note • Use Interleaved 2 of 5 for UCC and EAN 14.




Important • If additional information about the EAN-13 bar code is required, go to www.aimglobal.org.

Format: ^BEo,h,f,g

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N



Example: This is an example of an EAN-13 bar code:

ZPL II CODE	EAN-13 BAR CODE								
<pre>^XA ^FO100,100^BY3 ^BEN,100,Y,N ^FD12345678^FS ^XZ</pre>	 0 000123 456784								
EAN-13 BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9

Comments The EAN-13 bar code uses the Mod 10 check-digit scheme for error checking. For more information on Mod 10, see [Mod 10 Check Digit on page 1349](#).

^BF – MicroPDF417 Bar Code

The ^BF command creates a two-dimensional, multi-row, continuous, stacked symbology identical to PDF417, except it replaces the 17-module-wide start and stop patterns and left/right row indicators with a unique set of 10-module-wide row address patterns. These reduce overall symbol width and allow linear scanning at row heights as low as 2X.

MicroPDF417 is designed for applications with a need for improved area efficiency but without the requirement for PDF417's maximum data capacity. It can be printed only in specific combinations of rows and columns up to a maximum of four data columns by 44 rows.

Field data (^FD) and field hexadecimal (^FH) are limited to:

- 250 7-bit characters
- 150 8-bit characters
- 366 4-bit numeric characters

Format: ^BFo,h,m

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 9999 Default: value set by ^BY or 10 (if no ^BY value exists).
m = mode	Values: 0 to 33 (see Table 10, MicroPDF417 Mode on page 92) Default: 0 (see Table 10)



Example: This is an example of a MicroPDF417 bar code:

ZPL II CODE	MICRO-PDF417 BAR CODE
<pre> ^XA ^FO100,100^BY6 ^BFN,8,3 ^FDABCDEF GHIJKLMNOPQRSTU V^FS ^XZ </pre>	

To encode data into a MicroPDF417 bar code, complete these steps:

1. Determine the type of data to be encoded (for example, ASCII characters, numbers, 8-bit data, or a combination).
2. Determine the maximum amount of data to be encoded within the bar code (for example, number of ASCII characters, quantity of numbers, or quantity of 8-bit data characters).

3. Determine the percentage of check digits that are used within the bar code. The higher the percentage of check digits that are used, the more resistant the bar code is to damage — however, the size of the bar code increases.
4. Use [Table 10](#) with the information gathered from the questions above to select the mode of the bar code.

Table 10 • MicroPDF417 Mode

Mode (M)	Number of Data Columns	Number of Data Rows	% of Cws for EC	Max Alpha Characters	Max Digits
0	1	11	64	6	8
1	1	14	50	12	17
2	1	17	41	18	26
3	1	20	40	22	32
4	1	24	33	30	44
5	1	28	29	38	55
6	2	8	50	14	20
7	2	11	41	24	35
8	2	14	32	36	52
9	2	17	29	46	67
10	2	20	28	56	82
11	2	23	28	64	93
12	2	26	29	72	105
13	3	6	67	10	14
14	3	8	58	18	26
15	3	10	53	26	38
16	3	12	50	34	49
17	3	15	47	46	67
18	3	20	43	66	96
19	3	26	41	90	132
20	3	32	40	114	167
21	3	38	39	138	202
22	3	44	38	162	237
23	4	6	50	22	32
24	4	8	44	34	49
25	4	10	40	46	67
26	4	12	38	58	85
27	4	15	35	76	111
28	4	20	33	106	155
29	4	26	31	142	208
30	4	32	30	178	261
31	4	38	29	214	313
32	4	44	28	250	366
33	4	4	50	14	20

^BI – Industrial 2 of 5 Bar Codes

The ^BI command is a discrete, self-checking, continuous numeric symbology. The Industrial 2 of 5 bar code has been in use the longest of the 2 of 5 family of bar codes. Of that family, the Standard 2 of 5 (^BJ) and Interleaved 2 of 5 (^B2) bar codes are also available in ZPL II.

With Industrial 2 of 5, all of the information is contained in the bars. Two bar widths are employed in this code, the wide bar measuring three times the width of the narrow bar.

- ^BI supports a print ratio of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.




Important • If additional information about the Industrial 2 of 5 bar code, go to www.aimglobal.org.

Format: ^BIo,h,f,g

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N



Example: This is an example of an Industrial 2 of 5 bar code:

ZPL II CODE	INDUSTRIAL 2 OF 5 BAR CODE								
<pre> ^XA ^FO100,100^BY3 ^BIN,150,Y,N ^FD123456^FS ^XZ </pre>	 <p>123456</p>								
INDUSTRIAL 2 OF 5 BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9
Start/Stop (internal)									

^{^BJ} – Standard 2 of 5 Bar Code

The ^{^BJ} command is a discrete, self-checking, continuous numeric symbology.

With Standard 2 of 5, all of the information is contained in the bars. Two bar widths are employed in this code, the wide bar measuring three times the width of the narrow bar.

- ^{^BJ} supports a print ratio of 2.0:1 to 3.0:1.
- Field data (^{^FD}) is limited to the width (or length, if rotated) of the label.



Important • If additional information about the Standard 2 of 5 bar code is required, go to www.aimglobal.org.

Format: ^{^BJ}o,h,f,g

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^{^FW} value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^{^BY}
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N



Example: This is an example of a Standard 2 of 5 bar code:

ZPL II CODE					STANDARD 2 OF 5 BAR CODE				
<code> ^XA ^FO100,100^BY3 ^BJN,150,Y,N ^FD123456^FS ^XZ </code>									
STANDARD 2 OF 5 BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9
Start/Stop (automatic)									

^BK – ANSI Codabar Bar Code

The ANSI Codabar bar code is used in a variety of information processing applications such as libraries, the medical industry, and overnight package delivery companies. This bar code is also known as USD-4 code, NW-7, and 2 of 7 code. It was originally developed for retail price labeling.

Each character in this code is composed of seven elements: four bars and three spaces. Codabar bar codes use two character sets, numeric and control (start and stop) characters.

- ^BK supports a print ratio of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.



Important • If additional information about the ANSI Codabar bar code is required, go to www.aimglobal.org.


Format: ^BKo,e,h,f,g,k,l

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
e = check digit	Fixed Value: N
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N
k = designates a start character	Values: A, B, C, D Default: A
l = designates stop character	Values: A, B, C, D Default: A



Example: This is an example of an ANSI Codabar bar code:

ZPL II CODE										
^XA ^FO100,100^BY3 ^BKN,N,150,Y,N,A,A ^FD123456^FS ^XZ										

ANSI CODABAR BAR CODE										
										
A123456A										

ANSI CODABAR BAR CODE CHARACTERS										
0	1	2	3	4	5	6	7	8	9	
Control Characters										
- : . \$ / +										
Start/Stop Characters										
A B C D										

^BL - LOGMARS Bar Code

The ^BL command is a special application of Code 39 used by the Department of Defense. LOGMARS is an acronym for Logistics Applications of Automated Marking and Reading Symbols.

- ^BL supports a print ratio of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label. Lowercase letters in the ^FD string are converted to the supported uppercase LOGMARS characters.



Important • If additional information about the LOGMARS bar code is required, go to www.aimglobal.org.

Format: ^BLo,h,g

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
g = print interpretation line above code	Values: N = no Y = yes Default: N



Example: This is an example of a LOGMARS bar code:

ZPL II CODE		LOGMARS BAR CODE	
<pre> ^XA ^FO100,75^BY3 ^BLN,100,N ^FD12AB^FS ^XZ </pre>		<p>12ABO</p>	
LOGMARS BAR CODE CHARACTERS			
0 1 2 3 4 5 6 7 8 9 A B C D E F G H I J K L M N O P Q R S T U V W X Y Z - . \$ / + % SPACE			

Comments The LOGMARS bar code produces a *mandatory* check digit using Mod 43 calculations. For further information on the Mod 43 check digit, see [Mod 10 Check Digit on page 1349](#).

^BM – MSI Bar Code

The ^BM command is a pulse-width modulated, continuous, non-self-checking symbology. It is a variant of the Plessey bar code (^BP).

Each character in the MSI bar code is composed of eight elements: four bars and four adjacent spaces.

- ^BM supports a print ratio of 2.0:1 to 3.0:1.
- For the bar code to be valid, field data (^FD) is limited to 1 to 14 digits when parameter e is B, C, or D. ^FD is limited to 1 to 13 digits when parameter e is A, plus a quiet zone.




Important • If additional information about the MSI bar code is required, go to www.aimglobal.org.

Format: ^BMo,e,h,f,g,e2

Parameters	Details
o = orientation	<p>Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees</p> <p>Default: current ^FW value</p>
e = check digit selection	<p>Values: A = no check digits B = 1 Mod 10 C = 2 Mod 10 D = 1 Mod 11 and 1 Mod 10</p> <p>Default: B</p>
h = bar code height (in dots)	<p>Values: 1 to 32000 Default: value set by ^BY</p>
f = print interpretation line	<p>Values: N = no Y = yes</p> <p>Default: Y</p>
g = print interpretation line above code	<p>Values: N = no Y = yes</p> <p>Default: N</p>
e2 = inserts check digit into the interpretation line	<p>Values: N = no Y = yes</p> <p>Default: N</p>



Example: This is an example of a MSI bar code:

ZPL II CODE					MSI BAR CODE				
<pre> ^XA ^FO100,100^BY3 ^BMN,B,100,Y,N,N ^FD123456^FS ^XZ </pre>					 123456				
MSI BAR CODE CHARACTERS									
1	2	3	4	5	6	7	8	9	

^B0 – Aztec Bar Code Parameters

The ^B0 command creates a two-dimensional matrix symbology made up of square modules arranged around a bulls-eye pattern at the center.




Note • The Aztec bar code works with firmware version V60.13.0.11A and V50.13.2 or later.

Format: ^B0a,b,c,d,e,f,g

Parameters	Details
a = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: current ^FW value</p>
b = magnification factor	<p>Values: 1 to 10</p> <p>Default:</p> <ul style="list-style-type: none"> 1 on 150 dpi printers 2 on 200 dpi printers 3 on 300 dpi printers 6 on 600 dpi printers
c = extended channel interpretation code indicator	<p>Values:</p> <ul style="list-style-type: none"> Y = if data contains ECICs N = if data does not contain ECICs. <p>Default: N</p>
d = error control and symbol size/type indicator	<p>Values:</p> <ul style="list-style-type: none"> 0 = default error correction level 01 to 99 = error correction percentage (minimum) 101 to 104 = 1 to 4-layer compact symbol 201 to 232 = 1 to 32-layer full-range symbol 300 = a simple Aztec "Rune" <p>Default: 0</p>
e = menu symbol indicator	<p>Values:</p> <ul style="list-style-type: none"> Y = if this symbol is to be a menu (bar code reader initialization) symbol N = if it is not a menu symbol <p>Default: N</p>
f = number of symbols for structured append	<p>Values: 1 through 26</p> <p>Default: 1</p>
g = optional ID field for structured append	<p>The ID field is a text string with 24-character maximum</p> <p>Default: no ID</p>



Example: This is an example of the ^B0 command:

ZPL II CODE	GENERATED LABEL
<pre data-bbox="428 310 894 571">^XA ^B0R,7,N,0,N,1,0 ^FD 7. This is testing label 7^FS ^XZ</pre>	

^BP – Plessey Bar Code

The ^BP command is a pulse-width modulated, continuous, non-self-checking symbology.

Each character in the Plessey bar code is composed of eight elements: four bars and four adjacent spaces.

- ^BP supports a print ratio of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label.




Important • If additional information about the Plessey bar code is required, go to www.aimglobal.org.

Format: ^BPo,e,h,f,g

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
e = print check digit	Values: N = no Y = yes Default: N
h = bar code height (in dots)	Values: N = no Y = yes Default: N
f = print interpretation line	Values: N = no Y = yes Default: Y
g = print interpretation line above code	Values: N = no Y = yes Default: N



Example: This is an example of a Plessey bar code:

ZPL II CODE					PLESSEY BAR CODE				
<pre> ^XA ^FO100,100^BY3 ^BPN,N,100,Y,N ^FD12345^FS ^XZ </pre>					 12345				
PLESSEY BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9
			A	B	C	D	E	F	

^BQ – QR Code Bar Code

The ^BQ command produces a matrix symbology consisting of an array of nominally square modules arranged in an overall square pattern. A unique pattern at three of the symbol's four corners assists in determining bar code size, position, and inclination.

A wide range of symbol sizes is possible, along with four levels of error correction. User-specified module dimensions provide a wide variety of symbol production techniques.

QR Code Model 1 is the original specification, while QR Code Model 2 is an enhanced form of the symbology. Model 2 provides additional features and can be automatically differentiated from Model 1.

Model 2 is the recommended model and should normally be used.

This bar code is printed using field data specified in a subsequent ^FD string.

Encodable character sets include numeric data, alphanumeric data, 8-bit byte data, and Kanji characters.




Important • If additional information about the QR Code bar code is required, go to www.aimglobal.org.

Format: ^BQa,b,c,d,e

Parameters	Details
a = field orientation	Values: normal (^FW has no effect on rotation)
b = model	Values: 1 (original) and 2 (enhanced – recommended) Default: 2
c = magnification factor	Values: 1 to 10 Default: 1 on 150 dpi printers 2 on 200 dpi printers 3 on 300 dpi printers 6 on 600 dpi printers
d = error correction	Values: H = ultra-high reliability level Q = high reliability level M = standard level L = high density level Default: Q = if empty M = invalid values
e = mask value	Values: 0 - 7 Default: 7



Example 1: This is an example of a QR Code bar code:

ZPL II CODE	QR CODE BAR CODE
<pre> ^XA ^FO100,100 ^BQN,2,10 ^FDMM,AAC-42^FS ^XZ </pre>	

On the pages that follow are specific commands for formatting the ^BQ command with the ^FD statements that contain the information to be coded.

QR Switches (formatted into the ^FD field data)

There are 4 switch fields that are allowed, some with associated parameters and some without. Two of these fields are always present, one is optional, and one's presence depends on the value of another. The switches are always placed in a fixed order. The four switches, in order are:

- Mixed mode <D>iijxx,Optional (note that this switch ends with a comma “,“)
- Error correction level <H, Q, M, L>Mandatory
- Data input <A, M>,Mandatory (note that this switch ends with a comma “,“)
- Character Mode <N, A, Bdddd, K>Conditional (present if data input is M)

Mixed mode (Optional)

= D - allows mixing of different types of character modes in one code.

ii = code No. – a 2 digit number in the range 01 to 16

Value = subtracted from the Nth number of the divided code (must be two digits).

jj = No. of divisions – a 2 digit number in the range 02 to 16

Number of divisions (must be two digits).

xx = parity data – a 2 digit hexadecimal character in the range 00 to FF

Parity data value is obtained by calculating at the input data (the original input data before divided byte-by-byte through the EX-OR operation).

, = the mixed mode switch, when present, is terminated with a comma

Error correction level (Required)

= H, Q, M, or L

H = ultra-high reliability level

Q = high reliability level

M = standard level (default)

L = high density level

Data input (Required)

= A or M followed by a comma

A = Automatic Input (default). Character Mode is not specified.

Data character string JIS8 unit, Shift JIS. When the input mode is Automatic Input, the binary codes of 0x80 to 0x9F and 0xE0 to 0xFF cannot be set.

M = Manual Input. Character Mode must be specified.

Two types of data input mode exist: Automatic (A) and Manual (M). If A is specified, the character mode does not need to be specified. If M is specified, the character mode must be specified.

Character Mode (Required when data input = M)

= N, A, Bxxxx, or K

N = numeric: digits 0 – 9

A = alphanumeric: digits 0 – 9, upper case letters A – Z, space, and \$%*+-./: (45 characters)

Bxxxx = 8-bit byte mode. The 'xxxx' is the number of characters and must be exactly 4 decimal digits.

This handles the 8-bit Latin/Kana character set in accordance with JIS X 0201 (character values 0x00 to 0xFF).

K = Kanji — handles only Kanji characters in accordance with the Shift JIS system based on JIS X 0208. This means that all parameters after the character mode K should be 16-bit characters. If there are any 8-bit characters (such as ASCII code), an error occurs.

The data to be encoded follows immediately after the last switch.

Considerations for ^FD When Using the QR Code:**QR Switches (formatted into the ^FD field data)****mixed mode <D>**

D = allows mixing of different types of character modes in one code.

code No. <01 16>

Value = subtracted from the Nth number of the divided code (must be two digits).

No. of divisions <02 16>

Number of divisions (must be two digits).

parity data <1 byte>

Parity data value is obtained by calculating at the input data (the original input data before divided byte-by-byte through the EX-OR operation).

error correction level <H, Q, M, L>

H = ultra-high reliability level

Q = high reliability level

M = standard level (default)

L = high density level

character Mode <N, A, B, K>

N = numeric

A = alphanumeric

Bxxxx = 8-bit byte mode. This handles the 8-bit Latin/Kana character set in accordance with JIS X 0201 (character values 0x00 to 0xFF).

xxxx = number of data characters is represented by two bytes of BCD code.

K = Kanji — handles only Kanji characters in accordance with the Shift JIS system based on JIS X 0208. This means that all parameters after the character mode *K* should be 16-bit characters. If there are any 8-bit characters (such as ASCII code), an error occurs.

data character string <Data>

Follows character mode or it is the last switch in the ^FD statement.

data input <A, M>

A = Automatic Input (default). Data character string JIS8 unit, Shift JIS. When the input mode is Automatic Input, the binary codes of 0x80 to 0x9F and 0xE0 to 0xFF cannot be set.

M = Manual Input

Two types of data input mode exist: Automatic (A) and Manual (M). If A is specified, the character mode does not need to be specified. If M is specified, the character mode must be specified.

^FD Field Data (Normal Mode)

Automatic Data Input (A) with Switches

^FD


<error correction level>A,

<data character string>

^FS



Example 1: QR Code, normal mode with automatic data input.



1	Q = error correction level
2	A, = automatic setting
3	data string character

Manual Data Input (M) with Switches


^FD

<error correction level>M,

<character mode><data character string>

^FS


➔ **Example 1:** QR Code, normal mode with manual data input:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO20,20^BQ,2,10 ^FDHM,N123456789012345^FS ^XZ </pre>	

1
2
3
4

1	H = error correction level (ultra-high reliability level)
2	M ₁ = input mode (manual input)
3	N = character mode (numeric data)
4	data character string

➔ **Example 2:** QR Code, normal mode with standard reliability and manual data input:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO20,20^BQ,2,10^FDMM,AAC-42^FS ^XZ </pre>	

1
2
3
4

1	M = error correction level (standard-high reliability level)
2	M ₁ = manual input
3	A = alphanumeric data
4	AC-42 = data character string

^FD Field Data (Mixed Mode – requires more switches)

Automatic Data Input (A) with Switches

```

^FD
<D><code No.> <No. of divisions> <parity data>,
<error correction level> A,
<data character string>,
<data character string>,
< : >,
<data character string n**>
^FS
    
```

Manual Data Input (M) with Switches

```

^FD
<code No.> <No. of divisions> <parity data>,
<error correction level> M,
<character mode 1> <data character string 1>,
<character mode 2> <data character string 2>,
< : > < : >,
<character mode n> <data character string n**>
^FS
    
```

n** up to 200 in mixed mode



Example: QR Code, mixed mode with manual data input:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO,20,20^BQ,2,10 ^FDD03048F,LM,N0123456789,A12AABB,B0006qrcode^FS ^XZ </pre>	

<mixed mode identifier>	D	(mixed)
<code No.>	M	(code number)
<No. of divisions>	D	(divisions)
<parity data>	M	(0x0C)
<error correction level>	L	(high-density level)
<input mode>	M	(manual input)
<character mode>	N	(numeric data)

<data character string>		0123456789
<character mode>	A	(alphanumeric data)
<data character string>		12AABB
<character mode>	B	(8-bit byte data)
	0006	(number of bytes)
<data character string>		qrcode



Example: This is an example of QR Code, mixed mode with automatic data input:

```

^XA
^F020,20^BQ,2,10
^FDD03040C,LA,012345678912AABBqrcode^FS
^XZ
    
```

<mixed mode identifier>	D	D (mixed)
<code No.>	M	03 (code number)
<No. of divisions>	D	04 (divisions)
<parity data>	M	0C (0x0C)
<error correction level>	L	L (high-density level)
<input mode>	A	A (automatic input)
<data character string>		012345678912AABBqrcode



For proper functionality, when encoding Kanji characters in ^CI28-30 (Unicode) be sure the JIS.DAT table is loaded on the printer and specified.



Example: This is a Unicode example:

ZPL II CODE	GENERATED LABEL
<pre> AXA^SEE:JIS.DAT^CI28 ^F020,20^BQ,2,10^FDLM, K日月^FS ^XZ </pre>	

^BR – GS1 Databar


(formerly Reduced Space Symbology)

The ^BR command is bar code types for space-constrained identification from EAN International and the Uniform Code Council, Inc.


Format: ^BRa,b,c,d,e,f

Parameters	Details
a = orientation	Values: N = Normal R = Rotated I = Inverted B = Bottom-up Default: R
b = symbology type in the GS1 DataBar family	Values: 1 = GS1 DataBar Omnidirectional 2 = GS1 DataBar Truncated 3 = GS1 DataBar Stacked 4 = GS1 DataBar Stacked Omnidirectional 5 = GS1 DataBar Limited 6 = GS1 DataBar Expanded 7 = UPC-A 8 = UPC-E 9 = EAN-13 10 = EAN-8 11 = UCC/EAN-128 and CC-A/B 12 = UCC/EAN-128 and CC-C Default: 1
c = magnification factor	Values: 1 to 10 Default: 24 dot = 6, 12 dot is 3, 8 dot and lower is 2 12 dot = 6, > 8 dot is 3, 8 dot and less is 2
d = separator height	Values: 1 or 2 Default: 1
e = bar code height	The bar code height only affects the linear portion of the bar code. Only UCC/EAN and CC-A/B/C. Values: 1 to 32000 dots Default: 25
f = the segment width (GS1 DataBar Expanded only)	Values: 2 to 22, even numbers only, in segments per line Default: 22

➔ **Example 1:** This is an example of Symbology Type 7 - UPC-A:

ZPL II CODE	GENERATED LABEL
<pre>^XA ^FO10,10^BRN,7,5,2,100 ^FD12345678901 this is composite info^FS ^XZ</pre>	

➔ **Example 2:** This is an example of Symbology Type 1 - GS1 DataBar Omnidirectional:

ZPL II CODE	GENERATED LABEL
<pre>^XA ^FO10,10^BRN,1,5,2,100 ^FD12345678901 this is composite info^FS ^XZ</pre>	

^BS – UPC/EAN Extensions

The ^BS command is the two-digit and five-digit add-on used primarily by publishers to create bar codes for ISBNs (International Standard Book Numbers). These extensions are handled as separate bar codes.

The ^BS command is designed to be used with the UPC-A bar code (^BU) and the UPC-E bar code (^B9).

- ^BS supports a fixed print ratio.
- Field data (^FD) is limited to exactly two or five characters. ZPL II automatically truncates or pads on the left with zeros to achieve the required number of characters.




Important • If additional information about the UPC/EAN bar code is required, go to www.aimglobal.org.


Format: ^BS`o,h,f,g`

Parameters	Details
<code>o</code> = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
<code>h</code> = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
<code>f</code> = print interpretation line	Values: N = no Y = yes Default: Y
<code>g</code> = print interpretation line above code	Values: N = no Y = yes Default: Y

➔ **Example 1:** This is an example of a UPC/EAN Two-digit bar code:

ZPL II CODE	UPC/EAN 2-DIGIT BAR CODE								
<pre> ^XA ^FO100,100^BY3 ^BSN,100,Y,N ^FD12^FS ^XZ </pre>									
UPC/EAN 2-DIGIT BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9

➔ **Example 2:** This is an example of a UPC/EAN Five-digit bar code:

ZPL II CODE	UPC/EAN 5-DIGIT BAR CODE								
<pre> ^XA ^FO100,100^BY3 ^BSN,100,Y,N ^FD12345^FS ^XZ </pre>									
UPC/EAN 5-DIGIT BAR CODE CHARACTERS									
0	1	2	3	4	5	6	7	8	9

Care should be taken in positioning the UPC/EAN extension with respect to the UPC-A or UPC-E code to ensure the resulting composite code is within the UPC specification. For UPC codes, with a module width of **2** (default), the field origin offsets for the extension are:

➔ **Example 3:** This is an example of a UPC-A:

	Supplement Origin X - Offset	Adjustment Y - Offset
Normal	209 Dots	21 Dots
Rotated	0	209 Dots


This is an example of a UPC-E:

	Supplement Origin X - Offset	Adjustment Y - Offset
Normal	122 Dots	21 Dots
Rotated	0	122 Dots

Additionally, the bar code height for the extension should be 27 dots (0.135 inches) shorter than that of the primary code. A primary UPC code height of 183 dots (0.900 inches) requires an extension height of 155 dots (0.765 inches).



Example 4: This example illustrates how to create a normal UPC-A bar code for the value 7000002198 with an extension equal to 04414:

ZPL II CODE	UPC-A BAR CODE WITH EXTENSION
<pre> ^XA ^FO100,100^BY3 ^BUN,137 ^FD07000002198^FS ^FO400,121 ^BSN,117 ^FD04414^FS ^XZ </pre>	

^BT – TLC39 Bar Code

The ^BT bar code is the standard for the TCIF can tag telecommunications equipment.

The TCIF CLEI code, which is the MicroPDF417 bar code, is always four columns. The firmware must determine what mode to use based on the number of characters to be encoded.

Format: ^BT*o*,*w1*,*r1*,*h1*,*w2*,*h2*


Parameters	Details
o = orientation	Values: N = normal R = rotated I = inverted B = bottom up
w1 = width of the Code 39 bar code	Values: <i>(in dots):</i> 1 to 10 Default: <i>(600 dpi printers):</i> 4 Default: <i>(200- and 300 dpi printer):</i> 2
r1 = wide to narrow bar width ratio the Code 39 bar code	Values: 2.0 to 3.0(increments of 0.1) Default: 2.0
h1 = height of the Code 39 bar code	Values: <i>(in dots):</i> 1 to 9999 Default: <i>(600 dpi printer):</i> 120 Default: <i>(300 dpi printer):</i> 60 Default: <i>(200 dpi printer):</i> 40
h2 = row height of the MicroPDF417 bar code	Values: <i>(in dots):</i> 1 to 255 Default: <i>(600 dpi printer):</i> 8 Default: <i>(200- and 300 dpi printers):</i> 4
w2 = narrow bar width of the MicroPDF417 bar code	Values: <i>(in dots):</i> 1 to 10 Default: <i>(600 dpi printer):</i> 4 Default: <i>(200- and 300 dpi printers):</i> 2



Example: TLC39 Bar Code

This is an example on how to print TLC39 bar code. The callouts identify the key components and are followed by a detailed description below:

Use the command defaults to get results that are in compliance with TCIF industry standards; regardless of printhead density.



1	<p>ECI Number. If the seventh character is not a comma, only Code 39 prints. This means if more than 6 digits are present, Code 39 prints for the first six digits (and no Micro-PDF symbol is printed).</p> <ul style="list-style-type: none"> • Must be 6 digits. • Firmware generates invalid character error if the firmware sees anything but 6 digits. • This number is not padded.
2	<p>Serial number. The serial number can contain up to 25 characters and is variable length. The serial number is stored in the Micro-PDF symbol. If a comma follows the serial number, then additional data is used below.</p> <ul style="list-style-type: none"> • If present, must be alphanumeric (letters and numbers, no punctuation). <p>This value is used if a comma follows the ECI number.</p>
3	<p>Additional data. If present, it is used for things such as a country code. Data cannot exceed 150 bytes. This includes serial number commas.</p> <ul style="list-style-type: none"> • Additional data is stored in the Micro-PDF symbol and appended after the serial number. A comma must exist between each maximum of 25 characters in the additional fields. • Additional data fields can contain up to 25 alphanumeric characters per field. <p>The result is:</p>

ZPL II CODE
<pre>^XA^FO100, 100^BT^FD123456, ABCD12345678901234, 5551212, 888999 ^FS^XZ</pre>



^BU – UPC-A Bar Code

The ^BU command produces a fixed length, numeric symbology. It is primarily used in the retail industry for labeling packages. The UPC-A bar code has 11 data characters. The 6 dot/mm, 12 dot/mm, and 24 dot/mm printheads produce the UPC-A bar code (UPC/EAN symbologies) at 100 percent size. However, an 8 dot/mm printhead produces the UPC/EAN symbologies at a magnification factor of 77 percent.

- ^BU supports a fixed print ratio.
- Field data (^FD) is limited to exactly 11 characters. ZPL II automatically truncates or pads on the left with zeros to achieve required number of characters.



Important • If additional information about the UPC-A bar code is required, go to www.aimglobal.org.

Format: ^BUo,h,f,g,e

Parameters	Details
o = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: current ^FW value</p>
h = bar code height (in dots)	<p>Values: 1 to 9999</p> <p>Default: value set by ^BY</p>
f = print interpretation line	<p>Values:</p> <ul style="list-style-type: none"> N = no Y = yes <p>Default: Y</p>
g = print interpretation line above code	<p>Values:</p> <ul style="list-style-type: none"> N = no Y = yes <p>Default: N</p>
e = print check digit	<p>Values:</p> <ul style="list-style-type: none"> N = no Y = yes <p>Default: Y</p>

The font style of the interpretation line depends on the modulus (width of narrow bar) selected in ^BY:




Note • Zero is not allowed.

- **6 dot/mm printer:** a modulus of 2 dots or greater prints with an OCR-B interpretation line; a modulus of 1 dot prints font A.
- **8 dot/mm printer:** a modulus of 3 dots or greater prints with an OCR-B interpretation line; a modulus of 1 or 2 dots prints font A.

- **12 dot/mm printer:** a modulus of 5 dots or greater prints with an OCR-B interpretation line; a modulus of 1, 2, 3, or 4 dots prints font A.
- **24 dot/mm printer:** a modulus of 9 dots or greater prints with an OCR-B interpretation line; a modulus of 1 to 8 dots prints font A.



Example: This is an example of a UPC-A bar code with extension:

ZPL II CODE	UPC-A BAR CODE WITH EXTENSION
<pre>^XA ^FO100,100^BY3 ^BUN,137 ^FD07000002198^FS ^FO400,121 ^BSN,117 ^FD04414^FS ^XZ</pre>	

Comments The UPC-A bar code uses the Mod 10 check digit scheme for error checking. For further information on Mod 10, see [Mod 10 Check Digit on page 1349](#).

^BX – Data Matrix Bar Code

The ^BX command creates a two-dimensional matrix symbology made up of square modules arranged within a perimeter finder pattern.

Format: ^BXo,h,s,c,r,f,g,a

Parameters	Details
o = orientation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees <p>Default: current ^FW value</p>
h = dimensional height of individual symbol elements	<p>Values: 1 to the width of the label</p> <p>The individual elements are square — this parameter specifies both module and row height. If this parameter is zero (or not given), the h parameter (bar height) in ^BY is used as the approximate symbol height.</p>
s = quality level	<p>Values: 0, 50, 80, 100, 140, 200</p> <p>Default: 0</p> <p><i>Quality</i> refers to the amount of data that is added to the symbol for error correction. The AIM specification refers to it as the ECC value. ECC 50, ECC 80, ECC 100, and ECC 140 use convolution encoding; ECC 200 uses Reed-Solomon encoding. For new applications, ECC 200 is recommended. ECC 000-140 should be used only in closed applications where a single party controls both the production and reading of the symbols and is responsible for overall system performance.</p>
c = columns to encode	<p>Values: 9 to 49</p> <p>Odd values only for quality 0 to 140 (10 to 144); even values only for quality 200. Odd values only for quality 0 to 140 (10 to 144); even values only for quality 200. The number of rows and columns in the symbol is automatically determined. You might want to force the number of rows and columns to a larger value to achieve uniform symbol size. In the current implementation, quality 0 to 140 symbols are square, so the larger of the rows or columns supplied are used to force a symbol to that size. If you attempt to force the data into too small of a symbol, no symbol is printed. If a value greater than 49 is entered, the rows or columns value is set to zero and the size is determined normally. If an even value is entered, it generates INVALID-P (invalid parameter). If a value less than 9 but not 0, or if the data is too large for the forced size, no symbol prints; if ^CV is active, INVALID-L prints.</p>
r = rows to encode	<p>Values: 9 to 49</p>


Parameters	Details
<p>f = format ID (0 to 6) – not used with quality set at 200</p>	<p>Values:</p> <ul style="list-style-type: none"> 1 = field data is numeric + space (0..9,") – No \&" 2 = field data is uppercase alphanumeric + space (A..Z,") – No \&" 3 = field data is uppercase alphanumeric + space, period, comma, dash, and slash (0..9,A..Z,".-/") 4 = field data is upper-case alphanumeric + space (0..9,A..Z,") – no \&" 5 = field data is full 128 ASCII 7-bit set 6 = field data is full 256 ISO 8-bit set <p>Default: 6</p>
<p>g = escape sequence control character</p>	<p>Values: any character Default: ~ (tilde)</p> <p>This parameter is used only if quality 200 is specified. It is the escape character for embedding special control sequences within the field data.</p> <p>Important • A value must always be specified when using the escape sequence control character. If no value is entered, the command is ignored.</p> <p>The g parameter will continue to be underscore (_) for anyone with firmware version: V60.13.0.12, V60.13.0.12Z, V60.13.0.12B, V60.13.0.12ZB, or later.</p>
<p>a = aspect ratio</p> <div style="border: 1px solid blue; padding: 2px; width: fit-content; margin: 10px 0;">.16↑</div> <p>The a parameter is only supported in V60.16.5Z and V53.16.5Z or later.</p>	<p>Values:</p> <ul style="list-style-type: none"> 1 = square 2 = rectangular <p>Default: 1</p>

Table 11 •


ECC LEVEL	ID = 1	ID = 2	ID = 3	ID = 4	ID = 5	ID = 6
0	596	452	394	413	310	271
50	457	333	291	305	228	200
80	402	293	256	268	201	176
100	300	218	190	200	150	131
140	144	105	91	96	72	63

Maximum Field Sizes

➔ **Example 1:** This is an example of a square Data Matrix bar code:

ZPL II CODE	DATA MATRIX BAR CODE
<pre> ^XA ^FO100,100 ^BXN,10,200 ^FDZEBRA TECHNOLOGIES CORPORATION 333 CORPORATE WOODS PARKWAY VERNON HILLS, IL 60061-3109^FS ^XZ </pre>	

➔ **Example 2:** This is an example of a rectangle Data Matrix bar code:

ZPL II CODE	DATA MATRIX BAR CODE
<pre> ^XA ^FO100,100 ^BXN,10,200,,,,,2 ^FDZEBRA TECHNOLOGIES CORPORATION 333 CORPORATE WOODS PARKWAY ^FS ^XZ </pre>	

Effects of ^BY on ^BX

w = module width (no effect)

r = ratio (no effect)

h = height of symbol

If the dimensions of individual symbol elements are not specified in the ^BY command, the height of symbol value is divided by the required rows/columns, rounded, limited to a minimum value of one, and used as the dimensions of individual symbol elements.

Field Data (^FD) for ^BX

Quality 000 to 140

- The `&` and `||` can be used to insert carriage returns, line feeds, and the backslash, similar to the PDF417. Other characters in the control character range can be inserted only by using ^FH. Field data is limited to 596 characters for quality 0 to 140. Excess field data causes no symbol to print; if ^CV is active, INVALID-L prints. The field data must correspond to a user-specified format ID or no symbol prints; if ^CV is active, INVALID-C prints.
- The maximum field sizes for quality 0 to 140 symbols are shown in the table in the **g** parameter.

Quality 200

- If more than 3072 bytes are supplied as field data, it is truncated to 3072 bytes. This limits the maximum size of a numeric Data Matrix symbol to less than the 3116 numeric characters that the specification would allow. The maximum alphanumeric capacity is 2335 and the maximum 8-bit byte capacity is 1556.

- If **^FH** is used, field hexadecimal processing takes place before the escape sequence processing described below.
- The underscore is the default escape sequence control character for quality 200 field data. A different escape sequence control character can be selected by using parameter **g** in the **^BX** command.

The information that follows applies to firmware version: V60.13.0.12, V60.13.0.12Z, V60.13.0.12B, V60.13.0.12ZB, or later. The input string escape sequences can be embedded in quality 200 field data using the ASCII 95 underscore character (**_**) or the character entered in parameter **g**:

- **_X** is the shift character for control characters (e.g., **_@=NUL, _G=BEL, _0 is PAD**)
- **_1** to **_3** for FNC characters 1 to 3 (explicit FNC4, upper shift, is not allowed)
- FNC2 (Structured Append) must be followed by nine digits, composed of three-digit numbers with values between 1 and 254, that represent the symbol sequence and file identifier (for example, symbol 3 of 7 with file ID 1001 is represented by **_2214001001**)
- **5NNN** is code page NNN where NNN is a three-digit code page value (for example, Code Page 9 is represented by **_5009**)
- **_dNNN** creates ASCII decimal value NNN for a code word (must be three digits)
- **_** in data is encoded by **__** (two underscores)

The information that follows applies to all other versions of firmware. The input string escape sequences can be embedded in quality 200 field data using the ASCII 7E tilde character (**~**) or the character entered in parameter **g**:

- **~X** is the shift character for control characters (e.g., **~@=NUL, ~G=BEL, ~0 is PAD**)
- **~1** to **~3** for FNC characters 1 to 3 (explicit FNC4, upper shift, is not allowed)
- FNC2 (Structured Append) must be followed by nine digits, composed of three-digit numbers with values between 1 and 254, that represent the symbol sequence and file identifier (for example, symbol 3 of 7 with file ID 1001 is represented by **~2214001001**)
- **5NNN** is code page NNN where NNN is a three-digit code page value (for example, Code Page 9 is represented by **~5009**)
- **~dNNN** creates ASCII decimal value NNN for a code word (must be three digits)
- **~** in data is encoded by a **~** (tilde)

^BY – Bar Code Field Default

The ^BY command is used to change the default values for the module width (in dots), the wide bar to narrow bar width ratio and the bar code height (in dots). It can be used as often as necessary within a label format.

Format: ^BYw,r,h

Parameters	Details
w = module width (in dots)	Values: 1 to 10 Initial Value at Power Up: 2
r = wide bar to narrow bar width ratio	Values: 2.0 to 3.0, in 0.1 increments This parameter has no effect on fixed-ratio bar codes. Default: 3.0
h = bar code height (in dots)	Initial Value at Power Up: 10

For parameter **r**, the actual ratio generated is a function of the number of dots in parameter **w**, module width. See [Table 12 on page 126](#). Module width and height (**w** and **h**) can be changed at anytime with the ^BY command, regardless of the symbology selected.



Example: Set module width (**w**) to 9 and the ratio (**r**) to 2.4. The width of the narrow bar is 9 dots wide and the wide bar is 9 by 2.4, or 21.6 dots. However, since the printer rounds out to the nearest dot, the wide bar is actually printed at 22 dots. This produces a bar code with a ratio of 2.44 (22 divided by 9). This ratio is as close to 2.4 as possible, since only full dots are printed.

Table 12 • Shows Module Width Ratios in Dots

Ratio Selected (r)	Module Width in Dots (w)									
	1	2	3	4	5	6	7	8	9	10
2.0	2:1	2:1	2:1	2:1	2:1	2:1	2:1	2:1	2:1	2:1
2.1	2:1	2:1	2:1	2:1	2:1	2:1	2:1	2:1	2:1	2.1:1
2.2	2:1	2:1	2:1	2:1	2.2:1	2.16:1	2.1:1	2.12:1	2.1:1	2.2:1
2.3	2:1	2:1	2.3:1	2.25:1	2.2:1	2.16:1	2.28:1	2.25:1	2.2:1	2.3:1
2.4	2:1	2:1	2.3:1	2.25:1	2.4:1	2.3:1	2.28:1	2.37:1	2.3:1	2.4:1
2.5	2:1	2.5:1	2.3:1	2.5:1	2.4:1	2.5:1	2.4:1	2.5:1	2.4:1	2.5:1
2.6	2:1	2.5:1	2.3:1	2.5:1	2.6:1	2.5:1	2.57:1	2.5:1	2.5:1	2.6:1
2.7	2:1	2.5:1	2.6:1	2.5:1	2.6:1	2.6:1	2.57:1	2.65:1	2.6:1	2.7:1
2.8	2:1	2.5:1	2.6:1	2.75:1	2.8:1	2.6:1	2.7:1	2.75:1	2.7:1	2.8:1
2.9	2:1	2.5:1	2.6:1	2.75:1	2.8:1	2.8:1	2.85:1	2.87:1	2.8:1	2.9:1
3.0	3:1	3:1	3:1	3:1	3:1	3:1	3:1	3:1	3:1	3:1

Comments Once a ^BY command is entered into a label format, it stays in effect until another ^BY command is encountered.

^BZ – POSTAL Bar Code

The POSTAL bar code is used to automate the handling of mail. POSTAL codes use a series of tall and short bars to represent the digits.

- ^BZ supports a print ratio of 2.0:1 to 3.0:1.
- Field data (^FD) is limited to the width (or length, if rotated) of the label and by the bar code specification.


Format: ^BZo,h,f,g,t




Important • If additional information about the POSTAL and PLANET bar code is required, go to www.aimglobal.org, or contact the United States Postal Service <http://pe.usps.gov>. If additional information about the INTELLIGENT MAIL bar code is required, see: <http://ribbs.usps.gov/OneCodeSolution>.

Parameters	Details
o = orientation	Values: N = normal R = rotated 90 degrees (clockwise) I = inverted 180 degrees B = read from bottom up, 270 degrees Default: current ^FW value
h = bar code height (in dots)	Values: 1 to 32000 Default: value set by ^BY
f = print interpretation line	Values: N = no Y = yes Default: N
g = print interpretation line above code	Values: N = no Y = yes Default: N
t = Postal code type	Values: 0 = Postnet bar code 1 = Plant Bar Code 2 = Reserved 3 = USPS Intelligent Mail bar code Default: 0

➔ **Example 1:** This is an example of a POSTNET bar code:

ZPL II CODE	POSTNET BAR CODE
<pre> ^XA ^FO100,100^BY3 ^BZN,40,Y,N ^FD12345^FS ^XZ </pre>	 12345
POSTNET BAR CODE CHARACTERS	
0	1
2	3
4	5
6	7
8	9

➔ **Example 2:** This is an example of a USPS Intelligent Mail bar code:

ZPL II CODE	USPS INTELLIGENT MAIL BAR CODE
<pre> ^XA ^FO100,040^BZ,40,,,3 ^FD00123123456123456789^FS ^XZ </pre>	

^CC ~CC – Change Caret

The ^CC command is used to change the format command prefix. The default prefix is the caret (^).

Format: ^CCx or ~CCx

Parameters	Details
x = caret character change	Values: any ASCII character Default: a parameter is required. If a parameter is not entered, the next character received is the new prefix character.



Example: This is an example of how to change the format prefix to / from a ::

```
^XA
```

```
^CC/
```

```
/XZ
```

The forward slash (/) is set at the new prefix. Note the /XZ ending tag uses the new designated prefix character (/).



Example: This is an example of how to change the format prefix from ~ to a /:

```
~CC/
```

```
/XA/JUS/XZ
```

^CD ~CD – Change Delimiter

The ^CD and ~CD commands are used to change the delimiter character. This character is used to separate parameter values associated with several ZPL II commands. The default delimiter is a comma (.).

Format: ^CDa or ~CDa

Parameters	Details
a = delimiter character change	<p>Values: any ASCII character</p> <p>Default: a parameter is required. If a parameter is not entered, the next character received is the new prefix character.</p>



Example: This shows how to change the character delimiter to a semi-colon (;):

```

^XA
^F010,10
^GB10,10,3
^XZ
^XA
^CD;
^F010;10
^GB10;10;3
^XZ

```

- To save, the JUS command is required. Here is an example using JUS:

```

~CD;
^XA^JUS^XZ

```

^{^CF} – Change Alphanumeric Default Font

The ^{^CF} command sets the default font used in your printer. You can use the ^{^CF} command to simplify your programs.

Format: ^{^CF}f,h,w

Parameters	Details
f = specified default font	Values: A through Z and 0 to 9 Initial Value at Power Up: A
h = individual character height (in dots)	Values: 0 to 32000 Initial Value at Power Up: 9
w = individual character width (in dots)	Values: 0 to 32000 Initial Value at Power Up: 5 or last permanent saved value

Parameter **f** specifies the default font for every alphanumeric field. Parameter **h** is the default height for every alphanumeric field, and parameter **w** is the default width value for every alphanumeric field.

The default alphanumeric font is A. If you do not change the alphanumeric default font and do not use any alphanumeric field command (^{^AF}) or enter an invalid font value, any data you specify prints in font A.

Defining only the height or width forces the magnification to be proportional to the parameter defined. If neither value is defined, the last ^{^CF} values given or the default ^{^CF} values for height and width are used.



Example: This is an example of ^{^CF} code and the result of the code:

ZPL II CODE	GENERATED LABEL
^{^X} A ^{^CF} 0,89 ^{^FO} 20,50 ^{^F} DA GUIDE TO ^{^FS} ^{^FO} 20,150 ^{^F} DTHE ZPL II ^{^FS} ^{^FO} 20,250 ^{^F} DPROGRAMMING ^{^FS} ^{^FO} 20,350 ^{^F} DLANGUAGE ^{^FS} ^{^X} Z	<div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>A GUIDE TO THE ZPL II PROGRAMMING LANGUAGE</p> </div>

Comments Any font in the printer, including downloaded fonts, EPROM stored fonts, and fonts A through Z and 0 to 9, can also be selected with ^{^CW}.

^CI – Change International Font/Encoding

Zebra printers can print fonts using international character sets: U.S.A.1, U.S.A.2, UK, Holland, Denmark/Norway, Sweden/Finland, Germany, France 1, France 2, Italy, Spain, and several other sets, including the Unicode character set.

The ^CI command enables you to call up the international character set you want to use for printing. You can mix character sets on a label.

A character within a font can be remapped to a different numerical position.



In x.14 version of firmware and later, this command allows character remapping when parameter **a** = 0-13.

Format: ^CIa,s1,d1,s2,d2,...

Parameters	Details
<p>a = desired character set</p>	<p>Accepted values are 0 - 12 are Zebra Code Page 850 with specific character replacements. For details, see International Character Sets on page 134 and/or Zebra Code Page 850 — Latin Character Set on page 1317.</p> <p>Values:</p> <ul style="list-style-type: none"> 0 = Single Byte Encoding - U.S.A. 1 Character Set 1 = Single Byte Encoding - U.S.A. 2 Character Set 2 = Single Byte Encoding - U.K. Character Set 3 = Single Byte Encoding - Holland Character Set 4 = Single Byte Encoding - Denmark/Norway Character Set 5 = Single Byte Encoding - Sweden/Finland Character Set 6 = Single Byte Encoding - Germany Character Set 7 = Single Byte Encoding - France 1 Character Set 8 = Single Byte Encoding - France 2 Character Set 9 = Single Byte Encoding - Italy Character Set 10 = Single Byte Encoding - Spain Character Set <p><i>(parameter details continued on next page)</i></p>
<p> Note • These parameters are only valid when parameter a = 1 - 13</p>	<ul style="list-style-type: none"> c. The encoding is controlled by the conversion table (*.DAT). The correct table must be present for the conversion to function. The table generated by ZTools™ is the TrueType fonts internal encoding (Unicode). d. Shift-JIS encoding converts Shift-JIS to JIS and then looks up the JIS conversion in JIS.DAT. This table must be present for Shift-JIS to function. e. Supports ASCII transparency for Asian encodings. 7F and less are treated as single byte characters. 80 to FE is treated as the first byte of a 2 byte character 8000 to FEFF in the encoding table for Unicode. f. The ^CI17 command has been deprecated, along with the ^F8 and ^F16 commands that are required for the ^CI17 command to function. The recommended replacement is the ^CI28-30 commands.

Parameters	Details
<p>a = desired character set (continued)</p> <p>.14† Values 28 to 30 are only supported in firmware version V60.14.x, V50.14.x, or later.</p> <p>.16† Values 31 to 36 are only supported in firmware version x.16.x or later.</p>	<p>11 = Single Byte Encoding - Miscellaneous Character Set 12 = Single Byte Encoding - Japan (ASCII with Yen symbol) Character Set 13 = Zebra Code Page 850 (see page 1317) 14 = Double Byte Asian Encodings ^c 15 = Shift-JIS ^d 16 = EUC-JP and EUC-CN ^c 17 = Deprecated - UCS-2 Big Endian ^f 18 to 23 = Reserved 24 = Single Byte Asian Encodings ^c 25 = Reserved 26 = Multibyte Asian Encodings with ASCII Transparency ^c and ^e 27 = Zebra Code Page 1252 (see page 1322) 28 = Unicode (UTF-8 encoding) - Unicode Character Set 29 = Unicode (UTF-16 Big-Endian encoding) - Unicode Character Set 30 = Unicode (UTF-16 Little-Endian encoding) - Unicode Character Set 31 = Zebra Code Page 1250 (see page 1320) is supported for scalable fonts, such as Font 0, or a downloaded TrueType font. Bitmapped fonts (including fonts A-H) do not fully support Zebra Code Page 1250. This value is supported only on Zebra G-Series™ printers. 33 = Code Page 1251 34 = Code page 1253 35 = Code Page 1254 36 = Code Page 1255</p> <p>Initial Value at Power Up: 0</p>
s1 = source 1 (character output image)	Values: decimals 0 to 255
d1 = destination 1 (character input)	Values: decimals 0 to 255
s2 = source 2 (character output image)	Values: decimals 0 to 255
d2 = destination 2 (character input)	Values: decimals 0 to 255

- c.** The encoding is controlled by the conversion table (***.DAT**). The correct table must be present for the conversion to function. The table generated by ZTools™ is the TrueType fonts internal encoding (Unicode).
- d.** Shift-JIS encoding converts Shift-JIS to JIS and then looks up the JIS conversion in **JIS.DAT**. This table must be present for Shift-JIS to function.
- e.** Supports ASCII transparency for Asian encodings. 7F and less are treated as single byte characters. 80 to FE is treated as the first byte of a 2 byte character 8000 to FEFF in the encoding table for Unicode.
- f.** The **^CI17** command has been deprecated, along with the **^F8** and **^F16** commands that are required for the **^CI17** command to function. The recommended replacement is the **^CI28-30** commands.

Parameters	Details
... = continuation of pattern	Up to 256 source and destination pairs can be entered in this command.

- c. The encoding is controlled by the conversion table (* .DAT). The correct table must be present for the conversion to function. The table generated by ZTools™ is the TrueType fonts internal encoding (Unicode).
- d. Shift-JIS encoding converts Shift-JIS to JIS and then looks up the JIS conversion in **JIS .DAT**. This table must be present for Shift-JIS to function.
- e. Supports ASCII transparency for Asian encodings. 7F and less are treated as single byte characters. 80 to FE is treated as the first byte of a 2 byte character 8000 to FEFF in the encoding table for Unicode.
- f. The **^CI17** command has been deprecated, along with the **^F8** and **^F16** commands that are required for the **^CI17** command to function. The recommended replacement is the **^CI28-30** commands.



80 to FF could mean quad byte in GB18030. The **^CI26** command can also be used to support the GB 18030 and Big5 HKSCS encodings. The GB 18030 uses the **GB18030 .DAT** encoding table and BIG5 HKSCS uses the **BIG5HK .DAT** encoding table.



The **^CI17** command has been deprecated, along with the **^F8** and **^F16** commands that are required for the **^CI17** command to function. The recommended replacement is the **^CI28-30** commands.



We recommend that a **^CI** command (or Unicode BOM) is included at the beginning of each ZPL script. This is important when ZPL scripts with different encodings are being sent to a single printer. To assist in the interleaving of encoding schemes, the printer maintains two encoding states (**^CI0 - 28** and **^CI29 - 30**). It automatically acknowledges when it should switch encoding states, allowing it to distinguish between encodings, and maintains a **^CI** for each, but endianness is shared.



Example: This example remaps the Euro symbol (21) decimal to the dollar sign value (36) decimal. When the dollar sign character is sent to the printer, the Euro symbol prints:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^CI0,21,36 ^FO100,200^A0N50,50^FD\$0123^FS ^XZ </pre>	

The font selected determines the shape and resolution of the printed symbol.

International Character Sets

Hex	2	3	4	5	5	5	5	6	7	7	7	7
	3	0	0	B	C	D	E	0	B	C	D	E
CI0	#	0	@	[Φ]	^	'	{		}	~
CI1	#	0	@	¼	Φ	¾	^	'	¼	½	¾	~
CI2	£	0	@	[Φ]	^	'	{		}	~
CI3	f	0	§	[U]	^	'	{	ij	}	~
CI4	#	0	@	Æ	Ø	Å	^	'	æ	ø	å	~
CI5	Ü	0	É	Ä	Ö	Ä	Ü	é	ä	ö	ä	ü
CI6	#	0	§	Ä	Ö	Ü	^	'	ä	ö	ü	ß
CI7	£	0	à	[ç]	^	'	é		ù	è
CI8	#	0	à	â	ç	ê	î	ô	é	ù	è	û
CI9	£	0	§	[ç	é	^	ù	à	ò	è	ì
CI10	#	0	§	ì	Ñ	¿	^	'	{	ñ	ç	~
CI11	£	0	É	Ä	Ö	Ü	^	'	ä	ë	ï	ö
CI12	#	0	@	[¥]	^	'	{		}	~
CI13	#	0	@	[\]	^	'	{		}	~



Note • ^CI 13 = US keyboard

Comments The *space* character cannot be remapped for any font.

^CM – Change Memory Letter Designation

The ^CM command allows you to reassign a letter designation to the printer’s memory devices. If a format already exists, you can reassign the memory device to the corresponding letter without forcing, altering, or recreating the format itself.

Using this command affects every subsequent command that refers to specific memory locations.

Format: ^CMa,b,c,d

Parameters	Details
a = memory alias for B:	Values: B:, E:,R:, A:, and NONE Default: B:
b = memory alias for E:	Values: B:, E:,R:, A:, and NONE Default: E:
c = memory alias for R:	Values: B:, E:,R:, A:, and NONE Default: R:
d = memory alias for A:	Values: B:, E:,R:, A:, and NONE Default: A:
e = multiple alias	Values: M, or no value Default: no value <ul style="list-style-type: none"> • This parameter is supported on Xi4 and ZM400/ZM600 printers using firmware V53.17.7Z or later. • This parameter is supported on G-Series printers using firmware versions v56.17.7Z and v61.17.7Z or later. • This parameter is supported on printers using firmware V60.17.7Z or later.

Comments Unless the e (multiple alias) parameter is used, when two or more parameters specify the same letter designator, all letter designators are set to their default values.

It is recommended that after entering the ^CM command, ^JUS is entered to save changes to EEPROM. Any duplicate parameters entered will reset the letter designations back to the default.

If any of the parameters are out of specification, the command is ignored.

➔ **Example 1:** This example designates letter E: to point to the B: memory device, and the letter B: to point to the E:memory device.

```
^XA
^CME,B,R,A
^JUS
^XZ
```

➔ **Example 2:** This example designates that content sent to, or read from the B: or E: memory locations will be sent to or read from the E: memory location.

```
^XA
^CME,E,R,A,M
^JUS
^XZ
```


→ **Example 3:** This example designates that content sent to, or read from the A: or E: memory locations will be sent to or read from the E: memory location.

```
^XA  
^CMB, E, R, E, M  
^JUS  
^XZ
```

→ **Example 4:** This example designates that content sent to, or read from the A:, B: or E: memory locations will be sent to or read from the E: memory location.

```
^XA  
^CME, E, R, E, M  
^JUS  
^XZ
```



Note • Examples 2, 3 and 4 are the only valid uses of the multiple alias parameter.

^CN – Cut Now

The ^CN causes the printer to cycle the media cutter.



Important • This command works only when the printer is in Print Mode Kiosk (^MMk). If the printer is not in Print Mode Kiosk, then using this command has no effect. See [^MM](#) on page 275.

Supported Devices

- KR403

Format: ^CNa

Parameters	Details
a = Cut Mode Override	<p>Values:</p> <p>0 = Use the “kiosk cut amount” setting from ^KV</p> <p>1 = Ignore “kiosk cut amount” from ^KV and do a full cut</p> <p>Default: none</p> <p>The command is ignored if parameters are missing or invalid.</p>

^CO – Cache On

The ^CO command is used to change the size of the character cache. By definition, a *character cache* (referred to as cache) is a portion of the DRAM reserved for storing scalable characters. All printers have a default 40K cache that is always turned on. The maximum single character size that can be stored, without changing the size of the cache, is 450 dots by 450 dots.

There are two types of fonts used in Zebra printers: bitmapped and scalable. Letters, numbers, and symbols in a bitmapped font have a fixed size (for example: 10 points, 12 points, 14 points). By comparison, scalable fonts are not fixed in size.

Because their size is fixed, bitmapped fonts can be moved quickly to the label. In contrast, scalable fonts are much slower because each character is built on an as-needed basis before it is moved to the label. By storing scaled characters in a cache, they can be recalled at a much faster speed.

The number of characters that can be stored in the cache depends on two factors: the size of the cache (memory) and the size of the character (in points) being saved. The larger the point size, the more space in the cache it uses. The default cache stores every scalable character that is requested for use on a label. If the same character, with the same rotation and size is used again, it is quickly retrieved from cache.

It is possible that after a while the print cache could become full. Once the cache is full, space for new characters is obtained by eliminating an existing character from the print cache. Existing characters are eliminated by determining how often they have been used. This is done automatically. For example, a 28-point Q that was used only once would be a good candidate for elimination from the cache.

Maximum size of a single print cache character is 1500 dots by 1500 dots. This would require a cache of 274K. When the cache is too small for the desired style, smaller characters might appear but larger characters do not. If possible, increase the size of the cache.

Format: ^COa,b,c

Parameters	Details
a = cache on	Values: N = no Y = yes Default: Y
b = amount of additional memory to be added to cache (in K)	Values: 1 to 9999 Default: 40
c = cache type	Values: 0 = cache buffer (normal fonts) 1 = internal buffer (recommended for Asian fonts) Default: 0



Example: To resize the print cache to 62K, assuming a 22K existing cache:

^COY,40

To resize the print cache to 100K, assuming a 22K existing cache:

^COY,78

Print Cache Performance

For printing large characters, memory added to the cache by the **^CO** command is not physically added to the 22K cache already in the printer. In the second example above, the resulting 100K cache is actually two separate blocks of memory, 22K and 78K.

Because large characters need contiguous blocks of memory, a character requiring a cache of 90K would not be completely stored because neither portion of the 100K cache is big enough. Therefore, if large characters are needed, the **^CO** command should reflect the actual size of the cache you need.

Increasing the size of the cache improves the performance in printing scalable fonts. However, the performance decreases if the size of the cache becomes large and contains too many characters. The performance gained is lost because of the time involved searching the cache for each character.

Comments The cache can be resized as often as needed. Any characters in the cache when it is resized are lost. Memory used for the cache reduces the space available for label bitmaps, graphic, and fonts.

Some Asian fonts require an internal working buffer that is much larger than the normal cache. Since most fonts do not require this larger buffer, it is now a selectable configuration option. Printing with the Asian fonts greatly reduces the printer memory available for labels, graphics, fonts, formats, and label bitmaps.



Note • If you have firmware x.12 or greater this command is not required because the printer firmware automatically expands the size of the character cache as needed.

^CP – Remove Label

The ^CP command causes the printer to move a printed label out of the presenter area in one of several ways.

Supported Devices

- KR403

Format: ^CPa

Parameters	Details
a = kiosk present mode	<p>Values:</p> <ul style="list-style-type: none">0 = Eject presented page1 = Retracts presented page2 = Takes the action defined by c parameter of ^KV command. <p>Default: none</p> <p>The command is ignored if parameters are missing or invalid.</p>

^CT ~CT – Change Tilde

The ^CT and ~CT commands are used to change the control command prefix. The default prefix is the tilde (~).

Format: ^CTa or ~CTa

Parameters	Details
a = change control command character	Values: any ASCII character Default: a parameter is required. If a parameter is not entered, the next character received is the new control command character.



Example: This is an example of how to change the control command prefix from a ^ to a +:

```
^XA
^CT+
^XZ
+HS
```

^CV – Code Validation

The ^CV command acts as a switch to turn the code validation function on and off. When this command is turned on, all bar code data is checked for these error conditions:

- character not in character set
- check-digit incorrect
- data field too long (too many characters)
- data field too short (too few characters)
- parameter string contains incorrect data or missing parameter

When invalid data is detected, an error message and code is printed in reverse image in place of the bar code. The message reads **INVALID - X** where **X** is one of these error codes:

C = character not in character set
E = check-digit incorrect
L = data field too long
S = data field too short
P = parameter string contains incorrect data
(occurs only on select bar codes)

Once turned on, the ^CV command remains active from format to format until turned off by another ^CV command or the printer is turned off. The command is not permanently saved.

Format: ^CVa

Parameters	Details
a = code validation	Values: N = no Y = yes Default: N



Example: The examples below show the error labels ^CVY generates when incorrect field data is entered. Compare the letter following *INVALID* – to the listing on the previous page.

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^CVY ^FO50,50 ^BEN,100,Y,N ^FD97823456 890^FS ^XZ </pre>	
<pre> ^XA ^CVY ^FO50,50 ^BEN,100,Y,N ^FD9782345678907^FS ^XZ </pre>	
<pre> ^XA ^CVY ^FO50,50 ^BEN,100,Y,N ^FD97823456789081^FS ^XZ </pre>	
<pre> ^XA ^CVY ^FO50,50 ^BEN,100,Y,N ^FD97823456789^FS ^XZ </pre>	
<pre> ^XA ^CVY ^FO50,50 ^BQN2,3 ^FDHM,BQRCODE-22^FS ^XZ </pre>	

Comments If more than one error exists, the first error detected is the one displayed.

The ^CV command tests the integrity of the data encoded into the bar code. It is not used for (or to be confused with) testing the scan-integrity of an image or bar code.


^CW – Font Identifier

All built-in fonts are referenced using a one-character identifier. The ^CW command assigns a single alphanumeric character to a font stored in DRAM, memory card, EPROM, or Flash.

If the assigned character is the same as that of a built-in font, the downloaded font is used in place of the built-in font. The new font is printed on the label wherever the format calls for the built-in font. If used in place of a built-in font, the change is in effect only until power is turned off.

If the assigned character is different, the downloaded font is used as an additional font. The assignment remains in effect until a new command is issued or the printer is turned off.

Format: ^CWa,d:o.x

Parameters	Details
a = letter of existing font to be substituted, or new font to be added	Values: A through Z and 0 to 9 Default: a one-character entry is required
d = device to store font in (optional)	Values: R:, E:, B:, and A: Default: R:
o = name of the downloaded font to be substituted for the built-in, or as an additional font	Values: any name up to 8 characters Default: if a name is not specified, UNKNOWN is used
x = extension  .TTE is only supported in firmware version V60.14.x, V50.14.x, or later.	Values: .FNT = Font .TTF = TrueType Font .TTE = TrueType Extension



Example: These examples show how to use:

- **MYFONT.FNT** stored in DRAM whenever a format calls for Font A:
^XA
^CWA,R:MYFONT.FNT
^XZ
- **MYFONT.FNT** stored in DRAM additionally as Font Q:
^XA
^CWQ,R:MYFONT.FNT
^XZ
- **NEWFONT.FNT** stored in DRAM whenever a format calls for font F:
^XA
^CWF,R:NEWFONT.FNT
^XZ

DIRECTORY OF R:*.*	
R:NEWFONT.FNT	65268
R:MYFONT.FNT	65268
582164 BYTES FREE R:	

Label Listing Before Assignment

DIRECTORY OF R:*.*	
F R:NEWFONT.FNT	65268
AQ R:MYFONT.FNT	65268
582164 BYTES FREE R:	

Label Listing After Assignment

~DB – Download Bitmap Font

The ~DB command sets the printer to receive a downloaded bitmap font and defines native cell size, baseline, space size, and copyright.

This command consists of two portions, a ZPL II command defining the font and a structured data segment that defines each character of the font.

Format: ~DBd:o.x,a,h,w,base,space,#char,@,data

Parameters	Details
d = drive to store font	Values: R:, E:, B:, and A: Default: R:
o = name of font	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Format: .FNT
a = orientation of native font	Fixed Value: normal
h = maximum height of cell (in dots)	Values: 1 to 32000 Default: a value must be specified
w = maximum width of cell (in dots)	Values: 1 to 32000 Default: a value must be specified
base = dots from top of cell to character baseline	Values: 1 to 32000 Default: a value must be specified
space = width of space or non-existent characters	Values: 1 to 32000 Default: a value must be specified
#char = number of characters in font	Values: 1 to 256 (must match the characters being downloaded) Default: a value must be specified
@ = copyright holder	Values: 1 to 63 alphanumeric characters Default: a value must be specified
data = structured ASCII data that defines each character in the font	The # symbol signifies character code parameters, which are separated with periods. The character code is from 1 to 4 characters to allow for large international character sets to be downloaded to the printer. The data structure is: #xxx.h.w.x.y.i.data #xxx = character code h = bitmap height (in dot rows) w = bitmap width (in dot rows) x = x-offset (in dots) y = y-offset (in dots) i = typesetting motion displacement (width, including inter character gap of a particular character in the font) data = hexadecimal bitmap description



Example: This is an example of how to use the ~DB command. It shows the first two characters of a font being downloaded to DRAM.

```
~DBR:TIMES.FNT,N,5,24,3,10,2,ZEBRA 1992,  
#0025.5.16.2.5.18.  
O0FF  
O0FF  
FF00  
FF00  
FFFF  
#0037.4.24.3.6.26.  
O0FF00  
O0FF00  
O0FF00  
O0FF00
```

~DE – Download Encoding

The standard encoding for TrueType Windows® fonts is always Unicode. The ZPL II field data must be converted from some other encoding to Unicode that the Zebra printer understands. The required translation tables are provided with font packs. Some tables can be downloaded from www.zebra.com.

Format: ~DEd:o.x,s,data

Parameters	Details
d = location of table	Values: R:, E:, B:, and A: Default: R:
o = name of table	Values: any valid name, up to 8 characters Default: if a name is not specified, UNKNOWN is used
x = extension	Format: .DAT
s = table size	Values: the number of memory bytes required to hold the Zebra downloadable format of the font Default: if an incorrect value or no value is entered, the command is ignored
data = data string	Values: a string of ASCII hexadecimal values Default: if no data is entered, the command is ignored

➔ **Example:** This is an example of how to download the required translation table:

```
~DER:JIS.DAT,27848,300021213001...
```

(27848 two-digit hexadecimal values)

Comments For more information on ZTools or ZebraNet Bridge, see the program documentation included with the software.

For assistance with editing or adding mappings to .DAT tables, ZebraNet Bridge includes a .DAT table editor in the font wizard.

Encoding scheme for the data sent to the printer is the second four character and the encoding scheme for the font is the first four characters throughout the .DAT file. The data must be ordered by the second four characters (the encoding table).

➔ **Example:** This is an example of a .DAT table. The table below the example identifies the elements:

```
~DEE:EXAMPLE.DAT,16,
00310041 ← 1
00320042 ← 2
00330043 ← 3
00340044 ← 4
```

1	Input stream with 0041 will be mapped to 0031. The printer prints "1".
2	Input stream with 0042 will be mapped to 0032. The printer prints "2".
3	Input stream with 0043 will be mapped to 0033. The printer prints "3".
4	Input stream with 0044 will be mapped to 0034. The printer prints "4".

Data must have 0041, 0042, 0043, and 0044 in order. Multiple pairs can be on the same line.

^{^DF} – Download Format

The ^{^DF} command saves ZPL II format commands as text strings to be later merged using ^{^XF} with variable data. The format to be stored might contain field number (^{^FN}) commands to be referenced when recalled.

While use of stored formats reduces transmission time, no formatting time is saved—this command saves ZPL II as text strings formatted at print time.

Enter the ^{^DF} stored format command immediately after the ^{^XA} command, then enter the format commands to be saved.

Format: ^{^DF}d:o.x

Parameters	Details
d = device to store image	Values: R:, E:, B:, and A: Default: R:
o = image name	Values: 1 to 16 alphanumeric characters with a file type of 1 to 3 alphanumeric characters separated by a "." Default: if a name is not specified, UNKNOWN is used.
x = extension	Format: .ZPL

For a complete example of the ^{^DF} and ^{^XF} command, see [^{^DF} and ^{^XF} — Download format and recall format on page 38](#).



Example: This example is generated using the ^{^XF} command to recall this format:

ZPL II CODE	GENERATED LABEL
^{^XA} ^{^DFR:STOREFMT.ZPL^FS} ^{^FO25,25} ^{^AD,36,20^FN1^FS} ^{^FO165,25} ^{^AD,36,20^FN2^FS} ^{^FO25,75} ^{^AB,22,14^FDBUILT BY^FS} ^{^FO25,125} ^{^AE,28,15^FN1} ^{^XZ} ^{^XA} ^{^XFR:STOREFMT.ZPL^FS} ^{^FN1^FDZEBRA^FS} ^{^XZ}	<div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>ZEBRA PRINTER</p> <p>BUILT BY</p> <p>ZEBRA</p> </div>

~DG – Download Graphics

The ~DG command downloads an ASCII Hex representation of a graphic image. If .GRF is not the specified file extension, .GRF is automatically appended.

For more saving and loading options when downloading files, see [~DY on page 159](#).

Format: ~DGd:o,x,t,w,data

Parameters	Details
d = device to store image	Values: R:, E:, B:, and A: Default: R:
o = image name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Format: .GRF
t = total number of bytes in graphic	See the formula in the examples below.
w = number of bytes per row	See the formula in the examples below.
data = ASCII hexadecimal string defining image	The data string defines the image and is an ASCII hexadecimal representation of the image. Each character represents a horizontal nibble of four dots.

This is the key for the examples that follow:

- x = width of the graphic in millimeters
- y = height of the graphic in millimeters
- z = dots/mm = print density of the printer being programmed
- 8 = bits/byte



Examples: These are some example related to the ~DG command:

To determine the **t** parameter use this formula:

$$\frac{xz}{8} \times yz = totalbytes$$

To determine the correct t parameter for a graphic 8 mm wide, 16 mm high, and a print density of 8 dots/mm, use this formula:

$$8 \times 128 = 1024$$

$$t = 1024$$

Raise any portion of a byte to the next whole byte.

To determine the **w** parameter (the width in terms of bytes per row) use this formula:

$$\frac{xz}{8} = (totalbytes)/(row)$$

$$w = 8$$

To determine the correct w parameter for a graphic 8 mm wide and a print density of 8 dots/mm, use this formula:

$$\frac{8 \times 8}{8} = 8bytes$$

$$w = 8$$


Raise any portion of a byte to the next whole byte.

Parameter **w** is the first value in the **t** calculation.

The data parameter is a string of hexadecimal numbers sent as a representation of the graphic image. Each hexadecimal character represents a horizontal nibble of four dots. For example, if the first four dots of the graphic image are white and the next four black, the dot-by-dot binary code is 00001111. The hexadecimal representation of this binary value is 0F. The entire graphic image is coded in this way, and the complete graphic image is sent as one continuous string of hexadecimal values.

This is an example of using the ~DG command to load a checkerboard pattern into DRAM. The name used to store the graphic is **SAMPLE.GRF**:

ZPL II CODE
~DGR: SAMPLE.GRF, 00080, 010,
FFFFFFFFFFFFFFFF
8000FFFF0000FFFF0001
8000FFFF0000FFFF0001
8000FFFF0000FFFF0001
FFFF0000FFFF0000FFFF
FFFF0000FFFF0000FFFF
FFFF0000FFFF0000FFFF
FFFFFFFFFFFFFFFF
^XA
^FO20, 20^XGR: SAMPLE.GRF, 1, 1^FS
^XZ



Comments Do not use spaces or periods when naming your graphics. Always use different names for different graphics.

If two graphics with the same name are sent to the printer, the first graphic is erased and replaced by the second graphic.

~DN – Abort Download Graphic

After decoding and printing the number of bytes in parameter **t** of the ~DG command, the printer returns to normal Print Mode. Graphics Mode can be aborted and normal printer operation resumed by using the ~DN command.

Format: ~DN

Comments If you need to stop a graphic from downloading, you should abort the transmission from the host device. To clear the ~DG command, however, you must send a ~DN command.

~DS – Download Intellifont (Scalable Font)

The ~DS command is used to set the printer to receive a downloadable scalable font and defines the size of the font in bytes.

The ~DS command, and its associated parameters, is the result of converting a vendor-supplied font for use on a Zebra printer. To convert this font use the ZTools utility.

Format: ~DSd:o.x,s,data

Parameters	Details
d = device to store image	Values: R:, E:, B:, and A: Default: R:
o = image name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Fixed Value: .FNT
s = size of font in bytes	Fixed Value: this number is generated by ZTools and should not be changed
data = ASCII hexadecimal string that defines font	Fixed Value: this number is generated by ZTools and should not be changed



Example: This example shows the first three lines of a scalable font that was converted using the ZTools program and is ready to be downloaded to the printer. If necessary, the destination and object name can be changed.

```
~DSB:CGTIMES.FNT,37080,
O0FF00FF00FF00FF
FF0AECB28FFF00FF
```

Comments Downloaded scalable fonts are not checked for integrity. If they are corrupt, they cause unpredictable results at the printer.



If you are using a TrueType font use these commands: ~DT, ~DU, and ~DY. To determine when to use the noted commands, see [~DT on page 157](#), [~DU on page 158](#), and [~DY on page 159](#).

~DT – Download Bounded TrueType Font

Use ZTools to convert a TrueType font to a Zebra-downloadable format. that has less than 256 characters in it. To convert a font that has more than 256 characters, see [~DU on page 158](#). ZTools creates a downloadable file that includes a **~DT** command. For information on converting and downloading Intellifont information, see [~DS on page 156](#).

Format: `~DTd:o.x,s,data`

Parameters	Details
d = font location	Values: R:, E:, B:, and A: Default: R:
o = font name	Values: any valid TrueType name, up to 8 characters Default: if a name is not specified, UNKNOWN is used
x = extension	Fixed Value: .DAT
s = font size	Values: the number of memory bytes required to hold the Zebra-downloadable format of the font Default: if an incorrect value or no value is entered, the command is ignored
data = data string	Values: a string of ASCII hexadecimal values (two hexadecimal digits/byte). The total number of two-digit values must match parameter s . Default: if no data is entered, the command is ignored



Example: This is an example of how to download a true type font:

```
~DTR:FONT,52010,00AF01B0C65E...
```

(52010 two-digit hexadecimal values)

~DU – Download Unbounded TrueType Font

Some international fonts, such as Asian fonts, have more than 256 printable characters. These fonts are supported as *large TrueType fonts* and are downloaded to the printer with the **~DU** command. Use ZTools to convert the large TrueType fonts to a Zebra-downloadable format.

The Field Block (^FB) command cannot support the large TrueType fonts.

Format: ~DUd:o.x,s,data

Parameters	Details
d = font location	Values: R:, E:, B:, and A: Default: R:
o = font name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Format: .FNT
s = font size	Values: the number of memory bytes required to hold the Zebra-downloadable format of the font Default: if no data is entered, the command is ignored
data = data string	Values: a string of ASCII hexadecimal values (two hexadecimal digits/byte). The total number of two-digit values must match parameter s. Default: if no data is entered, the command is ignored



Example: This is an example of how to download an unbounded true type font:

```
~DUR:KANJI,86753,60CA017B0CE7...
```

(86753 two-digit hexadecimal values)

For similar commands, see [~DS on page 156](#), [~DT on page 157](#), and [~DY on page 159](#).

~DY – Download Objects

The ~DY command downloads to the printer graphic objects or fonts in any supported format. This command can be used in place of ~DG for more saving and loading options. ~DY is the preferred command to download TrueType fonts on printers with firmware later than X.13. It is faster than ~DU. The ~DY command also supports downloading wireless certificate files.






Note • When using certificate files, your printer supports:

- Using Privacy Enhanced Mail (PEM) formatted certificate files.
- Using the client certificate and private key as two files, each downloaded separately.
- Using exportable PAC files for EAP-FAST.
- Zebra recommends using Linear style memory devices for storing larger objects.

Format: ~DYd:f,b,x,t,w,data

Parameters	Details
d = file location .15† .NRD and .PAC files reside on E: in firmware versions V60.15.x, V50.15.x, or later.	Values: R:, E:, B:, and A: Default: R:
f = file name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
b = format downloaded in data field .14† .TTE and .TTF are only supported in firmware versions V60.14.x, V50.14.x, or later.	Values: A = uncompressed (ZB64, ASCII) B = uncompressed (.TTE, .TTF, binary) C = AR-compressed (used only by Zebra's BAR-ONE® v5) P = portable network graphic (.PNG) - ZB64 encoded Default: a value must be specified
x = extension of stored file .14† .TTE and .OTF are only supported in firmware versions V60.14.x, V50.14.x, or later. .15† .NRD and .PAC are only supported in firmware versions V60.15.x, V50.15.x, or later.	Values: B = bitmap E = TrueType Extension (.TTE) G = raw bitmap (.GRF) P = store as compressed (.PNG) T = TrueType (.TTF) or OpenType (.OTF) X = Paintbrush (.PCX) NRD = Non Readable File (.NRD) PAC = Protected Access Credential (.PAC) C = User defined menu file (WML) F = User defined webpage file (HTM) H = Printer feedback file (GET) Default: a value other than the accepted values defaults to .GRF

Parameters	Details
<p>t = total number of bytes in file</p> <p> .TTE is only supported in firmware versions V60.14.x, V50.14.x, or later.</p>	<p>Values:</p> <ul style="list-style-type: none"> .BMP This parameter refers to the actual size of the file, not the amount of disk space. .GRF images: the size after decompression into memory This parameter refers to the actual size of the file, not the amount of disk space. .PCX This parameter refers to the actual size of the file, not the amount of disk space. .PNG images: This parameter refers to the actual size of the file, not the amount of disk space. .TTF This parameter refers to the actual size of the file, not the amount of disk space. .TTE This parameter refers to the actual size of the file, not the amount of disk space.
<p>w = total number of bytes per row</p> <p> .TTE is only supported in firmware version V60.14.x, V50.14.x, or later.</p> <p> .NRD and .PAC files are supported in firmware version V60.15.x, V50.15.x, or later.</p>	<p>Values:</p> <ul style="list-style-type: none"> .GRF images: number of bytes per row .PNG images: value ignored .TTF images: value ignored .TTE images: value ignored .NRD images: value ignored .PAC images: value ignored
<p>data = data</p>	<p>ASCII hexadecimal encoding, ZB64, or binary data, depending on b.</p> <p>A, P = ASCII hexadecimal or ZB64 B, C = binary</p> <p>When binary data is sent, all control prefixes and flow control characters are ignored until the total number of bytes needed for the graphic format is received.</p>



Note • When transmitting fonts or graphics, the ~DY command and the binary content can be sent as two separate data streams. In cases where the ~DY command and data content are sent separately, the connection to the printer must be maintained until both the command and data content have been sent. If the command and data content are sent separately, the data light on the printer will remain lit until it receives all the data called for in the ~DY command. The download will be considered complete when the number of bytes called out in the ~DY command have been received.

For best results, graphic files must be monochrome (black and white) or dithered.



Example: This is an example of how to download a binary TrueType Font file of Size bytes using the name fontfile.ttf and storing it to permanent flash memory on the printer:

```
~DYE:FONTFILE.TTF,B,T,SIZE,,
```



Examples: These examples show:

- that when the **^IM** command is used with the **^FO** command, the **^IM** command (see [^IM on page 220](#)) moves the **logo.png** file from a storage area to the 0,0 position on the label. This is the ZPL code:

```
^XA  
^FO0,0^IMR:LOGO.PNG^FS  
^XZ
```

- that when the **^IL** command (see [^IL on page 219](#)) is used at the beginning of a label format, it loads a stored image (**logo.png**) of a format and merges it with additional data. It is automatically positioned at the 0,0 position of the label and does not require the **^FO** command. This is the ZPL code:

```
^XA  
^ILR:LOGO.PNG  
^XZ
```

Comments For more information on ZB64 encoding and compression, see [ZB64 Encoding and Compression on page 1365](#).



These are some important things to know about this command in firmware version V60.14.x, V50.14.x, or later:

- ZebraNet Bridge can be used to download fonts and graphics with this command.
- OpenType tables are only supported when downloading the font with this command
- OpenType fonts (**.OTF**) are supported if they are downloaded as a TrueType font. In the printer **.OTF** fonts have the **.TTF** extension.

~EG – Erase Download Graphics

See [^D](#) on page 217.

^FB – Field Block

The ^FB command allows you to print text into a defined *block type* format. This command formats an ^FD or ^SN string into a block of text using the origin, font, and rotation specified for the text string. The ^FB command also contains an automatic word-wrap function.

Format: ^FBa,b,c,d,e

Parameters	Details
a = width of text block line (in dots)	Values: 0 to the width of the label Default: 0 If the value is less than font width or not specified, text does not print.
b = maximum number of lines in text block	Values: 1 to 9999 Default: 1 Text exceeding the maximum number of lines overwrites the last line. Changing the font size automatically increases or decreases the size of the block.
c = add or delete space between lines (in dots)	Values: -9999 to 9999 Default: 0 Numbers are considered to be positive unless preceded by a minus sign. Positive values add space; negative values delete space.
d = text justification	Values: L = left C = center R = right J = justified Default: L If J is used the last line is left-justified.
e = hanging indent (in dots) of the second and remaining lines	Values: 0 to 9999 Default: 0



Example: These are examples of how the ^FB command affects field data.

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^CF0,30,30^FO25,50 ^FB250,4,, ^FDFD command that IS\& preceded by an FB \&command. ^FS ^XZ </pre>	<p>FD command that IS preceded by an FB command.</p>
<pre> ^XA ^CF0,30,30^FO25,50 ^FDFD command that IS NOT preceded by an FB command.^FS ^XZ </pre>	<p>FD command that IS NOT preceded by an FB cor</p>

Comments

This scheme can be used to facilitate special functions:

- \& = carriage return/line feed
- \(*) = soft hyphen (word break with a dash)
- \\ = backslash (\)

Item 1: ^CI13 must be selected to print a backslash (\).

Item 2: If a soft hyphen escape sequence is placed near the end of a line, the hyphen is printed. If it is not placed near the end of the line, it is ignored.

(*) = any alphanumeric character

- If a word is too long to print on one line by itself (and no soft hyphen is specified), a hyphen is automatically placed in the word at the right edge of the block. The remainder of the word is on the next line. The position of the hyphen depends on word length, not a syllable boundary. Use a soft hyphen within a word to control where the hyphenation occurs.
- Maximum data-string length is 3K, including control characters, carriage returns, and line feeds.
- Normal carriage returns, line feeds, and *word spaces* at line breaks are discarded.
- When using ^FT (Field Typeset), ^FT uses the baseline origin of the last possible line of text. Increasing the font size causes the text block to increase in size from bottom to top. This could cause a label to print past its top margin.
- When using ^FO (Field Origin), increasing the font size causes the text block to increase in size from top to bottom.
- ^FS terminates an ^FB command. Each block requires its own ^FB command.



While the ^FB command has a text justification parameter that defines the justification of the text within the block, it also interacts with the justification of ^FO and ^FT that define the justification of the origin.

The ^FB command does not support soft hyphens as a potential line break point. However, soft hyphen characters are always printed as if they were a hyphen.

The ^FB command does not support complex text. For complex text support, use ^TB.

^FC – Field Clock

The ^FC command is used to set the clock-indicators (delimiters) and the clock mode for use with the Real-Time Clock hardware. This command must be included within each label field command string each time the Real-Time Clock values are required within the field.

Format: ^FCa,b,c

Parameters	Details
a = primary clock indicator character	Values: any ASCII character Default: %
b = secondary clock indicator character	Values: any ASCII character Default: none—this value cannot be the same as a or c
c = third clock indicator character	Values: any ASCII character Default: none—this value cannot be the same as a or b



Example: Entering these ZPL commands sets the primary clock indicator to %, the secondary clock indicator to {, and the third clock indicator to #. The results are printed on a label with Primary, Secondary, and Third as field data.

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO10,100^A0N,50,50 ^FC%,{,# ^FDPrimary: %m/%d/%y^FS ^FO10,200^A0N,50,50 ^FC%,{,# ^FDSecondary: {m/{d/{y^FS ^FO10,300^A0N,50,50 ^FC%,{,# ^FDThird: #m/#d/#y^FS ^XZ </pre>	<div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>Primary: 00/00/00</p> <p>Secondary: 01/01/00</p> <p>Third: 01/01/00</p> </div>

Comments The ^FC command is ignored if the Real Time Clock hardware is not present. As of V60.13.0.10, (^SN) functions with (^FC) capabilities.

For more details on the Real Time Clock, see [Real Time Clock on page 1375](#).

^FD – Field Data

The ^FD command defines the data string for a field. The field data can be any printable character except those used as command prefixes (^ and ~).

In RFID printers, it can also be used to specify passwords to write to tags.

Format: ^FDa

Parameters	Details
a = <ul style="list-style-type: none">• data to be printed (all printers), or• a password to be written to a RFID tag (rfid printers)	Values: any data string up to 3072 bytes Default: none—a string of characters must be entered

Comments The ^ and ~ characters can be printed by changing the prefix characters—see [^CD ~CD on page 130](#) and [^CT ~CT on page 142](#). The new prefix characters cannot be printed.

Characters with codes above 127, or the ^ and ~ characters, can be printed using the ^FH and ^FD commands.

- ^CI13 must be selected to print a backslash (\).

For information on using soft hyphens, see [Comments on the ^FB command on page 164](#).

^FH – Field Hexadecimal Indicator

The ^FH command allows you to enter the hexadecimal value for any character directly into the ^FD statement. The ^FH command must precede each ^FD command that uses hexadecimal in its field.

Within the ^FD statement, the hexadecimal indicator must precede each hexadecimal value. The default hexadecimal indicator is _ (underscore). There must be a minimum of two characters designated to follow the underscore. The a parameter can be added when a different hexadecimal indicator is needed.

This command can be used with any of the commands that have field data (that is ^FD, ^FV (Field Variable), and ^SN (Serialized Data)).

Valid hexadecimal characters are:

0 1 2 3 4 5 6 7 8 9 A B C D E F a b c d e f

Format: ^FHa

Parameters	Details
a = hexadecimal indicator	Values: any character except current format and control prefix (^ and ~ by default) Default: _ (underscore)



Example: This is an example of how to enter a hexadecimal value directly into a ^FD statement: This is an example for ascii data using ^CI0.

ZPL II CODE	GENERATED LABEL
<pre>^XA ^FO100,100 ^AD^FH ^FDTilde _7e used for HEX^FS ^XZ</pre>	<div style="border: 1px solid black; padding: 5px; text-align: center;">Tilde ~ used for HEX</div>
<pre>^XA ^FO100,100 ^AD^FH\ ^FDTilde \7E used for HEX^FS ^XZ</pre>	<div style="border: 1px solid black; padding: 5px; text-align: center;">Tilde ~ used for HEX</div>



Examples: These are examples of how ^FH works with UTF-8 and UTF-16BE:

UTF-8

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^CI28 ^LL500 ^FO100,100 ^AA,20,20 ^FH^FDU+00A1 in UTF8 = _C2_A1^FS ^XZ </pre>	<div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>U+00A1 in UTF8 = i</p> </div>

UTF-16BE

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^CI29 ^LL500 ^FO100,100 ^AA,20,20 ^FH^FDU+00A1 in UTF16BE = _00_A1^FS ^XZ </pre>	<div style="border: 1px solid black; padding: 10px; text-align: center;"> <p>U+00A1 in UTF16BE = i</p> </div>

^FL – Font Linking

The ^FL command provides the ability to link any TrueType font, including private character fonts, to associated fonts.

If the base font does not have a glyph for the required character, the printer looks to the linked fonts for the glyph. The font links are user-definable. The font linking remains until the link is broken or the printer is turned off. To permanently save the font linking, use the ^JUS command.



Note • For assistance in setting up the font links, use the font wizard in ZebraNet Bridge.

Format: ^FL<ext>,<base>,<link>

Parameters	Details
<ext>	<p>This is the fully-qualified filename of the extension. This file name does not accept wildcards.</p> <p>The supported extensions for this parameter are: .TTF and .TTE. The format for this parameter is the memory device followed by the font name with the extension, as follows:</p> <p style="text-align: center;">E:SWISS721.TTF</p>
<base>	<p>This is the filename of the base font(s). The base font can be any of the following types:</p> <p style="text-align: center;">.FNT .TTF or .TTE</p> <p>From these font types you can only link to a .TTF or .TTE.</p> <p>The name of the base font can be expressed as a wild card; doing so will define multiple base fonts. The result will be that all base font files so defined will be linked to the file defined in the <ext> parameter.</p> <p>The filename does not have to match a file that is currently defined on the printer. A specification of *.TTF results in all *.TTF font files loaded on the printer currently or in the future to be linked with the specified <ext> font extension.</p>
<link>	<p>This is an indicator that determines if the extension is to be linked with the base, or unlinked from the base, as follows:</p> <p>Values:</p> <p style="padding-left: 20px;">0 = <ext> is to be unlinked (disassociated) from the file(s) specified in <base></p> <p style="padding-left: 20px;">1 = <ext> is to be linked (associated) with the file(s) specified by <base></p> <p>Default: must be an accepted value or it is ignored</p>

Comments A font can have up to five fonts linked to it. The printer resident font, **0.FNT** is always the last font in the list of font links, but is not included in the five link maximum. It can also be placed anywhere in the font links list.

The default glyph prints when a glyph cannot be found in any of the fonts in the link list. The advanced layout command ^PA determines if the default glyph is a space character or the default glyph of the base font, which is typically a hollow box.

The list of font links can be printed by using the ^LF command or retrieved with the ^HT command.



Examples: These examples show the code and output for no font linking and for font linking:

No Font Linking

In the no font linking example, the Swiss721 font does not have the Asian glyphs, which is why Asian glyphs do not print.

ZPL II CODE	GENERATED LABEL
<pre> ^XA^LL1200^CW1,E:SWISS721.TTF^CW2,E:ANMDJ.TTF^CI28^FS ^FO100,100^A0,50,50^FDNO FONT LINKING^FS ^FO100,300^A1,50,50^FDTEST WITH SWISS721^FS ^FO100,400^A1,50,50^FDDRAGONFLY 蜻蜓^FS ^FO100,600^A2,50,50^FDTEST WITH ANMDJ^FS ^FO100,700^A2,50,50^FDDRAGONFLY 蜻蜓^FS ^XZ </pre>	<div style="border: 1px solid black; padding: 10px;"> <p>NO FONT LINKING</p> <p>TEST WITH SWISS721</p> <p>DRAGONFLY</p> <p>TEST WITH ANMDJ</p> <p>DRAGONFLY 蜻蜓</p> </div>

Font Linking

In the font linking example, this code is sent down to link the ANMDJ . TTF font to SWISS721 . TTF font:

```

^XA
^FLE:ANMDJ.TTF,E:SWISS721.TTF,1^FS
^XZ
    
```

When the label reprints, the Asian characters are printed using the ANMDJ . TTF font, rather than the SWISS721 . TTF font.

ZPL II CODE	GENERATED LABEL
<pre> ^XA^LL1200^CW1,E:SWISS721.TTF^CW2,E:ANMDJ.TTF^CI28^FS ^FO100,100^A0,50,50^FDFONT LINKING^FS ^FO100,300^A1,50,50^FDTEST WITH SWISS721^FS ^FO100,400^A1,50,50^FDDRAGONFLY 蜻蜓^FS ^FO100,600^A2,50,50^FDTEST WITH ANMDJ^FS ^FO100,700^A2,50,50^FDDRAGONFLY 蜻蜓^FS ^XZ </pre>	<div style="border: 1px solid black; padding: 10px;"> <p>FONT LINKING</p> <p>TEST WITH SWISS721</p> <p>DRAGONFLY 蜻蜓</p> <p>TEST WITH ANMDJ</p> <p>DRAGONFLY 蜻蜓</p> </div>

^FM – Multiple Field Origin Locations

The ^FM command allows you to control the placement of bar code symbols.

It designates field locations for the PDF417 (^B7) and MicroPDF417 (^BF) bar codes when the structured append capabilities are used. This allows printing multiple bar codes from the same set of text information.

The structured append capability is a way of extending the text printing capacity of both bar codes. If a string extends beyond what the data limitations of the bar code are, it can be printed as a series: 1 of 3, 2 of 3, 3 of 3. Scanners read the information and reconcile it into the original, unsegmented text.


The ^FM command triggers multiple bar code printing on the same label with ^B7 and ^BF only. When used with any other commands, it is ignored.

Format: ^FMx1,y1,x2,y2,...

Parameters	Details
x1 = x-axis location of first symbol (in dots)	<p>Values: 0 to 32000 e = exclude this bar code from printing</p> <p>Default: a value must be specified</p>
y1 = y-axis location of first symbol (in dots)	<p>Values: 0 to 32000 e = exclude this bar code from printing</p> <p>Default: a value must be specified</p>
x2 = x-axis location of second symbol (in dots)	<p>Values: 0 to 32000 e = exclude this bar code from printing</p> <p>Default: a value must be specified</p>
y2 = y-axis location of second symbol (in dots)	<p>Values: 0 to 32000 e = exclude this bar code from printing</p> <p>Default: a value must be specified</p>
... = continuation of X,Y pairs	<p><i>Maximum number of pairs: 60</i></p>



Example: This example shows you how to generate three bar codes with the text "Zebra Technologies Corporation strives to be..." would need to be repeated seven times, which includes 2870 characters of data (including spaces) between ^FD and ^FS:


ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FM100,100,100,600,100,1200 ^BY2,3 ^B7N,5,5,9,83,N ^FDZebra Technologies Corporation strives to be the expert supplier of innovative solutions to specialty demand labeling and ticketing problems of business and government. We will attract and retain the best people who will understand our customer's needs and provide them with systems, hardware, software, consumables and service offering the best value, high quality, and reliable performance, all delivered in a timely manner ... ^FS^XZ </pre>	

1

1	The ellipse is not part of the code. It indicates that the text needs to be repeated seven times, as mentioned in the example description.
---	--



Example: This example assumes a maximum of three bar codes, with bar code 2 of 3 omitted:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FM100,100,e,e,100,1200 ^BY2,3 ^B7N,5,5,9,83,N ^FDZebra Technologies Corporation strives to be the expert supplier of innovative solutions to specialty demand labeling and ticketing problems of business and government. We will attract and retain the best people who will understand our customer's needs and provide them with systems, hardware, software, consumables and service offering the best value, high quality, and reliable performance, all delivered in a timely manner ... ^FS^XZ </pre> <p style="text-align: center;">1</p>	

1 The ellipse is not part of the code. It indicates that the text needs to be repeated seven times, as mentioned in the example description.

Comments Subsequent bar codes print once the data limitations of the previous bar code have been exceeded. For example, bar code 2 of 3 prints once 1 of 3 has reached the maximum amount of data it can hold. Specifying three fields does not ensure that three bar codes print; enough field data to fill three bar code fields has to be provided.

The number of the **x,y** pairs can exceed the number of bar codes generated. However, if too few are designated, no symbols print.

^FN – Field Number

The ^FN command numbers the data fields. This command is used in both ^DF (Store Format) and ^XF (Recall Format) commands.

In a stored format, use the ^FN command where you would normally use the ^FD (Field Data) command. In recalling the stored format, use ^FN in conjunction with the ^FD command.

The optional "a" parameter can be used with the KDU Plus to cause prompts to be displayed on the KDU unit. Also, when the Print on Label link is selected on the Directory page of ZebraLink enabled printers the field prompt displays.

The number of fields and data that can be stored is dependent in the available printer memory.



Note • The maximum number of ^FN commands that can be used depends on the amount of data that is placed in the fields on the label. It is recommended to use 400 or fewer fields.

Format: ^FN#"a"

Parameters	Details
# = number to be assigned to the field	Values: 0 to 9999 Default: 0
"a" = optional parameter*	Values: 255 alphanumeric characters maximum (a-z,A-Z,1-9 and space) Default: optional parameter

* This parameter is only available on printers with firmware V50.13.2, V53.15.5Z, V60.13.0.1, or later. For a complete example of the ^DF and ^XF command, see [^DF and ^XF — Download format and recall format on page 38](#).

Comments

- The same ^FN value can be stored with several different fields.
- If a label format contains a field with ^FN and ^FD, the data in that field prints for any other field containing the same ^FN value.
- For the "a" parameter to function as a prompt the characters used in the "a" parameter must be surrounded by double quotes (see example).



Example: The ^FN1"Name" would result in "Name" being used as the prompt on the KDU unit.

^FO – Field Origin

The ^FO command sets a field origin, relative to the label home (^LH) position. ^FO sets the upper-left corner of the field area by defining points along the x-axis and y-axis independent of the rotation.

Format: ^FOx,y,z

Parameters	Details
x = x-axis location (in dots)	Values: 0 to 32000 Default: 0
y = y-axis location (in dots)	Values: 0 to 32000 Default: 0
z = justification	Values: 0 = left justification 1 = right justification 2 = auto justification (script dependent) Default: last accepted ^FW value or ^FW default

.14↑ The z parameter is only supported in firmware versions V60.14.x, V50.14.x, or later.

Comments If the value entered for the x or y parameter is too high, it could position the field origin completely off the label.



This command interacts with the field direction parameter of ^FP and with the rotation parameter of ^A. For output and examples, see [Field Interactions on page 1369](#).

The auto justification option might cause unexpected results if variable fields or bidirectional text are used with ^FO. For the best results with bidirectional text and/or variable fields, use either the left of right justification option.



^FP – Field Parameter

The ^FP command allows vertical and reverse formatting of the font field, commonly used for printing Asian fonts.

Format: ^FPd,g

Parameters	Details
d = direction	Values: H = horizontal printing (left to right) V = vertical printing (top to bottom) R = reverse printing (right to left) Default: H
g = additional inter-character gap (in dots)	Values: 0 to 9999 Default: 0 if no value is entered

➔ **Example:** This is an example of how to implement reverse and vertical print:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO100,50 ^FPV,10 ^AV ^FDvertical^FS ^XZ </pre>	
<pre> ^XA ^FO350,50 ^FPR,10 ^AV ^FDreverse^FS ^XZ </pre>	



For vertical and reverse printing directions, combining semantic clusters are used to place characters.

This command interacts with the justification parameters of ^FO and ^FT and with the rotation parameter of ^A. For output and examples, see [Field Interactions on page 1369](#).

^FR – Field Reverse Print

The ^FR command allows a field to appear as white over black or black over white. When printing a field and the ^FR command has been used, the color of the output is the reverse of its background.

Format: ^FR



Example: In this example, the ^GB command creates areas of black allowing the printing to appear white:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^PR1 ^FO100,100 ^GB70,70,70,,3^FS ^FO200,100 ^GB70,70,70,,3^FS ^FO300,100 ^GB70,70,70,,3^FS ^FO400,100 ^GB70,70,70,,3^FS ^FO107,110^CF0,70,93 ^FR^FDREVERSE^FS ^XZ </pre>	

Comments The ^FR command applies to only one field and has to be specified each time. When multiple ^FR commands are going to be used, it might be more convenient to use the ^LR command.

^FS – Field Separator

The ^FS command denotes the end of the field definition. Alternatively, ^FS command can also be issued as a single ASCII control code SI (Control-O, hexadecimal 0F).

Format: ^FS

^FT – Field Typeset

The ^FT command sets the field position, relative to the home position of the label designated by the ^LH command. The typesetting origin of the field is fixed with respect to the contents of the field and does not change with rotation.



Note • The ^FT command is capable of concatenation of fields.

Format: ^FTx,y,z

Parameters	Details
x = x-axis location (in dots)	Values: 0 to 32000 Default: position after last formatted text field
y = y-axis location (in dots)	Values: 0 to 32000 Default: position after last formatted text field
z = justification	<p>Values:</p> <ul style="list-style-type: none"> 0 = left justification 1 = right justification 2 = auto justification (script dependent) <p>Default: last accepted ^FW value or ^FW default</p> <p>The auto justification option may cause unexpected results if variable fields or bidirectional text are used with ^FT. For best results with bidirectional text and/or variable fields, use either the left or right justification options.</p>




The z parameter is only supported in firmware version V60.14.x, V50.14.x, or later.

Table 13 • Typeset Justification

Left Justified	Text	For examples, see Field Interactions on page 1369 .
	Bar Codes	Origin is base of bar code, at left edge
	Graphic Boxes	Origin is bottom-left corner of the box
	Images	Origin is bottom-left corner of the image area
Right Justified	Text	For examples, see Field Interactions on page 1369 .
	Bar Codes	Origin is base of bar code, at right edge
	Graphic Boxes	Origin is bottom-right corner of the box
	Images	Origin is bottom-right corner of the image area



Example: This is an example of the ^FT command and concatenation:

ZPL II CODE	GENERATED LABEL
<pre>^XA ^FT10,200^A0N,30,20^FDACME ^FS ^FT^GS^FDC^FS ^FT^A0N,30,20^FDSummer ^FS ^FT^A0N,60,50^FDClearance ^FS ^FT^A0N,120,100^FDSale ^FS ^XZ</pre>	

When a coordinate is missing, the position following the last formatted field is assumed. This *remembering* simplifies field positioning with respect to other fields. Once the first field is positioned, other fields follow automatically.

There are several instances where using the ^FT command without specifying **x** and **y** parameters is not recommended:

- when positioning the first field in a label format
- at any time with the ^FN (Field Number) command
- following an ^SN (Serialization Data) command
- variable data
- bidirectional text



The right typeset justified is available only for printers with firmware version V60.14.x, V50.14.x, or later.

This command interacts with the field direction parameters of ^FP and with the rotation parameter of ^A. For output and code examples, see [Field Interactions on page 1369](#)

^FV – Field Variable

^FV replaces the ^FD (field data) command in a label format when the field is variable.

Format: ^FVa

Parameters	Details
a = variable field data to be printed	Values: 0 to 3072 byte string Default: if no data is entered, the command is ignored



Example: This is an example of how to use the ^MC and ^FV command:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO40,40 ^GB300,203,8^FS ^FO55,60^CF0,25 ^FVVARIABLE DATA #1^FS ^FO80,150 ^FDFIXED DATA^FS ^MCN ^XZ </pre>	
<pre> ^XA ^FO55,60^CF0,25 ^FVVARIABLE DATA #2^FS ^MCY ^XZ </pre>	


Comments ^FV fields are always cleared after the label is printed. ^FD fields are not cleared.

^FW – Field Orientation

The ^FW command sets the default orientation for all command fields that have an orientation (rotation) parameter (and in x.14 sets the default justification for all commands with a justification parameter). Fields can be rotated 0, 90, 180, or 270 degrees clockwise by using this command. In x.14, justification can be left, right, or auto.

The ^FW command affects only fields that follow it. Once you have issued a ^FW command, the setting is retained until you turn off the printer or send a new ^FW command to the printer.

Format: ^FWr,z

Parameters	Details
r = rotate field	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotated 90 degrees I = inverted 180 degrees B = bottom-up 270 degrees, read from bottom up <p>Initial Value at Power Up: N</p>
z = justification  The z parameter is available only with printers with firmware version V60.14.x, V50.14.x, or later.	<p>Values:</p> <ul style="list-style-type: none"> 0 = left justification 1 = right justification 2 = auto justification (script dependent) <p>Default: auto for ^TB and left for all other commands</p>



Example: This example shows how ^FW rotation works in conjunction with ^FO. In this example, note that:

- the fields using A0N print the field in normal rotation
- the fields with no rotation indicated (A0) follow the rotation used in the ^FW command (^FWR).

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FWR ^FO150,90^A0N,25,20^FDZebra Technologies^FS ^FO115,75^A0,25,20^FD0123456789^FS ^FO150,115^A0N,25,20^FD333 Corporate Woods Parkway^FS ^FO400,75^A0,25,20^FDXXXXXXXXXX^FS ^XZ </pre>	

Comments ^FW affects only the orientation in commands where the rotation parameter has not been specifically set. If a command has a specific rotation parameter, that value is used.



^FW affects only the justification in commands where the parameter has not been set. If a command has a specific justification parameter that value is used .

^FX – Comment

The ^FX command is useful when you want to add *non-printing* informational comments or statements within a label format. Any data after the ^FX command up to the next caret (^) or tilde (~) command does not have any effect on the label format. Therefore, you should avoid using the caret (^) or tilde (~) commands within the ^FX statement.

Format: ^FXc

Parameters	Details
c = non printing comment	Creates a non-printable comment.

➔ **Example:** This is an example of how to use the ^FX command effectively:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^LH100,100^FS ^FXSHIPPING LABEL^FS ^FO10,10^GB470,280,4^FS ^FO10,190^GB470,4,4^FS ^FO10,80^GB240,2,2^FS ^FO250,10^GB2,100,2^FS ^FO250,110^GB226,2,2^FS ^FO250,60^GB226,2,2^FS ^FO156,190^GB2,95,2^FS ^FO312,190^GB2,95,2^FS ^XZ </pre>	

Comments Correct usage of the ^FX command includes following it with the ^FS command.

^GB – Graphic Box

The ^GB command is used to draw boxes and lines as part of a label format. Boxes and lines are used to highlight important information, divide labels into distinct areas, or to improve the appearance of a label. The same format command is used for drawing either boxes or lines.

Format: ^GBw,h,t,c,r

Parameters	Details
w = box width (in dots)	Values: value of t to 32000 Default: value used for thickness (t) or 1
h = box height (in dots)	Values: value of t to 32000 Default: value used for thickness (t) or 1
t = border thickness (in dots)	Values: 1 to 32000 Default: 1
c = line color	Values: B = black W = white Default: B
r = degree of corner-rounding	Values: 0 (no rounding) to 8 (heaviest rounding) Default: 0

For the **w** and **h** parameters, keep in mind that printers have a default of 6, 8, 12, or 24 dots/millimeter. This comes out to 153, 203, 300, or 600 dots per inch. To determine the values for **w** and **h**, calculate the dimensions in millimeters and multiply by 6, 8, 12, or 24.

If the width and height are not specified, you get a solid box with its width and height as specified by value **t**.

The roundness-index is used to determine a rounding-radius for each box. Formula:

$$\text{rounding-radius} = (\text{rounding-index} / 8) * (\text{shorter side} / 2)$$

where the shorter side is the lesser of the width and height (after adjusting for minimum and default values).



Examples: Here are a few examples of graphic boxes:

Width: 1.5 inch; Height: 1 inch; Thickness: 10; Color: default; Rounding: default

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO50,50 ^GB300,200,10^FS ^XZ </pre>	

Width: 0 inch; Height: 1 inch; Thickness: 20; Color: default; Rounding: default:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO50,50 ^GB0,203,20^FS ^XZ </pre>	

Width: 1 inch; Height: 0 inch; Thickness: 30; Color: default; Rounding: default

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO50,50 ^GB203,0,20^FS ^XZ </pre>	

Width: 1.5 inch; Height: 1 inch; Thickness: 10; Color: default; Rounding: 5

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO50,50 ^GB300,200,10,,5^FS ^XZ </pre>	

^GC – Graphic Circle

The ^GC command produces a circle on the printed label. The command parameters specify the diameter (width) of the circle, outline thickness, and color. Thickness extends inward from the outline.

Format: ^GCd,t,c

Parameters	Details
d = circle diameter (in dots)	Values: 3 to 4095 (larger values are replaced with 4095) Default: 3
t = border thickness (in dots)	Values: 2 to 4095 Default: 1
c = line color	Values: B = black W = white Default: B



Example: This is an example of how to create a circle on the printed label:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO50,50 ^GC250,10,B^FS ^XZ </pre>	

^GD – Graphic Diagonal Line

The ^GD command produces a straight diagonal line on a label. This can be used in conjunction with other graphic commands to create a more complex figure.

Format: ^GDw,h,t,c,o

Parameters	Details
w = box width (in dots)	Values: 3 to 32000 Default: value of t (thickness) or 3
h = box height (in dots)	Values: 3 to 32000 Default: value of t (thickness) or 3
t = border thickness (in dots)	Values: 1 to 32000 Default: 1
c = line color	Values: B = black W = white Default: B
o = orientation (direction of the diagonal)	Values: R (or /) = right-leaning diagonal L (or \) = left-leaning diagonal Default: R



Example: This is an example of how to create a diagonal line connecting one corner with the opposite corner of a box on a printed label:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO150,100 ^GB350,203,10^FS ^FO155,110 ^GD330,183,10,,R^FS ^XZ </pre>	

^GE – Graphic Ellipse

The ^GE command produces an ellipse in the label format.

Format: ^GEw,h,t,c

Parameters	Details
w = ellipse width (in dots)	Values: 3 to 4095 (larger values are replaced with 4095) Default: value used for thickness (t) or 1
h = ellipse height (in dots)	Values: 3 to 4095 Default: value used for thickness (t) or 1
t = border thickness (in dots)	Values: 2 to 4095 Default: 1
c = line color	Values: B = black W = white Default: B



Example: This is an example of how to create a ellipse on a printed label:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^FO100,100 ^GE300,100,10,B^FS ^XZ </pre>	

^GF – Graphic Field

The ^GF command allows you to download graphic field data directly into the printer's bitmap storage area. This command follows the conventions for any other field, meaning a field orientation is included. The graphic field data can be placed at any location within the bitmap space.

Format: ^GFa,b,c,d,data

Parameters	Details
a = compression type	<p>Values:</p> <ul style="list-style-type: none"> A = ASCII hexadecimal (follows the format for other download commands) B = binary (data sent after the c parameter is strictly binary) C = compressed binary (data sent after the c parameter is in compressed binary format. The data is compressed on the host side using Zebra's compression algorithm. The data is then decompressed and placed directly into the bitmap.) <p>Default: A</p>
b = binary byte count	<p>Values: 1 to 99999</p> <p>This is the total number of bytes to be transmitted for the total image or the total number of bytes that follow parameter d. For ASCII download, the parameter should match parameter c. Out-of-range values are set to the nearest limit.</p> <p>Default: command is ignored if a value is not specified</p>
c = graphic field count	<p>Values: 1 to 99999</p> <p>This is the total number of bytes comprising the graphic format (width x height), which is sent as parameter d. Count divided by bytes per row gives the number of lines in the image. This number represents the size of the image, not necessarily the size of the data stream (see d).</p> <p>Default: command is ignored if a value is not specified</p>
d = bytes per row	<p>Values: 1 to 99999</p> <p>This is the number of bytes in the downloaded data that comprise one row of the image.</p> <p>Default: command is ignored if a value is not specified</p>
data = data	<p>Values:</p> <p>ASCII hexadecimal data: 00 to FF</p> <p>A string of ASCII hexadecimal numbers, two digits per image byte. CR and LF can be inserted as needed for readability. The number of two-digit number pairs must match the above count. Any numbers sent after count is satisfied are ignored. A comma in the data pads the current line with 00 (white space), minimizing the data sent. ~DN or any caret or tilde character prematurely aborts the download.</p> <p>Binary data: Strictly binary data is sent from the host. All control prefixes are ignored until the total number of bytes needed for the graphic format is sent.</p>



Example: This example downloads 8,000 total bytes of data and places the graphic data at location 100,100 of the bitmap. The data sent to the printer is in ASCII form.

^F0100,100^GFA,8000,8000,80,ASCII data



Example: This example downloads 8,000 total bytes of data and places the graphic data at location 100,100 of the bitmap. The data sent to the printer is in binary form.

^F0100,100^GFB,8000,8000,80,Binary data

^GS – Graphic Symbol

The ^GS command enables you to generate the registered trademark, copyright symbol, and other symbols.

Format: ^GS o,h,w

Parameters	Details
o = field orientation	Values: N = normal R = rotate 90 degrees clockwise I = inverted 180 degrees B = bottom-up, 270 degrees Default: N or last ^FW value
h = character height proportional to width (in dots)	Values: 0 to 32000 Default: last ^CF value
w = character width proportional to height (in dots)	Values: 0 to 32000 Default: last ^CF value



Example: Use the ^GS command followed by ^FD and the appropriate character (A through E) within the field data to generate the desired character:

ZPL II CODE	GENERATED LABEL
<pre> ^XA^CFD ^FO50,50 ^FDZEBRA PROGRAMMING^FS ^FO50,75 ^FDLANGUAGE II (ZPL II)^FS ^FO280,75 ^GS^FDC^FS ^XZ </pre>	

A = ® (Registered Trade Mark)

B = © (Copyright)

C = ™ (Trade Mark)

D = UL (Underwriters Laboratories approval)

E = S (Canadian Standards Association approval)

~HB – Battery Status

When the ~HB command is sent to the printer, a data string is sent back to the host. The string starts with an <STX> control code sequence and terminates by an <ETX><CR><LF> control code sequence.



Important • This command only responds to mobile printers.

Format: ~HB

Parameters: when the printer receives the command, it returns:

<STX>bb.bb, hh.hh, bt<ETX><CR><LF>

<STX>	=	ASCII start-of-text character
bb.bb	=	current battery voltage reading to the nearest 1/4 volt
hh.hh	=	current head voltage reading to the nearest 1/4 volt
bt	=	battery temperature in Celsius
<ETX>	=	ASCII end-of-text character
<CR>	=	ASCII carriage return
<LF>	=	ASCII line feed character

Comments This command is used for the power-supply battery of the printer and should not be confused with the battery backed-up RAM.

~HD - Head Diagnostic

The ~HD command echoes printer status information that includes the power supply and head temperature using the terminal emulator.

Format: ~HD



Example: This is an example of the ~HD command:

```
Head Temp = 29
Ambient Temp = 00
Head Test = Passed
Darkness Adjust = 23
Print Speed = 2
Slew Speed = 6
Backfeed Speed = 2
Static_pitch_length = 0521
Dynamic_pitch_length = 0540
Max_dynamic_pitch_length = 0540
Min_dynamic_pitch_length = 0537
COMMAND PFX = ~ : FORMAT PFX = ^ : DELIMITER = ,
P30 INTERFACE = None
P31 INTERFACE = None
P32 INTERFACE = Front Panel           Revision 5
P33 INTERFACE = None
P34 INTERFACE = None
P35 INTERFACE = None
Dynamic_top_position = 0008
No ribbon A/D = 0000
```

^HF – Host Format

The ^HF command sends stored formats to the host.

Format: ^HFd,o,x

Parameters	Details
d = device to recall image	Values: R:, E:, B:, and A: Default: R:
o = image name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Fixed Value: .ZPL



Example: This example shows the sequence and results.

Using a terminal emulator, you download this code to the printer:

```
^XA
^DFB:FILE1.ZPL
^F0100,100^A0,100
^FDTEST^FS
^XZ
```

Then you send this code to the printer:

```
^XA
^HFB:FILE1.ZPL
^XZ
```

The terminal emulator returns this code:

```
^XA^DFFILE1,
^F0100,100^A0,100^FDTEST^FS
^XZ
```

^HG – Host Graphic

The ^HG command is used to upload graphics to the host. The graphic image can be stored for future use, or it can be downloaded to any Zebra printer.

Format: ^HGd:o.x

Parameters	Details
d = device location of object	Values: R:, E:, B:, and A: Default: search priority
o = object name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Fixed Value: .GRF

Comments For more information on uploading graphics, see [^HY on page 215](#).

^HH – Configuration Label Return

The ^HH command echoes printer configuration back to the host, using a terminal emulator.

Format: ^HH



Example: This is an example of what is returned to the host when ^XA^HH^XZ is sent to the printer:

```

+10          DARKNESS
+000        TEAR OFF
TEAR OFF    PRINT MODE
NON-CONTINUOUS MEDIA TYPE
WEB        SENSOR TYPE
DIRECT-THERMAL PRINT METHOD
050 6/8 MM PRINT WIDTH
0622      LABEL LENGTH
22.01IN   557MM MAXIMUM LENGTH
9600      BAUD
8 BITS    DATA BITS
NONE      PARITY
XON/XOFF  HOST HANDSHAKE
NONE      PROTOCOL
000       NETWORK ID
NORMAL MODE COMMUNICATIONS
<~> 7EH  CONTROL PREFIX
<^> 5EH  FORMAT PREFIX
<,> 2CH  DELIMITER CHAR
ZPL II    ZPL MODE
NO MOTION MEDIA POWER UP
NO MOTION HEAD CLOSE
DEFAULT  BACKFEED
+000     LABEL TOP
+0000    LEFT POSITION
026     WEB S.
068     MEDIA S.
050     MARK S.
001     MARK MED S.
CS      MODES ENABLED
--      MODES DISABLED
864 8/MM FULL RESOLUTION
U32.10.2 <-  FIRMWARE
U2.2.6.98.A HARDWARE ID
CUSTOMIZED CONFIGURATION
1024.....R: RAM
8192.....B: MEMORY CARD
0768.....E: ONBOARD FLASH
NONE      FORMAT CONUERT
NONE      OPTION
05/14/03  RTC DATE
02:23    RTC TIME
DYNAMIC  IP RESOLUTION
ALL      IP PROTOCOL
010.003.005.090 IP ADDRESS
255.255.255.000 SUBNET MASK
010.003.005.001 DEFAULT GATEWAY

```

~HI – Host Identification

The ~HI command is designed to be sent from the host to the Zebra printer to retrieve information. Upon receipt, the printer responds with information on the model, software version, dots-per-millimeter setting, memory size, and any detected options.

Format: ~HI

When the printer receives this command, it returns:

XXXXXX,V1.0.0,dpm,000KB,X

XXXXXX = model of Zebra printer

V1.0.0 = version of software

dpm = dots/mm

6, 8, 12, or 24 dots/mm printheads

000KB = memory

512KB = 1/2 MB

1024KB = 1 MB

2048KB = 2 MB

4096KB = 4 MB

8192KB = 8 MB

x = recognizable options

only options specific to printer are shown (cutter, options, et cetera.)

~HM – Host RAM Status


Sending ~HM to the printer immediately returns a memory status message to the host. Use this command whenever you need to know the printer's RAM status.

When ~HM is sent to the Zebra printer, a line of data containing information on the total amount, maximum amount, and available amount of memory is sent back to the host.

Format: ~HM



Example: This example shows when the ~HM is sent to the printer, a line of data containing three numbers are sent back to the host. Each set of numbers is identified and explained in the table that follows:



1	The total amount of RAM (in kilobytes) installed in the printer. In this example, the printer has 1024K RAM installed.
2	The maximum amount of RAM (in kilobytes) available to the user. In this example, the printer has a maximum of 780K RAM available.
3	The amount of RAM (in kilobytes) currently available to the user. In this example, there is 780K of RAM in the printer currently available to the user.

Comments Memory taken up by bitmaps is included in the currently available memory value (due to ^MCN).

Downloading a graphic image, fonts, or saving a bitmap affects only the amount of RAM. The total amount of RAM and maximum amount of RAM does not change after the printer is turned on.

~HQ – Host Query

The ~HQ command group causes the printer to send information back to the host.

Supported Devices

- Xi4, RXi4
- ZM400/ZM600 with v53.17.1Z or later, RZ400/RZ600
- S4M with v53.17.1Z or later
- G-Series with v56.16.5 or later
or
G-Series with v61.16.5 or later

Format: ~HQquery-type

Parameter	Details
query-type	<p>For detailed examples of these parameters, see ~HQ Examples on page 202.</p> <p>Values:</p> <ul style="list-style-type: none"> ES = requests the printer's status - see Table 14 on page 201 and Table 15 on page 202 HA = hardware address of the internal wired print server JT = requests a summary of the printer's printhead test results MA = maintenance alert settings MI = maintenance information OD = odometer PH = printhead life history PP = printer's Plug and Play string SN = printer's serial number UI = USB product ID and BDC release version <p>Default: must be an accepted value or the command is ignored</p>

Comments The response to the ~HQ command starts with STX, a CR LF is inserted between each line, and the response ends with ETX.

Table 14 • Error Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16-9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
No Error	0	00000000	0	0	0	0	0	0	0	0
Error Present	1	00000000	X	X	X	X	X	X	X	X
Printhead Thermistor Open	1	00000000	X	X	X	X	X	2	X	X
Invalid Firmware Config.	1	00000000	X	X	X	X	X	1	X	X
Printhead Detection Error	1	00000000	X	X	X	X	X	X	8	X
Bad Printhead Element	1	00000000	X	X	X	X	X	X	4	X
Motor Over Temperature	1	00000000	X	X	X	X	X	X	2	X
Printhead Over Temperature	1	00000000	X	X	X	X	X	X	1	X

g. This error flag is supported only on KR403 printers.

Table 14 • Error Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16-9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
Cutter Fault	1	00000000	X	X	X	X	X	X	X	8
Head Open	1	00000000	X	X	X	X	X	X	X	4
Ribbon Out	1	00000000	X	X	X	X	X	X	X	2
Media Out	1	00000000	X	X	X	X	X	X	X	1
Clear Paper Path Failed ^g	1 ^g	00000000	X	X	X	X	8 ^g	X	X	X
Paper Feed Error ^g	1 ^g	00000000	X	X	X	X	4 ^g	X	X	X
Presenter Not Running ^g	1 ^g	00000000	X	X	X	X	2 ^g	X	X	X
Paper Jam during Retract ^g	1 ^g	00000000	X	X	X	X	1 ^g	X	X	X
Black Mark not Found ^g	1 ^g	00000000	X	X	X	8 ^g	X	X	X	X
Black Mark Calabrate Error ^g	1 ^g	00000000	X	X	X	4 ^g	X	X	X	X
Retract Function timed out ^g	1 ^g	00000000	X	X	X	2 ^g	X	X	X	X
Paused ^g	1 ^g	00000000	X	X	X	1 ^g	X	X	X	X

^g. This error flag is supported only on KR403 printers.

Table 15 • Warning Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16-9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
No Warning	0	00000000	0	0	0	0	0	0	0	0
Warning Present	1	00000000	X	X	X	X	X	X	X	X
Paper-near-end Sensor ^h	1 ^h	00000000	X	X	X	X	X	X	X	8 ^h
Replace Printhead	1	00000000	X	X	X	X	X	X	X	4
Clean Printhead	1	00000000	X	X	X	X	X	X	X	2
Need to Calibrate Media	1	00000000	X	X	X	X	X	X	X	1
Sensor 1 (Paper before head) ^h	1 ^h	00000000	X	X	X	X	X	X	1 ^h	X
Sensor 2 (Black mark) ^h	1 ^h	00000000	X	X	X	X	X	X	2 ^h	X
Sensor 3 (Paper after head) ^h	1 ^h	00000000	X	X	X	X	X	X	4 ^h	X
Sensor 4 (loop ready) ^h	1 ^h	00000000	X	X	X	X	X	X	8 ^h	X
Sensor 5 (presenter) ^h	1 ^h	00000000	X	X	X	X	X	1 ^h	X	X
Sensor 6 (retract ready) ^h	1 ^h	00000000	X	X	X	X	X	2 ^h	X	X
Sensor 7 (in retract) ^h	1 ^h	00000000	X	X	X	X	X	4 ^h	X	X
Sensor 8 (at bin) ^h	1 ^h	00000000	X	X	X	X	X	8 ^h	X	X

^h. This error flag is supported only on KR403 printers.

~HQ Examples

This section provides detail examples of all the available parameters.



Example 1: This example shows how to request the printer's status.

a. To request the printer's status, type **~HQES**

The printer responds with data similar to this:


```

PRINTER STATUS
  ERRORS:      1 00000000 00000005
  WARNINGS:    1 00000000 00000002
    
```

In this example, the Printer Status resolves to these conditions:

- The cover/printhead is open (value = 4).
- Media is out or not loaded into the printer (value = 1).
- The printhead needs to be cleaned (value = 2).
- Error nibble 1 is equal to 5 when the error status values are added together (4 + 1).

This illustration identifies the printer status definitions:



1	Flag
2	Nibble 16-9
3	Nibble 8-4
4	Nibble 3
5	Nibble 2
6	Nibble 1



Example 2: This example shows how the printer responds when the printer receives the **~HQES** command:

a. To see how the printer responds, type **~HQES**

The printer responds with data similar to this:

```

PRINTER STATUS
  ERRORS:      1 00000000 0000000B
  WARNINGS:    0 00000000 00000000
    
```

In this example, the printer status resolves to the following conditions:

- The cutter has a fault (value = 8).
- Ribbon is out or not loaded into the printer (value = 2).
- Media is out or not loaded into the printer (value = 1).
- Error byte 1 is equal to **B** when the error status values are added together (8 + 2 + 1 = hexadecimal B).



Example 3: This is an example of how to retrieve the hardware address of the internal wired print server.

- a. To get the hardware address of the internal wired print server, type **~HQHA**

The printer responds with data similar to this:

```
MAC ADDRESS
00:07:4d:2c:e0:7a
```



Example 4: This is an example of how to request a summary of the printer's printhead test results.

The **^JT** command is used to initiate printhead testing, set the testing interval, and set the element range to be tested. For more details see, [^JT on page 248](#).

- a. To request a summary of the printer's printhead test, type **~HQJT**

The printer responds with data similar to this:

```
PRINT HEAD TEST RESULTS
0,A,0000,0000,0000
```


When the printer has printed enough labels to trigger a printhead test, the initial data changes.

- b. To request a summary of the printer's printhead test, type **~HQJT**

The printer responds with data similar to this:

```
PRINT HEAD TEST RESULTS:
0,A,0015,0367,0000
```

This illustration identifies the printhead test field definitions:



1	Element failure
2	Manual (M) or automatic (A) range
3	First test element
4	Last test element
5	Failure count

➔ **Example 5:** This is an example of how to use the maintenance alert query for the ~HQ command.

- a. To get the current settings, type ~HQMA
The printer responds with data similar to this:

```
~HQMA
MAINTENANCE ALERT SETTINGS
HEAD REPLACEMENT INTERVAL:      1 km
HEAD REPLACEMENT FREQUENCY:     0 M
HEAD CLEANING INTERVAL:         0 M
HEAD CLEANING FREQUENCY:        0 M
PRINT REPLACEMENT ALERT:        NO
PRINT CLEANING ALERT:           NO
UNITS:                           C
```

➔ **Example 6:** This is an example of how to use the maintenance information query for the ~HQ command. Note that the message is controlled by the ^MI command.

- a. To get the current settings, type ~HQMI
The printer responds with data similar to this:

```
MAINTENANCE ALERT MESSAGES
CLEAN: PLEASE CLEAN PRINT HEAD
REPLACE: PLEASE REPLACE PRINT HEAD
```

➔ **Example 7:** This is an example of how to use the odometer query for the ~HQ command. Note that the units of measure are controlled by the ^MA command. Also, if the "Early Warning Maintenance State" is turned "ON" the printer response would also list LAST CLEANED and CURRENT PRINthead LIFE counters.

- a. To get the current settings, type ~HQOD
The printer responds with data similar to this:

```
PRINT METERS
TOTAL NONRESETTABLE:      8560 "
USER RESETTABLE CNTR1:    9 "
USER RESETTABLE CNTR2:    8560 "
```

The units of measure are set to inches.

- b. To change the units of measure to centimeters, type:

```
^XA^MA,,,C
^XZ
```

The units of measure are set to centimeters.

- c. To check the settings, type ~HQOD
The printer responds with data similar to this:

```
PRINT METERS
TOTAL NONRESETTABLE:      21744 cm
USER RESETTABLE CNTR1:    24 cm
USER RESETTABLE CNTR2:    21744 cm
```

➔ **Example 8:** This is an example of how to use the printhead life query for the **~HQ** command. Note that the units of measure are controlled by the **^MA** command.

- a. To get the current settings, type **~HQPH**
The printer responds with data similar to this:

```

LAST CLEANED: 257 "
HEAD LIFE HISTORY
#   DISTANCE
1:   257 "
2:  1489 "
3:  7070 "
    
```

1	The current life of the print head.
2	Line items 2 through 10 (the example only shows 2 through 3) tracks the measurement for each time the print head is changed.

➔ **Example 9:** This is an example of how to request the printer's Plug and Play string.

- a. To request the printer's Plug and Play string, type **~HQPP**
The printer responds with data similar to this:

```

PLUG AND PLAY MESSAGES
MFG: Zebra Technologies
CMD: ZPL
MDL: GX420t
    
```

➔ **Example 10:** This is an example of how to retrieve the printer's serial number.

- a. To get the printer's serial number, type **~HQSN**
The printer responds with data similar to this:

```

SERIAL NUMBER
41A06440023
    
```

➔ **Example 11:** This is an example of how to retrieve the printer's USB product ID and BCD release version.

- a. To get the printer's USB product ID and BCD release version, type **~HQUI**
The printer responds with data similar to this:

```

USB INFORMATION
PID:                               0085
RELEASE VERSION:                   15.01
    
```

~HS – Host Status Return

When the host sends ~HS to the printer, the printer sends three data strings back. Each string starts with an <STX> control code and is terminated by an <ETX><CR><LF> control code sequence. To avoid confusion, the host prints each string on a separate line.



Note • When a ~HS command is sent the printer will not send a response to the host if the printer is in one of these conditions:

- MEDIA OUT
- RIBBON OUT
- HEAD OPEN
- REWINDER FULL
- HEAD OVER-TEMPERATURE

String 1 <STX>aaa,b,c,dddd,eee,f,g,h,iii,j,k,l<ETX><CR><LF>

aaa	=	communication (interface) settings ^a
b	=	paper out flag (1 = paper out)
c	=	pause flag (1 = pause active)
dddd	=	label length (value in number of dots)
eee	=	number of formats in receive buffer
f	=	<i>buffer full</i> flag (1 = receive buffer full)
g	=	<i>communications diagnostic mode</i> flag (1 = diagnostic mode active)
h	=	<i>partial format</i> flag (1 = partial format in progress)
iii	=	unused (always 000)
j	=	<i>corrupt RAM</i> flag (1 = configuration data lost)
k	=	temperature range (1 = under temperature)
l	=	temperature range (1 = over temperature)

-
- i.** This string specifies the printer's baud rate, number of data bits, number of stop bits, parity setting, and type of handshaking. This value is a three-digit decimal representation of an eight-bit binary number. To evaluate this parameter, first convert the decimal number to a binary number.

The nine-digit binary number is read according to this table:

aaa = a ⁸ a ⁷ a ⁶ a ⁵ a ⁴ a ³ a ² a ¹ a ⁰	
a ⁷ = Handshake 0 = Xon/Xoff 1 = DTR	a ⁸ a ² a ¹ a ⁰ = Baud 0 000 = 110 0 001 = 300 0 010 = 600 0 011 = 1200 0 100 = 2400 0 101 = 4800 0 110 = 9600 0 111 = 19200 1 000 = 28800 (available only on certain printer models) 1 001 = 38400 (available only on certain printer models) 1 010 = 57600 (available only on certain printer models) 1 011 = 14400
a ⁶ = Parity Odd/Even 0 = Odd 1 = Even	
a ⁵ = Disable/Enable 0 = Disable 1 = Enable	
a ⁴ = Stop Bits 0 = 2 Bits 1 = 1 Bit	
a ³ = Data Bits 0 = 7 Bits 1 = 8 Bits	

String 2 <STX>mmm,n,o,p,q,r,s,t,uuuuuuuu,v,www<ETX><CR><LF>

mmm	= function settings ^j
n	= unused
o	= <i>head up</i> flag (1 = head in up position)
p	= <i>ribbon out</i> flag (1 = ribbon out)
q	= <i>thermal transfer mode</i> flag (1 = Thermal Transfer Mode selected)
r	= Print Mode <ul style="list-style-type: none"> 0 = Rewind 1 = Peel-Off 2 = Tear-Off 3 = Cutter 4 = Applicator 5 = Delayed cut 6 = Linerless Peel 7 = Linerless Rewind 8 = Partial Cutter 9 = RFID K = Kiosk S = Stream
s	= print width mode
t	= <i>label waiting</i> flag (1 = label waiting in Peel-off Mode)
uuuuuuuu	= labels remaining in batch
v	= <i>format while printing</i> flag (always 1)
www	= number of graphic images stored in memory

.14†

Values 4 to 5 are only supported in firmware version V60.14.x, V50.14.x, V53.15.x, or later.

j. This string specifies the printer's media type, sensor profile status, and communication diagnostics status. As in String 1, this is a three-digit decimal representation of an eight-bit binary number. First, convert the decimal number to a binary number.

k. These values are only supported on the ZE500, Xi4, RXi4, ZM400/ZM600, and RZ400/RZ600 printers.

The eight-digit binary number is read according to this table:

mmm = m7 m6 m5 m4 m3 m2 m1 m0	
m7 = Media Type 0 = Die-Cut 1 = Continuous	m4 m3 m2 m1 = Unused 0 = Off 1 = On
m6 = Sensor Profile 0 = Off	m0 = Print Mode 0 = Direct Thermal 1 = Thermal Transfer
m5 = Communications Diagnostics 0 = Off 1 = On	

String 3 <STX>xxxx,y<ETX><CR><LF>

xxxx = password

y = 0 (static RAM not installed)
 1 (static RAM installed)

[^]HT – Host Linked Fonts List



This command is available only for printers with firmware version V60.14.x, V50.14.x, or later.

The [^]HT command receives the complete list of font links over a communication port.



Example: The **SWISS.721.TTF** is the base font, **ANMDJ.TTF** is the first linked font, and **MSGOTHIC.TTF** is the second linked font:

ZPL II CODE	DATA RETURNED
[^] XA [^] HT [^] XZ	LIST OF FONT LINKS E:SWISS721.TTF E:ANMDJ.TTF E:MSGOTHIC.TTF

This is the code that was used to establish the font links:

```

^XA
^FLE:ANMDJ.TTF,E:SWISS721.TTF,1^FS
^FLE:MSGOTHIC.TTF,E:SWISS721.TTF,1^FS
^XZ
    
```

~HU – Return ZebraNet Alert Configuration

This command returns the table of configured ZebraNet Alert settings to the host.

Format: ~HU



Example: If the ~HU command is sent to the printer with existing Alert messages set to go to e-mail and SNMP traps, the data returned would look something like the information below. See [^SX](#) on page 324 for complete information on the individual parameter settings.

```
B, C, Y, Y, ADMIN@COMPANY.COM, 0
J, F, Y, Y, , 0
C, F, Y, Y, , 0
D, F, Y, Y, , 0
E, F, Y, N, , 0
F, F, Y, N, , 0
H, C, Y, N, ADMIN@COMPANY.COM, 0
N, C, Y, Y, ADMIN@COMPANY.COM, 0
O, C, Y, Y, ADMIN@COMPANY.COM, 0
P, C, Y, Y, ADMIN@COMPANY.COM, 0
```



Important • If there are no ^SX (alerts) set, the printer will not respond to the ~HU command.

The first line indicates that condition B (ribbon out) is routed to destination C (e-mail address).

The next two characters, Y and Y, indicate that the *condition set* and *condition clear* options have been set to **yes**.

The following entry is the destination that the Alert e-mail should be sent to; in this example it is **admin@company.com**.

The last figure seen in the first line is 0, which is the port number.

Each line shows the settings for a different Alert condition as defined in the ^SX command.

^HV – Host Verification

Use this command to return data from specified fields, along with an optional ASCII header, to the host computer. You can use this command with any field that has been assigned a number with the ^RT command or with the ^FN and ^RF commands.

Format: ^HV# , n , h , t , a

Parameters	Details
# = field number specified with another command	The value assigned to this parameter should be the same as the one used in another command. Values: 0 to 9999 Default: 0
n = number of bytes to be returned	Values: 1 to 256 Default: 64
h = header to be returned with the data	Delimiter characters terminate the string. This field is Field Hex (^FH) capable. Values: 0 to 3072 bytes Default: no header
t = termination	This field is Field Hex (^FH) capable. Values: 0 to 3072 characters
a = command applies to	When ^PQ is greater than 1 or if a void label occurs, send one response for a label format or one for every label printed. Values: F = Format L = Label Default: F



Example: The following code:

```
^XA
.
.
.
^FH_^HV0,8,EPC[, ]_0D_0A,L^FS
^PQ2
^XZ
```

Would return data similar to this:

```
EPC[12345678]
EPC[55554444]
```

^HW – Host Directory List

^HW is used to transmit a directory listing of objects in a specific memory area (storage device) back to the host device. This command returns a formatted ASCII string of object names to the host.

Each object is listed on a line and has a fixed length. The total length of a line is also fixed. Each line listing an object begins with the asterisk (*) followed by a blank space. There are eight spaces for the object name, followed by a period and three spaces for the extension. The extension is followed by two blank spaces, six spaces for the object size, two blank spaces, and three spaces for option flags (reserved for future use). The format looks like this:

```
<STX><CR><LF>
DIR R: <CR><LF>
*Name.ext(2sp.)(6 obj. sz.)(2sp.)(3 option flags)
*Name.ext(2sp.)(6 obj. sz.)(2sp.)(3 option flags)
<CR><LF>
-xxxxxxx bytes free
<CR><LF>
<ETX>
<STX> = start of text
<CR><LR> = carriage return/line feed
<ETX> = end on text
```

The command might be used in a stand-alone file to be issued to the printer at any time. The printer returns the directory listing as soon as possible, based on other tasks it might be performing when the command is received.

This command, like all ^ (caret) commands, is processed in the order that it is received by the printer.

Format: ^HwD:o.x

Parameters	Details
d = location to retrieve object listing	Values: R:, E:, B:, A: and Z: Default: R:
o = object name	Values: 1 to 8 alphanumeric characters Default: asterisk (*). A question mark (?) can also be used.
x = extension	Values: any extension conforming to Zebra conventions Default: asterisk (*). A question mark (?) can also be used.
f = format	Values: c = column format d = default format Default: d

.161

The **f** parameter is only supported in firmware version V60.16.0Z and V53.16.0Z or later.



Example: Listed is an example of the ^HW command to retrieve from information R:

```
^XA
^HWR:*. *
^XZ
```



Example: The printer returned this information as the Host Directory Listing: **-DIR R:*.***

```
*R:ARIALN1.FNT 49140
*R:ARIALN2.FNT 49140
*R:ARIALN3.FNT 49140
*R:ARIALN4.FNT 49140
*R:ARIALN.FNT 49140
*R:ZEBRA.GRF 8420
-794292 bytes free R:RAM
```

^HY – Upload Graphics

The ^HY command is an extension of the ^HG command. ^HY is used to upload graphic objects from the printer in any supported format.

Format: ^HYd:o.x

Parameters	Details
d = location of object	Values: R:, E:, B:, and A: Default: search priority
o = object name	Values: 1 to 8 alphanumeric characters Default: an object name must be specified
x = extension	Values: G = .GRF (raw bitmap format) P = .PNG (compressed bitmap format) Default: format of stored image

Comments The image is uploaded in the form of a ~DY command. The data field of the returned ~DY command is always encoded in the ZB64 format.

^HZ – Display Description Information

The ^HZ command is used for returning printer description information in XML format. The printer returns information on format parameters, object directories, individual object data, and print status information.

Format: ^HZb

Parameters	Details
b = display description to return	<p>Values:</p> <ul style="list-style-type: none"> a = display all information f = display printer format setting information l = display object directory listing information o = display individual object data information r = display printer status information <p>Default: if the value is missing or invalid, the command is ignored</p>

Format: ^HZ0,d:o,x,l

Parameters	Details
d = location of stored object	<p>Values: R:, E:, B:, and A:</p> <p>Default: R:</p>
o = object name	<p>Values: 1 to 8, or 1 to 16 alphanumeric characters based on parameter l.</p> <p>Default: if a name is not specified, UNKNOWN is used.</p>
x = extension	<p>Supported extensions for objects (parameter o) include:</p> <ul style="list-style-type: none"> .FNT — font .GRF — graphic .PNG — compressed graphic .ZPL — stored format .DAT — encoding table .ZOB — downloadable object .STO — Alert data file
l = long filename support	<p>Values:</p> <ul style="list-style-type: none"> Y = Yes If Y, the object data stores the filename as 16 characters. The data is only compatible with firmware version V60.13.0.5, or later. N = No If N, the object data stores the filename as 8 characters. The data is forward and backward compatible with all versions of firmware. <p>Default: N</p>



Example: This example shows the object data information for the object **SAMPLE.GRF** located on **R:**.

```
^XA
^HZ0,R:SAMPLE.GRF
^XZ
```


^ID – Object Delete

The ^ID command deletes objects, graphics, fonts, and stored formats from storage areas. Objects can be deleted selectively or in groups. This command can be used within a printing format to delete objects before saving new ones, or in a stand-alone format to delete objects.

The image name and extension support the use of the asterisk (*) as a wild card. This allows you to easily delete a selected groups of objects.

Format: ^IDd:o.x

Parameters	Details
d = location of stored object	Values: R:, E:, B:, and A: Default: R:
o = object name	Values: any 1 to 8 character name Default: if a name is not specified, UNKNOWN is used
x = extension	Values: any extension conforming to Zebra conventions Default: .GRF

→ **Example 1:** To delete stored formats from DRAM:

```
^XA
^IDR:*.ZPL^FS
^XZ
```

→ **Example 2:** To delete formats and images named SAMPLE from DRAM, regardless of the extension:

```
^XA
^IDR:SAMPLE.*^FS
^XZ
```

→ **Example 3:** To delete the image **SAMPLE1.GRF** prior to storing **SAMPLE2.GRF**:

```
^XA
^F025,25^AD,18,10
^FDDelete^FS
^F025,45^AD,18,10
^FDthen Save^FS
^IDR:SAMPLE1.GRF^FS
^ISR:SAMPLE2.GRF^FS^XZ
```

→ **Example 4:** In this the * is a wild card, indicating that all objects with the .GRF extension are deleted:

```
^XA
^IDR:*.GRF^FS
^XZ
```

Comments When an object is deleted from **R:**, the object can no longer be used and memory is available for storage. This applies only to **R:** memory. With the other memory types (**A:**, **B:**, **E:**) the deleted object is no longer available. The memory space recovers when an automatic defragmentation or initialization occurs.

The **^ID** command also frees up the uncompressed version of the object in DRAM.

If the name is specified as ***.ZOB**, all downloaded bar code fonts (or other objects) are deleted.

If the named downloadable object cannot be found in the **R:**, **E:**, **B:**, and **A:** device, the **^ID** command is ignored.

^IL – Image Load

The ^IL command is used at the beginning of a label format to load a stored image of a format and merge it with additional data. The image is always positioned at ^F00,0.



Important • See [^IS](#) on page 221.

Using this technique to overlay the image of constant information with variable data greatly increases the throughput of the label format.

Format: ^ILd:o.x

Parameters	Details
d = location of stored object	Values: R:, E:, B:, and A: Default: R:
o = object name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Fixed Value: .GRF, .PNG



Example: This example recalls the stored image **SAMPLE2.GRF** from DRAM and overlays it with the additional data. The graphic was stored using the ^IS command. For the stored label format, see the [^IS](#) on page 221 command.

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^ILR:SAMPLE2.GRF^FS ^CFD,36,20 ^FO15,210 ^FD900123^FS ^FO218,210 ^FDLINE 12^FS ^FO15,360^AD ^FDZEBRA THERMAL^FS ^FO15,400^AD ^FDTRANSFER PRINTER^FS ^FO15,540 ^FD54321^FS ^FO220,530 ^FDZ58643^FS ^FO15,670^A0,27,18 ^FDTesting Stored Graphic^FS ^FO15,700^A0,27,18 ^FDLabel Formats!!^FS ^XZ </pre>	<p>The generated label features the ZEBRA TECHNOLOGIES CORP logo at the top. Below the logo is a table with two columns: ARTICLE# (900123) and LOCATION (LINE 12). Underneath is a section for DESCRIPTION (ZEBRA THERMAL TRANSFER PRINTER). Another table follows with REG. NO. (54321) and WORK NUMBER (Z58643). At the bottom, there is a COMMENTS section containing the text: Testing Stored Graphic Label Formats!!</p>

^IM – Image Move

The ^IM command performs a direct move of an image from storage area into the bitmap. The command is identical to the ^XG command (Recall Graphic), except there are no sizing parameters.

Format: ^IMd:o.x

Parameters	Details
d = location of stored object	Values: R:, E:, B:, and A: Default: search priority
o = object name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Fixed Value: .GRF, .PNG



Example: This example moves the image **SAMPLE.GRF** from DRAM and prints it in several locations in its original size.

```

^XA
^FO100,100^IMR:SAMPLE.GRF^FS
^FO100,200^IMR:SAMPLE.GRF^FS
^FO100,300^IMR:SAMPLE.GRF^FS
^FO100,400^IMR:SAMPLE.GRF^FS
^FO100,500^IMR:SAMPLE.GRF^FS
^XZ

```

Comments By using the ^FO command, the graphic image can be positioned anywhere on the label.

The difference between ^IM and ^XG: ^IM does not have magnification, and therefore might require less formatting time. However, to take advantage of this, the image must be at a 8-, 16-, or 32-bit boundary.

^IS – Image Save

The ^IS command is used within a label format to save that format as a graphic image, rather than as a ZPL II script. It is typically used toward the end of a script. The saved image can later be recalled with virtually no formatting time and overlaid with variable data to form a complete label.

Using this technique to overlay the image of constant information with the variable data greatly increases the throughput of the label format.



Important • See [^L](#) on page 219.

Format: ^ISd:o.x,p

Parameters	Details
d = location of stored object	Values: R:, E:, B:, and A: Default: R:
o = object name	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension	Values: .GRF or .PNG Default: .GRF
p = print image after storing	Values: N = no Y = yes Default: Y



Example: This is an example of using the ^IS command to save a label format to DRAM. The name used to store the graphic is **SAMPLE2.GRF**.

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^LH10,15^FWN^BY3,3,85^CFD,36 ^GB430,750,4^FS ^FO10,170^GB200,144,2^FS ^FO10,318^GB410,174,2^FS ^FO212,170^GB206,144,2^FS ^FO10,498^GB200,120,2^FSR ^FO212,498^GB209,120,2^FS ^FO4,150^GB422,10,10^FS ^FO135,20^A0,70,60 ^FDZEBRA^FS ^FO80,100^A0,40,30 ^FDTECHNOLOGIES CORP^FS ^FO15,180^CFD,18,10^FS ^FDARTICLE#^FS ^FO218,180 ^FDLOCATION^FS ^FO15,328 ^FDDESCRIPTION^FS ^FO15,508 ^FDREQ.NO.^FS ^FO220,508 ^FDWORK NUMBER^FS ^FO15,630^AD,36,20 ^FDCOMMENTS:^FS ^ISR:SAMPLE2.GRF,Y ^XZ </pre>	<p>The generated label is a rectangular graphic with a rounded border. At the top, it reads 'ZEBRA TECHNOLOGIES CORP'. Below this is a table with two columns: 'ARTICLE#' and 'LOCATION'. Underneath is a larger section labeled 'DESCRIPTION'. Below that is another table with two columns: 'REQ. NO.' and 'WORK NUMBER'. At the bottom of the label is a section labeled 'COMMENTS:'.</p>

~JA – Cancel All

The ~JA command cancels all format commands in the buffer. It also cancels any batches that are printing.

The printer stops after the current label is finished printing. All internal buffers are cleared of data and the DATA LED turn off.

Submitting this command to the printer scans the buffer and deletes only the data before the ~JA in the input buffer — it does not scan the remainder of the buffer for additional ~JA commands.

Format: ~JA

^JB – Initialize Flash Memory

The ^JB command is used to initialize various types of Flash memory available in the Zebra printers.

Format: ^JBa

Parameters	Details
a = device to initialize	<p>Values:</p> <ul style="list-style-type: none">A = Option Flash memoryB = Flash card (PCMCIA)E = internal Flash memory <p>Default: a device must be specified</p>



Example: This is an example of initializing the different types of flash memory:

- ^JBA – initializes initial Compact Flash memory when installed in the printer.
- ^JBB – initializes the optional Flash card when installed in the printer.
- ^JBE – initializes the optional Flash memory when installed in the printer.



Note • Initializing memory can take several minutes. Be sure to allow sufficient time for the initialization to complete before power cycling the printer.

~JB – Reset Optional Memory

The ~JB command is used for these conditions:

- The ~JB command must be sent to the printer if the battery supplying power to the battery powered memory card fails and is replaced. A bad battery shows a *battery dead* condition on the Printer Configuration Label.
- The ~JB command can also be used to intentionally clear (reinitialize) the **B**: memory card. The card must **not** be write protected.

Format: ~JB

Comments If the battery is replaced and this command is not sent to the printer, the memory card cannot function.

~JC – Set Media Sensor Calibration

The ~JC command is used to force a label length measurement and adjust the media and ribbon sensor values.

Format: ~JC

Comments In Continuous Mode, only the media and ribbon sensors are calibrated.

This command is ignored on the HC100™ printer.

~JD - Enable Communications Diagnostics

The ~JD command initiates Diagnostic Mode, which produces an ASCII printout (using current label length and full width of printer) of all characters received by the printer. This printout includes the ASCII characters, the hexadecimal value, and any communication errors.

Format: ~JD

~JE - Disable Diagnostics

The ~JE command cancels Diagnostic Mode and returns the printer to normal label printing.

Format: ~JE

~JF – Set Battery Condition

There are two low battery voltage levels sensed by the *PA/PT400*™ printers. When battery voltage goes below the first level, the green LED begins flashing as a warning but printing continues. When this warning occurs, it is recommended to recharge the battery.

As printing continues, a second low voltage level is reached. At this point, both green and orange LEDs flash as a warning, and printing automatically pauses.

When pause on low voltage is active (~JFY) and the battery voltage level falls below the second *low voltage* level, printing pauses and an error condition is displayed as an indication that the printer should be plugged into the battery charger. By pressing FEED, printing continues on a label-by-label basis, but there is a high risk of losing label format information due to the continued decrease of battery voltage.

When pause on low voltage is not active (~JFN), and the battery voltage level falls below the second *low voltage* level, printing continues and the orange LED remains off. If the battery voltage continues to decrease, label information could be lost and cause the printer to stop operating. This option should be selected only when the printer is connected to the Car Battery Adapter. From time to time the printer might sense that battery voltage is below the first *low voltage* level, but due to the continuous recharging of the car battery, further loss of battery voltage is not a concern and printing continues.

If this option is not selected when using the Car Battery Adapter, you might need to press FEED to take the printer out of Pause Mode and print each label.

Format: ~JFp

Parameters	Details
p = pause on low voltage	Values: Y (pause on low voltage) or N (do not pause) N is suggested when the printer is powered by the Car Battery Adapter. Default: Y


~JG - Graphing Sensor Calibration

The ~JG command prints a graph (media sensor profile) of the sensor values.

Format: ~JG



Example: Sending the ~JG command to a printer configured for thermal transfer produces a series of labels resembling this image:



Comments The HC100™ printer does not perform a calibration, but does print a sensor profile label.

^JH – Early Warning Settings


The ^JH command configures the early warning messages that appear on the LCD.

Supported Devices

- ZE500 series
- *XiII*, *XiIIPlus*, *Xi4*, *RXi4*
- *PAX3*, *PAX4*
- ZM400, ZM600, RZ400, RZ600
- S4M
- G-Series ("f" parameter only)

Format: ^JHa,b,c,d,e,f,g,h,i,j

Parameter	Details
a = early warning media a = supplies warning (<i>Xi4</i> and <i>RXi4</i> printers only)	This parameter is for <i>XiIIPlus</i> , <i>Xi4</i> , <i>RXi4</i> , <i>PAX3</i> , and <i>PAX4</i> printers only. Values: E = enable D = disable Default: D
b = labels per roll	This parameter is for <i>XiIIPlus</i> , <i>PAX3</i> , and <i>PAX4</i> printers only. Values: 100 to 9999 Default: 900
c = media replaced	This parameter is for <i>XiIIPlus</i> , <i>PAX3</i> , and <i>PAX4</i> printers only. Values: Y = yes N = no Default: N

Parameter	Details																																				
d = ribbon length	<p>This parameter is for <i>XIIIPlus</i>, <i>PAX3</i>, <i>PAX4</i>, and ZE500 printers only.</p> <p>Values:</p> <p><i>XIIIPlus</i> series printers:</p> <table> <tr> <td>N = 0M</td> <td>4 = 300M</td> </tr> <tr> <td>0 = 100M</td> <td>5 = 350M</td> </tr> <tr> <td>1 = 150M</td> <td>6 = 400M</td> </tr> <tr> <td>2 = 200M</td> <td>7 = 450M</td> </tr> <tr> <td>3 = 250M</td> <td></td> </tr> </table> <p>PAX series printers:</p> <table> <tr> <td>N = 0M</td> <td>7 = 450M</td> </tr> <tr> <td>0 = 100M</td> <td>10 = 600M</td> </tr> <tr> <td>1 = 150M</td> <td>11 = 650M</td> </tr> <tr> <td>2 = 200M</td> <td>12 = 700M</td> </tr> <tr> <td>3 = 250M</td> <td>13 = 750M</td> </tr> <tr> <td>4 = 300M</td> <td>14 = 800M</td> </tr> <tr> <td>5 = 350M</td> <td>15 = 850M</td> </tr> <tr> <td>6 = 400M</td> <td>16 = 900M</td> </tr> </table> <p>ZE500 series printers:</p> <table> <tr> <td>N = 0M</td> <td>4 = 300M</td> </tr> <tr> <td>0 = 100M</td> <td>5 = 350M</td> </tr> <tr> <td>1 = 150M</td> <td>6 = 400M</td> </tr> <tr> <td>2 = 200M</td> <td>7 = 450M</td> </tr> <tr> <td>3 = 250M</td> <td>10 = 600M</td> </tr> </table> <p>Default:</p> <p>1 - for 96<i>XIIIPlus</i> 7 - for all other printers</p>	N = 0M	4 = 300M	0 = 100M	5 = 350M	1 = 150M	6 = 400M	2 = 200M	7 = 450M	3 = 250M		N = 0M	7 = 450M	0 = 100M	10 = 600M	1 = 150M	11 = 650M	2 = 200M	12 = 700M	3 = 250M	13 = 750M	4 = 300M	14 = 800M	5 = 350M	15 = 850M	6 = 400M	16 = 900M	N = 0M	4 = 300M	0 = 100M	5 = 350M	1 = 150M	6 = 400M	2 = 200M	7 = 450M	3 = 250M	10 = 600M
N = 0M	4 = 300M																																				
0 = 100M	5 = 350M																																				
1 = 150M	6 = 400M																																				
2 = 200M	7 = 450M																																				
3 = 250M																																					
N = 0M	7 = 450M																																				
0 = 100M	10 = 600M																																				
1 = 150M	11 = 650M																																				
2 = 200M	12 = 700M																																				
3 = 250M	13 = 750M																																				
4 = 300M	14 = 800M																																				
5 = 350M	15 = 850M																																				
6 = 400M	16 = 900M																																				
N = 0M	4 = 300M																																				
0 = 100M	5 = 350M																																				
1 = 150M	6 = 400M																																				
2 = 200M	7 = 450M																																				
3 = 250M	10 = 600M																																				
e = ribbon replaced	<p>This parameter is for <i>XIIIPlus</i>, <i>PAX3</i>, and <i>PAX4</i> printers only.</p> <p>Values:</p> <p>Y = yes N = no</p> <p>Default: N</p>																																				
f = early warning maintenance	<p>This parameter is for Xi4, RXi4, <i>PAX4</i>, ZM400, ZM600, RZ400, RZ600, and S4M printers only.</p> <p>Values:</p> <p>E = enabled D = disabled</p> <p>Default: D</p> <p> Important • On G-Series printers, this parameter must be enabled for the ^MA driven system to work.</p>																																				

Parameter	Details																						
g = head cleaning interval	<p>Accepted value exceptions: accepted values for <i>XiIII</i> printer are 100M through 450M; accepted values for 600 dpi <i>XiIII</i> printers are 100M through 150M; accepted values for <i>PAX4</i> series printers are up to 900M by increments of 50M; accepted values for ZM400/ZM600, RZ400/RZ600, and S4M printers are 0M through 450M.</p> <p>Values:</p> <table> <tr> <td>0 = 100M</td> <td>11 = 650M</td> </tr> <tr> <td>1 = 150M</td> <td>12 = 700M</td> </tr> <tr> <td>2 = 200M</td> <td>13 = 750M</td> </tr> <tr> <td>3 = 250M</td> <td>14 = 800M</td> </tr> <tr> <td>4 = 300M</td> <td>15 = 850M</td> </tr> <tr> <td>5 = 350M</td> <td>16 = 900M</td> </tr> <tr> <td>6 = 400M</td> <td></td> </tr> <tr> <td>7 = 450M</td> <td></td> </tr> <tr> <td>8 = 500M</td> <td></td> </tr> <tr> <td>9 = 550M</td> <td></td> </tr> <tr> <td>10 = 600M</td> <td></td> </tr> </table> <p>Default: 1 - for 96<i>XiIIIPlus</i> 7 - for all other printers</p>	0 = 100M	11 = 650M	1 = 150M	12 = 700M	2 = 200M	13 = 750M	3 = 250M	14 = 800M	4 = 300M	15 = 850M	5 = 350M	16 = 900M	6 = 400M		7 = 450M		8 = 500M		9 = 550M		10 = 600M	
0 = 100M	11 = 650M																						
1 = 150M	12 = 700M																						
2 = 200M	13 = 750M																						
3 = 250M	14 = 800M																						
4 = 300M	15 = 850M																						
5 = 350M	16 = 900M																						
6 = 400M																							
7 = 450M																							
8 = 500M																							
9 = 550M																							
10 = 600M																							
h = head clean	<p>Values: N = No Y = Yes</p> <p>Default: N</p>																						
i = head life threshold	<p>Values: 0 – 0 in or off 100-3500000 in</p> <p>Default: 1000000</p>																						
j = head replaced	<p>Values: N = no Y = yes</p> <p>Default: N</p>																						

Comments To permanently save the changes to the ^JH command, send ^XA^JUS^XZ.

^JI – Start ZBI (Zebra BASIC Interpreter)




Identifies features that are available in printers with firmware version V60.16.2Z, V53.16.2Z, or later.

^JI works much like the ~JI command. Both commands are sent to the printer to initialize the Zebra BASIC Interpreter.

In interactive mode, ^JI can be sent through one of the communication ports (serial, parallel, or Ethernet) to initialize the printer to receive ZBI commands. This command can be sent from one of the Zebra software utilities, such as ZTools, or from a terminal emulation program.

When the command is received, the printer responds by sending a ZBI header back to the console, along with the program version number. This indicates that the interpreter is active.

Format: ^JIid:o.x,b,c,d

Parameters	Details
d = location of program to run after initialization	Values: R:, E:, B:, and A: Default: location must be specified
o = name of program to run after initialization	Values: any valid program name Default: name must be specified
x = extension of program to run after initialization	Fixed Value: .BAS, .BAE  .BAE is only supported in firmware version V60.16.0Z or later
b = console control	Values: Y = console on N = console off Default: Y
c = echoing control	Values: Y = echo on N = echo off Default: Y
d = memory allocation for ZBI *	Values: 20K to 1024K Default: 50K

* This parameter is only available on printers with firmware V60.12.0.x or earlier.

Comments When the printer is turned on, it can receive ZPL II commands and label formats. However, for the printer to recognize ZBI commands and programs, it must be initialized using ^JI or ~JI.

Only one ZBI interpreter can be active in the printer at a time. If a second **^JI** or **~JI** command is received while the interpreter is running, the command is ignored.

The interpreter is deactivated by entering one of two commands:

- ZPL** at the ZBI prompt
- ~JQ** at an active ZPL port

~JI – Start ZBI (Zebra BASIC Interpreter)



Identifies features that are available in printers with firmware version V60.16.2Z, V53.16.2Z, or later.

~JI works much like the **^JI** command. Both commands are sent to the printer to initialize the Zebra BASIC Interpreter.

In interactive mode, **~JI** can be sent through one of the communication ports (serial, parallel, or Ethernet) to initialize the printer to receive ZBI commands. This command can be sent from one of the Zebra software utilities, such as ZTools, or from a standard PC program, such as Hyper terminal.

When the command is received, the printer responds by sending a ZBI header back to the console, along with the program version number. This indicates that the interpreter is active.

Format: ~JI

Comments While receiving commands, the printer *echoes* the received characters back to the source. This can be toggled on and off with the ZBI ECHO command.

When the printer is turned on, it can receive ZPL II commands and label formats. However, for the printer to recognize ZBI commands and formats, it must be initialized using **^JI** or **~JI**.

Only one ZBI interpreter can be active in the printer at a time. If a second **~JI** or **^JI** command is received while the interpreter is running, the command is ignored.

The interpreter is deactivated by entering one of these commands:


ZPL at the ZBI prompt

~JQ at an active ZPL port

^JJ – Set Auxiliary Port

The ^JJ command allows you to control an online verifier or applicator device.

Format: ^JJa,b,c,d,e,f

Parameters	Details
a = operational mode for auxiliary port	<p>Values:</p> <ul style="list-style-type: none"> 0 = off 1 = reprint on error—the printer stops on a label with a verification error. When PAUSE is pressed, the label reprints (if ^JZ is set to reprint). If a bar code is near the upper edge of a label, the label feeds out far enough for the bar code to be verified and then backfeeds to allow the next label to be printed and verified. 2 = maximum throughput—the printer stops when a verification error is detected. The printer starts printing the next label while the verifier is still checking the previous label. This mode provides maximum throughput, but does not allow the printer to stop immediately on a label with a verification error. <p>Default: 0</p>
b = application mode	<p>Values:</p> <ul style="list-style-type: none"> 0 = off 1 = End Print signal normally high, and low only when the printer is moving the label forward. 2 = End Print signal normally low, and high only when the printer is moving the label forward. 3 = End Print signal normally high, and low for 20 ms when a label has been printed and positioned. 4 = End Print signal normally low, and high for 20 ms when a label has been printed and positioned. <p>Default: 0</p> <p> Note • The Set/Get/Do command device.applicator.end_print on page 621 controls the same setting as the b parameter.</p>
c = application mode start signal print	<p>Values:</p> <ul style="list-style-type: none"> p = Pulse Mode – Start Print signal must be de-asserted before it can be asserted for the next label. 1 = Level Mode – Start Print signal does not need to be de-asserted to print the next label. As long as the Start Print signal is low and a label is formatted, a label prints. <p>Default: 0</p>
d = application label error mode	<p>Values:</p> <ul style="list-style-type: none"> e = error mode—the printer asserts the <i>Service Required</i> signal (svce_req - pin 10) on the application port, enters into Pause Mode, and displays an error message on the LCD. f = Feed Mode—a blank label prints when the web is not found where expected to sync the printer to the media. <p>Default: f</p>

Parameters	Details
e = reprint mode	<p>Values:</p> <ul style="list-style-type: none"> e = enabled—the last label reprints after the signal is asserted. If a label is canceled, the label to be reprinted is also canceled. This mode consumes more memory because the last printed label is not released until it reprints. d = disabled—printer ignores the Reprint signal. <p>Default: d</p>
f = ribbon low mode	<p>Values:</p> <ul style="list-style-type: none"> e = <i>enabled</i> – printer warning issued when ribbon low. d = <i>disabled</i> – printer warning not issued when ribbon low. <p>Default: e</p>

~JL - Set Label Length

The ~JL command is used to set the label length. Depending on the size of the label, the printer feeds one or more blank labels.

Format: ~JL

^JM – Set Dots per Millimeter

The ^JM command lowers the density of the print—24 dots/mm becomes 12, 12 dots/mm becomes 6, 8 dots/mm becomes 4, and 6 dots/mm becomes 3. ^JM also affects the field origin (^FO) placement on the label (see example below).



When sent to the printer, the ^JM command doubles the format size of the label. Depending on the printhead, normal dot-per-millimeter capabilities for a Zebra printer are 12 dots/mm (304 dots/inch), 8 dots/mm (203 dots/inch) or 6 dots/mm (153 dots/inch).

This command must be entered before the first ^FS command in a format. The effects of ^JM are persistent.

Format: ^JMn

Parameters	Details
n = set dots per millimeter	Values: A = 24 dots/mm, 12 dots/mm, 8 dots/mm or 6 dots/mm B = 12 dots/mm, 6 dots/mm, 4 dots/mm or 3 dots/mm Default: A

➔ **Example:** This example of the affects of alternating the dots per millimeter:

ZPL II CODE	GENERATED LABEL
<pre> ^XA ^JMA^FS ^FO100,100 ^B2N,50,Y,N,N ^FD1234567890^FS ^XZ </pre>	
<pre> ^XA ^JMB^FS ^FO100,100 ^B2N,50,Y,N,N ^FD1234567890^FS ^XZ </pre>	

Comments If ^JMB is used, the UPS MaxiCode bar code becomes out of specification.

~JN – Head Test Fatal

The ~JN command turns on the head test option. When activated, ~JN causes the printer to halt when a head test failure is encountered.

Once an error is encountered the printer remains in error mode until the head test is turned off (~J0) or power is cycled.

Format: ~JN

Comments If the communications buffer is full, the printer is not able to receive data. In this condition, the ~J0 command is not received by the printer.

~J0 - Head Test Non-Fatal

The ~J0 command configures the printer to run the head test with error reporting enabled. When ~J0 is used an error will be displayed and printing will stop if the head test fails. The user can push the PAUSE button on the printer to bypass the error. This command differs from the ~JN (Head Test Fatal) command in that a power cycle is not required in the event of a head test failure.

~J0 is the default print head test condition. This setting is changed when the printer receives a ~JN (Head Test Fatal) command.

Format: ~J0

~JP – Pause and Cancel Format

The ~JP command clears the format currently being processed and places the printer into Pause Mode.

The command clears the next format that would print, or the oldest format from the buffer. Each subsequent ~JP command clears the next buffered format until the buffer is empty. The DATA indicator turns off when the buffer is empty and no data is being transmitted.

Issuing the ~JP command is identical to using CANCEL on the printer, but the printer does not have to be in Pause Mode first.

Format: ~JP

~JQ – Terminate Zebra BASIC Interpreter



Identifies features that are available in printers with firmware version V60.16.2Z, V53.16.2Z, or later.

The **~JQ** command is used when Zebra BASIC Interpreter is active. Sending **~JQ** to the printer terminates the ZBI session.

Format: ~JQ

Comments Entering ZPL at the command prompt also terminates a ZBI session.

~JR – Power On Reset

The ~JR command resets all of the printer's internal software, performs a power-on self-test (POST), clears the buffer and DRAM, and resets communication parameters and default values. Issuing a ~JR command performs the same function as a manual power-on reset.

Format: ~JR

^JS – Sensor Select

Format: ^JSa



Note • This command is ignored on Zebra ZM400/ZM600 and RZ400/RZ600 printers. This command is only for use with the S4M and Z Series printers (with the exception of the ZM400/ZM600/RZ400/RZ600).

Parameters	Details
a = sensor selection	<p>Values:</p> <ul style="list-style-type: none"> A = auto select R = reflective sensor T = transmissive sensor <p>Default:</p> <ul style="list-style-type: none"> Z series = A S4M = R

~JS – Change Backfeed Sequence

The **~JS** command is used to control the backfeed sequence. This command can be used on printers with or without built-in cutters.

These are the primary applications:

- to allow programming of the *rest point* of the cut edge of continuous media.
- provide immediate backfeed after peel-off when the printer is used in a print/apply application configuration.

This command stays in effect only until the printer is turned off, a new **~JS** command is sent, or the setting is changed on the control panel. When a **~JS** command is encountered, it overrides the current control panel setting for the Backfeed Sequence.

The most common way of eliminating backfeed is to operate in Rewind Mode. Rewind Mode does not backfeed at all. After a label prints, the leading edge of the next label is placed at the print line. This eliminates the need to backfeed and does not introduce a non printable area at the leading edge or bottom of the label. It also does not allow the label to be taken from the printer because it is not fed out from under the printhead.

Running in another mode with backfeed turned off allows the label to be removed and eliminates the time-reduction of the backfeed sequence.

Format: **~JSb**

Parameters	Details
b = backfeed order in relation to printing	<p>Values:</p> <p>A = 100 percent backfeed after printing and cutting</p> <p>B = 0 percent backfeed after printing and cutting, and 100 percent before printing the next label</p> <p>N = normal — 90 percent backfeed after label is printed</p> <p>0 = off — turn backfeed off completely</p> <p>10 to 90 = percentage value</p> <p>The value entered must be a multiple of 10. Values not divisible by 10 are rounded to the nearest acceptable value. For example, ~JS55 is accepted as 50 percent backfeed.</p> <p>Default: N</p>

Comments When using a specific value, the difference between the value entered and 100 percent is calculated before the next label is printed. For example, a value of 40 means 40 percent of the backfeed takes place after the label is cut or removed. The remaining 60 percent takes place before the next label is printed.

The value for this command is also reflected in the Backfeed parameter on the printer configuration label.

For **~JSN** — the Backfeed parameter is listed as DEFAULT

For **~JSA** — or 100% the Backfeed parameter is listed as AFTER

For **~JSB** — or 0% the Backfeed parameter is listed as BEFORE

For **~JS10** — 10% of the backfeed takes place after the label is cut or removed. The remaining 90% takes place before the next label is printed.

This command is ignored on the HC100™ printer.

^JT – Head Test Interval

The ^JT command allows you to change the printhead test interval from every 100 labels to any desired interval. With the ^JT command, the printer is allowed to run the test after printing a label. When a parameter is defined, the printer runs the test after printing a set amount of labels.

The printer's default head test state is off. Parameters for running the printhead test are defined by the user.

Format: ^JT####,a,b,c

Parameters	Details
#### = four-digit number of labels printed between head tests	Values: 0000 to 9999 If a value greater than 9999 is entered, it is ignored. Default: 0000 (off)
a = manually select range of elements to test	Values: N = no Y = yes Initial Value at Power Up: N
b = first element to check when parameter a is Y	Values: 0 to 9999 Initial Value at Power Up: 0
c = last element to check when parameter a is Y	Values: 0 to 9999 Initial Value at Power Up: 9999

Comments The ^JT command supports testing a range of print elements. The printer automatically selects the test range by tracking which elements have been used since the previous test.

^JT also turns on Automatic Mode to specify the first and last elements for the head test. This makes it possible to select any specific area of the label or the entire print width.

If the last element selected is greater than the print width selected, the test stops at the selected print width.

Whenever the head test command is received, a head test is performed on the next label unless the count is set to 0 (zero).

^JU – Configuration Update

The ^JU command sets the active configuration for the printer.

Format: ^JUa

Parameters	Details
a = active configuration	<p>Values:</p> <ul style="list-style-type: none">F = reload factory settingsN = reload factory network settings <p>These values are lost at power-off if not saved with ^JUS.</p> <ul style="list-style-type: none">R = recall last saved settingsS = save current settings <p>These values are used at power-on.</p> <p>Default: a value must be specified</p>

^JW – Set Ribbon Tension

^JW sets the ribbon tension for the printer it is sent to.

Format: ^JWt

Parameters	Details
t = tension	Values: L = low M = medium H = high Default: a value must be specified

Comments ^JW is used only for *PAX* series printers.

~JX – Cancel Current Partially Input Format

The ~JX command cancels a format currently being sent to the printer. It does not affect any formats currently being printed, or any subsequent formats that might be sent.

Format: ~JX

^JZ – Reprint After Error

The ^JZ command reprints a partially printed label caused by a **Ribbon Out**, **Media Out**, or **Head Open** error condition. The label is reprinted as soon as the error condition is corrected.

This command remains active until another ^JZ command is sent to the printer or the printer is turned off.

Format: ^JZa

Parameters	Details
a = reprint after error	Values: N = no Y = yes Initial Value at Power Up: Y

Comments ^JZ sets the error mode for the printer. If ^JZ changes, only labels printed after the change are affected.

If the parameter is missing or incorrect, the command is ignored.

~KB – Kill Battery (Battery Discharge Mode)

To maintain performance of the rechargeable battery in the portable printers, the battery must be fully discharged and recharged regularly. The ~KB command places the printer in battery discharge mode. This allows the battery to be drained without actually printing.

Format: ~KB

Comments While the printer is in Discharge Mode, the green power LED flashes in groups of three flashes.

Discharge Mode might be terminated by sending a printing format to the printer or by pressing either of the control panel keys.

If the battery charger is plugged into the printer, the battery is automatically recharged once the discharge process is completed.

^KD – Select Date and Time Format (for Real Time Clock)

The ^KD command selects the format that the Real-Time Clock's date and time information presents as on a configuration label. This is also displayed on the *Printer Idle* LCD control panel display, and displayed while setting the date and time.

Format: ^KDa

Parameters	Details
a = value of date and time format	<p>Values:</p> <ul style="list-style-type: none">0 = normal, displays <i>Version Number</i> of firmware1 = MM/DD/YY (24-hour clock)2 = MM/DD/YY (12-hour clock)3 = DD/MM/YY (24-hour clock)4 = DD/MM/YY (12-hour clock) <p>Default: 0</p>

Comments If the Real-Time Clock hardware is not present, Display Mode is set to 0 (Version Number).

If Display Mode is set to 0 (Version Number) and the Real-Time Clock hardware is present, the date and time format on the configuration label is presented in format 1.

If Display Mode is set to 0 (Version Number) and the Real-Time Clock hardware is present, the date and time format on the control panel display is presented in format 1.

For more details on select date and time format for the Real Time Clock, see [Real Time Clock on page 1375](#).

^KL - Define Language

The ^KL command selects the language displayed on the control panel.

Format: ^KL*a*

Parameters	Details
a = language	<p>Values:</p> <ul style="list-style-type: none">1 = English2 = Spanish3 = French4 = German5 = Italian6 = Norwegian7 = Portuguese8 = Swedish9 = Danish10 = Spanish211 = Dutch12 = Finnish13 = Japanese14 = Korean /15 = Simplified Chinese /16 = Traditional Chinese /17 = Russian /18 = Polish /19 = Czech /20 = Romanian / <p>Default: 1</p>

- i. These values are only supported on the ZT200 Series, ZE500 Series, Xi4, RXi4, ZM400/ ZM600, and RZ400/RZ600 printers.

^KN – Define Printer Name

The printer's network name and description can be set using the ^KN command. ^KN is designed to make your Zebra printer easy for users to identify. The name the administrator designates is listed on the configuration label and on the Web page generated by the printer.

Format: ^KNa,b



Note • If you issue the command ^KN, (without the a and b parameters) you are setting the printer name and description to a blank string.

To cause the printer name and printer description settings controlled by the ^KN command to be saved, you must issue the ^JUS command.

Parameters	Details
a = printer name	<p>Values: up to 16 alphanumeric characters</p> <p>Default:</p> <ul style="list-style-type: none"> If no printer name is specified in a printer with a MAC address, the printer name will default to "ZBRxxx," where xxx is the last three octets of the MAC address converted into ASCII text. For printers without a MAC address, if a value is not entered, the current stored value is erased. <p>If more than 16 characters are entered, only the first 16 are used.</p>
b = printer description	<p>Values: up to 35 alphanumeric characters</p> <p>Default: if a value is not entered, the current stored value is erased</p> <p>If more than 35 characters are entered, only the first 35 are used.</p> <p>Note • The value of this parameter will be displayed on the printer's web page in parentheses.</p>



Example: This is an example of how to change the printer's network name and description: This shows how a configuration looks before using this command and after using this command:

```
^XA
^KNZebra1,desk_printer
^XZ
```

Before using this command:

PRINTER CONFIGURATION	
Zebra Technologies ZTC 105SL-200dpi	
+18.....	DARKNESS
-016.....	TEAR OFF
TEAR OFF.....	PRINT MODE
NON-CONTINUOUS.....	MEDIA TYPE
WEB.....	SENSOR TYPE
THERMAL-TRANS.....	PRINT METHOD
101 4/8 MM.....	PRINT WIDTH
1233.....	LABEL LENGTH
7.0IN 177MM.....	MAXIMUM LENGTH
PARALLEL.....	PARALLEL COMM.
RS232.....	SERIAL COMM.
9600.....	BAUD
8 BITS.....	DATA BITS
NONE.....	PARITY
XON/XOFF.....	HOST HANDSHAKE
NONE.....	PROTOCOL
000.....	NETWORK
NORMAL MODE.....	COMM
<^> ?EL	
<^>	

After using this command:

PRINTER CONFIGURATION	
Zebra Technologies ZTC 105SL-200dpi Zebra1 desk_printer	
+18.....	DARKNESS
-016.....	TEAR OFF
TEAR OFF.....	PRINT MODE
NON-CONTINUOUS.....	MEDIA TYPE
WEB.....	SENSOR TYPE
THERMAL-TRANS.....	PRINT METHOD
101 4/8 MM.....	PRINT WIDTH
1233.....	LABEL LENGTH
7.0IN 177MM.....	MAXIMUM LENGTH
PARALLEL.....	PARALLEL COMM.
RS232.....	SERIAL COMM.
9600.....	BAUD
8 BITS.....	DATA BITS
NONE.....	PARITY
XON/XOFF.....	HOST HANDSHAKE
NONE.....	PROTOCOL
000.....	NETWORK
NORMAL MODE.....	COMM
<^> ?EL	
<^>	

^KP – Define Password

The ^KP command is used to define the password that must be entered to access the control panel switches and LCD Setup Mode.

Format: ^KP*a*,*b*

Parameters	Details
<i>a</i> = mandatory four-digit password	Values: any four-digit numeric sequence Default: 1234
<i>b</i> = password level	Values: 1, 2, 3, 4 Default: 3 Note • The <i>b</i> parameter applies only to the S4M printers.

➔ **Example 1:** This example shows how to set a new control panel password:

```
^XA  
^KP5678  
^XZ
```

➔ **Example 2:** This example shows how to set a new control panel password (5678) at a specific password level (level 2) (applicable to the S4M printer only):

```
^XA  
^KP5678,2  
^XZ
```

Comments If you forget your password, the printer can be returned to a default Setup Mode and the default password 1234 is valid again. Caution should be used, however — this also sets the printer configuration values back to their defaults.

To return the printer to the default factory settings using ZPL, send this:

```
^XA  
^JUF  
^XZ
```

To return the printer to the default factory settings using the control panel keys, see your printer's User Guide for the procedure.

^KV – Kiosk Values

The ^KV command sets several parameters that affect the printers operation when ^MM is set to K - Kiosk mode

Supported Devices

- KR403

Format: ^KV`a,b,c,d,e`

Parameters	Details
a = kiosk cut amount	<p>Values: 0 = normal cut 10-60 = partial cut, value = mm of media left uncut</p> <p>Default: 0 This parameter is ignored if it is missing or invalid. The current value of the parameter remains unchanged.</p>
b = kiosk cut margin	<p>Values: 2 - 9 = mm of distance</p> <p>Default: 9 = mm of distance This parameter is ignored if it is missing or invalid. The current value of the parameter remains unchanged.</p>
c = kiosk present type	<p>Values: 0 = Eject page when new page is printed 1 = Retract page when new page is printed 2 = Do nothing when new page is printed</p> <p>Default: 0 This parameter is ignored if it is missing or invalid. The current value of the parameter remains unchanged.</p>
d = kiosk present timeout	<p>Values: 0-300 = If label is not taken, retract label when timeout expires. Timeout is in seconds. Zero (0) indicates that there is no timeout. The label will stay presented until removed manually or a new label is printed.</p> <p>Default: 0 This parameter is ignored if it is missing or invalid. The current value of the parameter remains unchanged.</p>
e = presenter loop length	<p>Values: 0 = paper is fed straight through the presenter 3-1023 = loop length in mm.</p> <p>Default: 400 400= gives a loop of approximately 400mm This parameter is ignored if it is missing or invalid. The current value of the parameter remains unchanged. . If this is greater than loop_length_max (see SGD media.present.loop_length_max) then it will be set equal to loop_length_max.</p>

Kiosk Printing Examples

The following examples demonstrate the use of the ^KV, ^CN, ^PN and ^CP commands with 80mm wide continuous media and the printer set to Kiosk Mode (^MMK).



Example 1: In this example, the ^KV command is set to the following:

- Cut - Full Cut
- Cut Margin - 9 mm
- Present Type - Eject page when the next page is printed
- Present Timeout - 6 seconds after printing, if the document is not taken, it will be retracted
- Presenter Loop Length - No loop

```
^XA
^MMK
^KV0,9,0,6,0
^F050,50^A0N,50,50^FDZebra Technologies^FS
^CN1
^PN0
^XZ
```



Note • The ^CN1 command (Cut Now) is included to ensure that a full cut is done. The ^PN0 (Present Now) command is included to ensure that the media is ejected when the user pulls on the leading edge of the media. In this example, if the user does not pull on the leading edge of the second document, it will be retracted.



Example 2: This example contains only one change from the Example 1 - the Presenter Loop Length is now 100mm, and two documents will be printed instead of one.

```
^XA
^MMK
^KV0,9,2,6,100
^F050,50^A0N,50,50^FDZebra Technologies^FS
^CN1^PN0
^PQ2
^XZ
```



Example 3: In this example, two documents will be printed, each one will be ejected from the printer.

```
^XA
^MMK
^KV0,9,2,6,100
^F050,50^A0N,50,50^FDZebra Technologies^FS
^CN1^CP0
^PQ2
^XZ
```



Example 4: In this example, two documents, with partial cuts, will be printed, and a third document, with a full cut, will be printed.

```
^XA
^MMK
^KV50,9,0,0,0
^F050,50^A0N,50,50^FDPartial Cut^FS
^CN0^PN0
^PQ2
^XZ
^XA
^MMK
^KV0,9,2,6,0
^F050,50^A0N,50,50^FDFull Cut^FS
^CN1^CP0
^XZ
```



Example 5: In this example, four documents will be printed – three with a partial cut and the fourth with a full cut. Additionally, the document length is set to 406 dots and the Media Tracking mode is set to "Continuous Media, Variable Length". The third document contains fields that are positioned outside of the 406 dot length – however, because the printer is set to "Continuous Media, Variable Length" Media Tracking mode, the printer will automatically adjust the document length to compensate.

```
^XA
^MMK
^LL406
^KV20,9,0,0,0
^F050,50^A0N,50,50^FDPartial Cut^FS
^CN0^PN0
^PQ2
^XZ

^XA
^MMK
^MNV
^KV20,9,0,0,0
^F050,50^A0N,50,50^FDPartial Cut^FS
^F050,150^A0N,50,50^FDPrinting Line 1^FS
^F050,250^A0N,50,50^FDPrinting Line 2^FS
^F050,350^A0N,50,50^FDPrinting Line 3^FS
^F050,450^A0N,50,50^FDPrinting Line 4^FS
^F050,550^A0N,50,50^FDPrinting Line 5^FS
^F050,650^A0N,50,50^FDPrinting Line 6^FS
^F050,750^A0N,50,50^FDPrinting Line 7^FS
^F050,850^A0N,50,50^FDPrinting Line 8^FS
^F050,950^A0N,50,50^FDPrinting Line 9^FS
^F050,1050^A0N,50,50^FDPrinting Line 10^FS
^F050,1150^A0N,50,50^FDPrinting Line 11^FS
^F050,1250^A0N,50,50^FDPrinting Line 12^FS
^F050,1350^A0N,50,50^FDPrinting Line 13^FS
^F050,1450^A0N,50,50^FDPrinting Line 14^FS
^F050,1550^A0N,50,50^FDPrinting Line 15^FS
^CN0^PN0
^XZ

^XA
^MMK
^KV0,9,0,0,0
^F050,50^A0N,50,50^FDFull Cut^FS
^CN0^PN1^CP0
^PQ1
^XZ
```

^LF – List Font Links




This command is available only for printers with firmware version V60.14.x, V50.14.x, or later.

The ^LF command prints out a list of the linked fonts.



Example: This example shows that **SWISS721.TTF** is the based font. **ANMDJ.TTF** is the first linked font, and **MSGOTHIC.TTF** is the second linked extension:

ZPL II CODE	GENERATED LABEL
<pre>^XA ^LF ^XZ</pre>	

This is the code that established the font links:

```
^XA
^FLE:ANMDJ.TTF,E:SWISS721.TTF,1^FS
^FLE:MSGOTHIC.TTF,E:SWISS721.TTF,1^FS
^XZ
```

^LH – Label Home

The ^LH command sets the label home position.

The default home position of a label is the upper-left corner (position 0,0 along the x and y axis). This is the axis reference point for labels. Any area below and to the right of this point is available for printing. The ^LH command changes this reference point. For instance, when working with preprinted labels, use this command to move the reference point below the preprinted area.

This command affects only fields that come after it. It is recommended to use ^LH as one of the first commands in the label format.

Format: ^LHx,y

Parameters	Details
x = x-axis position (in dots)	Values: 0 to 32000 Initial Value at Power Up: 0 or last permanently saved value
y = y-axis position (in dots)	Values: 0 to 32000 Initial Value at Power Up: 0 or last permanently saved value

Depending on the printhead used in your printer, use one of these when figuring the values for **x** and **y**:

6 dots = 1 mm, 152 dots = 1 inch
8 dots = 1 mm, 203 dots = 1 inch
11.8 dots = 1 mm, 300 dots = 1 inch
24 dots = 1 mm, 608 dots = 1 inch

Comments To be compatible with existing printers, this command must come before the first ^FS (Field Separator) command. Once you have issued an ^LH command, the setting is retained until you turn off the printer or send a new ^LH command to the printer.

^LL – Label Length

The ^LL command defines the length of the label. This command is necessary when using continuous media (media not divided into separate labels by gaps, spaces, notches, slots, or holes).

To affect the current label and be compatible with existing printers, ^LL must come before the first ^FS (Field Separator) command. Once you have issued ^LL, the setting is retained until you turn off the printer or send a new ^LL command.

Format: ^LLy

Parameters	Details
y = y-axis position (in dots)	<p>Values: 1 to 32000, not to exceed the maximum label size. While the printer accepts any value for this parameter, the amount of memory installed determines the maximum length of the label.</p> <p>Default: typically set through the LCD (if applicable), or to the maximum label length capability of the printer.</p>

Comments These formulas can be used to determine the value of y:

For 6 dot/mm printheads...	Label length in inches x 152.4 (dots/inch) = y
For 8 dot/mm printheads...	Label length in inches x 203.2 (dots/inch) = y
For 12 dot/mm printheads...	Label length in inches x 304.8 (dots/inch) = y
For 24 dot/mm printheads...	Label length in inches x 609.6 (dots/inch) = y

Values for y depend on the memory size. If the entered value for y exceeds the acceptable limits, the bottom of the label is cut off. The label also shifts down from top to bottom.

If multiple ^LL commands are issued in the same label format, the last ^LL command affects the next label unless it is prior to the first ^FS.

This command is ignored on the HC100™ printer.

^LR – Label Reverse Print

The ^LR command reverses the printing of all fields in the label format. It allows a field to appear as white over black or black over white.

Using the ^LR is identical to placing an ^FR command in all current and subsequent fields.

Format: ^LRa

Parameters	Details
a = reverse print all fields	Values: N = no Y = yes Initial Value at Power Up: N or last permanently saved value



Example: This is an example that shows printing white over black and black over white. The ^GB command is used to create the black background.

ZPL II CODE	GENERATED LABEL
<pre> ^XA^LRY ^FO100,50 ^GB195,203,195^FS ^FO180,110^CFG ^FDLABEL^FS ^FO130,170 ^FDREVERSE^FS ^XZ </pre>	

Comments The ^LR setting remains active unless turned off by ^LRN or the printer is turned off.



Note • ^GB needs to be used together with ^LR.

Only fields following this command are affected.

^LS – Label Shift

The ^LS command allows for compatibility with Z-130 printer formats that are set for less than full label width. It is used to shift all field positions to the left so the same commands used on a Z-130 or Z-220 Printer can be used on other Zebra printers.

To determine the value for the ^LS command, use this formula:

$$\text{Z-130 and Z-220 values for } ^LHx + ^F0x \\ (\text{distance from edge of label}) = \text{printer value for } ^LSa$$

If the print position is less than 0, set ^LS to 0.

Format: ^LSa



Important • The ability to save the ^LS command depends on the version of firmware.

Parameters	Details
a = shift left value (in dots)	Values: -9999 to 9999 Initial Value at Power Up: 0

Comments When entering positive values, it is not necessary to use the + sign. The value is assumed to be positive unless preceded by a negative sign (-).

To be compatible with existing Zebra printers, this command must come before the first ^FS (Field Separator) command. Once you have issued an ^LS command, the setting is retained until you turn off the printer or send a new ^LS command to the printer.

^LT – Label Top

The ^LT command moves the entire label format a maximum of 120 dot rows up or down from its current position, in relation to the top edge of the label. A negative value moves the format towards the top of the label; a positive value moves the format away from the top of the label.

This command can be used to fine-tune the position of the finished label without having to change any of the existing parameters.



Important • For some printer models, it is possible to request a negative value large enough to cause the media to backup into the printer and become unthreaded from the platen. This condition can result in a printer error or unpredictable results.

Format: ^LTx

Parameters	Details
x = label top (in dot rows)	<p>Values:</p> <p>HC100: 0 to 120</p> <p>XIIIPlus 600dpi: -240 to 240</p> <p>All other Zebra printers: -120 to 120</p> <p>Default: a value must be specified or the command is ignored</p>

Comments The Accepted Value range for x might be smaller depending on the printer platform.

The Label Top value shown on the front panel of the printer is double the value used in the ZPL format.

The ^LT command does not change the media rest position.

^MA – Set Maintenance Alerts



This command is available only for printers with firmware version V60.15.x, V50.15.x, or later.

The ^MA command controls how the printer issues printed maintenance alerts. Maintenance alerts are labels that print with a warning that indicates the printhead needs to be cleaned or changed.

Supported Devices

- Xi4, RXi4
- ZM400/ZM600, RZ400/RZ600
- S4M with v53.15.5Z or later
- G-Series



Important • ^MA settings do not impact or effect the functionality of the Xi4 Supplies Warning system.

Format: ^MAtype,print,printlabel_threshold,frequency,units

Parameters	Details
type = type of alert	<p>Values:</p> <ul style="list-style-type: none"> R = head replacement C = head cleaning <p>Default: This parameter must be specified as R or C for print, printlabel_threshold, and frequency to be saved. However, units will always be set.</p>
print = determines if the alert prints a label	<p>Values:</p> <ul style="list-style-type: none"> Y = print a label N = do not print label <p>Default: N</p>
printlabel threshold = distance where the first alert occurs	<p>Values:</p> <ul style="list-style-type: none"> R = head replacement (unit of measurement for head is km with a range of 0 to 150 km) C = clean head with a range of 100 to 2000 meters. 0 = off (when set to 0, the selected alert is disabled; otherwise it is enabled). <p>Default: R = 50 km (1,968,500 inches) and C = 0 (off).</p>
frequency = distance before reissuing the alert	<p>The unit of measurement is in meters. The range is 0 to 2000. The range for G-Series printers is 0 or 5 to 2000 meters. When set to 0, the alert label is only printed on power-up or when the printer is reset.</p> <p>Default: 0 (print on power-up).</p>

Parameters	Details
<code>units</code> = odometer and printhead maintenance commands	<p>The units parameter reports units of the odometer and printhead maintenance commands, as follows: <code>~HQOD</code>, <code>~HQPH</code>, <code>~WQOD</code>, <code>~WQPH</code>.</p> <p>Values:</p> <ul style="list-style-type: none">C = centimeters (displays as: <code>cm</code>)I = inches (displays as: <code>"</code>)M = meters (displays as: <code>M</code>) <p>Default: <code>I</code></p>



Example: This example sets the printed head cleaning message to print after five meters and to repeat every one meter after that until a `~ROC` command is issued.

The Early Warning Maintenance setting must be ON. To enable the maintenance alert system on the G-Series™ printer the `^JH` command is used; on other Zebra printers the front panel can also be used.

1. To set `^MA` to print out a label flagging the need to clean the head, type:

```
^XA^MAC,Y,5,1^XZ
```

When the threshold is met a label will print indicating that the head needs to be clean.

2. For this example, the message on the label looks like this:

PLEASE CLEAN PRINT HEAD

For details resetting the units of measure, see the `~HQ` examples on [page 202](#).

Comments Any values outside the specified range are ignored.

The intent of this command is to cause a label to print when the defined threshold is reached.

^MC – Map Clear

In normal operation, the bitmap is cleared after the format has been printed. The ^MC command is used to retain the current bitmap. This applies to current and subsequent labels until cleared with ^MCY.

Format: ^MCa



Important • To produce a label template, ^MC must be used with ^FV.

Parameters	Details
a = map clear	Values: Y (clear bitmap) or N (do not clear bitmap) Initial Value at Power Up: Y

Comments The ^MC command retains the image of the current label after formatting. It appears in the background of the next label printed.

^MD – Media Darkness

The ^MD command adjusts the darkness relative to the current darkness setting.

Format: ^MDa

Parameters	Details
a = media darkness level	<p>Values: -30 to 30, depending on current value</p> <p>Initial Value at Power Up: 0</p> <p>If no value is entered, this command is ignored.</p>



Example 1: These examples show setting the printer to different darkness levels:

- If the current value (value on configuration label) is 16, entering the command ^MD-9 decreases the value to 7.
- If the current value (value on configuration label) is 1, entering the command ^MD15 increases the value to 16.
- If the current value (value on configuration label) is 25, entering the command ^MD10 increases only the value to 30, which is the maximum value allowed.

Each ^MD command is treated separately in relation to the current value as printed on the configuration label.



Note • On Zebra G-Series™ printers the value set with the ^MD command is persistent across power cycles.



Important • The darkness setting range for the *XIIIPlus*, Xi4, and RXi4 is 0 to 30 in increments of 0.1.

The firmware is setup so that the ^MD and ~SD commands (ZPL darkness commands) accepts that range of settings.



Example 2: These are examples of the *XIIIPlus*, Xi4, and RXi4 Darkness Setting:

```
^MD8.3
```

```
~SD8.3
```



Example 3: For example, this is what would happen if two ^MD commands were received:

Assume the current value is 15. An ^MD-6 command is received that changes the current value to 9. Another command, ^MD2, is received. The current value changes to 17.

The two ^MD commands are treated individually in relation to the current value of 15.

Comments The ~SD command value, if applicable, is added to the ^MD command.

^MF – Media Feed

The ^MF command dictates what happens to the media at power-up and at head-close after the error clears.

Format: ^MFp,h

Parameters	Details
p = feed action at power-up	Values: F = feed to the first web after sensor C = (see ~JC on page 226 definition) L = (see ~JL on page 239 definition) N = no media feed S = short calibration <i>m</i> Default: C
h = feed action after closing printhead	Values: F = feed to the first web after sensor C = (see ~JC on page 226 definition) L = (see ~JL on page 239 definition) N = no media feed S = short calibration <i>m</i> Default: C

m. These values are supported only on Xi4, RXi4, *Xi11Plus*, PAX, ZM400/ZM600, RZ400/RZ600, and S4M printers.

Comments It is important to remember that if you choose the **N** setting, the printer assumes that the media and its position relative to the printhead are the same as before power was turned off or the printhead was opened. Use the ^JU command to save changes.

^MI – Set Maintenance Information Message



This command is available only for printers with firmware version V60.15.x, V50.15.x, or later.

The ^MI command controls the content of maintenance alert messages, which are reminders printed by the printer to instruct the operator to clean or replace the printhead.

Supported Devices

- Xi4, RXi4
- ZM400/ZM600m RZ400/RZ600
- S4M with v53.15.5Z or later
- G-Series

Format: ^MItype,message

Parameters	Details
type = identifies the type of alert	Values: R = head replacement C = head cleaning Default: R
message = message that prints on the label when a maintenance alert occurs	The maximum length of each message is 63 characters. All characters following the comma and preceding the next tilde (~) or carat (^) define the message string. Commas (,) are not allowed in the message. Default: HEAD CLEANING = please clean printhead HEAD REPLACEMENT = please replace printhead



Example: This example sets the printhead (head) replacement warning message. Printing of this message is controlled by the ^MA command.

1. To customize the text of this label, type something like this:
`^XA^MIR,PRINT HEAD NEEDS REPLACEMENT - CALL EXT 1000^XZ`
 The label prints whatever you program it to say.
2. For this example, the message on the label looks like this:

PRINT HEAD NEEDS REPLACEMENT - CALL EXT 1000

^ML – Maximum Label Length

The ^ML command lets you adjust the maximum label length.



Note • This command does not apply when in continuous mode.

Format: ^MLa

Parameters	Details
a = maximum label length (in dot rows)	Values: the dpi of the printer multiplied by two, up to the maximum length of label Default: last permanently saved value

Comments For calibration to work properly, you must set the maximum label length equal to or greater than your actual label length.

This command is ignored on the HC100™ printer

^MM – Print Mode

The ^MM command determines the action the printer takes after a label or group of labels has printed.



Note • Refer to the User Guide for your printer to determine which print modes are supported by your printer.

Format: ^MMa,b

Parameters	Details
a = desired mode	<p>Values:</p> <ul style="list-style-type: none"> T = Tear-off ⁿ P = Peel-off (not available on S-300) ⁿ R = Rewind (depends on printer model) A = Applicator (depends on printer model) ⁿ C = Cutter (depends on printer model) D = Delayed cutter ⁿ F = RFID ⁿ L = Reserved ^{n, o} U = Reserved ^{n, o} K = Kiosk ^p <p>Default:</p> <p>The values available for parameter a depend on the printer being used and whether it supports the option. For RFID printers:</p> <ul style="list-style-type: none"> A = R110PAX4 print engines F = other RFID printers
b = prepeel select	<p>Values:</p> <ul style="list-style-type: none"> N = no Y = yes <p>Default: N</p> <p>The command is ignored if parameters are missing or invalid. The current value of the command remains unchanged.</p>

n. This value is not supported on the KR403 or ZD500R printer.

o. This value is supported only on the ZM400 and ZM600 printers.

p. This value is supported only the KR403 printer.

This list identifies the different modes of operation:

- Tear-off — after printing, the label advances so the web is over the tear bar. The label, with liner attached, can be torn off manually.
- Peel-off — after printing, the label moves forward and activates a Label Available Sensor. Printing stops until the label is manually removed from the printer.
Power Peel – liner automatically rewinds using an optional internal rewind spindle.
Value Peel – liner feeds down the front of the printer and is manually removed.
Prepeel – after each label is manually removed, the printer feeds the next label forward to prepeel a small portion of the label away from the liner material. The printer then backfeeds and prints the label. The prepeel feature assists in the proper peel operation of some media types.

- Rewind — the label and liner are rewound on an (optional) external rewind device. The next label is positioned under the printhead (no backfeed motion).
- Applicator — when used with an application device, the label move far enough forward to be removed by the applicator and applied to an item. This applies only to printers that have applicator ports and that are being used in a print-and-apply system.
- Cutter — after printing, the media feeds forward and is automatically cut into predetermined lengths.
- Delayed cutter — When the printer is in the Delayed Cut PRINT MODE, it will cut the label when it receives the ~JK (Delayed Cut) command. To activate the ~JK command, the printer's PRINT MODE must be set to Delayed Cut and there must be a label waiting to be cut. When the printer is not in the Delayed Cut PRINT MODE, the printer will not cut the label when it receives the ~JK command.



Note • Send ~JK in a separate file - it cannot be sent at the end of a set of commands.

The Delayed Cut feature can be activated:

- through PRINT MODE on the printer's control panel
- with a ^MMD command
- RFID — increases throughput time when printing batches of RFID labels by eliminating backfeed between labels.
- Kiosk — after printing, the media is moved in a presentation position, most applications maintain a loop of media in the printer.

Comments Be sure to select the appropriate value for the print mode being used to avoid unexpected results.

This command is ignored on the HC100™ printer.

^MN – Media Tracking

This command specifies the media type being used and the black mark offset in dots.

This bulleted list shows the types of media associated with this command:

- Continuous Media – this media has no physical characteristic (such as a web, notch, perforation, black mark) to separate labels. Label length is determined by the ^LL command.
- Continuous Media, variable length – same as Continuous Media, but if portions of the printed label fall outside of the defined label length, the label size will automatically be extended to contain them. This label length extension applies only to the current label. Note that ^MNV still requires the use of the ^LL command to define the initial desired label length.
- Non-continuous Media – this media has some type of physical characteristic (such as web, notch, perforation, black mark) to separate the labels.

Format: ^MNa,b

Parameters	Details
a = media being used	<p>Values:</p> <ul style="list-style-type: none"> N = continuous media Y = non-continuous media web sensing ^{q, r} W = non-continuous media web sensing ^{q, r} M = non-continuous media mark sensing A = auto-detects the type of media during calibration ^{q, s} V = continuous media, variable length ^t <p>Default: a value must be entered or the command is ignored</p>
b = black mark offset in dots	<p>This sets the expected location of the media mark relative to the point of separation between documents. If set to 0, the media mark is expected to be found at the point of separation. (i.e., the perforation, cut point, etc.)</p> <p>All values are listed in dots. This parameter is ignored unless the a parameter is set to M. If this parameter is missing, the default value is used.</p> <p>Values:</p> <ul style="list-style-type: none"> -80 to 283 for direct-thermal only printers -240 to 566 for 600 dpi printers -75 to 283 for KR403 printers -120 to 283 for all other printers <p>Default: 0</p>

- q. Provides the same result.
- r. This value is not supported on the KR403 printer.
- s. This parameter is supported only on G-series printers.
- t. This parameter is supported only on the KR403 printer.

Comments This command is ignored on the HC100™ printer.

^MP – Mode Protection

The ^MP command is used to disable the various mode functions on the control panel. Once disabled, the settings for the particular mode function can no longer be changed and the LED associated with the function does not light.

Because this command has only one parameter, each mode must be disabled with an individual ^MP command.

Format: ^MPa

Parameters	Details
a = mode to protect	<p>Values:</p> <ul style="list-style-type: none"> D = disable Darkness Mode P = disable Position Mode C = disable Calibration Mode E = enable all modes S = disable all mode saves (modes can be adjusted but values are not saved) W = disable Pause F = disable Feed X = disable Cancel M = disable menu changes <p>Default: a value must be entered or the command is ignored</p>



Example: This example shows the ZPL code that disables modes D and C. It also shows the effects on the configuration label before and after the ZPL code is sent:

```

^XA
^MPD
^MPC
^XZ
    
```

Before

```

DPCSFXM..... MODES ENABLED
..... MODES DISABLED
    
```

After

```

.P.SFXM..... MODES ENABLED
D.C..... MODES DISABLED
    
```

PRINTER CONFIGURATION	
Zebra Technologies	
ZPL 110X111Plus-300dpi	
ZBR1482777	
10.2.....	DARKNESS
2 IPS.....	PRINT SPEED
+000.....	TEAR OFF
TEAR OFF.....	PRINT MODE
NON-CONTINUOUS.....	MEDIA TYPE
MEB.....	SENSOR TYPE
THERMAL-TRANS.....	PRINT METHOD
105 08/12 MM.....	PRINT WIDTH
1828.....	LABEL LENGTH
39.0IN 988MM.....	MAXIMUM LENGTH
MEDIA DISABLED.....	EARLY WARNING
PRINT. OFF.....	EARLY WARNING
NOT CONNECTED.....	USB COMM.
BIDIRECTIONAL.....	PARALLEL COMM.
RS232.....	SERIAL COMM.
9600.....	BAUD
8 BITS.....	DATA BITS
NONE.....	PARITY
XON/XOFF.....	HOST HANDSHAKE
NONE.....	PROTOCOL
000.....	NETWORK ID
NORMAL MODE.....	COMMUNICATIONS
< > 7EH.....	CONTROL PREFIX
< > 5EH.....	FORMAT PREFIX
< > 2CH.....	DELIMITER CHAR
ZPL 11.....	ZPL MODE
NO MOTION.....	MEDIA POWER UP
NO MOTION.....	HEAD CLOSE
DEFAULT.....	BACKFEED
+000.....	LABEL TOP
+0000.....	LEFT POSITION
0000.....	HEAD TEST COUNT
1447.....	HEAD RESISTOR
OFF.....	VERTIFIER PORT
OFF.....	APPLICATOR PORT
ENABLED.....	ERROR ON PAUSE
PULSE MODE.....	START PRINT SIG
FEED MODE.....	RESYNCH MODE
DISABLED.....	REPRINT MODE
050.....	MEDIA S.
079.....	MEDIA S.
072.....	RIBBON S.
012.....	MARK LABEL
050.....	MARK S.
000.....	MARK MED S.
079.....	MEDIA LED
039.....	RIBBON LED
028.....	MARK LED
+10.....	LCD ADJUST
DPCSFXM.....	MODES ENABLED
.....	MODES DISABLED
1248 12/PP FULL.....	RESOLUTION
V60.15.12907 <.....	FIRMWARE
V30 79089 57.....	HARDWARE ID
CUSTOMIZED.....	CONFIGURATION
NONE.....	COMPACT FLASH
11776k.....	RAM
2048k.....	ONBOARD FLASH
NONE.....	FORMAT CONVERT
005 DISPLAY.....	PSE INTERFACE
001 POWER SUPPLY.....	PSE INTERFACE
.....	TWINAX/CDMX ID
FW VERSION.....	IDLE DISPLAY
11/18/06.....	RTC DATE
18:10.....	RTC TIME
NONE.....	ZEBRA NET II
NO.....	RFID READY
15940 IN.....	NONRESET CNTR
15940 IN.....	RESET CNTR1
15940 IN.....	RESET CNTR2
39850 CM.....	NONRESET CNTR
39850 CM.....	RESET CNTR1
39850 CM.....	RESET CNTR2
4207 LABELS.....	NONRESET CNTR
4207 LABELS.....	RESET CNTR1
4207 LABELS.....	RESET CNTR2
ok 36850.0 5 NYS07015.41008.07.VH1..	
2006-06-14 16:30:23	TIME STAMP

FIRMWARE IN THIS PRINTER IS COPYRIGHTED

^MT – Media Type

The ^MT command selects the type of media being used in the printer.

These are the choices for this command:

- Thermal Transfer Media – this media uses a high-carbon black or colored ribbon. The ink on the ribbon is bonded to the media.
- Direct Thermal Media – this media is heat sensitive and requires no ribbon.

Format: ^MTa

Parameters	Details
a = media type used	Values: T = thermal transfer media D = direct thermal media Default: a value must be entered or the command is ignored

Comments This command is ignored on the HC100™ printer.

^MU – Set Units of Measurement

The ^MU command sets the units of measurement the printer uses. ^MU works on a field-by-field basis. Once the mode of units is set, it carries over from field to field until a new mode of units is entered.

^MU also allows for printing at lower resolutions — 600 dpi printers are capable of printing at 300, 200, and 150 dpi; 300 dpi printers are capable of printing at 150 dpi.

Format: ^MUa,b,c

Parameters	Details
a = units	Values: D = dots I = inches M = millimeters Default: D
b = format base in dots per inch	Values: 150, 200, 300 Default: a value must be entered or the command is ignored
c = desired dots-per-inch conversion	Values: 300, 600 Default: a value must be entered or the command is ignored

→ Example 1: This is an example of Setting Units:

Assume 8 dot/millimeter (203 dot/inch) printer.

Field based on dots:

```
^MUd^F0100,100^GB1024,128,128^FS
```

Field based on millimeters:

```
^MUm^F012.5,12.5^GB128,16,16^FS
```

Field based on inches:

```
^MUi^F0.493,.493^GB5.044,.631,.631^FS
```

→ Example 2: This is an example of Converting dpi Values.

Convert a 150 dpi format to a 300 dpi format with a base in dots:

```
^MUd,150,300
```

Convert a 150 dpi format to a 600 dpi format with a base in dots:

```
^MUd,150,600
```

Convert a 200 dpi format to a 600 dpi format with a base in dots:

```
^MUd,200,600
```

To reset the conversion factor to the original format, enter matching values for parameters b and c:

```
^MUd,150,150
```

```
^MUd,200,200
```

```
^MUd,300,300
```

```
^MUd,600,600
```

Comments This command should appear at the beginning of the label format to be in proper ZPL II format. To turn the conversion off, enter matching values for parameter b and c.

^MW – Modify Head Cold Warning

The ^MW command allows you to set the head cold warning indicator based on the operating environment.

Format: ^MWa

Parameters	Details
a = enable head cold warning	Values: Y = enable head cold warning N = disable head cold warning



Important • When a parameter is **not** given, the instruction is *ignored*.

[^]NC – Select the Primary Network Device

The [^]NC command selects the wired or wireless print server as the primary network device.

Supported Devices

- Xi4, RXi4
- ZM400/ZM600, RZ400/RZ600

The Xi4, RXi4, ZM400/ZM600, and RZ400/RZ600 printers support the simultaneous installation of an internal, external, and a wireless print server. Even though all three print servers may be installed, only one is connected to the network and is the active print server. [Table 16](#) outlines priorities and identifies which device becomes the active print server when multiple print servers are installed.

Table 16 • Effect of Primary Network Setting on Active Print Server

If the Primary Network is set to:	Installed and Connected to a Live Ethernet Network			Then, the Active Print Server will be:
	Internal	External	Wireless ^u	
Wired	X	X	X	Internal
		X	X	External
			X	Wireless
Wireless	X	X	X	Wireless
	X	X		Internal
		X		External

^u. A wireless option board must have an active radio that can properly associate to an access point.

Format: [^]NCa

Parameters	Details
a = primary network device	<p>Values:</p> <p>1 = wired primary</p> <p>2 = wireless primary</p> <p>Default: 1</p> <p>must be an accepted value or it is ignored</p>

~NC – Network Connect

The ~NC command is used to connect a particular printer to a network by calling up the printer's network ID number.

Format: ~NC###

Parameters	Details
### = network ID number assigned (must be a three-digit entry)	Values: 001 to 999 Default: 000 (none)

Comments Use this command at the beginning of any label format to specify which printer on the network is going to be used. Once the printer is established, it continues to be used until it is changed by another ~NC command. This command must be included in the label format to *wake up the printer*.

The commands ^MW, ~NC, ^NI, ~NR, and ~NT are used only with RS-422/485 printer communications.

^ND – Change Network Settings

The ^ND command changes the network settings on supported printers.

For the external wired print server settings, the ^ND command is the same as the ^NS command. For the wireless print server settings, the ^ND command is the same as the ^WI command.

Supported Devices

- Xi4 with firmware V53.17.1Z or later
- RXi4
- RZ400/RZ600 with firmware R53.15.xZ or later
- ZM400/ZM600 with firmware V53.15.xZ or later
- G-Series

Format: ^NDa,b,c,d,e,f,g,h,i,j

Parameters	Details
a = the device that is being modified	Values: 1 = external wired 2 = internal wired 3 = wireless
b = IP resolution	Values: A = All B = BOOTP C = DHCP and BOOTP D = DHCP G = Gleaning only (Not recommended when the Wireless Print Server or Wireless Plus Print Server is installed.) R = RARP P = Permanent Default: A
c = IP address	Values: Any properly formatted IP address in the xxx.xxx.xxx.xxx format.
d = subnet mask	Values: Any properly formatted subnet mask in the xxx.xxx.xxx.xxx format.
e = default gateway	Values: Any properly formatted gateway in the xxx.xxx.xxx.xxx format.
f = WINS server address	Values: Any properly formatted WINS server in the xxx.xxx.xxx.xxx format.
g = connection timeout checking	Values: Y = yes N = no Default: Y
h = timeout value	Time, in seconds, before the connection times out. Values: 0 through 9999 Default: 300
i = ARP broadcast interval	Time, in minutes, that the broadcast is sent to update the device's ARP cache. Values: 0 through 30 Default: 0 (no ARP sent)

Parameters	Details
j = base raw port number	The port number that the printer should use for its RAW data. Values: 1 through 65535 Default: 9100

^NI – Network ID Number

The ^NI command is used to assign a network ID number to the printer. This must be done before the printer can be used in a network.

Format: ^NI###

Parameters	Details
### = network ID number assigned (must be a three-digit entry)	Values: 001 to 999 Default: 000 (none)

Comments The last network ID number set is the one recognized by the system.

The commands ~NC, ^NI, ~NR, and ~NT are used only with RS-485 printer communications.

~NR – Set All Network Printers Transparent

The ~NR command sets all printers in the network to be transparent, regardless of ID or current mode.

Format: ~NR

Comments The commands ~NC, ^NI, ~NR, and ~NT are used only with RS-485 printer communications.

^NS – Change Wired Networking Settings

Use this command to change the wired print server network settings.

Format: ^NSa,b,c,d,e,f,g,h,i

Parameters	Details
a = IP resolution	Values: A = ALL B = BOOTP C = DHCP AND BOOTP D = DHCP G = GLEANING ONLY R = RARP P = PERMANENT Default: A_ Use of GLEANING ONLY is not recommended when the Wireless Print Server or Wireless Plus Print Server is installed.
b = IP address	Values: Any properly formatted IP address in the xxx.xxx.xxx.xxx format.
c = subnet mask	Values: Any properly formatted subnet mask in the xxx.xxx.xxx.xxx format.
d = default gateway	Values: Any properly formatted gateway in the xxx.xxx.xxx.xxx format.
e = WINS server address	Values: Any properly formatted WINS server in the xxx.xxx.xxx.xxx format.
f = connection timeout checking	Values: Y = Yes N = No Default: Y
g = timeout value	Time, in seconds, before the connection times out. Values: 0 through 9999 Default: 300
h = ARP broadcast interval	Time, in minutes, that the broadcast is sent to update the device's ARP cache. Values: 0 through 30 Default: 0 (no ARP sent)
i = base raw port number	The port number that the printer should use for its RAW data. Values: 1 through 65535 Default: 9100



Example:

```

^XA
^NSa,192.168.0.1,255.255.255.0,192.168.0.2
^XZ

```

Comments For the Xi4, RXi4, ZM400/ZM600, and RZ400/RZ600 printers, Zebra recommends that you use the ^ND command instead of the ^NS command.

~NT – Set Currently Connected Printer Transparent

The ~NT command sets the currently connected network printer to be transparent.

Format: ~NT

Comments With Z Series® printers, the ~NT command functions the same as the ~NR command. All Z Series printers on a network receive the transmission.

The commands ~NC, ^NI, ~NR, and ~NT are used only with RS-485 printer communications.

^PA – Advanced Text Properties



This command is available only for printers with firmware version V60.14.x, V50.14.x, or later.

The ^PA command is used to configure advanced text layout features.

Format: ^PAa,b,c,d

Parameters	Details
a = default glyph	This determines whether the default glyph is a space character or the default glyph of the base font, which is typically a hollow box. Values: 0 = off (space as default glyph) 1 = on (default glyph of font is used, often a hollow box, but depends on the font.) Default: 0
b = bidirectional text layout	This determines whether the bidirectional text layout is turned on or off. Values: 0 = off 1 = on Default: 0
c = character shaping	This determines whether character shaping is turned on or off. Values: 0 = off 1 = on Default: 0
d = OpenType table support	This determines whether the OpenType support is turned on or off. Values: 0 = off 1 = on Default: 0

^PF – Slew Given Number of Dot Rows

The ^PF command causes the printer to slew labels (move labels at a high speed without printing) a specified number of dot rows from the bottom of the label. This allows faster printing when the bottom portion of a label is blank.

Format: ^PF#

Parameters	Details
# = number of dots rows to slew	Values: 0 to 32000 Default: a value must be entered or the command is ignored

^PH ~PH – Slew to Home Position

The ^PH or ~PH command causes the printer to feed one blank label.

The ~PH command feeds one label after the format currently being printed is done or when the printer is placed in pause.

The ^PH command feeds one blank label after the current format prints.

Format: ^PH or ~PH

~PL – Present Length Addition

The ~PL command adds an additional amount to how far the paper is ejected during a present cycle. A standard amount of 50mm is always added to clear the kiosk wall. This amount is added to that 50mm. The total amount of media ejected when a ^PN is executed, then, is 50mm + ~PL value + ^PN value.

Supported Devices

- KR403

Format: ^PLa

Parameters	Details
a = additional eject length	<p>Values: 000-255 = additional mm of media to eject</p> <p>Default: 000</p> <p>The command is ignored if parameters are missing or invalid.</p>

^PM – Printing Mirror Image of Label

The ^PM command prints the entire printable area of the label as a mirror image. This command flips the image from left to right.

Format: ^PMa

Parameters	Details
a = print mirror image of entire label	Values: N = no Y = yes Default: N



Example: This is an example of printing a mirror image on a label:

ZPL II CODE	GENERATED LABEL
<pre>^XA^PMY ^FO100,100 ^CFG ^FDMIRROR^FS ^FO100,160 ^FDIMAGE^FS ^XZ</pre>	

Comments If the parameter is missing or invalid, the command is ignored. Once entered, the ^PM command remains active until ^PMN is received or the printer is turned off.

^PN – Present Now

The ^PN command causes the printer to run a Presenter cycle. The parameter defines the amount of media ejected. The total amount of media ejected when a ^PN is executed, then, is 50mm + ~PL value + ^PN value. (See [~PL on page 294](#)).

Supported Devices

- KR403

Format: ^PNa

Parameters	Details
a = media eject length	Values: 0-255 = additional mm of media to eject Default: none The command is ignored if parameters are missing or invalid.

^PO – Print Orientation

The ^PO command inverts the label format 180 degrees. The label appears to be printed upside down. If the original label contains commands such as ^LL, ^LS, ^LT and ^PF, the inverted label output is affected differently.

Format: ^POa

Parameters	Details
a = invert label 180 degrees	Values: N = normal I = invert Default: N



Example: This is an example of printing a label at 180 degrees:

ZPL II CODE	GENERATED LABEL
<pre> ^XA^CFD ^POI ^LH330,10 ^FO50,50 ^FDZEBRA TECHNOLOGIES^FS ^FO50,75 ^FDVernon Hills, IL^FS ^XZ </pre>	

The ^POI command inverts the x, y coordinates. All image placement is relative to these inverted coordinates. Therefore, a different ^LH (Label Home) can be used to move the print back onto the label.

Comments If multiple ^PO commands are issued in the same label format, only the last command sent to the printer is used.

Once the ^PO command is sent, the setting is retained until another ^PO command is received or the printer is turned off.

The N value for the a parameter is not supported on the HC100™ printer.

^PP ~PP – Programmable Pause

The ~PP command stops printing after the current label is complete (if one is printing) and places the printer in Pause Mode.

The ^PP command is not immediate. Therefore, several labels might print before a pause is performed. This command pauses the printer after the current format prints.

The operation is identical to pressing PAUSE on the control panel of the printer. The printer remains paused until PAUSE is pressed or a ~PS (Print Start) command is sent to the printer.

Format: ^PP or ~PP

^PQ – Print Quantity

The ^PQ command gives control over several printing operations. It controls the number of labels to print, the number of labels printed before printer pauses, and the number of replications of each serial number.

Format: ^PQq,p,r,o,e

Parameters	Details
q = total quantity of labels to print	Values: 1 to 99,999,999 Default: 1
p = pause and cut value (labels between pauses)	Values: 1 to 99,999,999 Default: 0 (no pause)
r = replicates of each serial number	Values: 0 to 99,999,999 replicates Default: 0 (no replicates)
o = override pause count	Values: N = no Y = yes Default: N
e = cut on error label (RFID void is an error label)	Values: N = no - if a cutter is installed, a cut will be made after a voided RFID label ONLY if a cut would be made after the non-voided label and this was the last retry. Y = yes - if a cutter is installed, a cut will be made after ANY voided RFID label. Default: Y

If the **o** parameter is set to **Y**, the printer cuts but does not pause, and the printer does **not** pause after every group count of labels has been printed. With the **o** parameter set to **N** (default), the printer pauses after every group count of labels has been printed.



Example: This example shows the control over print operations:

^PQ50,10,1,Y: This example prints a total of 50 labels with one replicate of each serial number. It prints the total quantity in groups of 10, but does not pause after every group.

^PQ50,10,1,N: This example prints a total of 50 labels with one replicate of each serial number. It prints the total quantity in groups of 10, pausing after every group.

~PR – Applicator Reprint

If the ~PR command is enabled (see [^JJ on page 237](#)), the last label printed reprints, similar to the applicator asserting the Reprint signal on the applicator port. This command is similar to [device.applicator.reprint on page 625](#).

Supported Devices

- ZE500
- *XIIIPlus*
- Xi4 with firmware V53.17.1Z or later
- *PAX2, PAX4*
- S4M
- ZM400/ZM600

Format: ~PR

Comments Pressing PREVIOUS on the control panel also causes the last label to reprint.

^PR – Print Rate

The ^PR command determines the media and slew speed (feeding a blank label) during printing.

The printer operates with the selected speeds until the setting is reissued or the printer is turned off.

The print speed is application-specific. Because print quality is affected by media, ribbon, printing speeds, and printer operating modes, it is very important to run tests for your applications.



Important • Some models go to default print speed when power is turned off.

Format: ^PRp,s,b

Parameters	Details
p = print speed	<p>Values:</p> <ul style="list-style-type: none"> 1 = 25.4 mm/sec. (1 inch/sec.) ^v A or 2 = 50.8 mm/sec. (2 inches/sec.) B or 3 = 76.2 mm/sec. (3 inches/sec.) C or 4 = 101.6 mm/sec. (4 inches/sec.) 5 = 127 mm/sec.(5 inches/sec.) D or 6 = 152.4 mm/sec. (6 inches/sec.) 7 = 177.8 mm/sec. (7 inches/sec.) E or 8 = 203.2 mm/sec. (8 inches/sec.) 9 = 220.5 mm/sec. 9 inches/sec.) 10 = 245 mm/sec.(10 inches/sec.) 11 = 269.5 mm/sec.(11 inches/sec.) 12 = 304.8 mm/sec. 12 inches/sec.) 13 = 13 in/sec ^w 14 = 14 in/sec ^w <p>Default: A</p>
s = slew speed	<p>Values:</p> <ul style="list-style-type: none"> A or 2 = 50.8 mm/sec. (2 inches/sec.) B or 3 = 76.2 mm/sec. (3 inches/sec.) C or 4 = 101.6 mm/sec. (4 inches/sec.) 5 = 127 mm/sec. 5 inches/sec.) D or 6 = 152.4 mm/sec. (6 inches/sec.) 7 = 177.8 mm/sec. (7 inches/sec.) E or 8 = 203.2 mm/sec. (8 inches/sec.) 9 = 220.5 mm/sec. (9 inches/sec.) 10 = 245 mm/sec. (10 inches/sec.) 11 = 269.5 mm/sec. 11 inches/sec.) 12 = 304.8 mm/sec. 12 inches/sec.) 13 = 13 in/sec ^w 14 = 14 in/sec ^w <p>Default: D</p>

v. This value is supported only on the 110Xi4-600dpi, 110XiIIIPlus-600dpi, and RXi printers.

w. This value is supported only on the Xi4 and RXi4 printers.

Parameters	Details
b = backfeed speed	<p>Values:</p> <ul style="list-style-type: none"> A or 2 = 50.8 mm/sec. (2 inches/sec.) B or 3 = 76.2 mm/sec. (3 inches/sec.) C or 4 = 101.6 mm/sec. (4 inches/sec.) 5 = 127 mm/sec.(5 inches/sec.) D or 6 = 152.4 mm/sec. (6 inches/sec.) 7 = 177.8 mm/sec. (7 inches/sec.) E or 8 = 203.2 mm/sec. (8 inches/sec.) 9 = 220.5 mm/sec. 9 inches/sec.) 10 = 245 mm/sec. 10 inches/sec.) 11 = 269.5 mm/sec. 11 inches/sec.) 12 = 304.8 mm/sec. 12 inches/sec.) 13 = 13 in/sec ^w 14 = 14 in/sec ^w <p>Default: A</p>

v. This value is supported only on the 110Xi4-600dpi, 110XiIIIPlus-600dpi , and RXi printers.

w. This value is supported only on the Xi4 and RXi4 printers.

Comments The speed setting for **p**, **s**, and **b** is dependent on the limitations of the printer. If a particular printer is limited to a rate of 6 ips (inches per second), a value of 12 can be entered but the printer performs only at a 6 ips rate. See your printer’s User Guide for specifics on performance.

This command is ignored on the HC100 printer.

~PS – Print Start

The ~PS command causes a printer in Pause Mode to resume printing. The operation is identical to pressing PAUSE on the control panel of the printer when the printer is already in Pause Mode.

Format: ~PS

^PW – Print Width

The ^PW command allows you to set the print width.

Format: ^PWa

Parameters	Details
a = label width (in dots)	Values: 2, to the width of the label If the value exceeds the width of the label, the width is set to the label's maximum size. Default: last permanently saved value

Comments This command is ignored on the HC100™ printer.

~RO – Reset Advanced Counters

The ~RO command resets the advanced counters used by the printer to monitor label generation in inches, centimeters, and number of labels.

Format: ~ROc

Parameters	Details
c = counter number	<p>Values:</p> <ul style="list-style-type: none"> 1 = reset counter 1 2 = reset counter 2 3 = reset valid RFID label counter 4 = reset voided RFID label counter C = reset head cleaned counter ^x R = reset head replaced counter and head cleaned counter ^x <p>Default: a value must be specified or the command is ignored</p>

x. These values are supported only on Xi4, RXi4, ZM400/ZM600, RZ400/RZ600, S4M, and G-Series printers.

➔ **Example 1:** This example shows how the counter portion of the printer configuration labels looks when counter 1 is reset by sending ~R01.

Before

```

➔ 296862 IN..... NONRESET CNTR
➔ 296862 IN..... RESET CNTR1
➔ 296862 IN..... RESET CNTR2
➔ 753289 CM..... NONRESET CNTR
➔ 753289 CM..... RESET CNTR1
➔ 753289 CM..... RESET CNTR2
➔ 92928 LABLS..... NONRESET CNTR
➔ 92928 LABLS..... RESET CNTR1
➔ 92928 LABLS..... RESET CNTR2

```

After

```

➔ 296876 IN..... NONRESET CNTR
➔ 0 IN..... RESET CNTR1
➔ 296876 IN..... RESET CNTR2
➔ 753323 CM..... NONRESET CNTR
➔ 0 CM..... RESET CNTR1
➔ 753323 CM..... RESET CNTR2
➔ 92930 LABLS..... NONRESET CNTR
➔ 0 LABLS..... RESET CNTR1
➔ 92930 LABLS..... RESET CNTR2

```

^SC – Set Serial Communications

The ^SC command allows you to change the serial communications parameters you are using.

Format: ^SCa,b,c,d,e,f

Parameters	Details
a = baud rate	Values: 110 ^y ; 300; 600; 1200; 2400; 4800; 9600; 14400; 19200; 28800; 38400; or 57600; 115200 Default: must be specified or the parameter is ignored
b = word length (in data bits)	Values: 7 or 8 Default: must be specified
c = parity	Values: N (none), E (even), or O (odd) Default: must be specified
d = stop bits	Values: 1 or 2 Default: must be specified
e = protocol mode	Values: X = XON/XOFF D = DTR/DSR R = RTS M = DTR/DSR XON/XOFF ^z Default: must be specified
f = Zebra protocol	Values: A = ACK/NAK N = none Z = Zebra Default: must be specified

- y. This value is not supported on Xi4, RXi4, ZM400/ZM600, RZ400/RZ600, and S4M printers.
- z. This parameter is supported only on G-Series printers. Using the DTR/DSR XON/XOFF mode will cause the printer to respond to either DTR/DSR or XON/XOFF, depending on which method is first received from the host device.

Comments If any of the parameters are missing, out of specification, not supported by a particular printer, or have a ZPL-override DIP switch set, the command is ignored.

A ^JUS command causes the changes in Communications Mode to persist through power-up and software resets.

~SD – Set Darkness

The **~SD** command allows you to set the darkness of printing. **~SD** is the equivalent of the darkness setting parameter on the control panel display.

Format: ~SD##

Parameters	Details
## = desired darkness setting (two-digit number)	Values: 00 to 30 Default: last permanently saved value



Important • The darkness setting range for the *XiIIIPlus*, Xi4, and RXi4 is 0 to 30 in increments of 0.1. The firmware is setup so that the **^MD** and **~SD** commands (ZPL darkness commands) accept that range of settings.



Example: These are examples of the *XiIIIPlus*, Xi4, and RXi4 Darkness Setting:

^MD8.3

~SD8.3

Comments The **^MD** command value, if applicable, is added to the **~SD** command.

^SE – Select Encoding Table

The ^SE command is used to select the desired ZPL or ZPL II encoding table.

Format: ^SEd:o.x

Parameters	Details
d = location of encoding table	Values: R:, E:, B:, and A: Default: R:
o = name of encoding table	Values: 1 to 8 alphanumeric characters Default: a value must be specified
x = extension	Fixed Value: .DAT

The encoding tables are provided with the font card or downloaded in flash with the font. The table appears as XXXXXX.DAT in a directory label printed by the ZPL commands.

The most active encoding table is indicated by the * on the directory label.



Example:

```
^XA^WD*:*.*^XZ
```

^SF – Serialization Field (with a Standard ^FD String)

The ^SF command allows you to serialize a standard ^FD string. The maximum size of the mask and increment string is 3K combined.



In firmware version x.14 and later, strings are serialized from the last character in the backing store with regard to the alignment of the mask and increment strings. For combining semantic clusters that do not get incremented, the mask character % needs to be added to the increment string.

Format: ^SFa,b

Parameters	Details
a = mask string	<p>The mask string sets the serialization scheme. The length of the string mask defines the number of characters (or in firmware version x.14 and later, combining semantic clusters) in the current ^FD string to be serialized. The mask is aligned to the characters (or in firmware version x.14 and later, combining semantic clusters) in the ^FD string starting with the right-most (or in firmware x.14 and later, last) in the backing store position.</p> <p><i>Mask String placeholders:</i></p> <ul style="list-style-type: none"> D or d – Decimal numeric 0–9 H or h – Hexadecimal 0–9 plus a-f or A-F O or o – Octal 0–7 A or a – Alphabetic A–Z or a–z N or n – Alphanumeric 0–9 plus A–Z or a–z % – Ignore character or skip
b = increment string	<p>The increment string is the value to be added to the field on each label. The default value is equivalent to a decimal value of one. The string is composed of any characters (or in firmware version x.14 and later, combining semantic clusters) defined in the serial string. Invalid characters (or in firmware version x.14 and later, combining semantic clusters) are assumed to be equal to a value of zero in that characters (or in firmware version x.14 and later, combining semantic clusters) position.</p> <p>The increment value for alphabetic strings start with 'A' or 'a' as the zero placeholder. This means to increment an alphabetic character (or in firmware version x.14 and later, combining semantic cluster) by one, a value of 'B' or 'b' must be in the increment string.</p>

For characters that do not get incremented, the % character needs to be added to the increment string.



Example 1: This is an example of serializing a ^FD string. The ZPL II code generates three separate labels as seen in Generated Labels:

ZPL II CODE	GENERATED LABELS
<pre> ^XA ^FO100,100 ^CF0,100 ^FD12A^SFnnA,F^FS ^PQ3 ^XZ </pre>	<div style="border: 1px solid black; padding: 5px; text-align: center; font-size: 24pt; font-weight: bold;">12K</div> <div style="border: 1px solid black; padding: 5px; text-align: center; font-size: 24pt; font-weight: bold;">12F</div> <div style="border: 1px solid black; padding: 5px; text-align: center; font-size: 24pt; font-weight: bold;">12A</div>

This mask has the first characters (or in firmware version x.14 and later, the first combining semantic clusters) as alphanumeric (**nn** = 12) and the last digit as uppercase alphabetic (A). The decimal value of the increment number is equivalent to 5 (F). The number of labels generated depends on the number specified by the ^PQ command.

In a similar instance, the ^FD string could be replaced with either of the ^FD strings below to generate a series of label, determined by ^PQ.

Using this ZPL code:

```
^FDBL0000^SFAAdddd,1
```

The print sequence on this series of labels is:

```
BL0000, BL0001, ... BL0009, BL0010, ...
```

```
BL0099, BL0100, ... BL9999, BM0000...
```

Using this ZPL code:

```
^FDBL00-0^SFAAdd%d,1%1
```

The print sequence on this series of labels is:

```
BL00-0, BL01-1, BL02-2, ... BL09-9,
```

```
BL11-0, BL12-1...
```



Important notes about masking for firmware version V60.14.x, V50.14.x, or later:

- A single % masks an entire combining semantic cluster rather than a single code point.
- The mask string and increment string should be aligned at the last code point in their respective backing stores.
- Control and bidirectional characters do not require a mask and are ignored for serialization purposes.

The following examples show the importance of capitalization and location within the mask.



Example 2: In this example, the printer cycles with every two printed labels and alternates between H (position 18), and then Z (position 36). With n or N, the serial number increments from 0 - 9 and a-z or A-Z (36 positions overall). With each completed cycle, the second cluster (nn) increments one position (from 00, 01, 02 ...) per cycle:

ZPL II CODE	GENERATED LABELS
<pre> ^XA ^FO100,50^A0N,50,50^FDzzz^SFnnN,I^FS ^PQ10 ^XZ </pre>	



Example 3: In this example, lower case i increments with a mask string of nnN. Nothing changes because the first cluster (Z) never triggers the second cluster (zz) to change.

ZPL II CODE	GENERATED LABELS
<pre> ^XA ^FO100,50^A0N,50,50^FDzzz^SFnnN,i^FS ^PQ10 ^XZ </pre>	

^SI – Set Sensor Intensity



This command is available only for printers with firmware versions V53.15.x or later.

The ^SI command is used to change the values for the media sensors, which are also set during the media calibration process. The media calibration process is described in your specific printer's user's guide.

Supported Devices

- Xi4 with firmware V53.17.1Z or later
- RXi4 with firmware V53.17.7Z or later
- ZM400/ZM600 with firmware V53.15.xZ or later
- RZ400/RZ600 with firmware R53.15.xZ or later

Format: ^SIa,b

Parameters	Details
a = indicates the setting to modify	Values: 1 = transmissive sensor brightness setting 2 = transmissive sensor baseline setting Default: must be an accepted value or the entire command is ignored
b = the value to use for the sensor being configured	The ranges for this parameter are the same for the accepted values in parameter a . Values: 0 to 196 Default: must be an accepted value or the entire command is ignored

^SL – Set Mode and Language (for Real-Time Clock)

The ^SL command is used to specify the Real-Time Clock's mode of operation and language for printing information.



Important •

- Time is read when the image is created. If the image stays in the queue longer than the specified time the image will be recreated with a new time.
- There are incidents when the same time or a larger space of time may be printed on labels. This is due to the format complexity and print speed.

Format: ^SLa,b

Parameters	Details
a = mode	<p>Values:</p> <p>S = Start Time Mode. This is the time that is read from the Real-Time Clock when label formatting begins (when ^XA is received). The first label has the same time placed on it as the last label.</p> <p>T = Time Now Mode. This is the time that is read from the Real-Time Clock when the label to be printed is placed in print queue. <i>Time Now</i> is similar to a serialized time or date field.</p> <p>Numeric Value = With the Enhanced Real Time Clock (V60.13.0.10 or later) a time accuracy tolerance can be specified. Range = 1 to 999 seconds, 0 = one second tolerance</p> <p>Example: SL30,1 = Accuracy tolerance of 30 seconds and use English.</p> <p>Default: S</p>
b = language	<p>Values:</p> <p>1 = English</p> <p>2 = Spanish</p> <p>3 = French</p> <p>4 = German</p> <p>5 = Italian</p> <p>6 = Norwegian</p> <p>7 = Portuguese</p> <p>8 = Swedish</p> <p>9 = Danish</p> <p>10 = Spanish 2</p> <p>11 = Dutch</p> <p>12 = Finnish</p> <p>13 = Japanese</p> <p>14 = Korean ^{aa}</p> <p>15 = Simplified Chinese ^{aa}</p> <p>16 = Traditional Chinese ^{aa}</p> <p>17 = Russian ^{aa}</p> <p>18 = Polish ^{aa}</p> <p>Default: the language selected with ^KL or the control panel</p>



Value 13 is only supported in firmware versions V60.14.x, V50.14.x, or later.

^{aa}These values are only supported on the Xi4, RXi4, ZM400/ZM600, and RZ400/RZ600 printers.

Comments These are some comments to be aware of:

- The ^SL command must be placed before the first ^FO command.

- As of V60.13.0.10 all supported printers have Enhanced Real Time Clock capabilities the RTC will not print time fields that are more than sixty seconds old, rather it will update the time prior to printing (^SLT or ^SL60). To control time with increments other than sixty seconds the ^SL command can be used with a numeric value (^SL30). ^SLS can keep times longer than sixty seconds.

For more details on set mode and language with the Real-Time Clock, see [Real Time Clock on page 1375](#).

^SN – Serialization Data

The ^SN command allows the printer to index data fields by a selected increment or decrement value, making the data fields increase or decrease by a specified value each time a label is printed. This can be performed on 100 to 150 fields in a given format and can be performed on both alphanumeric and bar code fields. A maximum of 12 of the right- most integers are subject to indexing.



In x.13 and earlier, the first integer found when scanning from right to left starts the indexing portion of the data field.



In x.14 and later, the first integer found when scanning from end of the backing store towards the beginning starts the indexing portion of the data field.



In x.13 and earlier, if the alphanumeric field to be indexed ends with an alpha character, the data is scanned, character by character, from right to left until a numeric character is encountered. Serialization takes place using the value of the first number found.



In x.14 and later, if the backing store of the alphanumeric field to be indexed ends with an alpha character, the data is scanned, character by character, from the end of the backing store until a numeric character is encountered. Serialization takes place using the value of the first number found.

Format: ^SNv,n,z

Parameters	Details
v = starting value	Values: 12-digits maximum for the portion to be indexed Default: 1
n = increment or decrement value	Values: 12-digit maximum Default: 1 To indicate a decrement value, precede the value with a minus (-) sign.
z = add leading zeros (if needed)	Values: N = no Y = yes Default: N



Example: This example shows incrementing by a specified value:

ZPL II CODE	GENERATED LABELS
<pre> ^XA ^FO260,110 ^CFG ^SN001,1,Y^FS ^PQ3 ^XZ </pre> <p><i>Note: The ZPL II code above will generate three separate labels, seen to the right.</i></p>	<div style="border: 1px solid black; padding: 10px; text-align: center; margin-bottom: 5px;">001</div> <div style="border: 1px solid black; padding: 10px; text-align: center; margin-bottom: 5px;">002</div> <div style="border: 1px solid black; padding: 10px; text-align: center;">003</div>

Comments Incrementing and decrementing takes place for each serial-numbered field when all replicates for each serial number have been printed, as specified in parameter *r* of the ^PQ (print quality) command.

If, during the course of printing serialized labels, the printer runs out of either paper or ribbon, the first label printed (after the media or ribbon has been replaced and calibration completed) has the same serial number as the *partial* label printed before the *out* condition occurred. This is done in case the last label before the *out* condition did not fully print. This is controlled by the ^JZ command.

Using Leading Zeros

In the ^SN command, the *z* parameter determines if leading zeros are printed or suppressed. Depending on which value is used (**Y** = print leading zeros; **N** = do not print leading zeros), the printer either prints or suppresses the leading zeros.

The default value for this parameter is **N** (do not print leading zeros).

Print Leading Zeros



In x.13 and earlier, the starting value consists of the right-most consecutive sequence of digits.



In x.14 and later, the starting value consists of the first number working backwards in the backing store consecutive sequence of digits. The width (number of digits in the sequence) is determined by scanning from right to left until the first non-digit (space or alpha character) is encountered. To create a specific width, manually place leading zeros as necessary.

Suppressing Leading Zeros



In x.13 and earlier, the starting value consists of the right-most consecutive sequence of digits, including any leading spaces.



In x.14 or later, the starting value consists of the first number working backwards in the backing store consecutive sequence of digits, including any leading spaces.

^SO – Set Offset (for Real-Time Clock)

The ^SO command is used to set the secondary and the tertiary offset from the primary Real-Time Clock.



Note • For each label only one S02 command can be used. If more than one offset is required, S03 must be used.

Format: ^SOa,b,c,d,e,f,g

Parameters	Details
a = clock set	Values: 2 = secondary 3 = third Default: value must be specified
b = months offset	Values: -32000 to 32000 Default: 0
c = days offset	Values: -32000 to 32000 Default: 0
d = years offset	Values: -32000 to 32000 Default: 0
e = hours offset	Values: -32000 to 32000 Default: 0
f = minutes offset	Values: -32000 to 32000 Default: 0
g = seconds offset	Values: -32000 to 32000 Default: 0

For more detail on set offset, see [Real Time Clock on page 1375](#).

^SP – Start Print

The ^SP command allows a label to start printing at a specified point before the entire label has been completely formatted. On extremely complex labels, this command can increase the overall throughput of the print.

The command works as follows: Specify the dot row at which the ^SP command is to begin. This creates a label *segment*. Once the ^SP command is processed, all information in that segment prints. During the printing process, all of the commands after the ^SP continue to be received and processed by the printer.

If the segment after the ^SP command (or the remainder of the label) is ready for printing, media motion does not stop. If the next segment is not ready, the printer stops mid-label and wait for the next segment to be completed. Precise positioning of the ^SP command requires a trial-and-error process, as it depends primarily on print speed and label complexity.

The ^SP command can be effectively used to determine the worst possible print quality. You can determine whether using the ^SP command is appropriate for the particular application by using this procedure.

If you send the label format up to the first ^SP command and then wait for printing to stop before sending the next segment, the printed label is a sample of the worst possible print quality. It drops any field that is out of order.

If the procedure above is used, the end of the label format must be:

^SP#^FS

Comments ^SPa

Parameters	Details
a = dot row to start printing	Values: 0 to 32000 Default: 0



Example: In this example, a label 800 dot rows in length uses ^SP500. Segment 1 prints while commands in Segment 2 are being received and formatted.



^SQ – Halt ZebraNet Alert

The ^SQ command is used to stop the ZebraNet Alert option.

Format: ^SQa,b,c

Parameters	Details
a = condition type	Values: A = paper out B = ribbon out C = printhead over-temp D = printhead under-temp E = head open F = power supply over-temp G = ribbon-in warning (Direct Thermal Mode) H = rewind full I = cut error J = printer paused K = PQ job completed L = label ready M = head element out N = ZBI (Zebra BASIC Interpreter) runtime error O = ZBI (Zebra BASIC Interpreter) forced error Q = clean printhead R = media low S = ribbon low T = replace head U = battery low V = RFID error (in RFID printers only) W = all errors (in RFID printers only) * = all errors (in non-RFID printers)
b = destination	Values: A = serial port B = parallel port C = e-mail address D = TCP/IP E = UDP/IP F = SNMP trap * = wild card to stop alerts for all destinations
c = halt messages	Values: Y = halt messages N = start messages Default: Y

^SR – Set Printhead Resistance

The ^SR command allows you to set the printhead resistance.

Format: ^SR####

Parameters	Details
#### = resistance value (four-digit numeric value)	Values: 0488 to 1175 Default: last permanently saved value

Comments To avoid damaging the printhead, this value should be less than or equal to the value shown on the printhead being used. Setting a higher value could damage the printhead.



Note • New printer models automatically set head resistance.

^SS – Set Media Sensors


The ^SS command is used to change the values for media, web, ribbon, and label length set during the media calibration process. The media calibration process is described in your specific printer's user's guide.

Format: ^SSw,m,r,l,m2,r2,a,b,c

Parameters	Details
w = web (three-digit value)	Values: 000 to 100 Default: value shown on the media sensor profile or configuration label
m = media (three-digit value)	Values: 000 to 100 Default: value shown on the media sensor profile or configuration label
r = ribbon (three-digit value)	Values: 000 to 100 Default: value shown on the media sensor profile or configuration label
l = label length (in dots, four-digit value)	Values: 0001 to 32000 Default: value calculated in the calibration process
m2 = intensity of media LED (three-digit value)	Values: 000 to 255 Default: value calculated in the calibration process
r2 = intensity of ribbon LED (three-digit value)	Values: 000 to 255 Default: value calculated in the calibration process
a = mark sensing (three-digit value)	Values: 000 to 100 Default: value calculated in the calibration process
b = mark media sensing (three-digit value)	Values: 000 to 100 Default: value calculated in the calibration process
c = mark LED sensing (three-digit value)	Values: 000 to 255 Default: value calculated in the calibration process



Example: Below is an example of a media sensor profile. Notice the numbers from 000 to 100 and where the words WEB, MEDIA, and RIBBON appear in relation to those numbers. Also notice the black vertical spike. This represents where the printer sensed the transition from media-to-web-to-media.



The media and sensor profiles produced vary in appearance from printer to printer.

Comments The **m2** and **r2** parameters have no effect in Stripe® S-300 and S-500 printers. This command is ignored on the HC100™ printer.

Maximum values for parameters depend on which printer platform is being used.

^ST – Set Date and Time (for Real-Time Clock)

The ^ST command sets the date and time of the Real-Time Clock.

Format: ^STa,b,c,d,e,f,g

Parameters	Details
a = month	Values: 01 to 12 Default: current month
b = day	Values: 01 to 31 Default: current day
c = year	Values: 1998 to 2097 Default: current year
d = hour	Values: 00 to 23 Default: current hour
e = minute	Values: 00 to 59 Default: current minute
f = second	Values: 00 to 59 Default: current second
g = format	Values: A = a.m. P = p.m. M = 24-hour military Default: M

For more details on set date and time, see [Real Time Clock on page 1375](#).

^SX – Set ZebraNet Alert

The ^SX command is used to configure the ZebraNet Alert System.

Format: ^SXa,b,c,d,e,f



Note • The values in this table apply to firmware version V48.12.4 or later.

Parameters	Details
a = condition type	<p>Values:</p> <ul style="list-style-type: none"> A = paper out B = ribbon out C = printhead over-temp D = printhead under-temp E = head open F = power supply over-temp G = ribbon-in warning (Direct Thermal Mode) H = rewind full I = cut error J = printer paused K = PQ job completed L = label ready M = head element out N = ZBI (Zebra BASIC Interpreter) runtime error O = ZBI (Zebra BASIC Interpreter) forced error P = power on Q = clean printhead R = media low S = ribbon low T = replace head U = battery low V = RFID error (in RFID printers only) * = all errors <p>Default: if the parameter is missing or invalid, the command is ignored</p>
b = destination for route alert	<p>Values:</p> <ul style="list-style-type: none"> A = serial port B* = parallel port C = e-mail address D = TCP/IP E = UDP/IP F = SNMP trap <p>Default: If this parameter is missing or invalid, the command is ignored. * Requires bidirectional communication.</p>
c = enable <i>condition</i> set alert to this destination	<p>Values:</p> <ul style="list-style-type: none"> N = no Y = yes <p>Values: Y or previously configured value</p>

Parameters	Details
d = enable condition clear alert to this destination	Values: N = no Y = yes Values: N or previously configured value Parameters e and f are sub-options based on destination. If the sub-options are missing or invalid, these parameters are ignored.
e = destination setting	Values: Internet e-mail address (e.g. user@company.com) IP address (for example, 10.1.2.123) SNMP trap IP or IPX addresses
f = port number	Values: TCP port # (0 to 65535) UDP port # (0 to 65535)



Example: This is an example of the different (b) destinations that you can send for the condition type (a):

Serial: ^SXA,A,Y,Y
 Parallel: ^SXA,B,Y,Y
 E-Mail: ^SXA,C,Y,Y,admin@company.com
 TCP: ^SXA,D,Y,Y,123.45.67.89,1234
 UDP: ^SXA,E,Y,Y,123.45.67.89,1234
 SNMP Trap: ^SXA,F,Y,Y,255.255.255.255

Comments In the example above for SNMP Trap, entering 255.255.255.255 broadcasts the notification to every SNMP manager on the network. To route the device to a single SNMP manager, enter a specific address (123.45.67.89).

^SZ – Set ZPL Mode

The ^SZ command is used to select the programming language used by the printer. This command gives you the ability to print labels formatted in both ZPL and ZPL II.

This command remains active until another ^SZ command is sent to the printer or the printer is turned off.

Format: ^SZa

Parameters	Details
a = ZPL version	Values: 1 = ZPL 2 = ZPL II Default: 2

Comments If the parameter is missing or invalid, the command is ignored.

~TA – Tear-off Adjust Position

The ~TA command lets you adjust the rest position of the media after a label is printed, which changes the position at which the label is torn or cut.

Format: ~TA###



Important • These are some important facts about this command:

- For 600 dpi printers, the step size doubles.
- If the number of characters is **less than 3**, the command is ignored.

Parameters	Details
### = change in media rest position (3-digit value in dot rows must be used.)	Values: -120 to 120 0 to 120 (on the HC100) Default: last permanent value saved

Comments If the parameter is missing or invalid, the command is ignored.

^TB – Text Blocks



This command is available only for printers with firmware version V60.14.x, V50.14.x, or later.

The ^TB command prints a text block with defined width and height. The text block has an automatic word-wrap function. If the text exceeds the block height, the text is truncated. This command supports complex text layout features.



Note • ^TB is the preferred command for printing fields or blocks of text, instead of ^FB.

Format: ^TBa,b,c

Parameters	Details
a = block rotation	<p>Values:</p> <ul style="list-style-type: none"> N = normal R = rotate 90 degrees clockwise I = invert 180 degrees B = read from bottom up-270 degrees <p>Default: whatever was specified by the last ^A (which has the default of ^FW)</p>
b = block width in dots	<p>Values:</p> <ul style="list-style-type: none"> 1 to the width of the label in dots <p>Default: 1 dot</p>
c = block height in dots	<p>Values:</p> <ul style="list-style-type: none"> 1 to the length of the label in dots <p>Default: 1 dot</p>

Comments Facts about the ^TB command:

- Justification of ^TB command comes from ^FO, ^FT, or ^FN command. If no justification is determined then the default is auto justification.
- Data between < and > is processed as an escape sequence; for example, <<> will print <.
- The ^TB command has an automatic word-wrap function. Soft hyphens do not print and are not used as a line break position.

^TO – Transfer Object

The ^TO command is used to copy an object or group of objects from one storage device to another. It is similar to the copy function used in PCs.

Source and destination devices must be supplied and must be different and valid for the action specified. Invalid parameters cause the command to be ignored.

The asterisk (*) can be used as a wild card for object names and extensions. For instance, **ZEBRA.*** or ***.GRF** are acceptable forms for use with the ^TO command.

At least one source parameter (**d**, **o**, or **x**) and one destination parameter (**s**, **o**, or **x**) must be specified. If only ^TO is entered, the command is ignored.

Format: ^TOs:o.x,d:o.x

Parameters	Details
s = source device of stored object	Values: R:, E:, B:, and A: Default: if a drive is not specified, all objects are transferred to the drive set in parameter s
o = stored object name	Values: any existing object conforming to Zebra conventions Default: if a name is not specified, * is used — all objects are selected
x = extension	Values: any extension conforming to Zebra conventions Default: if an extension is not specified, * is used — all extensions are selected
d = destination device of the stored object	Values: R:, E:, B:, and A: Default: a destination must be specified
o = name of the object at destination	Values: up to 8 alphanumeric characters Default: if a name is not specified, the name of the existing object is used
x = extension	Values: any extension conforming to Zebra conventions Default: if an extension is not specified, the extension of the existing object is used

Comments Parameters **o**, **x**, and **s** support the use of the wild card (*).

If the destination device does not have enough free space to store the object being copied, the command is canceled.

Zebra files (**Z:*.***) cannot be transferred. These files are copyrighted by Zebra Technologies.

Transferring Objects

These are some examples of using the ^TO command.



Example 1: To copy the object **ZLOGO.GRF** from DRAM to an optional Memory Card and rename it **ZLOGO1.GRF**, write the following format:

```
^XA
^TOR:ZLOGO.GRF,B:ZLOGO1.GRF
^XZ
```



Example 2: To copy the object **SAMPLE.GRF** from an optional Memory Card to DRAM and keep the same name, write this format:

```
^XA
^TOB: SAMPLe .GRF , R: SAMPLe .GRF
^XZ
```

Transferring Multiple Objects

The asterisk (*) can be used to transfer multiple object files (except *.FNT) from DRAM to the Memory Card. For example, assume you have several object files that contain logos. These files are named **LOGO1.GRF**, **LOGO2.GRF**, and **LOGO3.GRF**.

To transfer all these files to the memory card using the name **NEW** instead of **LOGO**, place an asterisk after the names **NEW** and **LOGO** in the transfer command. This copies all files beginning with **LOGO** in one command.

```
^XA
^TOR: LOGO* .GRF , B: NEW* .GRF
^XZ
```

During a multiple transfer, if a file is too big to be stored on the memory card, that file is skipped. All remaining files attempt to be transferred. All files that can be stored within the space limitations are transferred, while other files are ignored.

~WC – Print Configuration Label

The ~WC command is used to generate a printer configuration label. The printer configuration label contains information about the printer setup, such as sensor type, network ID, ZPL mode, firmware version, and descriptive data on the **R:**, **E:**, **B:**, and **A:** devices.

Format: ~WC

Comments This command works only when the printer is idle.

PRINTER CONFIGURATION	
Zebra Technologies	
ZTC Z4MPlus-200 dpi	
140XiiiIplus	
Zebra	
+12.....	DARKNESS
6 IPS.....	PRINT SPEED
+000.....	TEAR OFF
TEAR OFF.....	PRINT MODE
CONTINUOUS.....	MEDIA TYPE
WEB.....	SENSOR TYPE
AUTO SELECT.....	SENSOR SELECT
THERMAL-TRANS.....	PRINT METHOD
101 4/8 MM.....	PRINT WIDTH
2000.....	LABEL LENGTH
39.0IN 988MM.....	MAXIMUM LENGTH
BIDIRECTIONAL.....	PARALLEL COMM.
RS232.....	SERIAL COMM.
9600.....	BAUD
8 BITS.....	DATA BITS
NONE.....	PARITY
XON/XOFF.....	HOST HANDSHAKE
NONE.....	PROTOCOL
000.....	NETWORK ID
NORMAL MODE.....	COMMUNICATIONS
<~> 7EH.....	CONTROL PREFIX
<^> 5EH.....	FORMAT PREFIX
<, > 2CH.....	DELIMITER CHAR
ZPL II.....	ZPL MODE
CALIBRATION.....	MEDIA POWER UP
CALIBRATION.....	HEAD CLOSE
DEFAULT.....	BACKFEED
+000.....	LABEL TOP
+0020.....	LEFT POSITION
DISABLED.....	REPRINT MODE
070.....	WEB S.
070.....	MEDIA S.
072.....	RIBBON S.
100.....	TAKE LABEL
015.....	MEDIA LED
103.....	RIBBON LED
+10.....	LCD ADJUST
DPSWFXM.....	MODES ENABLED
.....	MODES DISABLED
832 8/MM FULL.....	RESOLUTION
V60.14.5Z <-.....	FIRMWARE
V23 ---- 57.....	HARDWARE ID
CUSTOMIZED.....	CONFIGURATION
3584k.....	R: RAM
2048k.....	E: ONBOARD FLASH
NONE.....	FORMAT CONVERT
CUTTER.....	OPTION
FW VERSION.....	IDLE DISPLAY
04/03/07.....	RTC DATE
15:51.....	RTC TIME
NO.....	RFID READY
SELECTED ITEMS.....	PASSWORD LEVEL
GL 47277.04MS050224.79000.04.VH2.....	

FIRMWARE IN THIS PRINTER IS COPYRIGHTED

^WD – Print Directory Label

The ^WD command is used to print a label listing bar codes, objects stored in DRAM, or fonts.

For bar codes, the list shows the name of the bar code. For fonts, the list shows the name of the font, the number to use with ^A command, and size. For objects stored in DRAM, the list shows the name of the object, extension, size, and option flags. All lists are enclosed in a double-line box.

Format: ^WDd:o.x

Parameters	Details
d = source device – optional	Values: R:, E:, B:, A: and Z: Default: R:
o = object name – optional	Values: 1 to 8 alphanumeric characters Default: * The use of a ? (question mark) is also allowed.
x = extension – optional	Values: any extension conforming to Zebra conventions .FNT = font .BAR = bar code .ZPL = stored ZPL format .GRF = GRF graphic .CO = memory cache .DAT = font encoding .BAS = ZBI encrypted program .BAE = ZBI encrypted program .STO = data storage .PNG = PNG graphic * = all objects .TTF = TrueType Font .TTE = True Type Extension Default: * The use of a ? (question mark) is also allowed.

.14↑

.TTF and .TTE are only supported in firmware version V60.14.x, V50.14.x, or later.

➔ **Example 1:** To print a label listing all objects in DRAM, enter:

```
^XA
^WDR:*. *
^XZ
```

➔ **Example 2:** To print a label listing all resident bar codes, enter:

```
^XA
^WDZ:*.BAR
^XZ
```

➔ **Example 3:** To print a label listing all resident fonts, enter:

```
^XA
^WDZ:*.FNT
^XZ
```

~WQ – Write Query

The ~WQ command triggers the printer to print a label with odometer, maintenance or alert, and printhead history information.

Supported Devices

- Xi4 with firmware V53.17.1Z or later
- RXi4 with firmware V53.17.7Z or later
- ZM400/ZM600 with firmware V53.15.xZ or later
- RZ400/RZ600 with firmware R53.15.xZ or later
- S4M with firmware V53.15.4Z or later
- G-Series

Format: ~WQquery-type

Parameter	Details
query-type	<p>For detailed examples of these parameters, see ~WQ Examples on page 334.</p> <p>Values:</p> <p>ES = requests the printer’s status. For details see, Table 17 on page 333 and Table 18 on page 334.</p> <p>HA = hardware address of the internal wired print server</p> <p>JT = requests a summary of the printer’s printhead test results</p> <p>MA = maintenance alert settings</p> <p>MI = maintenance information</p> <p>OD = odometer</p> <p>PH = printhead life history</p> <p>PP = printer’s Plug and Play string</p> <p>SN = printer’s serial number</p> <p>UI = printer’s USB product ID and BCD release version</p> <p>Default: must be an accepted value or the command is ignored</p>

Table 17 • Error Flags (~WQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16-9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
No Error	0	00000000	0	0	0	0	0	0	0	0
Error Present	1	00000000	X	X	X	X	X	X	X	X
Printhead Thermistor Open	1	00000000	X	X	X	X	X	2	X	X
Invalid Firmware Config.	1	00000000	X	X	X	X	X	1	X	X
Printhead Detection Error	1	00000000	X	X	X	X	X	X	8	X
Bad Printhead Element	1	00000000	X	X	X	X	X	X	4	X
Motor Over Temperature	1	00000000	X	X	X	X	X	X	2	X
Printhead Over Temperature	1	00000000	X	X	X	X	X	X	1	X
Cutter Fault	1	00000000	X	X	X	X	X	X	X	8
Head Open	1	00000000	X	X	X	X	X	X	X	4

ab.This error flag is supported only on KR403 printers.

Table 17 • Error Flags (~WQES) (Continued)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16-9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
Ribbon Out	1	00000000	X	X	X	X	X	X	X	2
Media Out	1	00000000	X	X	X	X	X	X	X	1
Clear Paper Path Failed ^{ab}	1 ^{ab}	00000000	X	X	X	X	8 ^{ab}	X	X	X
Paper Feed Error ^{ab}	1 ^{ab}	00000000	X	X	X	X	4 ^{ab}	X	X	X
Presenter Not Running ^{ab}	1 ^{ab}	00000000	X	X	X	X	2 ^{ab}	X	X	X
Paper Jam during Retract ^{ab}	1 ^{ab}	00000000	X	X	X	X	1 ^{ab}	X	X	X
Black Mark not Found ^{ab}	1 ^{ab}	00000000	X	X	X	8 ^{ab}	X	X	X	X
Black Mark Calabrate Error ^{ab}	1 ^{ab}	00000000	X	X	X	4 ^{ab}	X	X	X	X
Retract Function timed out ^{ab}	1 ^{ab}	00000000	X	X	X	2 ^{ab}	X	X	X	X
Paused ^{ab}	1 ^{ab}	00000000	X	X	X	1 ^{ab}	X	X	X	X

^{ab}. This error flag is supported only on KR403 printers.

Table 18 • Warning Flags (~WQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16-9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
No Warning	0	00000000	0	0	0	0	0	0	0	0
Warning Present	1	00000000	X	X	X	X	X	X	X	X
Paper-near-end Sensor ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	X	X	8 ^{ac}
Replace Printhead	1	00000000	X	X	X	X	X	X	X	4
Clean Printhead	1	00000000	X	X	X	X	X	X	X	2
Need to Calibrate Media	1	00000000	X	X	X	X	X	X	X	1
Sensor 1 (Paper before head) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	X	1 ^{ac}	X
Sensor 2 (Black mark) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	X	2 ^{ac}	X
Sensor 3 (Paper after head) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	X	4 ^{ac}	X
Sensor 4 (loop ready) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	X	8 ^{ac}	X
Sensor 5 (presenter) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	1 ^{ac}	X	X
Sensor 6 (retract ready) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	2 ^{ac}	X	X
Sensor 7 (in retract) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	4 ^{ac}	X	X
Sensor 8 (at bin) ^{ac}	1 ^{ac}	00000000	X	X	X	X	X	8 ^{ac}	X	X

^{ac}. This error flag is supported only on KR403 printers.

~WQ Examples

This section provides detailed examples of all the available parameters.



Example 1: This example shows how to request the printer's status.

- To request the printer's status, type `~WQES`

A label similar to this prints out:


```

PRINTER STATUS
ERRORS:      1 00000000 00000005
WARNINGS:    1 00000000 00000002
    
```

In this example, the Printer Status resolves to these conditions:

- The cover/printhead is open (value = 4).
- Media is out or not loaded into the printer (value = 1).
- The printhead needs to be cleaned (value = 2).
- Error nibble 1 is equal to 5 when the error status values are added together (4+1).

This illustration identifies the printer status definitions:



1	Flag
2	Nibble 16-9
3	Nibble 8-4
4	Nibble 3
5	Nibble 2
6	Nibble 1



Example 2: This example shows how to request the printer's status.

- To request the printer's status, type `~WQES`

A label similar to this prints out:

```

PRINTER STATUS
ERRORS:      1 00000000 0000000B
WARNINGS:    0 00000000 00000000
    
```

In the example shown above, the Printer Status resolves to the following conditions:

- The cutter has a fault. (value = 8).
- Ribbon is out or not loaded into the printer (value = 2).
- Media is out or not loaded into the printer (value = 1).
- Error byte 1 is equal to **B** when the error status values are added together (8 + 2 + 1 = hexadecimal B).

➔ **Example 3:** This is an example of how to print the hardware address of the internal wired print server.

1. To print the hardware address of the internal wired print server, type `~WQHA`
A label similar to this prints out:

```
MAC ADDRESS
00:07:4d:2c:e0:7a
```

➔ **Example 4:** This is an example of how to print a summary of the printer's printhead test results.

The `^JT` command is used to initiate printhead testing, set the testing interval, and set the element range to be tested. For more details see, [^JT on page 248](#).

1. To request a summary of the printer's printhead test, type `~WQJT`
A label similar to this prints out:


```
PRINT HEAD TEST RESULTS
0,A,0000,0000,0000
```

When the printer has printed enough labels to trigger a printhead test, the initial data changes.

1. To request a summary of the printer's printhead test, type `~WQJT`
A label similar to this prints out:

```
PRINT HEAD TEST RESULTS
0,A,0015,0367,0000
```

This illustration identifies the printhead test field definitions:



1	Element failure
2	Manual (M) or automatic (A) range
3	First test element
4	Last test element
5	Failure count

➔ **Example 5:** This is an example of how to print the maintenance alert query for the ~WQ command.

1. To get the current settings, type ~WQMA

A label similar to this prints out:

```

MAINTENANCE ALERT SETTINGS
HEAD REPLACEMENT INTERVAL:      1 km
HEAD REPLACEMENT FREQUENCY:    0 M
HEAD CLEANING INTERVAL:        0 M
HEAD CLEANING FREQUENCY:       0 M
PRINT REPLACEMENT ALERT:       NO
PRINT CLEANING ALERT:          NO
UNITS:                          C

```

➔ **Example 6:** This is an example of how to use the odometer query for the ~WQ command. Note that the units of measure are controlled by the ^MA command. Also, if the "Early Warning Maintenance State" is turned "ON" the printer response would also list LAST CLEANED and CURRENT PRINTHEAD LIFE counters.

1. To get the current settings, type ~WQOD

A label similar to this prints out:

```

PRINT METERS
TOTAL NONRESETTABLE:           8560 "
USER RESETTABLE CNTR1:         9 "
USER RESETTABLE CNTR2:         8560 "

```

The units of measure are set to inches.

1. To change the units of measure to centimeters, type:

```
^XA^MA,,,,C
```

```
^XZ
```

The units of measure are set to centimeters.

2. To check the settings, type ~WQOD.

A label similar to this prints out:

```

PRINT METERS
TOTAL NONRESETTABLE:           21744 cm
USER RESETTABLE CNTR1:         24 cm
USER RESETTABLE CNTR2:         21744 cm

```

➔ **Example 7:** This is an example of how to print the maintenance information query for the ~WQ command. Note that the message is controlled by the ^MI command.

1. To get the current settings, type ~WQMI

A label similar to this prints out:

```

MAINTENANCE ALERT MESSAGES
CLEAN: PLEASE CLEAN PRINT HEAD
REPLACE: PLEASE REPLACE PRINT HEAD

```

➔ **Example 8:** This is an example of how to print the printhead life query for the ~WQ command. Note that the units of measure are controlled by the ^MA command.

1. To get the current settings, type ~WQPH
A label similar to this prints out:

```

LAST CLEANED:                257 "
HEAD LIFE HISTORY
# DISTANCE
1: 257 "
2: 1489 "
3: 7070 "
    
```

1	The current life of the print head.
2	Line items 2 through 10 (the example only shows 2 through 3) tracks the measurement for each time the print head is changed.

➔ **Example 9:** This is an example of how to print the printer’s Plug and Play string.

1. To print the printer’s Plug and Play string, type ~WQPP
A label similar to this prints out:

```

PLUG AND PLAY MESSAGES
MFG: Zebra Technologies
CMD: ZPL
MDL: Gx420d
    
```

➔ **Example 10:** This is an example of how to print the printer’s serial number.

1. To get the printer’s serial number, type ~WQSN
A label similar to this prints out:

```

SERIAL NUMBER
30A07070005
    
```

➔ **Example 11:** This is an example of how to print the printer’s USB product ID and BCD release version.

1. To print the printer’s USB product ID and BCD release version, type ~WQUI
A label similar to this prints out:

```

USB INFORMATION
PID: 0084
RELEASE VERSION: 15.01
    
```

^XA – Start Format

The ^XA command is used at the beginning of ZPL II code. It is the opening bracket and indicates the start of a new label format. This command is substituted with a single ASCII control character STX (control-B, hexadecimal 02).

Format: ^XA

Comments Valid ZPL II format requires that label formats should start with the ^XA command and end with the ^XZ command.

^XB – Suppress Backfeed

The ^XB command suppresses forward feed of media to tear-off position depending on the current printer mode. Because no forward feed occurs, a backfeed before printing of the next label is not necessary; this improves throughput. When printing a batch of labels, the last label should not contain this command.

Format: ^XB

^XB in the Tear-off Mode

Normal Operation: backfeed, print, and feed to rest

^XB Operation: print (Rewind Mode)

^XB in Peel-off Mode

Normal Operation: backfeed, print, and feed to rest

^XB Operation: print (Rewind Mode)



Note • To prevent jamming in cutter mode, ^XB suppresses backfeed and cutting.

^XF – Recall Format

The ^XF command recalls a stored format to be merged with variable data. There can be multiple ^XF commands in one format, and they can be located anywhere within the code.

When recalling a stored format and merging data using the ^FN (Field Number) function, the calling format must contain the ^FN command to merge the data properly.

While using stored formats reduces transmission time, no formatting time is saved. The ZPL II format being recalled is saved as text strings that need to be formatted at print time.

Format: ^XFd:o.x

Parameters	Details
d = source device of stored image	Values: R:, E:, B:, and A: Default: search priority (R:, E:, B:, and A:)
o = name of stored image	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension l	Fixed Value: .ZPL

For a complete example of the ^DF and ^XF command, see [^DF and ^XF — Download format and recall format on page 38](#).

^XG – Recall Graphic

The ^XG command is used to recall one or more graphic images for printing. This command is used in a label format to merge graphics, such as company logos and piece parts, with text data to form a complete label.

An image can be recalled and resized as many times as needed in each format. Other images and data might be added to the format.

Format: ^XGd:o.x,mx,my

Parameters	Details
d = source device of stored image	Values: R:, E:, B:, and A: Default: search priority (R:, E:, B:, and A:)
o = name of stored image	Values: 1 to 8 alphanumeric characters Default: if a name is not specified, UNKNOWN is used
x = extension 1	Fixed Value: .GRF
mx = magnification factor on the x-axis	Values: 1 to 10 Default: 1
my = magnification factor on the y-axis	Values: 1 to 10 Default: 1



Example: This is an example of using the ^XG command to recall the image **SAMPLE.GRF** from DRAM and print it in five different sizes in five different locations on the same label:

```

^XA
^F0100,100^XGR:SAMPLE.GRF,1,1^FS
^F0100,200^XGR:SAMPLE.GRF,2,2^FS
^F0100,300^XGR:SAMPLE.GRF,3,3^FS
^F0100,400^XGR:SAMPLE.GRF,4,4^FS
^F0100,500^XGR:SAMPLE.GRF,5,5^FS
^XZ

```

^XS – Set Dynamic Media Calibration

The ^XS command controls whether dynamic media calibration is performed to compensate for variations in label length, position, transmissivity, and/or reflectance after a printer is powered-up or the printer has been opened (for example to change or check the media).

Supported Devices

- G-Series

Format: ^XSlength,threshold

Parameters	Details
length = dynamic length calibration	Values: Y = enable N = disable Default: Y
threshold = dynamic threshold calibration	Values: Y = enable N = disable Default: Y
gain = dynamic gain calibration (to be in a future implementation)	Values: Y = enable N = disable Default: Y

^XZ - End Format

The ^XZ command is the ending (closing) bracket. It indicates the end of a label format. When this command is received, a label prints. This command can also be issued as a single ASCII control character ETX (Control-C, hexadecimal 03).

Format: ^XZ

Comments Label formats must start with the ^XA command and end with the ^XZ command to be in valid ZPL II format.

^ZZ – Printer Sleep

The ^ZZ command places the printer in an idle or shutdown mode.

Format: ^ZZt,b

Parameters	Details
t = number of second (idle time) prior to shutdown	Values: 0 to 999999 – setting 0 disables automatic shutdown Default: last permanently saved value or 0
b = label status at shutdown	Values: Y = indicates to shutdown when labels are still queued N = indicates all labels must be printed before shutting down Default: N

Comments The ^ZZ command is only valid on the PA400 and PT400 battery-powered printers.

ZPL RFID Commands

This section contains the ZPL II commands for RFID-specific applications.

For additional information, refer to the *RFID Programming Guide* for your printer. A copy is available on the User CD provided with your printer and online at <http://www.zebra.com/manuals>.

RFID Command Overview

In addition to reading or encoding RFID tags, the RFID ZPL commands also provide for RFID exception handling, such as setting the number of read/write retries before declaring a transponder defective (set with **^RR**, **^RT**, and **^WT**) or setting the number of labels that will be attempted if an error occurs (set with **^RS**).

For example, if an RFID label fails to program correctly or if the transponder cannot be detected, the printer ejects the label and prints VOID across it. The printer will try to print another label with the same data and format for the number of RFID labels specified by the **^RS** command. If the problem persists, the printer follows the error handling instructions specified by the **^RS** command: the printer may remove the problematic format from the print queue and proceed with the next format (if one exists in the buffer), or it may place the printer in Pause or Error mode.

If a parameter is designated as *not applicable* for a particular printer, any value entered for the parameter will be ignored, but the place holder for the field is required.

Printer and Firmware Compatibility

Before using a particular command, verify that it is compatible with your printer and firmware version. See the following tables:

- [Table 19, ZD500R Series Printer Command and Firmware Compatibility on page 349](#)
- [Table 20, RXi Series Printer Command and Firmware Compatibility on page 350](#)
- [Table 21, RZ Series and R110PAX4 Printer Command and Firmware Compatibility on page 351](#)
- [Table 22, R4Mplus, RP4T, and R2844-Z Printer Command and Firmware Compatibility on page 352](#)

Table 19 • ZD500R Series Printer Command and Firmware Compatibility

Command	Function	ZD500R
		Firmware
		all
^HL or ~HL on page 353	Return RFID Data Log to Host	*
^HR on page 354	Calibrate RFID Tag Position	*
^HV on page 212	Host Verification	*
^RA on page 361	Read AFI or DSFID Byte	—
^RB on page 362	Define EPC Data Structure	*
^RE on page 364	Enable/Disable E.A.S. Bit	—
^RF on page 365	Read or Write RFID Format	*
^RI on page 369	Get RFID Tag ID	—
^RL on page 370	Lock/Unlock RFID Tag Memory	*
^RM on page 372	Enable RFID Motion	—
^RN on page 373	Detect Multiple RFID Tags in Encoding Field	—
~RO on page 305	Reset Advanced Counters	*
^RQ on page 374	Quick Write EPC Data and Passwords	—
^RR on page 376	Specify RFID Retries for a Block or Enable Adaptive Antenna Selection	—
^RS on page 378	Set Up RFID Parameters	*
^RT on page 383	Read RFID Tag	—
^RU on page 385	Read Unique RFID Chip Serialization	*
~RV on page 387	Report RFID Encoding Results	—
^RW on page 388	Set RF Power Levels for Read and Write	*
^RZ on page 392	Set RFID Tag Password and Lock Tag	—
^WF on page 395	Encode AFI or DSFID Byte	—
^WT on page 396	Write (Encode) Tag	—
^WV on page 398	Verify RFID Encoding Operation	—

* = Supported

— = Not supported

a. Use the ^RF, ^RM, and ^RR commands rather than the ^RT command.

b. Use the ^RF, ^RM, ^RR, and ^WV commands rather than the ^WT command.

Table 20 • RXi Series Printer Command and Firmware Compatibility

Command	Function	R110Xi4	R110Xi HF	R110Xi and R170Xi
		Firmware		
		all	all	all
^HL or ~HL on page 353	Return RFID Data Log to Host	*	*	*
^HR on page 354	Calibrate RFID Tag Position	*	*	*
^RA on page 361	Read AFI or DSFID Byte	—	*	—
^RB on page 362	Define EPC Data Structure	*	*	*
^RE on page 364	Enable/Disable E.A.S. Bit	—	*	—
^RF on page 365	Read or Write RFID Format	*	*	*
^RI on page 369	Get RFID Tag ID	*	*	* (R60.13.0.13ZD or later)
^RL on page 370	Lock/Unlock RFID Tag Memory	—	—	—
^RM on page 372	Enable RFID Motion	*	*	*
^RN on page 373	Detect Multiple RFID Tags in Encoding Field	*	*	* (R60.13.0.3 or later)
~RO on page 305	Reset Advanced Counters	*	*	*
^RQ on page 374	Quick Write EPC Data and Passwords	*	—	* (R60.15.7Z or later)
^RR on page 376	Specify RFID Retries for a Block or Enable Adaptive Antenna Selection	*	*	*
^RS on page 378	Set Up RFID Parameters	*	*	*
^RT on page 383	Read RFID Tag	—	* a	* a
^RU on page 385	Read Unique RFID Chip Serialization	—	—	—
~RV on page 387	Report RFID Encoding Results	*	—	*
^RW on page 388	Set RF Power Levels for Read and Write	*	*	*
^RZ on page 392	Set RFID Tag Password and Lock Tag	*	—	*
^WF on page 395	Encode AFI or DSFID Byte	—	*	—
^WT on page 396	Write (Encode) Tag	—	* b	* b
^WV on page 398	Verify RFID Encoding Operation	—	—	*

* = Supported

— = Not supported

a. Use the ^RF, ^RM, and ^RR commands rather than the ^RT command.

b. Use the ^RF, ^RM, ^RR, and ^WV commands rather than the ^WT command.

Table 21 • RZ Series and R110PAX4 Printer Command and Firmware Compatibility

Command	Function	RZ400 and RZ600		R110PAX4	
		Firmware			
		V53.17.7Z or later	R53.16.X	R62.X.X	R63.X.X
^HL or ~HL on page 353	Return RFID Data Log to Host	*	*	*	*
^HR on page 354	Calibrate RFID Tag Position	*	*	*	*
^RA on page 361	Read AFI or DSFID Byte	—	—	—	—
^RB on page 362	Define EPC Data Structure	*	*	*	*
^RE on page 364	Enable/Disable E.A.S. Bit	—	—	—	—
^RF on page 365	Read or Write RFID Format	*	*	*	*
^RI on page 369	Get RFID Tag ID	*	*	* (R62.13.0.13ZC or later)	* (R63.13.0.11Z or later)
^RL on page 370	Lock/Unlock RFID Tag Memory	—	—	—	—
^RM on page 372	Enable RFID Motion	*	*	*	*
^RN on page 373	Detect Multiple RFID Tags in Encoding Field	*	*	*	—
~RO on page 305	Reset Advanced Counters	*	*	*	*
^RQ on page 374	Quick Write EPC Data and Passwords	*	*	* (R62.15.7Z or later)	—
^RR on page 376	Specify RFID Retries for a Block or Enable Adaptive Antenna Selection	*	*	*	*
^RS on page 378	Set Up RFID Parameters	*	*	*	*
^RT on page 383	Read RFID Tag	* a	* a	* a	* a
^RU on page 385	Read Unique RFID Chip Serialization	—	—	—	—
~RV on page 387	Report RFID Encoding Results	*	*	*	*
^RW on page 388	Set RF Power Levels for Read and Write	*	*	*	*
^RZ on page 392	Set RFID Tag Password and Lock Tag	*	*	*	*
^WF on page 395	Encode AFI or DSFID Byte	—	—	—	—
^WT on page 396	Write (Encode) Tag	* b	* b	* b	* b
^WV on page 398	Verify RFID Encoding Operation	*	*	*	*

* = Supported

— = Not supported

a. Use the ^RF, ^RM, and ^RR commands rather than the ^RT command.

b. Use the ^RF, ^RM, ^RR, and ^WV commands rather than the ^WT command.

c. For parameter e, the only accepted value is N for No Action.

Table 22 • R4Mplus, RP4T, and R2844-Z Printer Command and Firmware Compatibility

Command	Function	R4Mplus					RP4T	R2844-Z
		Firmware					all	all
		SP994X	SP999X	SP1027X	SP1056X	SP1082X		
^HL or ~HL on page 353	Return RFID Data Log to Host	*	*	*	*	*	*	—
^HR on page 354	Calibrate RFID Tag Position	*	*	*	*	*	*	—
^RA on page 361	Read AFI or DSFID Byte	—	—	—	—	—	—	—
^RB on page 362	Define EPC Data Structure	*	*	*	*	*	*	—
^RE on page 364	Enable/Disable E.A.S. Bit	—	—	—	—	—	—	*
^RF on page 365	Read or Write RFID Format	*	*	*	*	*	*	—
^RI on page 369	Get RFID Tag ID	*	*	*	*	*	*	*
^RL on page 370	Lock/Unlock RFID Tag Memory							
^RM on page 372	Enable RFID Motion	*	*	*	*	*	*	—
^RN on page 373	Detect Multiple RFID Tags in Encoding Field	—	—	—	—	—	*	—
~RO on page 305	Reset Advanced Counters	*	*	*	*	*	*	—
^RQ on page 374	Quick Write EPC Data and Passwords	—	—	—	—	—	*	—
^RR on page 376	Specify RFID Retries for a Block or Enable Adaptive Antenna Selection	*	*	*	*	*	*	—
^RS on page 378	Set Up RFID Parameters	*	*	*	*	*	* c	*
^RT on page 383	Read RFID Tag	* a	* a	* a	* a	* a	* a	*
^RU on page 385	Read Unique RFID Chip Serialization	—	—	—	—	—	—	—
~RV on page 387	Report RFID Encoding Results	* (SP994J or later)	* (SP999C or later)	*	*	*	*	—
^RW on page 388	Set RF Power Levels for Read and Write	*	*	*	*	*	*	—
^RZ on page 392	Set RFID Tag Password and Lock Tag	*	*	*	*	*	*	—
^WF on page 395	Encode AFI or DSFID Byte	—	—	—	—	—	—	—
^WT on page 396	Write (Encode) Tag	* b	* b	* b	* b	* b	* b	*
^WV on page 398	Verify RFID Encoding Operation	*	*	*	*	*	*	—

* = Supported

— = Not supported

a. Use the ^RF, ^RM, and ^RR commands rather than the ^RT command.

b. Use the ^RF, ^RM, ^RR, and ^WV commands rather than the ^WT command.

c. For parameter e, the only accepted value is N for No Action.

^HL or ~HL – Return RFID Data Log to Host

The printer continually logs RFID data and stores it in the printer's RAM. This command requests that the RFID data log be returned to the host computer, to clear the current data log, and to restart data recording. The ~HL command is processed immediately, while the ^HL command is processed after all of the previous formats (^XA ... ^XZ) have been processed.

Format: ^HL or ~HL

In the log, RFID data displays in this format:

```
[RFID operation],[program position],[antenna element],
[read or write power],[RFID status],[data]
```

where

[RFID operation]

R = read
W = write
L = lock
S = RFID settings
E = log file reset

[program position],[antenna element],[read or write power]*

Additional information about the program position, the antenna, and the read or write power follows the RFID operation.

Such as:

```
R,F1,D3,27,00000000,DATA
```

where **F1** = the program position, **D3** = the antenna, and **27** is the write power.

* With some older versions of firmware, these parameters do not display.

[RFID status]

or ##### = an RFID error code (See the *RFID Programming Guide* for your printer for more information on error codes. A copy of the manual is located on the User CD that came with your printer, or you can download a copy from <http://www.zebra.com/manuals>.)

RPWR = read power

WPWR = write power

ANT = antenna

PPOS = program position

FFFFFFF (or limited to length FFFF for some printers) = indicates that the log file was reset

[data]

the data read or written

Comments

- Data is shown in the format specified by the ^RFW command (ASCII, Hex, or EPC).
- If the log exceeds 64K (approximately 1500 operations), the data log is cleared automatically, and data recording restarts. When this happens, the following appears in the log:

```
E,FFFFFFF,Logfile automatically reset
```

- If the printer loses power, the log is lost. If the log results are important to you, retrieve the information frequently.

^HR – Calibrate RFID Tag Position

Use this command to initiate tag calibration for RFID media. During the tag calibration process (which can take up to 5 minutes on some printers, depending on the type of RFID inlay and the label size) the printer moves the media, reads the tag's TID to determine chip type, calibrates the RFID tag position, and determines the optimal settings for the RFID media being used. Depending on the printer, these settings include the programming position, the antenna element to use, and the read/write power level to use.



Important • Consider the following before using this command:

- This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.
- For the R110Xi4 and ZD500R printers, leave all transponders before and after the tag that is being calibrated. This allows the printer to determine RFID settings which do not encode the adjacent tag. Allow a portion of media to extend out the front of the printer to allow for backfeed during the tag calibration procedure.
- With some printers, you should not perform transponder calibration for RFID media that meets the transponder placement specifications for your printer because doing so will slow the printer's throughput unnecessarily. For more information about tag calibration, refer to the *RFID Programming Guide* for your printer. A copy of the manual is located on the User CD that came with your printer, or you can download a copy from <http://www.zebra.com/manuals>.

Results of the ^HR tag calibration are returned to the host computer. The "run" option in the `rfid.tag.calibrate` SGD command performs the same calibration but does not create a results table.

To restore the printer's default programming position at any time, use the "restore" option in the `rfid.tag.calibrate` SGD command (see [rfid.tag.calibrate on page 887](#)).

Format: ^HRa,b,c,d,e

Parameters	Details
a = start string	This parameter specifies the user text to appear before the results table. Values: any string less than 65 characters Default: start
b = end string	This parameter specifies the user text to appear after the results table. Values: any string less than 65 characters Default: end

Parameters	Details
<p>c = start position</p>	<p>This parameter specifies the start position of the calibration range. All numeric values are in millimeters. Forward or backward designations assume that the label's initial position is with the leading edge at the print line.</p> <p>Values:</p> <p>Forward: F0 to Fxxx (where xxx is the label length in millimeters or 999, whichever is less) The printer feeds the label forward for the specified distance and then begins transponder calibration.</p> <p>Backward: B0 to B30 (Not valid on the RP4T printer.) The printer backfeeds the label for the specified distance and then begins transponder calibration. Allow at least 1.25 in. (32 mm) of empty media liner to extend out of the front of the printer.</p> <p>Default:</p> <p>For the R110Xi4 and ZD500R: B20 —The printer backfeeds 20 mm before starting transponder calibration.</p> <p>For the ZT400 with RFID option: B30 —The printer backfeeds 30 mm before starting transponder calibration.</p> <p>For all other supported printers: F0—The printer moves the media to the start position relative to the leading edge of the label and then performs the RFID tag calibration.</p>
<p>d = end position</p>	<p>This parameter specifies the end position of the calibration range (last program position to check). All numeric values are in millimeters. Forward or backward designations assume that the label's initial position is with the leading edge at the print line.</p> <p>Values:</p> <p>Forward: F0 to Fxxx (where xxx is the label length in millimeters or 999, whichever is less) The printer performs transponder calibration until it reaches the specified end position and then ends the process.</p> <p>Backward: B0 to B30 (Not valid on the RP4T printer.) The printer performs transponder calibration until it reaches the specified end position and then ends the process. Valid only with a backward start position that is greater than the end position.</p> <p>A = Automatic (Valid only on the R110Xi4 and ZD500R printers.) The printer automatically ends the transponder calibration process after successfully reading and encoding a consecutive range of 5 mm on the label. The ZD500R also ensures that no other tags can be programmed at the programming position with the calibration-determined power levels.</p> <p>Default:</p> <p>For the R110Xi4 and ZD500R: A</p> <p>For all other supported printers: Label length as shown on the printer configuration label</p>

Parameters	Details
<p>e = antenna and read/write power level detection</p>	<div data-bbox="537 285 602 348" data-label="Image"> </div> <p>Note •</p> <ul style="list-style-type: none"> • This parameter is valid only on the R110Xi4, ZD500R, and ZT400 printers. • The ZD500R printer has only one antenna, so this parameter applies only to the read/write power level settings. <p>This parameter specifies whether to select the antenna and read/write power levels automatically or manually.</p> <p>Values:</p> <ul style="list-style-type: none"> A = Automatic. The printer automatically scans through the antennas and read/write power during calibration. M = Manual. The printer uses the current antenna and read/write power level settings. <p>Default: A</p>



Example 1: When the printer is using Absolute mode and the following command is sent to the printer:

```
^XA^HR^XZ
```

the printer starts the transponder calibration and returns a results table such as the following:

```
start
position=195
215, ,
214, ,
213, ,
212, ,
211, ,
210, ,W
209,R,
208, ,
207, ,
206, ,W
205,R,
204, ,
203, ,
202, ,W
201,R,W
200,R,W
199,R,W
198,R,W
197,R,W
196,R,W
195,R,W <---****
194,R,W
193,R,W
192,R,W
191,R,W
190,R,W
189,R,
188, ,
187, ,
186, ,
185, ,
.
.
.
end
```

Each line in the results table appears as:

```
Row, Read Result, Write Result
```

where

Row = the dot row where calibration occurred

Read Result = results of calibration (R = read, “ ” = unable to read)

Write Result = results of calibration (W = write, “ ” = unable to write)

The optimal programming position is 195. This is identified at the top of the table (**position=195**) and with an the arrow (<---****) in the table.



Example 2: When the printer is using Relative mode and the following command is sent to the printer:

```
^HRstart,end,B20,F42,M
```

the printer starts the tag calibration and returns a results table such as the following:

```
start
position=F0 MM
leading edge
B20, ,
B19, ,
B18, ,
B17, ,
...
B8, ,
B7, ,
B6, ,
B5, ,
B4,R,W
B3,R,W
B2,R,W
B1,R,W
F0,R,W<---**** F0 MM
F1,R,W
F2,R,W
F3,R,W
F4, ,
F5, ,
F6, ,
F7, ,
F8, ,
F9, ,
F10, ,
...
F38, ,
F39, ,
F40, ,
F41, ,
F42, ,
trailing edge
end
```

Each line in the results table appears as:

```
Row, Read Result, Write Result
```

where

Row = the position from the leading edge of the label where calibration occurred

Read Result = results of calibration (R = read, “ ” = unable to read)

Write Result = results of calibration (W = write, “ ” = unable to write)

The optimal programming position is F0 (program with the leading edge of the label at the print line). This is identified at the top of the table (**position=F0 MM**) and with an the arrow (**<---******) in the table.



Example 3: When the ^HR command is sent to the printer, the printer performs tag calibration and returns a results table such as the following:

```

start
position=B14 MM,A1,18,25
tid information=E200.3414:Alien
leading edge
Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,
EPC,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,
B30,A1,12,18,A1,29,A1, ,A1, ,A1, ,B1, ,B1,17,24,B1, ,B1, ,B1, ,
B29,A1,13,18,A1,25, ,A1, ,A1, ,A1, ,B1, ,B1,14,19,B1, ,B1, ,B1, ,
B28,A1,15,20,A1,23,29,A1, ,A1, ,A1, ,B1, ,B1,09,15,B1, ,B1, ,B1, ,
B27,A1,17,22,A1,23,29,A1, ,A1, ,A1, ,B1, ,B1,08,14,B1, ,B1, ,B1, ,
B26,A1,19,25,A1, ,A1, ,A1, ,A1, ,B1, ,B1,09,15,B1,28, ,B1, ,B1, ,
B25,A1,22,28,A1,22,27,A1, ,A1, ,A1, ,B1, ,B1,11,18,B1,26, ,B1, ,B1, ,
B24,A1,26, ,A1,13,19,A1, ,A1, ,A1, ,B1, ,B1,15,21,B1,27, ,B1, ,B1, ,
B23,A1, ,A1,08,14,A1, ,A1, ,A1, ,B1, ,B1,18,24,B1, ,B1, ,B1, ,
B22,A1, ,A1,05,11,A1, ,A1, ,A1, ,B1, ,B1,21,28,B1,19,24,B1, ,B1, ,
B21,A1, ,A1,05,11,A1, ,A1, ,A1, ,B1, ,B1,25, ,B1,11,17,B1, ,B1, ,
B20,A1, ,A1,06,12,A1, ,A1, ,A1, ,B1, ,B1,30, ,B1,07,13,B1, ,B1, ,
B19,A1, ,A1,08,15,A1, ,A1, ,A1, ,B1, ,B1, ,B1,05,11,B1, ,B1, ,
B18,A1, ,A1,15,22,A1, ,A1, ,A1, ,B1, ,B1, ,B1,05,10,B1, ,B1, ,
B17,A1, ,A1,22,28,A1, ,A1, ,A1, ,B1, ,B1, ,B1,05,11,B1, ,B1, ,
B16,A1, ,A1,16,23,A1, ,A1, ,A1, ,B1, ,B1, ,B1,07,13,B1, ,B1, ,
B15,A1, ,A1,13,19,A1, ,A1, ,A1, ,B1, ,B1, ,B1,13,20,B1, ,B1, ,
B14,A1, ,A1,12,19,A1, ,A1, ,A1, ,B1, ,B1, ,B1,18,23,B1, ,B1, ,<-
--***A1
B13,A1, ,A1,14,20,A1,24,30,A1, ,A1, ,B1, ,B1, ,B1,10,16,B1, ,B1, ,
B12,A1, ,A1,15,22,A1,22,29,A1, ,A1, ,B1, ,B1, ,B1,08,14,B1, ,B1, ,
B11,A1, ,A1,18,25,A1,26, ,A1, ,A1, ,B1, ,B1, ,B1,08,14,B1, ,B1, ,
B10,A1, ,A1,21,27,A1,26, ,A1, ,A1, ,B1, ,B1, ,B1,11,17,B1,26, ,B1, ,
B09,A1, ,A1,24, ,A1,15,21,A1, ,A1, ,B1, ,B1, ,B1,14,20,B1,25, ,B1, ,
B08,A1, ,A1,28, ,A1,09,15,A1, ,A1, ,B1, ,B1, ,B1,17,23,B1, ,B1, ,
B07,A1, ,A1, ,A1,06,11,A1, ,A1, ,B1, ,B1, ,B1,20,26,B1,27,30,B1, ,
B06,A1, ,A1, ,A1,05,11,A1, ,A1, ,B1, ,B1, ,B1,24,30,B1,16,19,B1, ,
B05,A1, ,A1, ,A1,05,11,A1, ,A1, ,B1, ,B1, ,B1,28, ,B1,10,14,B1, ,
B04,A1, ,A1, ,A1,08,14,A1, ,A1, ,B1, ,B1, ,B1, ,B1,07,11,B1, ,
B03,A1, ,A1, ,A1,12,18,A1, ,A1, ,B1, ,B1, ,B1, ,B1,06,11,B1, ,
B02,A1, ,A1, ,A1,20,26,A1, ,A1, ,B1, ,B1, ,B1, ,B1,06,10,B1, ,
B01,A1, ,A1, ,A1,18,24,A1, ,A1, ,B1, ,B1, ,B1, ,B1,09,13,B1, ,
F00,A1, ,A1, ,A1,14,21,A1, ,A1, ,B1, ,B1, ,B1, ,B1,12,17,B1, ,
F01,A1, ,A1, ,A1,13,19,A1, ,A1, ,B1, ,B1, ,B1, ,B1,20,25,B1, ,
F02,A1, ,A1, ,A1,13,19,A1,27, ,A1, ,B1, ,B1, ,B1, ,B1,16,20,B1, ,
F03,A1, ,A1, ,A1,14,21,A1,26,29,A1, ,B1, ,B1, ,B1, ,B1,11,16,B1, ,
F04,A1, ,A1, ,A1,17,24,A1,27, ,A1, ,B1, ,B1, ,B1, ,B1,11,15,B1, ,
F05,A1, ,A1, ,A1,19,26,A1, ,A1, ,B1, ,B1, ,B1, ,B1,12,16,B1,25, ,
F06,A1, ,A1, ,A1,22,29,A1,23,26,A1, ,B1, ,B1, ,B1, ,B1,15,18,B1,23,28,
F07,A1, ,A1, ,A1,26, ,A1,15,19,A1, ,B1, ,B1, ,B1, ,B1,17,22,B1,23,29,
F08,A1, ,A1, ,A1, ,A1,10,14,A1, ,B1, ,B1, ,B1, ,B1,20,25,B1, ,
F09,A1, ,A1, ,A1, ,A1,08,12,A1, ,B1, ,B1, ,B1, ,B1,24,28,B1,21,26,
F10,A1, ,A1, ,A1, ,A1,08,11,A1, ,B1, ,B1, ,B1, ,B1,27, ,B1,13,18,
trailing edge
end

```

In the results table, the tags visible to the antenna elements are numbered, and the EPC number that is unique to each tag is displayed.

Each line in the results table gives a row number followed by readings associated with RFID tags that are visible at that row. Multiple values on a line indicate that multiple tags were visible. The order of the RFID tags is arbitrary.

```
[Row],[Antenna Element],[Min Read Power],[Min Write Power],
[Antenna Element],[Min Read Power],[Min Write Power] ...
```

where

- Row = the position from the leading edge of the label where calibration occurred
- Antenna Element = the antenna used (the ZD500R only has A1)
- Minimum Read Power = calibration results (0 – 30) for a tag visible from that row
- Minimum Write Power = calibration results (0 – 30) for the same tag

The read and write power values are left empty (such as **A1**, , ,) when no tag is found.

In the sample results table for this example, at position **B25** (25 mm behind the print line), two RFID tags are visible to the printer at antenna A1. Tag 1 (EPC 7109) can be read at power level 22 and written to at power level 28. Tag 2 (EPC BA29) can be read at power level 22 and written to at power level 27. At that position, Tags 2 and 3 are visible to antenna B1 while Tag 1 is not.

```

      Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,
EPC,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,
...
B25,A1,22,28,A1,22,27,A1, , ,A1, , ,A1, , ,B1, , ,B1,11,18,B1,26, ,B1, , ,B1, , ,
B24,A1,26, ,A1,13,19,A1, , ,A1, , ,A1, , ,B1, , ,B1,15,21,B1,27, ,B1, , ,B1, , ,
B23,A1, , ,A1,08,14,A1, , ,A1, , ,A1, , ,B1, , ,B1,18,24,B1, , ,B1, , ,B1, , ,
B22,A1, , ,A1,05,11,A1, , ,A1, , ,A1, , ,B1, , ,B1,21,28,B1,19,24,B1, , ,B1, , ,
B21,A1, , ,A1,05,11,A1, , ,A1, , ,A1, , ,B1, , ,B1,25, ,B1,11,17,B1, , ,B1, , ,
...

```

At position **B23**, only Tag 2 is visible to antenna A1. Tag 1 is no longer visible.

```

      Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,
EPC,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,
...
B25,A1,22,28,A1,22,27,A1, , ,A1, , ,A1, , ,B1, , ,B1,11,18,B1,26, ,B1, , ,B1, , ,
B24,A1,26, ,A1,13,19,A1, , ,A1, , ,A1, , ,B1, , ,B1,15,21,B1,27, ,B1, , ,B1, , ,
B23,A1, , ,A1,08,14,A1, , ,A1, , ,A1, , ,B1, , ,B1,18,24,B1, , ,B1, , ,B1, , ,
B22,A1, , ,A1,05,11,A1, , ,A1, , ,A1, , ,B1, , ,B1,21,28,B1,19,24,B1, , ,B1, , ,
B21,A1, , ,A1,05,11,A1, , ,A1, , ,A1, , ,B1, , ,B1,25, ,B1,11,17,B1, , ,B1, , ,
...

```

At position **B13**, Tag 3 (EPC 6FD0) becomes visible to antenna A1 and can be read with at power level 24 and written to at power level 30.

```

      Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,Tag 1 ,Tag 2 ,Tag 3 ,Tag 4 ,Tag 5 ,
EPC,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,7109 ,BA29 ,6FD0 ,58AE ,9CDE ,
...
B16,A1, , ,A1,16,23,A1, , ,A1, , ,A1, , ,B1, , ,B1, , ,B1,07,13,B1, , ,B1, , ,
B15,A1, , ,A1,13,19,A1, , ,A1, , ,A1, , ,B1, , ,B1, , ,B1,13,20,B1, , ,B1, , ,
B14,A1, , ,A1,12,19,A1, , ,A1, , ,A1, , ,B1, , ,B1, , ,B1,18,23,B1, , ,B1, , ,<-
--****A1
B13,A1, , ,A1,14,20,A1,24,30,A1, , ,A1, , ,B1, , ,B1, , ,B1,10,16,B1, , ,B1, , ,
...

```

The arrow (<--****) in the table indicates that a valid program position and power levels were found during calibration. The program position is identified at the top of the table as **position=B14 MM** (backfeed 14 millimeters). The optimal antenna element at that position is A1. The optimal read power is 18, and the optimal write power is 25.

```

start
position=B14 MM,A1,18,25
tid information=E200.3414:Alien
leading edge
...
B14,A1, , ,A1,12,19,A1, , ,A1, , ,A1, , ,B1, , ,B1, , ,B1,18,23,B1, , ,B1, , ,<-
--****A1
...

```


^RA – Read AFI or DSFID Byte



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to read the AFI or DSFID byte. The data can be returned to the host via the ^HV command.

Format: ^RA#,f,r,m,b

Parameters	Details
# = field number specified with another command	The value assigned to this parameter should be the same as the one used in the ^RT command. Values: 0 to 9999 Default: 0
f = format	Values: 0 = ASCII 1 = Hexadecimal Default: 0
r = number of retries	Values: 0 to 10 Default: 0
m = motion	Values: 0 = Feed label after writing. 1 = No Feed after writing. Other ZPL may cause a feed. Default: 0
b = type of byte to read	Values: A = AFI byte D = DSFID byte Default: A

→ **Example 1:** This example reads the AFI byte in ASCII format and returns **AFI Byte:x** to the host. The printer will retry the command five times if necessary. A voided label is generated if the read is unsuccessful after these retries. The data read will go into the ^FN1 location of the recalled format.

```

^XA
^F020,120^A0N,60^FN1^FS
^RA1,0,5,0^FS
^HV1,,AFI Byte:^FS
^XZ

```

→ **Example 2:** This example reads the DSFID byte in ASCII format and returns **DSFID Byte:x** to the host. The printer will retry the command three times if necessary. A voided label is generated if the read is unsuccessful after these retries. The data read will go into the ^FN1 location of the recalled format.

```

^XA
^F020,120^A0N,60^FN1^FS
^RA1,0,3,0,D^FS
^HV1,,DSFID Byte:^FS
^XZ

```

^RB – Define EPC Data Structure



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to define the structure of EPC data, which can be read from or written to an RFID tag. For more information about EPC specifications, refer to the EPC Global web site. All parameters in this command are persistent and will be used in subsequent formats if not provided. The values are initially set to the default values.

RFID tags can have different partitions defined. This command specifies the number of partitions and how many bits are in each partition.

Format: ^RBn,p0,p1,p2, ..., p15

Parameters	Details
n = total bit size of the partitions	Specify the number of bits to include in the partitions. Values: 1 to n, where n is the bit size of the tag. Default: 96
p0 ... p15 = partition sizes	Specify the number of bits to include in the individual partitions. The partition sizes must add up to the bit size specified for the previous parameter. The largest individual partition size is 64 bits. Values: 1 to 64 Default: 1

➔ **Example 1:** The following command specifies that there are 96 bits used with three fields. Fields 1, 2, and 3 contain 10, 26, and 60 bits, respectively.

```
^RB96,10,26,60
```

The ZPL code to encode a tag with this format would look like this:

```
^RFW,E^FD1000.67108000.1122921504606846976^FS
```

When the tag is being encoded, the tag stores the data in the following way:

- Field 1 contains **1000**. This value is stored in the first 10 bits
- Field 2 contains **67108000**. This value is stored in the next 26 bits.
- Field 3 contains **1122921504606846976**. This value is stored in the remaining 60 bits.

➔ **Example 2:** The following command specifies that there are 64 bits used with eight 8-bit fields.

```
^RB64,8,8,8,8,8,8,8,8^FS
```

The ZPL code to encode a tag with this format would look like this:

```
^RFW,E^FD1.123.160.200.249.6.1.0^FS
```

When writing to the tag, each set of data is written in its respective 8-bit field.



Example 3: This example uses the SGTIN-96 standard, which defines 96-bit structure in the following way:

	Header	Filter Value	Partition	Company Prefix Index	Item Reference	Serial Number
SGTIN-96	8 bits	3 bits	3 bits	20–40 bits	24 bits	38 bits
	10 (binary value)	8 (decimal capacity)	8 (decimal capacity)	16,383 (decimal capacity)	9 to 1,048,575 (decimal capacity*)	33,554,431 (decimal capacity)

* Capacity of Item Reference field varies with the length of the company prefix.

The ZPL code to encode a tag with this format would look like this:

```

^XA
^RB96,8,3,3,20,24,38^FS
^RFW,E^FD48,1,6,770289,10001025,1^FS
^XZ
    
```

These commands would put


- **48** in the header
- **1** as the filter value
- **6** as the partition (indicates a 20-bit prefix and 24-bit item reference)
- **770289** as the company prefix
- **10001025** as the item reference
- **1** as the serial number

To read this EPC data and print the results on the label, you would use the following code:

```

^XA
^RB96,8,3,3,20,24,38^FS
^F050,50^A0N,40^FN0^FS
^FN0^RFR,E^FS
^XZ
    
```

The resulting label would look like this:



^RE – Enable/Disable E.A.S. Bit



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to enable or disable the Electronic Article Surveillance (E.A.S.) bit that is available in some ISO15693 tags (such as Philips). This command works only on those ISO15693 transponders and will be ignored if the tag does not support E.A.S.

Format: ^REt,r

Parameters	Details
t = Enable/disable the E.A.S. bit in the ISO15693 transponder	Values: N = Disable E.A.S. Y = Enable E.A.S. Default: N
r = number of retries	Values: 0 to 10 Default: 0



Example: This example enables the E.A.S. bit in the transponder. It will retry the command five times if necessary.

```
^XA  
^REy,5  
^XZ
```







^RF – Read or Write RFID Format


Use this command to read or write to (encode) an RFID tag or to specify the access password.

When using this command to read a tag, you may use a field variable to print the tag data on the label or to return the data to the host. For more information on how memory is stored on a Gen 2 tag or for examples that use a field variable, refer to the *RFID Programming Guide* for your printer. A copy of the manual is located on the User CD that came with your printer, or you can download a copy from <http://www.zebra.com/manuals>.

Format: ^RFo,f,b,n,m

Parameters	Details
o = operation	<p>Specifies the action to be performed.</p> <p>Values:</p> <ul style="list-style-type: none"> W = write to (encode) the tag L = write with LOCK (if supported by tag type; Gen 2 tag type does not use this locking function) R = read the tag P = read password (Gen 2 tag type only. Not supported on all Gen 2 printers, including the ZD500R printer.) S = specify the access password <p>Default: W</p>
f = format	<p>Values:</p> <ul style="list-style-type: none"> A = ASCII H = Hexadecimal E = EPC (ensure proper setup with the ^RB command) <p>Default: H</p>

Parameters	Details								
<p>For Gen 2 tag type only: b = password OR b = starting block number For tag types other than Gen 2: b = starting block number</p>	<p>For Gen 2 tag type only: What you specify for this parameter depends on what you enter for other parameters.</p> <table border="1" data-bbox="532 386 1422 1281"> <thead> <tr> <th data-bbox="532 386 727 533">If the Operation parameter value is...</th> <th data-bbox="727 386 1422 533">Then...</th> </tr> </thead> <tbody> <tr> <td data-bbox="532 533 727 945"> <p>W</p> </td> <td data-bbox="727 533 1422 945"> <p> Note • When the memory bank parameter is set to E (EPC 96-bit) or A (EPC and Auto adjust PC bits), this value is always set to 2.</p> <p>Values:</p> <ul style="list-style-type: none"> • P, which indicates that an access password, a kill password, or both follow in a ^FD command. Each password must be 8 hex characters. If the password is omitted, it is not written. An access password is used in subsequent lock commands in the format. • 0 to <i>n</i>, which specifies the 16-bit starting block number, where <i>n</i> is the maximum number of blocks for the bank specified in the memory bank parameter. <p>Default: 0</p> </td> </tr> <tr> <td data-bbox="532 945 727 1209"> <p>R</p> </td> <td data-bbox="727 945 1422 1209"> <p> Note • When the memory bank parameter is set to E (EPC 96-bit) or A (EPC and Auto adjust PC bits), this value is always set to 2.</p> <p>Values:</p> <ul style="list-style-type: none"> • 0 to <i>n</i>, which specifies the 16-bit starting block number, where <i>n</i> is the maximum number of blocks for the bank specified in the memory bank parameter. <p>Default: 0</p> </td> </tr> <tr> <td data-bbox="532 1209 727 1281"> <p>S</p> </td> <td data-bbox="727 1209 1422 1281"> <p>This parameter must be P and must be followed by the access password in a ^FD command.</p> </td> </tr> </tbody> </table> <p>For tag types other than Gen 2: Specifies the starting block number. Values: 0 to <i>n</i>, where <i>n</i> is the maximum number of blocks for the tag. Default: 0</p>	If the Operation parameter value is...	Then...	<p>W</p>	<p> Note • When the memory bank parameter is set to E (EPC 96-bit) or A (EPC and Auto adjust PC bits), this value is always set to 2.</p> <p>Values:</p> <ul style="list-style-type: none"> • P, which indicates that an access password, a kill password, or both follow in a ^FD command. Each password must be 8 hex characters. If the password is omitted, it is not written. An access password is used in subsequent lock commands in the format. • 0 to <i>n</i>, which specifies the 16-bit starting block number, where <i>n</i> is the maximum number of blocks for the bank specified in the memory bank parameter. <p>Default: 0</p>	<p>R</p>	<p> Note • When the memory bank parameter is set to E (EPC 96-bit) or A (EPC and Auto adjust PC bits), this value is always set to 2.</p> <p>Values:</p> <ul style="list-style-type: none"> • 0 to <i>n</i>, which specifies the 16-bit starting block number, where <i>n</i> is the maximum number of blocks for the bank specified in the memory bank parameter. <p>Default: 0</p>	<p>S</p>	<p>This parameter must be P and must be followed by the access password in a ^FD command.</p>
If the Operation parameter value is...	Then...								
<p>W</p>	<p> Note • When the memory bank parameter is set to E (EPC 96-bit) or A (EPC and Auto adjust PC bits), this value is always set to 2.</p> <p>Values:</p> <ul style="list-style-type: none"> • P, which indicates that an access password, a kill password, or both follow in a ^FD command. Each password must be 8 hex characters. If the password is omitted, it is not written. An access password is used in subsequent lock commands in the format. • 0 to <i>n</i>, which specifies the 16-bit starting block number, where <i>n</i> is the maximum number of blocks for the bank specified in the memory bank parameter. <p>Default: 0</p>								
<p>R</p>	<p> Note • When the memory bank parameter is set to E (EPC 96-bit) or A (EPC and Auto adjust PC bits), this value is always set to 2.</p> <p>Values:</p> <ul style="list-style-type: none"> • 0 to <i>n</i>, which specifies the 16-bit starting block number, where <i>n</i> is the maximum number of blocks for the bank specified in the memory bank parameter. <p>Default: 0</p>								
<p>S</p>	<p>This parameter must be P and must be followed by the access password in a ^FD command.</p>								

Parameters	Details
<p>n = number of bytes to read or write</p>	<p>Specifies the number of bytes to read or write.</p> <p>For high-frequency (HF) printers: Values: 1 to <i>n</i>, where <i>n</i> is the maximum number of bytes for the tag. Default: 1</p> <p>For Gen 2 tag type only: When E or A is specified for the memory bank parameter, this value is not required. Values: 1 to <i>n</i>, where <i>n</i> is the maximum number of bytes for the tag. Default: 1</p> <p>For all other printers and tag types: This parameter applies only when the starting block number is 1. Values: 1 to <i>n</i>, where <i>n</i> is the maximum number of bytes for the tag. For UCODE EPC 1.19, <i>n</i> is 32. Default: 1</p>
<p>m = Gen 2 memory bank</p>	<p> Note • This parameter applies to Gen 2 tags only.</p> <p>Specifies the Gen 2 memory bank. For more information about Gen 2 memory, refer to the <i>RFID Programming Guide</i> for your printer.</p> <p>Values:</p> <ul style="list-style-type: none"> E = EPC 96-bit (When writing data, this parameter performs the operation on Gen 2 bit address 20_h and accesses 12 bytes of the EPC memory bank. When reading data, this parameter reads the amount of data specified in the PC bits on the tag.) A = EPC and Auto adjust PC bits (When writing data, this parameter performs the operation on Gen 2 bit address 20_h of the EPC memory bank and accesses the number of bytes specified in the ^FD. The PC bits will be updated to match the amount of data written to the tag. When reading data, this parameter reads the amount of data specified in the PC bits on the tag.) <p>NOTE: This value is supported only by the ZD500R™ printer and ZT400™ Series RFID printers.</p> <ul style="list-style-type: none"> 0 = Reserved 1 = EPC 2 = TID (Tag ID) 3 = User <p>Default: E</p>



Example 1: This example encodes 96-bit data in ASCII format. (The ^RS command can be omitted for printers that use Gen 2 tag types only.)

```

^XA
^RS8
^RFW,A^FD00 my data^FS
^XZ
    
```

- **Example 2:** This example encodes 96-bit EPC data, as specified by the **^RB** command.
- ```
^XA
^RB96,8,3,3,20,24,38
^RFW,E^FD16,3,5,78742,146165,1234567891^FS
^XZ
```
- **Example 3:** This example encodes 4 bytes of hexadecimal formatted data, starting in block 3 of Gen 2 EPC bank 1. (The **^RS** command can be omitted for printers that use Gen 2 tag types only.)
- ```
^XA
^RS8
^RFW,H,3,4,1^FD11112222^FS
^XZ
```
- **Example 4:** This example reads the extended Gen 2 tag ID (TID), which is not read by the **^RI** command, and returns the results to the host computer. The results are labeled with the header “8-byte Tag ID Data.” (The **^RS** command can be omitted for printers that use Gen 2 tag types only.)
- ```
^XA
^RS8
^RFR,H,0,8,2^FN1^FS^HV1,,8-byte Tag ID Data:^FS
^XZ
```
- **Example 5:** This command writes and specifies both the access password (**12345678**) and the kill password (**88887777**) separated by a comma.
- ```
^RFW,H,P^FD12345678,88887777^FS
```
- This command writes the access password only:
- ```
^RFW,H,P^FD12345678^FS
```
- This command writes the kill password only (a comma must be used before it to distinguish it from an access password):
- ```
^RFW,H,P^FD,88887777^FS
```
- See the examples for [^RL on page 370](#) for how this command would be used in a format.
- **Example 6:** This command writes **1122334455667788** to the bit address 20h of the EPC memory and updates the PC bits bit address 10h to 14h to reflect 8 bytes (4 words) of data.
- ```
^RFW,H,,A^FD1122334455667788^FS
```
- **Example 7:** This command specifies the access password for the tag, which will be used in subsequent lock commands in the format. The access password specified must match the one stored on the tag. This command does not write the password to the tag. See the examples for [^RL on page 370](#) for how this command would be used in a format.
- ```
^RFS,H,P^FD12345678^FS
```


^RI – Get RFID Tag ID




Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to get the unique serial number of the tag and return it in hexadecimal format. The data can be sent back to the host via the **^HV** command.

For Gen 2 tag types, this command returns the 32-bit tag ID (TID) for the tag. If your Gen 2 tag supports TID data beyond 32 bits, see [^RF on page 365](#) to access the TID memory bank.

Format: ^RIa,b,c,d

Parameters	Details
a = number to be assigned to the field	Values: 0 to 9999 Default: 0
b = specify data order	 Note • This parameter applies only to the R110Xi HF and R2844-Z printers. Values: 0 = Most significant byte first for Tag*It and PicoTag. Least significant byte first for I*code and ISO15693. 1 = Reverse the data order Default: 0
c = number of retries	Values: 0 to 10 Default: 0
d = motion	Values: 0 = Feed label after writing 1 = No Feed after writing (other ZPL commands may cause a feed) Default: 0



Example: This example reads a tag ID, prints it on a label, and sends string **Tag ID:xxxxxxxx** to the host. The data read will go into the **^FN0** location of the format. The printer will retry the command five times, if necessary.

```

^XA
^FO20,120^A0N,60^FN0^FS
^RI0,,5^FS
^HV0,,Tag ID:^FS
^XZ
  
```

^RL – Lock/Unlock RFID Tag Memory

The ^RL command has two distinct formats and functions:

- **^RLM – Lock/Unlock the Specified Memory Bank**
Locks a password or an entire memory bank in a writeable or unwriteable state. These locks/unlocks can be permanent or reversible.
- **^RLB – Permanently Lock Specified Memory Sections**
Locks blocks of user memory in an unwriteable state.

^RLM – Lock/Unlock the Specified Memory Bank

The ^RLM command locks/unlocks the specified password or memory bank on an RFID tag. You can use this command to do the following:

- lock individual passwords, thereby preventing or allowing subsequent reads or writes of that password
- lock individual memory banks, thereby preventing or allowing subsequent writes to those banks
- Permanently lock (permalock) the lock status for a password or memory bank

Format: ^RLM,k,a,e,u

Parameters	Details
k = kill password function	Values: U = unlock the kill password* L = lock the kill password* O = permanently unlock (Open) the kill password P = permanently lock (Protected) the kill password
a = access password function	Values: U = unlock the access password* L = lock the access password* O = permanently unlock (Open) the access password P = permanently lock (Protected) the access password
e = EPC memory bank function	Values: U = unlock the EPC memory bank* L = lock the EPC memory bank* O = permanently unlock (Open) the EPC memory bank P = permanently lock (Protected) the EPC memory bank
u = USER memory bank function	Values: U = unlock the USER memory bank* L = lock the USER password bank* O = permanently unlock (Open) the USER memory bank P = permanently lock (Protected) the USER memory bank

* The access password must be set to something other than the default of 00000000 to use this value. See [Example 4 on page 371](#) for an example.

^RLB – Permanently Lock Specified Memory Sections

The ^RLB command permanently locks (permalocks) one or more sections (individual sub-portions) in a tag's user memory. The section sizes for each tag is defined by the tag manufacturer.

Format: ^RLB,s,n

Parameters	Details
s = starting section	Specify the starting section of memory to lock.
n = number of sections	Specify the number of sections to lock.

➔ **Example 1:** The following command locks all memory banks using a previously specified access password.

```
^RLM,L,L,L,L^FS
```

➔ **Example 2:** The following command locks the user memory banks using a previously specified access password.

```
^RLM,,,L^FS
```

➔ **Example 3:** The following command permalocks sections 0 to 4 of user memory using a previously specified access password.

```
^RLB,0,4^FS
```

➔ **Example 4:** This code does the following:

- writes 12 bytes to user memory
- writes "12345678" to the access password and "11223344" to the kill password
- permalocks 6 sections of user memory using "12345678" as the access password
- locks the kill and access passwords and permanently unlocks the EPC memory, using "12345678" as the access password

```
^XA
```

```
^RFW,H,0,12,3^FD112233445566778899001122^FS
```

```
^RFW,H,P^FD12345678,11223344^FS
```

```
^RLB,0,6^FS
```

```
^RLM,L,L,0^FS
```

```
^XZ
```

➔ **Example 5:** This code does the following:

- writes 12 bytes to user memory
- permalocks 6 sections of user memory using "00000000" as the access password
- permalocks the kill password and access password using "00000000" as the access password

```
^XA
```

```
^RFW,H,0,12,3^FD112233445566778899001122^FS
```

```
^RLB,0,6^FS
```

```
^RLM,P,P^FS
```

```
^XZ
```

^RM – Enable RFID Motion



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to enable or disable RFID motion. By default, labels automatically print at the end of the format. This command allows you to inhibit the label from actually moving when it reaches the program position, which is useful for debugging, setup, and custom applications. This parameter is not persistent (carried over from label to label).

Format: ^RMe

Parameters	Details
e = enable	Values: Y = Yes, move the label N = No, do not move the label Default: Y

^RN – Detect Multiple RFID Tags in Encoding Field




Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to enable or disable detection of multiple RFID tags in the encoding field. By default, the printer checks for more than one tag in the field before attempting to read or write. If more than one tag is found, the label over the antenna support is voided, and the **RFID ERR STATUS** parameter on the control panel displays **MULTIPLE TAGS**. To speed up printing and encoding by up to 200 ms, the check may be disabled.



Note • This parameter is persistent across labels (carried over from label to label), but is NOT persistent across power cycles.

Format: ^RNe

Parameters	Details
e = enable	<p>Values:</p> <ul style="list-style-type: none"> Y = Yes, check for multiple tags N = No, do not check for multiple tags <p>Default:</p> <ul style="list-style-type: none"> Y = Printers with firmware R60.13.0.5 and earlier N = Printers with firmware R60.13.0.7 and later <p> Note • If an invalid parameter value is entered, the default value will be used.</p>

^RQ – Quick Write EPC Data and Passwords



Important • This command is not supported by all RFID tags, printers, or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command with an Alien Higgs RFID tag and appropriate firmware to write the EPC data, access password, and kill password with one command. Doing so reduces the encoding time.



Note • The access password on the tag to be written to must be 00000000 prior to sending this command.

Format: ^RQf,c,o[data]

Parameters	Details
f = format	<p>Values: A = ASCII H = Hexadecimal E = EPC</p> <p>Default: H</p>
c = chip type	<p>Values: 0 (Higgs IC tag)</p> <p>Default: 0</p>
o = option	<p>Values: 0 (write 96-bit EPC)</p> <p>Default: 0</p>
data = the EPC data, access password, and kill password	<p>Use the ^FD command to specify the passwords in the following format: ^FD[EPC],[access],[kill]</p> <p>where:</p> <p>EPC = the EPC data in the format specified by the f parameter. The data should match what would be programmed with the ^RF command.</p> <p>access = an optional access password in hexadecimal format. If this field is left blank, 0x00000000 is written as the access password.</p> <p>kill = an optional kill password in hexadecimal format. If this field is left blank, 0x00000000 is written as the kill password.</p>



Example 1: This example writes the EPC data to the tag in hexadecimal format. The unspecified access and kill passwords are written as zeroes (0x00000000).

```
^XA^RQ^FD112233445566778899001122^XZ
```



Example 2: This example writes the EPC data to the tag in hexadecimal format. The access password is written as 0xAAAAAAAA, and the kill password is written as 0xBBBBBBBB.

```
^XA^RQ^FD112233445566778899001122,AAAAAAAA,BBBBBBBB^XZ
```



Example 3: This example writes the EPC data to the tag in EPC format. The unspecified access and kill passwords are written as zeroes (0x00000000).

```
^XA^RB96,30,30,30,6^RQE^FD1234.5678.9012.12^XZ
```



Example 4: This example writes the EPC data to the tag in hexadecimal format. The access password is written as 0xAAAAAAAA, and the unspecified kill password is written as zeroes (0x00000000).

```
^XA^RB96,30,30,30,6^RQE^FD1234.5678.9012.12,AAAAAAAA^XZ
```

^RR – Specify RFID Retries for a Block or Enable Adaptive Antenna Selection



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command for the following:




- to change the number of times that the printer attempts to read or write to a particular block of a single RFID tag (Not applicable to printers with firmware V75.19.7Z or later.)
- to enable the adaptive antenna element selection feature

This command is persistent and will be used in subsequent formats if not provided.



Note • This command's function is different than the "number of labels" parameter in the ^RS command.

Format: ^RRn,a

Parameters	Details
n = number of retries	 Note • This parameter does not apply to the ZT400 printer. Values: 0 to 10 Default: 6
a = adaptive antenna element selection	 Note • This parameter is valid only on R110Xi4 and ZT400 printers with a label that is 2 in. (51 mm) or longer. If the printer cannot find RFID tags with the antenna element specified during the number of retries specified (if applicable), the printer may try neighboring antenna elements. If the printer is unsuccessful communicating with the RFID tag after trying the neighboring antenna elements, the printer voids the label.  Note • Activating this parameter may slow throughput on damaged or weak RFID tags. Values: 0 or 1 0 = None. The printer uses only the current antenna element selection. 1 = Neighbors. The printer attempts to read the tag using the antenna elements to the left/right and above/below the current antenna element. The antenna element that is successful is used for all subsequent RFID commands until the next unsuccessful attempt. Default: 0



Example 1: This example sets the read block retries to 5.

```

^XA
^FN1^RR5^RFR,H^FS
^HV1^FS
^XZ
    
```




Example 2: This example sets the write block retries to 2.

```
^XA  
^RR2^RFW,H^FD1234^FS  
^XZ
```



Example 3: On an R110Xi4 printer, this example sets the write retries to 2 and allows the printer to try neighboring antennas in the event that the current antenna cannot write to the RFID tag.

```
^XA  
^RR2,1^RFW,H^FD1234^FS  
^XZ
```

^RS – Set Up RFID Parameters


Use this command to set up RFID parameters including tag type; programming position; and error handling. In addition to reading or encoding RFID tags, the RFID ZPL commands also provide for RFID exception handling, such as setting the number of read/write retries before declaring a transponder defective (set with ^RR, ^RT, and ^WT) or setting the number of labels that will be attempted if an error occurs (set with ^RS).


For example, if an RFID label fails to program correctly or if the transponder cannot be detected, the printer ejects the label and prints **VOID** across it. The printer will try to print another label with the same data and format for the number of labels specified (parameter **n**). If the problem persists, the printer follows the error handling instructions specified by the error handling parameter (parameter **e**): the printer may remove the problematic format from the print queue and proceed with the next format (if one exists in the buffer), or it may place the printer in Pause or Error mode.






Use care when using this command in combination with ^RT or ^RF for reading tag data. Problems can occur if the data read from the tag is going to be printed on the label. Any data read from the tag must be positioned to be printed above the read/write position. Failure to do this will prevent read data from being printed on the label.

Format: ^RS*t,p,v,n,e,a,c,s*

Parameters	Details
t = tag type	<p>Tells the printer/print engine which tag type you are using. If you specify a tag type that is not supported by your printer or firmware, the printer uses its default value. For the supported tag types and defaults, see Table 23 on page 381.</p> <p>Values:</p> <p>UHF Printers</p> <ul style="list-style-type: none"> 0 = None 1 = EPC Class 0 2 = EPC Class 0 Plus 3 = EPC Class 1 64-bit 4 = EPC Class 1 96-bit 5 = UCODE EPC 1.19 6 = Impinj Class 0 Plus 7 = ISO 18000-06A 8 = EPC Class 1, Generation 2 (Gen 2) 9 = ISO 18000-06B <p>HF Printers</p> <p> Note • Only the R110Xi HF printer (firmware version R65.X.X) supports the use of letters for this parameter. All other printers use the numbers.</p> <ul style="list-style-type: none"> A or 0 = None B or 1 = Auto detect (query tag to determine) C or 2 = Tag*It (Texas Instruments Tagit tags) D or 3 = I*code (Phillips Icode tags) E or 4 = Pico Tag (Inside Technology's) F or 5 = ISO 15693 G or 6 = EPC tag (13.56 MHz) H or 7 = UID Tag I or 8 = Mifare UltraLight <p>Default: varies by printer (see Table 23 on page 381)</p>

Parameters	Details
<p>p = read/write position of the tag (programming position)</p>	<p>This parameter sets the read/write position of the tag.</p> <p> Important • If a label format specifies a value for the programming position, this value will be used for the programming position for all labels until a new position is specified or until the tag calibration procedure is run.</p> <p>Values:</p> <p>For the ZD500R only:</p> <p>F0 to Fxxx (where xxx is the label length in millimeters or 999, whichever is less) The printer prints the first part of a label until it reaches the specified distance and then begins programming. After programming, the printer prints the remainder of the label.</p> <p>B0 to B30 The printer backfeeds the label for the specified distance and then begins programming. To account for the backfeed, allow empty media liner to extend out of the front of the printer when using a backward programming position.</p> <p>up = move to the next value down = move to the previous value</p> <p>For other RFID printers:</p> <p><i>Absolute Mode</i> (all firmware versions): xxxx = 0 to label length (in dot rows). Move the media to the specified position xxxx on the label, measured in dot rows from the label top, before encoding. Set to 0 (no movement) if the tag is already in the effective area without moving the media.</p> <p><i>Relative Mode</i> (firmware versions V53.17.6 and later): F0 to Fxxx (where xxx is the label length in millimeters or 999, whichever is less) The printer prints the first part of a label until it reaches the specified distance and then begins programming. After programming, the printer prints the remainder of the label.</p> <p>B0 to B30 (Does not apply to the RP4T printer.) The printer backfeeds the label for the specified distance and then begins programming. To account for the backfeed, allow empty media liner to extend out of the front of the printer when using a backward programming position.</p> <p>Default:</p> <p>For the R2844-Z and RPAX: 0 (no movement) For printers using V53.17.6, V74.19.6Z, and later: F0 (which moves the leading edge of the label to the print line) For all other printers or firmware: label length minus 1 mm (1/16 in.)</p>
<p>v = length of void printout</p>	<p>Sets the length of the void printout in vertical (Y axis) dot rows.</p> <p>Values: 0 to label length</p> <p>Default: label length</p>

Parameters	Details
n = number of labels to try encoding	<p>The number of labels that will be attempted in case of read/encode failure.</p> <p>Values: 1 to 10</p> <p>Default: 3</p>
e = error handling	<p>If an error persists after the specified number of labels are tried, perform this error handling action.</p> <p>Values:</p> <ul style="list-style-type: none"> N = No action (printer drops the label format causing the error and moves to the next queued label) P = Place printer in Pause mode (label format stays in the queue until the user cancels) E = Place printer in Error mode (label format stays in the queue until the user cancels) <p>Default: N</p> <p> Note • You can set the printer to send an error message to the host for each failure. To enable or disable this unsolicited error message, refer to the ^SX and ^SQ ZPL commands. Use V for the condition type for an RFID error.</p>
a = signals on applicator	<p> Note • This parameter does not apply to the R2844-Z. For the R4Mplus, this parameter applies only to printers with firmware version SP994X (R4Mplus European version).</p> <p>Single Signal Mode</p> <p>In this mode, one start print signal starts printing. Then, at the program position (parameter p), the printer automatically stops and encodes the tag. Printing continues, and a single end print signal signifies the completion of the label.</p> <p>Double Signal Mode</p> <p>With RFID, when there is a non-zero program position, the label is logically split into two parts. The first part is printed, the tag encodes, and then the second part prints. If this parameter is set to “D,” then the label is split into two and requires both portions of the label to be controlled by the applicator. This means that a start print signal triggers the first portion of the label, and then when the printer reaches the RFID program position (and the motor stops), an end print signal is provided. In this mode, a second start print signal is required to print the rest of the label. When the label is complete, a final end print signal is provided.</p> <p> Note • If parameter p is zero, then single signal mode is used (parameter ignored). If p is F0 (or B0) with backfeed-after, then single signal mode is used (parameter ignored).</p> <p>Values:</p> <ul style="list-style-type: none"> S = single signal D = double signal (For the R110PAX4, Double mode will work only if the read/write position is changed from the default of zero.) <p>Default: S</p>
c = reserved	Not applicable.
s = void print speed	<p> Note • This parameter does not apply to the R2844-Z printer. For the R4Mplus printer, this parameter applies only to printers with firmware version SP994X (R4Mplus European version).</p> <p>If a label is voided, the speed at which “VOID” will be printed across the label.</p> <p>Values: any valid print speed</p> <p>Default: the printer’s maximum print speed</p>

Supported Tag Types Table 23 shows the tag types supported by different RFID printers/print engines and firmware versions. Depending on your country or on the firmware version that you are using, your printer may not support all of the tag types listed. If you specify an unsupported tag type, the printer uses the default value. If a tag type is shown as supported but does not work with your printer, you may need to upgrade the printer's firmware (see <http://www.zebra.com/firmware>).

Table 23 • Supported Tag Types and Default Values

Printer	UHF Printers												HF Printers			
	ZD500R	R110Xi4	R110Xi R170Xi	R110PA/4				R4Mplus				RZ400/ RZ600	R110Xi HF	R2844-Z		
Firmware Version	V74.19.6Z and later	V53.17.7 and later	R60.13.X	R60.15.X and later	R62.13.X	R62.15.X and later	R63.13.X	R63.15.X and later	SP9940, SP999E, SP1027E, SP1082E, and earlier	SP994P, SP999F, SP1027F, SP1082F, and later	SP1056D and earlier	SP1056E and later	R53.16.X and later	R65.13.X	R65.15.X and later	all
Tag Type																
UHF Tag Types and Options																
None (no tag type specified)	—	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—
EPC Class 0	—	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—
EPC Class 0 Plus	—	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—
EPC Class 1 64-bit	—	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—
EPC Class 1 96-bit	—	—	#	*	#	*	—	*	*	*	—	—	—	—	—	—
UCODE EPC 1.19	—	—	* a	*	—	*	#	*	#	*	#	*	—	—	—	—
Impinj Class 0 Plus	—	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—
ISO 18000-06A	—	—	—	—	*	—	—	*	*	*	—	—	—	—	—	—
EPC Class 1, Generation 2 (Gen 2)	#	#	*	#	*	#	—	#	*	#	*	#	#	—	—	—
ISO 18000-06B	—	—	*	*	*	*	—	*	*	*	*	*	—	—	—	—
HF Tag Types and Options																
Auto-detect the tag type by querying the tag	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	#
Tag*It (Texas Instruments Tagit tags)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
I*code (Phillips Icode tags)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
Pico Tag (Inside Technology's)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
ISO 15693	—	—	—	—	—	—	—	—	—	—	—	—	—	#	#	*
EPC tag	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
UID Tag	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Mifare UltraLight	—	—	—	—	—	—	—	—	—	—	—	—	—	*	*	—

= Default value * = Accepted value — = Not supported

a. Requires R60.13.0.13ZD or later.

➔ **Example 1:** The following are examples of Absolute Mode and Relative Mode for the tag position parameter (parameter **p**).


Absolute Mode

1. **^RS,520** sets the encode position at 520 dots from the top edge of the label.
2. **^RS,0** programs the tag without moving the media.

Relative Mode

1. **^RS,F1** sets the encode position 1 mm forward from the leading edge of the label.
2. **^RS,B10** sets the encode position 10 mm backwards from the leading edge of the label.
3. **^RS,F0** sets the encode position at the leading edge of the label.
4. **^RS,B0** sets the encode position at the leading edge of the label.

➔ **Example 2:** The following shows the difference between absolute and relative programming positions for the tag position parameter (parameter **p**) with a 6-inch (152-mm, 1216-dot) label length. The end results are that the tag is programmed with the label in the same position.



1	^RS,496 , Absolute Mode, 496 dots from the top of the label
2	^RS,F90 , Relative Mode, 90 mm from the leading edge of the label


^RT – Read RFID Tag



Note • The ^RT command is provided only for backward-compatibility with label formats that were developed for older Zebra RFID printers. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you should not use this command.

Use this command to tell the printer to read the current RFID tag data. The data can be returned to the host via the ^HV command.

Format: ^RT#,b,n,f,r,m,s

Parameters	Details
# = number to be assigned to the field	Values: 0 to 9999 Default: 0
b = starting block number	Values: 0 to <i>n</i> , where <i>n</i> is the maximum number of blocks for the tag. Default: 0
n = number of blocks/bytes to read	Values: 1 to <i>n</i> , where <i>n</i> is the maximum number of blocks for the tag type minus the starting block number. For example, if the tag has 8 blocks (starting with block 0) and you start with block 6, <i>n</i> can be 2. This would return block 6 and block 7 information. Default: 1
f = format	Values: 0 = ASCII 1 = Hexadecimal Default: 0
r = number of retries	Changes the number of times that the printer attempts to read a particular block of a single RFID tag. (Same retry rules as the ^RR command.) Values: 0 to 10 Default: 0
m = motion	Enables or disables RFID motion for the current field. Values: 0 = Feed label after writing. 1 = No feed after writing. Other ZPL may cause a feed. Default: 0
s = special mode	 Note • This parameter is used only for the printers referenced here. For R4Mplus printers with firmware version SP920X (U.S. version): Specify actions for mismatched checksums. For EPC Class 1 (Alien reader) only. Not applicable for EPC class 0. Default: 0 Values: 0 = Do not read if mismatched checksum 1 = Read even if mismatched checksum For R110Xi HF and R2844-Z printers: Specify data order. Default: 0 Values: 0 = least significant byte first 1 = most significant byte first

→ **Example 1:** This example reads a tag, prints the data on a label, and sends the string **Tag Data:xxxxxxxx** back to the host. The data read will go into the **^FN1** location of the format. The printer will retry the command five times, if necessary.

```
^XA
^F020,120^A0N,60^FN1^FS
^RT1,, ,5^FS
^HV1,,Tag Data:^FS
^XZ
```

→ **Example 2:** This example reads from a tag twice and prints the results on a label.

```
^XA
^F020,120^A0N,60^FN1^FS
^F020,100^A0N,20^FN2^FS
^RT1,7,3,,5^FS
^RT2,3,2,,5^FS
^XZ
```

The first **^RT** command starts at block 7 and reads three blocks of data in ASCII format. The data read will go into the **^FN1** location of the format. The printer will retry the command five times, if necessary.

The second **^RT** command starts at block 2 and reads two blocks of data in ASCII format. The data read will go into the **^FN2** location of the format. The printer will retry the command five times, if necessary.

^RU – Read Unique RFID Chip Serialization

Use this command to read the TID (Tag ID) data from the current chip and format a unique 38-bit serial number, which will be placed in the lower (least significant) 38 bits of the EPC code.

Format: ^RUa,b

Parameters	Details
a = prefix	<p>Specifies the prefix in ASCII Binary</p> <p>Values: Only ASCII characters 1 and 0 are accepted. Maximum of 38 characters. The number of bits in the value specifies the length of the prefix. The prefix is placed as the left-most (most significant) bits in the unique serial number.</p> <p>If nothing is specified, the default value will be used.</p> <p>Default: The MCS prefix is determined by the MDID in the TID of the chip read:</p> <ul style="list-style-type: none"> • 100 = EM Micro • Impinj = 101 • Alien = 110 • NXP = 111
b = special character	<p>Special character for serial number inclusion.</p> <p>Values: Any ASCII character other than the current Command character, Control character, Delimiter character, or any of the Real-Time Clock (RTC) characters.</p> <p>Default: #</p>



Note • Serial number inclusion:

One of several data elements can be included into any ^FD data string in the same way that Real Time Clock data is included. Use any of the commands below to include a data pattern based on the serial number. These are defined using the default value for the Special Character.

- #S = include 38-bit serial number derived from TID in decimal form.
- #H = include 38-bit serial number derived from TID in hexadecimal form.
- #E = include the entire 96-bit EPC code, including the 38-bit serial number derived from TID in decimal form.
- #F = include the entire 96-bit EPC code, including the 38-bit serial number derived from TID in hexadecimal form.
- #P = include the entire 96-bit EPC code, but use the tag's preprogrammed, 38-bit SGTIN serial number in decimal form.*
- #Q = include the entire 96-bit EPC code, but use the tag's preprogrammed, 38-bit SGTIN serial number in hexadecimal form.*

* If the EPC has been preprogrammed (typically by the manufacturer) with the chip-based RFID serialization scheme, then the serialized data does not have to be written back to the EPC memory, which saves time. #P and #Q simply format the data that is read from the EPC memory bank.



Example 1: Read the TID from the tag, create a serial number based on the tag type, write 12<serial number (5 bytes)>000000000000 to the 96-bit EPC field, and print the serial number (in hex format) on the label.

```

^XA
^RU
^F010,10^A0N,50,50^FDSerial Number: #H^FS
^RFW,H^FD12#H^FS
^XZ

```

→ **Example 2:** Read the TID from the tag, create a serial number based on the tag type, write the serial number to the EPC field (lower 38 bits) while maintaining the contents of the rest of the EPC memory, print **Serial Number: <serial number in hex format>** on the label, and return **Serial Number: <serial number in hex format>** to the host. Perform this operation on three label formats.

```
^XA
^RU
^F010,10^A0N,50,50^FN1^FS
^FN1^FDSerial Number: #H^FS
^FH^HV1,24, ,_0D_0A,L^FS
^RFW,H^FD#F^FS
^PQ3
^XZ
```

→ **Example 3:** Read the full EPC (already serialized) from the tag, print **Serial Number: <full EPC in decimal format>** on the label, and return **Serial Number: <full EPC in decimal format>** to the host.

```
^XA
^RU
^F010,10^A0N,50,50^FN1^FS
^FN1^FDSerial Number: #P^FS
^FH^HV1,44, ,_0D_0A,L^FS
^XZ
```

~RV – Report RFID Encoding Results



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to tell the printer to send RFID encoding success or failure results to the host computer after each label format completes.

Format: ~RVa

Parameters	Details
a = enable/disable	Enables or disables the results reporting feature. Values: E = Enable D = Disable Default: D

➔ **Example 1:** Assume that the following code is sent and that there is no RFID tag in the field.

```

~RVE
^XA
^RS8,0,,3
^RMY
^RFR,H
^XZ

```

The printer attempts to program a tag three times and then returns the following to the host:

```
_,3_
```

The minus sign indicates that the programming attempt failed entirely and voided three labels.

➔ **Example 2:** Assume that the same code is sent and that the first two attempts at programming a tag are unsuccessful. The third attempt succeeds.

```

~RVE
^XA
^RS8,0,,3
^RMY
^RFR,H
^XZ

```

The printer attempts to program a tag three times and then returns the following to the host:

```
_,2_
```

The plus sign indicates that the programming attempt was successful and voided two labels.

^RW – Set RF Power Levels for Read and Write



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to set the RFID read and write power levels if the desired levels are not achieved through RFID tag calibration. If not enough power is applied, the tag may not have sufficient power for programming, and tag data will fail to encode. If too much power is applied, the extra power may cause data communication errors or may cause the wrong tag to be programmed.



Note • For the R110Xi4, ZT400, and ZD500R printers:

During RFID tag calibration, the printer automatically selects the best read/write power levels and the best antenna element (not applicable to the ZD500R) for the media being used. The R110Xi4 printer may also set the levels during an adaptive antenna sweep. Use the `~HL` command (see [^HL or ~HL on page 353](#)) to view the antenna element and power settings being used.




Note • For the R110Xi4, ZT400, and ZD500R printers:


During RFID tag calibration, the printer automatically selects the best read/write power levels and the best antenna element (not applicable to the ZD500R) for the media being used. The R110Xi4 printer may also set the levels during an adaptive antenna sweep. Use the `~HL` command (see [^HL or ~HL on page 353](#)) to view the antenna element and power settings being used.

Format: ^RW*r,w,a*

Parameters	Details
<code>r</code> = read power	<p>This parameter sets the power level to match the desired output as calibrated in the factory.</p> <p>R53.16.3, V53.17.5, and later: Values: 0 to 30 Default: 16</p> <p>R60.16.4, R62.16.4, R63.16.4, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values: 0 to 30, H (high), M (medium), L (low) Default: L</p> <p>R65.X and older versions of other firmware: Values: H = high M = medium L = low Default: L</p>

Parameters	Details
<p>w = write power</p>	<div data-bbox="532 289 597 352" data-label="Image"> </div> <p>Note • This parameter is ignored on the R110Xi HF printer (firmware version R65.X) because read and write powers cannot be specified separately. The printer uses the value that you specified for read power for both the read and write power settings.</p> <p>This parameter sets the power level to match the desired output as calibrated in the factory.</p> <p>R53.16.3, V53.17.5, and later: Values: 0 to 30 Default: 16</p> <p>R60.16.4, R62.16.4, R63.16.4, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values: 0 to 30, H (high), M (medium), L (low) Default: L</p> <p>Older versions of firmware: Values: H = high M = medium L = low Default: L</p>

Parameters	Details
<p>a = RFID antenna element selection</p>	<p>ZD500R: This printer only has one antenna element, so the value used is always A1.</p> <p>ZT400: This parameter selects an antenna element from the printer's antenna array.</p> <p>Values: E1, E2, E3, E4 D1, D2, D3, D4 C1, C2, C3, C4 B1, B2, B3, B4 A1, A2, A3, A4</p>  <p>Default: A4</p> <p>(Continued on next page)</p>

Parameters	Details
<p>a = RFID antenna element selection</p>	<p>(Continued from previous page)</p> <p>R110Xi4 (V53.17.5 and later): This parameter selects an antenna element from the printer's antenna array.</p> <p>Values: A1, A2, A3, A4, B1, B2, B3, B4, C1, C2, C3, C4, D2, D3, D4, E2, E3, E4, F2, F3, F4 (combinations D1, E1, and F1 are invalid)</p>  <p>Default: A4</p> <p>R110Xi HF (R65.X): This parameter selects the antenna port that provides the best results for reading and writing.</p> <p>Values: 1 = antenna port 1 2 = antenna port 2</p> <p>Default: 1</p>

➔ **Example 1:** The following command selects the antenna at row D, column 3 on an R110Xi4 printer:

```
^RW, ,D3
```

➔ **Example 2:** The following command sets the read/write power level to Medium and selects antenna 2 on an R110Xi HF printer:

```
^RWM, , 2
```

➔ **Example 3:** The following command sets the read and write power levels to High on an R110PAX4 printer:

```
^RWH, H
```

^RZ – Set RFID Tag Password and Lock Tag



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.


Use this command to define a password for a tag during writing.


With Gen 2 tags, you can lock a tag’s memory bank with an access password or define a kill password that can be used to permanently disable the tag. If you do not set access or kill passwords for a tag, the tag ignores any read or write commands that try to use these functions.



Note • The printer can set a kill password, but the printer cannot kill a tag.

Format: ^RZp,m,l

Parameters	Details
p = password	<p>This parameter sets a password for the RFID tag.</p> <p>For tag types other than Gen 2: The password is 8 bits. The memory bank and lock style parameters are ignored. The password must be 2 hexadecimal characters long. Values: 00 to FF (hexadecimal) Default: 00</p> <p>For Gen 2 tag type only: Gen 2 tags use a 32-bit password and specify the memory bank and lock style. The password must be 8 hexadecimal characters long. Use ^RF on page 365 to read the passwords. Values: 00000000 to FFFFFFFF (hexadecimal) Default: none</p>
m = memory bank	<p> Note • This parameter applies to Gen 2 tags only.</p> <p>This parameter specifies the type of RFID tag password.</p> <p>Values: K = kill password A = access password E = EPC T = tag identifier (TID) U = user Default: none</p>

Parameters	Details
l = lock style	 Note • This parameter applies to Gen 2 tags only. This parameter specifies the RFID tag password status. Values: U = unlocked L = locked O = permanently unlocked (open) P = permanently locked (protected) W = write value (used only for the kill password memory bank) Default: none

➔ **Example 1:** On a tag that is not Gen 2, this example encodes **5A** as the tag password.

```
^XA
^RZ5A^FS
^XZ
```

➔ **Example 2:** On a Gen 2 tag, this example encodes EPC data **112233445566778899001122** to the tag in Hex format, write protects the tag's EPC data with password **1234ABCD**, and leaves the tag's access password unlocked.

```
^XA
^RFW,H^FD112233445566778899001122^FS
^RZ1234ABCD,E,L^FS
^XZ
```

➔ **Example 3:** On a Gen 2 tag, this example encodes EPC data **112233445566778899001122** to the tag in Hex format, write protects the tag's EPC data with password **1234ABCD**, and makes the tag's access password unreadable.

```
^XA
^RFW,H^FD112233445566778899001122^FS
^RZ1234ABCD,E,L^FS
^RZ1234ABCD,A,L^FS
^XZ
```

The following code unprotects EPC data **112233445566778899001122** using the password **1234ABCD**, encodes EPC data **newdata** to the tag in ASCII format, and then write protects the tag's new EPC data. The access password and its lock state are not changed, so the access password remains unreadable.

```
^XA
^RZ1234ABCD,E,U^FS
^RFW,A^FDnewdata^FS
^RZ1234ABCD,E,L^FS
^XZ
```



Example 4: This example unlocks the locked access password from the previous example.

```
^XA  
^RZ1234ABCD,A,U^FS  
^XZ
```

^WF – Encode AFI or DSFID Byte

Use this command to encode the AFI or DSFID byte to a tag. Error handling is set by the ^RS command.



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility](#) on page 349 for the list of printers and firmware with which you can use this command.

Format: ^WFr,m,w,f,b

Parameters	Details
r = number of retries	Values: 0 to 10 Default: 0
m = motion	Values: 0 = Feed label after writing. 1 = No Feed after writing. Other ZPL may cause a feed. Default: 0
w = write protect	Values: 0 = Not write protected 1 = Write protect Default: 0
f = data format	Values: 0 = ASCII 1 = Hexadecimal Default: 0
b = type of byte to read	Values: A = AFI byte D = DSFID byte Default: A

➔ **Example 1:** This example encodes data “R” (hex 52) as the AFI byte. The printer will try the command up to five times, if necessary.

```
^XA
^WF5^FDR
^XZ
```

➔ **Example 2:** This example encodes data hex 66 as the AFI byte. The printer will try the command up to three times, if necessary.

```
^XA
^WF3,,,1^FD66
^XZ
```

➔ **Example 3:** This example encodes data hex 77 as the DSFID byte. The printer will try the command up to four times, if necessary.

```
^XA
^WF4,,,1,D^FD77
^XZ
```

^WT – Write (Encode) Tag



Note • The ^WT command is provided only for backward-compatibility with label formats that were developed for older Zebra RFID printers. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you should not use this command.

Use this command to encode the current RFID tag. Check the amount of data memory available for the tag that you will be using. If you send more data than the memory can hold, the printer truncates the data.

Format: ^WT**b,r,m,w,f,v**

Parameters	Details
b = block number	<p>Specifies the block number to encode. This parameter is tag-dependent.</p> <ul style="list-style-type: none"> For most tags, use block 0. For EPC Class 0 Plus, block 0 is EPC data, and block 1 is user data. For the R4Mplus, this parameter does not apply to printers with firmware version SP902X. With other versions of firmware in this printer, you can encode 12 bytes (96 bits) to block 0, but you can encode only the first byte of block 1. <p>Values: 0 to <i>n</i>, where <i>n</i> is the maximum number of blocks for the tag. Default: 0</p>
r = number of retries	<p>Changes the number of times that the printer attempts to encode a particular block of a single RFID tag. (Same function as the ^RR command.)</p> <p>Values: 0 to 10 Default: 0</p>
m = motion	<p>Enables or disables RFID motion. (Same function as the ^RM command.)</p> <p>Values: 0 = Feed label after writing 1 = No feed after writing (other ZPL may cause a feed)</p> <p>Default: 0</p>
w = write protect	<p>Values: 0 = Not write protected 1 = Write protected</p> <p>Default: 0</p>
f = data format	<p>Values: 0 = ASCII 1 = Hexadecimal</p> <p>Default: 0</p>

Parameters	Details
<p>For the R110Xi HF: v = reverse the data order</p> <p>For other supported printers: v = verify valid data</p>	<p>This parameter is not used in the R2844-Z.</p> <p>For the R110Xi HF: Reverses the data order. Values: N = Do not reverse the data order (Most significant byte first for Tag*It and PicoTag. Last significant byte first for I*code and ISO 15693) Y = Reverse the data order Default: N</p> <p>For other supported printers: For reliability, some manufacturers encode tags with known data (such as A5A5). This parameter flags whether the preprogrammed data is verified. (Same function as the ^WV command.) Values: N = Do not verify Y = Verify valid data before writing Default: N</p>

➔ **Example:** This sample encodes data “RFIDRFID” and will try writing up to five times, if necessary.

```

^XA
^WT,5^FDRFIDRFID^FS
^XZ
    
```

^WV – Verify RFID Encoding Operation



Important • This command is not supported by all printers or firmware. See [Printer and Firmware Compatibility on page 349](#) for the list of printers and firmware with which you can use this command.

Use this command to enable or disable the write verify function. When write verify is enabled, this command verifies the RFID encoding operation to ensure that the tag about to be programmed contains the hex data “A5A5” in the first two bytes. This parameter is not persistent (carried over from label to label).

Format: ^WVe

Parameters	Details
e = enable	Values: Y or N Default: N



Notes • _____

ZPL Wireless Commands

This section contains ZPL commands for the Wireless and Wireless Plus print servers.

^KC – Set Client Identifier (Option 61)

The ^KC command allows the print server to have its own client identifier (CID).

Format: ^KCa,b,c,d

Parameters	Details
a = enable or disable	<p>Values:</p> <ul style="list-style-type: none"> 0 = disable (default) 1 = enabled, use MAC address 2 = enabled, ASCII value 3 = enabled, HEX value <p>Default: 0</p>
b = device	<p>Values:</p> <ul style="list-style-type: none"> 0 = all devices 1 = wireless 2 = external wired ^{ad} 3 = internal wired <p>Default: 1</p>
c = prefix (optional)	<p>Values: 11 ASCII characters or 22 hexadecimal values. The prefix can be cleared by defaulting the network settings on the printer.</p>
d = identifier	<p>Values: 60 ASCII characters or 120 hexadecimal values. Minimum field length is 2 bytes. The suffix can be cleared by defaulting the network settings on the printer.</p>

ad.This applies only to the Xi4, RXi4, ZM400, ZM600, RZ400, or RZ600 printers when it is used with the external ZebraNet 10/100 print server using firmware v1.1.5 or later.

^NB – Search for Wired Print Server during Network Boot

Use this command to tell the printer whether to search for a wired print server at bootup. This command is ignored on the Xi4, RXi4, ZM400, ZM600, RZ400, and RZ600 printers.



Note • Only one print server can be installed in the S4M at one time, so this check does not occur.

Table 24 identifies which device becomes the active print server under different conditions.

Table 24 • Results of Check for Wired Print Server

If the Check for Wired Print Server is set to:	Installed and Connected to a Live Ethernet Network		Then, the Active Print Server will be:
	Wired	Wireless ^{ae}	
Skip	X	X	Wireless
	X	—	Wired
	—	X	Wireless
Check	X	X	Wired
	X	—	Wired
	—	X	Wireless

^{ae}A wireless option board must have an active radio that can properly associate to an access point.

Format: ^NBa

Parameters	Details
a = check for wired print server at boot time	Values: C = CHECK S = SKIP CHECK Default: S

^NN – Set SNMP

Use this command to set the Simple Network Management Protocol (SNMP) parameters.

Format: ^NNa,b,c,d,e,f

Parameters	Details
a = system name	Same as printer name. Values: Up to 17 alphanumeric characters
b = system contact	Any contact information as desired (such as a name or phrase) Values: Up to 50 alphanumeric characters
c = system location	The printer's model information. Values: Up to 50 alphanumeric characters
d = get community name	Values: Up to 19 alphanumeric characters Default: public
e = set community name	Values: Up to 19 alphanumeric characters Default: public
f = trap community name	Values: Up to 20 alphanumeric characters Default: public

^NP – Set Primary/Secondary Device

Use this command to specify whether to use the printer's or the print server's LAN/WLAN settings at boot time. The default is to use the printer's settings.

When the printer is set as the primary device, you can set it up using ZPL commands or the Wireless Setup Wizard utility, and any wired print server inserted into the printer will use those settings. The drawbacks to using the printer as primary are:

Any wired print server inserted into the printer will lose its original settings if the printer is set to check for the wired print server and the Primary Device is set to **PRINTER** (see [^NB on page 403](#)).

Format: ^NP`a`

Parameters	Details
<code>a</code> = device to use as primary	Values: P = printer M = MPS/Printserver Default: P

^NT – Set SMTP

Use this command to set the Simple Mail Transfer Protocol (SMTP) parameters. This allows you to set the e-mail settings for alerts.

Format: ^NTa,b

Parameters	Details
a = SMTP server address	Values: Any properly formatted server address in the xxx.xxx.xxx.xxx format
b = print server domain	Values: Any properly formatted print server domain name. A domain name is one or more labels separated by a period ("dot"), and a label consists of letters, numbers, and hyphens. An example of a domain name is zebra.com

^NW – Set Web Authentication Timeout Value

Use this command to set the timeout value for the printer home page. The printer will prompt for the printer password only the first time that certain screens are accessed until 1) the web authentication timeout value is reached (default value is 5 minutes) or 2) the printer is reset. At that time, the printer will prompt for the password again.

Format: ^NWa

Parameters	Details
a = timeout value	The timeout value in minutes for an IP address to be authenticated to the printer web pages. Values: 0 (no secure pages can be accessed without entering the printer password) to 255 minutes Default: 5

^WA – Set Antenna Parameters

Use this command to set the values for the receive and transmit antenna.

Format: ^WAa,b

Parameters	Details
a = receive antenna	Values: D = diversity L = left R = right Default: D
b = transmit antenna	Values: D = diversity L = left R = right Default: D

^WE – Set WEP Mode





Note • The ^WE command is provided only for backward-compatibility with printers using firmware prior to V50.15.x, V53.15.x, or X60.15.x. For these firmware versions and later, use ^WX on page 419 to set the security type and related parameters.

Use this command to command enable Wired Equivalent Privacy (WEP) mode and set WEP values. WEP is a security protocol for wireless local area networks (WLANs).

Be careful to include the exact number of commas required for this command when setting encryption keys (parameters e through h). A missing or extra comma will cause the keys to be stored in the wrong slots and can prevent the printer from joining the wireless network.

Format: ^WEa,b,c,d,e,f,g,h

Parameters	Details
a = encryption mode	<p>Values: OFF 40 = 40-bit encryption 128 = 128-bit encryption Default: OFF</p>
b = encryption index	<p>Tells the printer which encryption key to use. Values: 1 = Key 1 2 = Key 2 3 = Key 3 4 = Key 4 Default: 1</p>
c = authentication type	<p>Values: O (Open System), S (Shared Key) O = Open System S = Shared Key Default: O</p> <p> Note • If you enable Shared Key authentication with Encryption Mode set to OFF, this value resets to O (Open).</p>
d = encryption key storage	<p>Values: H (Hex key storage), S (string key storage) H = Hex key storage S = String key storage Default: H</p>
e, f, g, h = encryption keys 1 through 4	<p>Values: The actual value for the encryption key The encryption mode affects what can be entered for the encryption keys:</p> <ul style="list-style-type: none"> • For 40-bit, encryption keys can be set to any 5 hex pairs or any 10 alphanumeric characters. • For 128-bit, encryption keys can be set to any 13 hex pairs or any 26 alphanumeric characters. <p> Note • When using hex storage, do not add a leading 0x on the WEP key.</p>

→ **Example 1:** This example sets encryption to 40-bit, activates encryption key 1, and sets encryption key 1 to the string **12345**.

```
^WE40, , , , 12345
```

In this example, the Encryption Index, Authentication Type, and Encryption Key Storage parameters are left blank with commas as placeholders for the fields. The printer uses the default values for these parameters.

→ **Example 2:** This example sets encryption to 128-bit, activates encryption key 2, and sets encryption keys 1 and 2 to hex values.

```
^WE128, 2, , H, 12345678901234567890123456, 98765432109876543210987654
```

The value for encryption key 1 is stored and can be activated in the future by the following command:

```
^WE128, 1
```

→ **Example 3:** This example sets encryption to 128-bit, activates encryption key 4, and sets encryption key 4 to a hex value.

```
^WE128, 4, , H, , , , 98765432109876543210987654
```

Values are not required for encryption keys 1 through 3 when setting encryption key 4. In this example, commas are used as placeholders for the fields for encryption keys 1 through 3. Any previously stored values for these encryption keys do not change.



Important • Make sure that you include the exact number of commas required to get to the slot for encryption key 4 (parameter **h**).

^WI – Change Wireless Network Settings

Use this command to change the wireless network settings.

Zebra recommends using [^ND on page 285](#) for these settings if you have any of the following printers:

- Xi4 printers with firmware V53.17.1Z or later
- RXi4 printers with firmware V53.17.7Z or later
- ZM400, ZM600, or S4M printers with firmware V53.15.xZ or later
- RZ400/RZ600 printers with firmware R53.16.x or later

Format: ^WIa,b,c,d,e,f,g,h,i

Parameters	Details
a = IP resolution	Values: A = All B = BOOTP C = DHCP and BOOTP D = DHCP G = Gleaning only (Not recommended when the Wireless Print Server or Wireless Plus Print Server is installed.) R = RARP P = Permanent Default: A
b = IP address	Values: Any properly formatted IP address in the xxx.xxx.xxx.xxx format. Default: 000.000.000.000
c = subnet mask	Values: Any properly formatted subnet mask in the xxx.xxx.xxx.xxx format. Default: 000.000.000.000
d = default gateway	Values: Any properly formatted gateway in the xxx.xxx.xxx.xxx format. Default: 000.000.000.000
e = WINS server address	Values: Any properly formatted WINS server in the xxx.xxx.xxx.xxx format. Default: 000.000.000.000
f = connection timeout checking	Values: Y = yes N = no Default: Y
g = timeout value	Time, in seconds, before the connection times out. Values: 0 through 9999 Default: 300
h = ARP broadcast interval	Time, in minutes, that the broadcast is sent to update the device's ARP cache. Values: 0 through 30 Default: 0 (no ARP sent)
i = base raw port number	The port number that the printer should use for its RAW data. Values: 1 through 65535 Default: 9100

^WL – Set LEAP Parameters



Note • The ^WL command is provided only for backward-compatibility with printers using firmware prior to V50.15.x or X60.15.x. For these firmware versions and later, use ^WX on page 419 to set the security type and related parameters.

Use this command to enable Cisco® Lightweight Extensible Authentication Protocol (LEAP) mode and set parameters. LEAP is user authentication method that is available with some wireless radio cards.

Format: ^WL**a**,**b**,**c**

Parameters	Details
a = mode	Values: OFF, ON Default: OFF
b = user name	Values: Any 1 to 32 alphanumeric including special characters Default: user
c = password	Values: Any 1 to 32 alphanumeric including special characters Default: password

~WL - Print Network Configuration Label

Generates a network configuration label (Figure 2).

Format: ~WL

Figure 2 • Network Configuration Label

Wireless Print Server	Wireless Plus Print Server and Internal Wireless Plus Print Server	Other Printers/ Print Engines																																																																																																																																																																																																																																																																																																																																										
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr><th colspan="2" style="text-align: center;">Network Configuration</th></tr> </thead> <tbody> <tr><td colspan="2">Zebra Technologies</td></tr> <tr><td colspan="2">ZTC 140xi11IP1us-200dpi</td></tr> <tr><td colspan="2">ZBR3258042</td></tr> <tr><td>NO.....</td><td>WIRED PS CHECK?</td></tr> <tr><td>Printer.....</td><td>LOAD LAN FROM?</td></tr> <tr><td colspan="2">Wired</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>000.000.000.000.....</td><td>IP ADDRESS</td></tr> <tr><td>000.000.000.000.....</td><td>SUBNET MASK</td></tr> <tr><td>000.000.000.000.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>000.000.000.000.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>0300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>0000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td colspan="2">Wireless*</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>010.003.015.030.....</td><td>IP ADDRESS</td></tr> <tr><td>255.255.255.000.....</td><td>SUBNET MASK</td></tr> <tr><td>000.000.000.000.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>000.000.000.000.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>0300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>0000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td>YES.....</td><td>CARD INSERTED</td></tr> <tr><td>015FH.....</td><td>CARD MFG ID</td></tr> <tr><td>000AH.....</td><td>CARD PRODUCT ID</td></tr> <tr><td>5.02.19.....</td><td>CARD FIRMWARE</td></tr> <tr><td>00082131b6ba.....</td><td>MAC ADDRESS</td></tr> <tr><td>YES.....</td><td>DRIVER INSTALLED</td></tr> <tr><td>INFRASTRUCTURE.....</td><td>OPERATING MODE</td></tr> <tr><td>125.....</td><td>ESSID</td></tr> <tr><td>100.....</td><td>TX POWER</td></tr> <tr><td>ON.....</td><td>1 Mb/s</td></tr> <tr><td>ON.....</td><td>2 Mb/s</td></tr> <tr><td>ON.....</td><td>5.5 Mb/s</td></tr> <tr><td>ON.....</td><td>11 Mb/s</td></tr> <tr><td>11 Mb/s.....</td><td>CURRENT TX RATE</td></tr> <tr><td>DIVERSITY.....</td><td>RECEIVE ANTENNA</td></tr> <tr><td>DIVERSITY.....</td><td>XMIT ANTENNA</td></tr> <tr><td>YES.....</td><td>ASSOCIATED</td></tr> <tr><td>NONE.....</td><td>WLAN SECURITY</td></tr> <tr><td>OPEN.....</td><td>WEP TYPE</td></tr> <tr><td>1.....</td><td>WEP INDEX</td></tr> <tr><td>LONG.....</td><td>PREAMBLE</td></tr> <tr><td>020.....</td><td>POOR SIGNAL</td></tr> </tbody> </table> <p style="font-size: small;">FIRMWARE IN THIS PRINTER IS COPYRIGHTED</p>	Network Configuration		Zebra Technologies		ZTC 140xi11IP1us-200dpi		ZBR3258042		NO.....	WIRED PS CHECK?	Printer.....	LOAD LAN FROM?	Wired		ALL.....	IP PROTOCOL	000.000.000.000.....	IP ADDRESS	000.000.000.000.....	SUBNET MASK	000.000.000.000.....	DEFAULT GATEWAY	000.000.000.000.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	0300.....	TIMEOUT VALUE	0000.....	ARP INTERVAL	9100.....	BASE RAW PORT	Wireless*		ALL.....	IP PROTOCOL	010.003.015.030.....	IP ADDRESS	255.255.255.000.....	SUBNET MASK	000.000.000.000.....	DEFAULT GATEWAY	000.000.000.000.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	0300.....	TIMEOUT VALUE	0000.....	ARP INTERVAL	9100.....	BASE RAW PORT	YES.....	CARD INSERTED	015FH.....	CARD MFG ID	000AH.....	CARD PRODUCT ID	5.02.19.....	CARD FIRMWARE	00082131b6ba.....	MAC ADDRESS	YES.....	DRIVER INSTALLED	INFRASTRUCTURE.....	OPERATING MODE	125.....	ESSID	100.....	TX POWER	ON.....	1 Mb/s	ON.....	2 Mb/s	ON.....	5.5 Mb/s	ON.....	11 Mb/s	11 Mb/s.....	CURRENT TX RATE	DIVERSITY.....	RECEIVE ANTENNA	DIVERSITY.....	XMIT ANTENNA	YES.....	ASSOCIATED	NONE.....	WLAN SECURITY	OPEN.....	WEP TYPE	1.....	WEP INDEX	LONG.....	PREAMBLE	020.....	POOR SIGNAL	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr><th colspan="2" style="text-align: center;">Network Configuration</th></tr> </thead> <tbody> <tr><td colspan="2">Zebra Technologies</td></tr> <tr><td colspan="2">PRINTER NAME</td></tr> <tr><td colspan="2">ZBR2934792</td></tr> <tr><td>0.0.0 *.....</td><td>OPTION FIRMWARE</td></tr> <tr><td>Wired.....</td><td>PRIMARY NETWORK</td></tr> <tr><td>NO.....</td><td>LOAD FROM EXT?</td></tr> <tr><td>Internal Wired.....</td><td>ACTIVE PRINTSRVR</td></tr> <tr><td colspan="2">External Wired</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>000.000.000.000.....</td><td>IP ADDRESS</td></tr> <tr><td>255.255.255.000.....</td><td>SUBNET MASK</td></tr> <tr><td>000.000.000.000.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>000.000.000.000.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td colspan="2">Internal Wired*</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>010.003.004.116.....</td><td>IP ADDRESS</td></tr> <tr><td>255.255.255.000.....</td><td>SUBNET MASK</td></tr> <tr><td>010.003.004.001.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>010.003.001.098.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td>00074d2b4168.....</td><td>MAC ADDRESS</td></tr> <tr><td colspan="2">Wireless</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>000.000.000.000.....</td><td>IP ADDRESS</td></tr> <tr><td>255.255.255.000.....</td><td>SUBNET MASK</td></tr> <tr><td>000.000.000.000.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>000.000.000.000.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td>NO.....</td><td>CARD INSERTED</td></tr> <tr><td>0000H.....</td><td>CARD MFG ID</td></tr> <tr><td>0000H.....</td><td>CARD PRODUCT ID</td></tr> <tr><td>000000000000.....</td><td>MAC ADDRESS</td></tr> <tr><td>YES.....</td><td>DRIVER INSTALLED</td></tr> <tr><td>INFRASTRUCTURE.....</td><td>OPERATING MODE</td></tr> <tr><td>125.....</td><td>ESSID</td></tr> <tr><td>100.....</td><td>TX POWER</td></tr> <tr><td>ON.....</td><td>1 Mb/s</td></tr> <tr><td>ON.....</td><td>2 Mb/s</td></tr> <tr><td>ON.....</td><td>5.5 Mb/s</td></tr> <tr><td>ON.....</td><td>11 Mb/s</td></tr> <tr><td>11 Mb/s.....</td><td>CURRENT TX RATE</td></tr> <tr><td>DIVERSITY.....</td><td>RECEIVE ANTENNA</td></tr> <tr><td>DIVERSITY.....</td><td>XMIT ANTENNA</td></tr> <tr><td>OPEN.....</td><td>WEP TYPE</td></tr> <tr><td>NONE.....</td><td>WLAN SECURITY</td></tr> <tr><td>1.....</td><td>WEP INDEX</td></tr> <tr><td>020.....</td><td>POOR SIGNAL</td></tr> <tr><td>LONG.....</td><td>PREAMBLE</td></tr> <tr><td>NO.....</td><td>ASSOCIATED</td></tr> <tr><td>ON.....</td><td>PULSE ENABLED</td></tr> <tr><td>15.....</td><td>PULSE RATE</td></tr> <tr><td>OFF.....</td><td>INTL MODE</td></tr> <tr><td>07FFH.....</td><td>CHANNEL MASK</td></tr> </tbody> </table> <p style="font-size: small;">FIRMWARE IN THIS PRINTER IS COPYRIGHTED</p>	Network Configuration		Zebra Technologies		PRINTER NAME		ZBR2934792		0.0.0 *.....	OPTION FIRMWARE	Wired.....	PRIMARY NETWORK	NO.....	LOAD FROM EXT?	Internal Wired.....	ACTIVE PRINTSRVR	External Wired		ALL.....	IP PROTOCOL	000.000.000.000.....	IP ADDRESS	255.255.255.000.....	SUBNET MASK	000.000.000.000.....	DEFAULT GATEWAY	000.000.000.000.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	300.....	TIMEOUT VALUE	000.....	ARP INTERVAL	9100.....	BASE RAW PORT	Internal Wired*		ALL.....	IP PROTOCOL	010.003.004.116.....	IP ADDRESS	255.255.255.000.....	SUBNET MASK	010.003.004.001.....	DEFAULT GATEWAY	010.003.001.098.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	300.....	TIMEOUT VALUE	000.....	ARP INTERVAL	9100.....	BASE RAW PORT	00074d2b4168.....	MAC ADDRESS	Wireless		ALL.....	IP PROTOCOL	000.000.000.000.....	IP ADDRESS	255.255.255.000.....	SUBNET MASK	000.000.000.000.....	DEFAULT GATEWAY	000.000.000.000.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	300.....	TIMEOUT VALUE	000.....	ARP INTERVAL	9100.....	BASE RAW PORT	NO.....	CARD INSERTED	0000H.....	CARD MFG ID	0000H.....	CARD PRODUCT ID	000000000000.....	MAC ADDRESS	YES.....	DRIVER INSTALLED	INFRASTRUCTURE.....	OPERATING MODE	125.....	ESSID	100.....	TX POWER	ON.....	1 Mb/s	ON.....	2 Mb/s	ON.....	5.5 Mb/s	ON.....	11 Mb/s	11 Mb/s.....	CURRENT TX RATE	DIVERSITY.....	RECEIVE ANTENNA	DIVERSITY.....	XMIT ANTENNA	OPEN.....	WEP TYPE	NONE.....	WLAN SECURITY	1.....	WEP INDEX	020.....	POOR SIGNAL	LONG.....	PREAMBLE	NO.....	ASSOCIATED	ON.....	PULSE ENABLED	15.....	PULSE RATE	OFF.....	INTL MODE	07FFH.....	CHANNEL MASK	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr><th colspan="2" style="text-align: center;">Network Configuration</th></tr> </thead> <tbody> <tr><td colspan="2">Zebra Technologies</td></tr> <tr><td colspan="2">ZTC 105SL-200dpi</td></tr> <tr><td colspan="2">ZBR12908662</td></tr> <tr><td>1.10.1729.....</td><td>OPTION FIRMWARE</td></tr> <tr><td>NO.....</td><td>WIRED PS CHECK?</td></tr> <tr><td>Printer.....</td><td>LOAD LAN FROM?</td></tr> <tr><td colspan="2">Wired</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>000.000.000.000.....</td><td>IP ADDRESS</td></tr> <tr><td>000.000.000.000.....</td><td>SUBNET MASK</td></tr> <tr><td>000.000.000.000.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>000.000.000.000.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>0300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>0000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td colspan="2">Wireless*</td></tr> <tr><td>ALL.....</td><td>IP PROTOCOL</td></tr> <tr><td>010.003.015.034.....</td><td>IP ADDRESS</td></tr> <tr><td>255.255.255.000.....</td><td>SUBNET MASK</td></tr> <tr><td>000.000.000.000.....</td><td>DEFAULT GATEWAY</td></tr> <tr><td>000.000.000.000.....</td><td>WINS SERVER IP</td></tr> <tr><td>YES.....</td><td>TIMEOUT CHECKING</td></tr> <tr><td>0300.....</td><td>TIMEOUT VALUE</td></tr> <tr><td>0000.....</td><td>ARP INTERVAL</td></tr> <tr><td>9100.....</td><td>BASE RAW PORT</td></tr> <tr><td>YES.....</td><td>CARD INSERTED</td></tr> <tr><td>015FH.....</td><td>CARD MFG ID</td></tr> <tr><td>000AH.....</td><td>CARD PRODUCT ID</td></tr> <tr><td>5.60.21.....</td><td>CARD FIRMWARE</td></tr> <tr><td>000e84c4f876.....</td><td>MAC ADDRESS</td></tr> <tr><td>YES.....</td><td>DRIVER INSTALLED</td></tr> <tr><td>INFRASTRUCTURE.....</td><td>OPERATING MODE</td></tr> <tr><td>125.....</td><td>ESSID</td></tr> <tr><td>100.....</td><td>TX POWER</td></tr> <tr><td>ON.....</td><td>1 Mb/s</td></tr> <tr><td>ON.....</td><td>2 Mb/s</td></tr> <tr><td>ON.....</td><td>5.5 Mb/s</td></tr> <tr><td>ON.....</td><td>11 Mb/s</td></tr> <tr><td>11 Mb/s.....</td><td>CURRENT TX RATE</td></tr> <tr><td>DIVERSITY.....</td><td>RECEIVE ANTENNA</td></tr> <tr><td>DIVERSITY.....</td><td>XMIT ANTENNA</td></tr> <tr><td>YES.....</td><td>ASSOCIATED</td></tr> <tr><td>NONE.....</td><td>WLAN SECURITY</td></tr> <tr><td>OPEN.....</td><td>WEP TYPE</td></tr> <tr><td>1.....</td><td>WEP INDEX</td></tr> <tr><td>LONG.....</td><td>PREAMBLE</td></tr> <tr><td>020.....</td><td>POOR SIGNAL</td></tr> <tr><td>ON.....</td><td>PULSE ENABLED</td></tr> <tr><td>15.....</td><td>PULSE RATE</td></tr> <tr><td>ON.....</td><td>INTL MODE</td></tr> <tr><td>07FFH.....</td><td>CHANNEL MASK</td></tr> </tbody> </table> <p style="font-size: small;">FIRMWARE IN THIS PRINTER IS COPYRIGHTED</p>	Network Configuration		Zebra Technologies		ZTC 105SL-200dpi		ZBR12908662		1.10.1729.....	OPTION FIRMWARE	NO.....	WIRED PS CHECK?	Printer.....	LOAD LAN FROM?	Wired		ALL.....	IP PROTOCOL	000.000.000.000.....	IP ADDRESS	000.000.000.000.....	SUBNET MASK	000.000.000.000.....	DEFAULT GATEWAY	000.000.000.000.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	0300.....	TIMEOUT VALUE	0000.....	ARP INTERVAL	9100.....	BASE RAW PORT	Wireless*		ALL.....	IP PROTOCOL	010.003.015.034.....	IP ADDRESS	255.255.255.000.....	SUBNET MASK	000.000.000.000.....	DEFAULT GATEWAY	000.000.000.000.....	WINS SERVER IP	YES.....	TIMEOUT CHECKING	0300.....	TIMEOUT VALUE	0000.....	ARP INTERVAL	9100.....	BASE RAW PORT	YES.....	CARD INSERTED	015FH.....	CARD MFG ID	000AH.....	CARD PRODUCT ID	5.60.21.....	CARD FIRMWARE	000e84c4f876.....	MAC ADDRESS	YES.....	DRIVER INSTALLED	INFRASTRUCTURE.....	OPERATING MODE	125.....	ESSID	100.....	TX POWER	ON.....	1 Mb/s	ON.....	2 Mb/s	ON.....	5.5 Mb/s	ON.....	11 Mb/s	11 Mb/s.....	CURRENT TX RATE	DIVERSITY.....	RECEIVE ANTENNA	DIVERSITY.....	XMIT ANTENNA	YES.....	ASSOCIATED	NONE.....	WLAN SECURITY	OPEN.....	WEP TYPE	1.....	WEP INDEX	LONG.....	PREAMBLE	020.....	POOR SIGNAL	ON.....	PULSE ENABLED	15.....	PULSE RATE	ON.....	INTL MODE	07FFH.....	CHANNEL MASK
Network Configuration																																																																																																																																																																																																																																																																																																																																												
Zebra Technologies																																																																																																																																																																																																																																																																																																																																												
ZTC 140xi11IP1us-200dpi																																																																																																																																																																																																																																																																																																																																												
ZBR3258042																																																																																																																																																																																																																																																																																																																																												
NO.....	WIRED PS CHECK?																																																																																																																																																																																																																																																																																																																																											
Printer.....	LOAD LAN FROM?																																																																																																																																																																																																																																																																																																																																											
Wired																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
0300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
0000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
Wireless*																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
010.003.015.030.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
255.255.255.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
0300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
0000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
YES.....	CARD INSERTED																																																																																																																																																																																																																																																																																																																																											
015FH.....	CARD MFG ID																																																																																																																																																																																																																																																																																																																																											
000AH.....	CARD PRODUCT ID																																																																																																																																																																																																																																																																																																																																											
5.02.19.....	CARD FIRMWARE																																																																																																																																																																																																																																																																																																																																											
00082131b6ba.....	MAC ADDRESS																																																																																																																																																																																																																																																																																																																																											
YES.....	DRIVER INSTALLED																																																																																																																																																																																																																																																																																																																																											
INFRASTRUCTURE.....	OPERATING MODE																																																																																																																																																																																																																																																																																																																																											
125.....	ESSID																																																																																																																																																																																																																																																																																																																																											
100.....	TX POWER																																																																																																																																																																																																																																																																																																																																											
ON.....	1 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	2 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	5.5 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	11 Mb/s																																																																																																																																																																																																																																																																																																																																											
11 Mb/s.....	CURRENT TX RATE																																																																																																																																																																																																																																																																																																																																											
DIVERSITY.....	RECEIVE ANTENNA																																																																																																																																																																																																																																																																																																																																											
DIVERSITY.....	XMIT ANTENNA																																																																																																																																																																																																																																																																																																																																											
YES.....	ASSOCIATED																																																																																																																																																																																																																																																																																																																																											
NONE.....	WLAN SECURITY																																																																																																																																																																																																																																																																																																																																											
OPEN.....	WEP TYPE																																																																																																																																																																																																																																																																																																																																											
1.....	WEP INDEX																																																																																																																																																																																																																																																																																																																																											
LONG.....	PREAMBLE																																																																																																																																																																																																																																																																																																																																											
020.....	POOR SIGNAL																																																																																																																																																																																																																																																																																																																																											
Network Configuration																																																																																																																																																																																																																																																																																																																																												
Zebra Technologies																																																																																																																																																																																																																																																																																																																																												
PRINTER NAME																																																																																																																																																																																																																																																																																																																																												
ZBR2934792																																																																																																																																																																																																																																																																																																																																												
0.0.0 *.....	OPTION FIRMWARE																																																																																																																																																																																																																																																																																																																																											
Wired.....	PRIMARY NETWORK																																																																																																																																																																																																																																																																																																																																											
NO.....	LOAD FROM EXT?																																																																																																																																																																																																																																																																																																																																											
Internal Wired.....	ACTIVE PRINTSRVR																																																																																																																																																																																																																																																																																																																																											
External Wired																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
255.255.255.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
Internal Wired*																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
010.003.004.116.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
255.255.255.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
010.003.004.001.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
010.003.001.098.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
00074d2b4168.....	MAC ADDRESS																																																																																																																																																																																																																																																																																																																																											
Wireless																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
255.255.255.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
NO.....	CARD INSERTED																																																																																																																																																																																																																																																																																																																																											
0000H.....	CARD MFG ID																																																																																																																																																																																																																																																																																																																																											
0000H.....	CARD PRODUCT ID																																																																																																																																																																																																																																																																																																																																											
000000000000.....	MAC ADDRESS																																																																																																																																																																																																																																																																																																																																											
YES.....	DRIVER INSTALLED																																																																																																																																																																																																																																																																																																																																											
INFRASTRUCTURE.....	OPERATING MODE																																																																																																																																																																																																																																																																																																																																											
125.....	ESSID																																																																																																																																																																																																																																																																																																																																											
100.....	TX POWER																																																																																																																																																																																																																																																																																																																																											
ON.....	1 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	2 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	5.5 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	11 Mb/s																																																																																																																																																																																																																																																																																																																																											
11 Mb/s.....	CURRENT TX RATE																																																																																																																																																																																																																																																																																																																																											
DIVERSITY.....	RECEIVE ANTENNA																																																																																																																																																																																																																																																																																																																																											
DIVERSITY.....	XMIT ANTENNA																																																																																																																																																																																																																																																																																																																																											
OPEN.....	WEP TYPE																																																																																																																																																																																																																																																																																																																																											
NONE.....	WLAN SECURITY																																																																																																																																																																																																																																																																																																																																											
1.....	WEP INDEX																																																																																																																																																																																																																																																																																																																																											
020.....	POOR SIGNAL																																																																																																																																																																																																																																																																																																																																											
LONG.....	PREAMBLE																																																																																																																																																																																																																																																																																																																																											
NO.....	ASSOCIATED																																																																																																																																																																																																																																																																																																																																											
ON.....	PULSE ENABLED																																																																																																																																																																																																																																																																																																																																											
15.....	PULSE RATE																																																																																																																																																																																																																																																																																																																																											
OFF.....	INTL MODE																																																																																																																																																																																																																																																																																																																																											
07FFH.....	CHANNEL MASK																																																																																																																																																																																																																																																																																																																																											
Network Configuration																																																																																																																																																																																																																																																																																																																																												
Zebra Technologies																																																																																																																																																																																																																																																																																																																																												
ZTC 105SL-200dpi																																																																																																																																																																																																																																																																																																																																												
ZBR12908662																																																																																																																																																																																																																																																																																																																																												
1.10.1729.....	OPTION FIRMWARE																																																																																																																																																																																																																																																																																																																																											
NO.....	WIRED PS CHECK?																																																																																																																																																																																																																																																																																																																																											
Printer.....	LOAD LAN FROM?																																																																																																																																																																																																																																																																																																																																											
Wired																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
0300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
0000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
Wireless*																																																																																																																																																																																																																																																																																																																																												
ALL.....	IP PROTOCOL																																																																																																																																																																																																																																																																																																																																											
010.003.015.034.....	IP ADDRESS																																																																																																																																																																																																																																																																																																																																											
255.255.255.000.....	SUBNET MASK																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	DEFAULT GATEWAY																																																																																																																																																																																																																																																																																																																																											
000.000.000.000.....	WINS SERVER IP																																																																																																																																																																																																																																																																																																																																											
YES.....	TIMEOUT CHECKING																																																																																																																																																																																																																																																																																																																																											
0300.....	TIMEOUT VALUE																																																																																																																																																																																																																																																																																																																																											
0000.....	ARP INTERVAL																																																																																																																																																																																																																																																																																																																																											
9100.....	BASE RAW PORT																																																																																																																																																																																																																																																																																																																																											
YES.....	CARD INSERTED																																																																																																																																																																																																																																																																																																																																											
015FH.....	CARD MFG ID																																																																																																																																																																																																																																																																																																																																											
000AH.....	CARD PRODUCT ID																																																																																																																																																																																																																																																																																																																																											
5.60.21.....	CARD FIRMWARE																																																																																																																																																																																																																																																																																																																																											
000e84c4f876.....	MAC ADDRESS																																																																																																																																																																																																																																																																																																																																											
YES.....	DRIVER INSTALLED																																																																																																																																																																																																																																																																																																																																											
INFRASTRUCTURE.....	OPERATING MODE																																																																																																																																																																																																																																																																																																																																											
125.....	ESSID																																																																																																																																																																																																																																																																																																																																											
100.....	TX POWER																																																																																																																																																																																																																																																																																																																																											
ON.....	1 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	2 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	5.5 Mb/s																																																																																																																																																																																																																																																																																																																																											
ON.....	11 Mb/s																																																																																																																																																																																																																																																																																																																																											
11 Mb/s.....	CURRENT TX RATE																																																																																																																																																																																																																																																																																																																																											
DIVERSITY.....	RECEIVE ANTENNA																																																																																																																																																																																																																																																																																																																																											
DIVERSITY.....	XMIT ANTENNA																																																																																																																																																																																																																																																																																																																																											
YES.....	ASSOCIATED																																																																																																																																																																																																																																																																																																																																											
NONE.....	WLAN SECURITY																																																																																																																																																																																																																																																																																																																																											
OPEN.....	WEP TYPE																																																																																																																																																																																																																																																																																																																																											
1.....	WEP INDEX																																																																																																																																																																																																																																																																																																																																											
LONG.....	PREAMBLE																																																																																																																																																																																																																																																																																																																																											
020.....	POOR SIGNAL																																																																																																																																																																																																																																																																																																																																											
ON.....	PULSE ENABLED																																																																																																																																																																																																																																																																																																																																											
15.....	PULSE RATE																																																																																																																																																																																																																																																																																																																																											
ON.....	INTL MODE																																																																																																																																																																																																																																																																																																																																											
07FFH.....	CHANNEL MASK																																																																																																																																																																																																																																																																																																																																											

^WP – Set Wireless Password



Note • This command does not apply to the S4M.

Use this command to set the four-digit wireless password (not the same as the general printer password). If the wireless password is **0000**, the Wireless and Wireless Plus print servers run in an “unprotected” mode, which means that you do not need to enter the wireless password through the control panel to view or modify wireless settings.

If a wireless password is set, the values for the following parameters will not appear through the control panel until the wireless password is entered:

- MAC Address
- ESSID
- WLAN Security
- WEP Type
- WEP Index
- Reset Network

Format: ^WP`a,b`

Parameters	Details
a = old wireless password	Values: 0000 through 9999 Default: 0000
b = new wireless password	Values: 0000 through 9999 Default: 0000

^WR – Set Transmit Rate

Use this command to change the transmission rate for 802.11b wireless print servers.

Format: ^WRa,b,c,d,e

Parameters	Details
a = rate 1	Sets the 1 Mb/s transmit rate. Values: Y (On), N (Off)
b = rate 2	Sets the 2 Mb/s transmit rate. Values: Y (On), N (Off)
c = rate 5.5	Sets the 5.5 Mb/s transmit rate. Values: Y (On), N (Off)
d = rate 11	Sets the 11 Mb/s transmit rate. Values: Y (On), N (Off)
e = transmit power	Values: 1, 5, 20, 30, 50, 100

~WR – Reset Wireless Radio Card and Print Server

Use this command to reinitialize the wireless radio card and the print server (wired or wireless) when the Wireless or Wireless Plus print server is running. The command also causes any wireless radio card in the printer to reassociate to the wireless network.

Format: ~WR

^WS – Set Wireless Radio Card Values

Use this command to set the wireless radio card values for ESSID, Operating Mode, and Card Preamble.

Format: ^WSe,o,p,h,i,j,k





Parameters	Details
e = ESSID value	Values: Any value up to 32 characters, including all ASCII and Extended ASCII characters, including the space character. When this parameter is left blank, the ESSID is not changed. Default: 125
o = operating mode	Values: I (Infrastructure), A (Adhoc) Default: I
p = wireless radio card preamble	Values: L = long S = short Default: L
h = wireless pulse  This parameter is supported in firmware version V60.15.x, V50.15.x, R6x.15.x, R53.15.x, ZSPx, or later.	Adds a pulse to the network traffic generated by the printer. This pulse is necessary with some network configurations to keep the printer online. Values: 0 = disabled 1 = enabled Default: 1
i = wireless pulse interval  This parameter is supported in firmware version V60.15.x, V50.15.x, R6x.15.x, R53.15.x, ZSPx, or later.	Sets the interval at which the wireless pulse is sent when the wireless pulse feature is enabled. Values: 5 to 300 seconds Default: 15
j = channel mask  This parameter is supported in firmware version X60.15.x, V50.15.x, or later.	For commonly used channel masks, see Table 25 . Values: 4 Hexadecimal digits preceded by "0x" (0x0000 to 0xFFFF) Default: 0x7FF
k = international mode  This parameter is supported in firmware version X60.15.x, V50.15.x, or later.	In international mode, the printer uses the channel set by the access point. Values: 0 (Disabled), 1 (Enabled) Default: 0

Table 25 • Channel Mask Settings

Region	Channel Mask
United States, Canada, Latin America	0x7FF
Europe, Middle East, Africa, other	0x1FFF
Japan	0x3FFF

^WX – Configure Wireless Securities

Use this command to configure the wireless security settings for your printer. Values entered for this command must match what is configured on your WLAN and must be supported by the wireless radio card that you are using.

The ^WX command replaces individual ZPL commands for different security types.




Note • When using certificate files, your printer supports:

- Using Privacy Enhanced Mail (PEM) formatted certificate files.
- Using the client certificate and private key as two files, each downloaded separately.
- Using exportable PAC files for EAP-FAST.
- The supporting parameters that are required vary based on the security type that you select. See [Supporting Parameters for Different Security Types on page 421](#) for instructions for each security type.





Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.


Format: ^WXa,[zero or more supporting parameters]

Parameters	Details
a = security type	<p>Enter the two-digit code for the security type that your WLAN uses. For which supporting parameters (b through n) to use with the different security types, see Supporting Parameters for Different Security Types on page 421.</p> <p> Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.</p> <p>Values: 01 to 15</p> <p>01 = No wireless security is active 09 = WPA PSK (R6x15.x, R53.15.x, ZSPx, and later.)</p> <p>02 = WEP 40-bit 10 = WPA EAP-TLS</p> <p>03 = WEP 128-bit 11 = WPA EAP-TTLS</p> <p>04 = EAP-TLS 12 = WPA EAP-FAST</p> <p>05 = EAP-TTLS 13 = WPA PEAP</p> <p>06 = EAP-FAST 14 = WPA LEAP</p> <p>07 = PEAP 15 = Kerberos</p> <p>08 = LEAP</p> <p>Default: 01</p>
b = WEP encryption index*	<p>Specifies which encryption key to use for WEP encryption. A value must be specified if using WEP 40-bit or WEP 128-bit.</p> <p>Values: 1, 2, 3, 4</p> <p>Default: 1</p>
c = WEP authentication type*	<p>Enables the WEP key authentication type. A value must be specified if using WEP 40-bit or WEP 128-bit.</p> <p>Values: 0 or S</p> <p>0 = open system</p> <p>S = shared key</p> <p>Default: 0</p>

* Not used for all security types

Parameters	Details
d = WEP key type*	<p>Specifies the format of the WEP key. A value must be specified if using WEP 40-bit or WEP 128-bit.</p> <p>Values: H or S H = hex key storage S = string key storage</p> <p>Default: S</p>
e, f, g, h = WEP encryption keys 1 through 4*	<p>Specifies the actual values of any WEP encryption keys to be used. A value must be specified for at least one WEP encryption key if you specify 40-bit or 128-bit WEP encryption for the security type.</p> <p> Important • Be careful to include the exact number of commas required for this command when setting encryption keys (parameters e through h). A missing or extra comma will cause the keys to be stored in the wrong slots and can prevent the printer from joining the wireless network.</p> <p>The encryption mode affects what can be entered for the encryption keys:</p> <ul style="list-style-type: none"> • For 40-bit, encryption keys can be set to any 5 hex pairs or any 10 alphanumeric characters. • For 128-bit, encryption keys can be set to any 13 hex pairs or any 26 alphanumeric characters. <p> Note • When using hex storage, do not add a leading 0x on the WEP key.</p> <p>Values: The actual value for the encryption key</p> <p>Default: None</p>
i = user ID*	<p>Specifies a user ID for security types that require one. A value must be specified if using the following security types:</p> <ul style="list-style-type: none"> • EAP-TTLS • LEAP • WPA LEAP • PEAP • WPA PEAP • WPA EAP-TTLS • Kerberos <p>Values: The actual value for the user ID.</p> <p>Default: user</p>
j = password*	<p>Specifies a password for security types that require one. A value must be specified if using the following security types:</p> <ul style="list-style-type: none"> • EAP-TTLS • LEAP • WPA LEAP • PEAP • WPA PEAP • WPA EAP-TTLS • Kerberos <p>Values: The actual value for the password.</p> <p>Default: password</p>

* Not used for all security types

Parameters	Details
k = optional private key password*	<p>Specifies an optional private key password for security types that require one. A value must be specified if using the following security types:</p> <ul style="list-style-type: none"> • EAP-TLS • EAP-FAST • WPA EAP-TLS • WPA EAP-FAST <p>Values: The actual value for the optional private key. Default: None</p>
l = realm*	<p>Specifies the realm for security types that require it. A value must be specified if using Kerberos.</p> <p>Values: The actual value for the realm. Default: kerberos</p>
m = Key Distribution Center (KDC)*	<p>Specifies the KDC for security types that require it. A value must be specified if using Kerberos.</p> <p>Values: The actual value for the KDC. Default: krbtgt"</p>
n = Pre-Shared Key (PSK) value*	<p>Enter the PSK value. This value is calculated and must be the same for each device on the WLAN. Use ZebraNet Bridge to generate the PSK value. A value must be specified if using WPA PSK.</p> <p> Important • Do not enter a pass phrase for this field in this command. To use a pass phrase, use the ZebraNet Bridge Enterprise Wireless Setup Wizard.</p> <p>Values: a minimum of 64 hexadecimal digits Default: None</p>

* Not used for all security types

Supporting Parameters for Different Security Types

The supporting parameters required for this command vary based on the security type that you select. You should not use all of the supporting parameters each time that you use this command, nor will you use extra commas to separate unused fields. Follow the example and format for your specific security type in this section, substituting your own wireless network data.

Security Type 01: No Wireless Security Active

Format: ^WX01



Example: This example turns off all wireless securities controlled under this command, but it does not reset the printer's wireless settings to their defaults.

```
^XA
^WX01
^JUS^XZ
```

Security Type 02: WEP 40-Bit

Format: ^WX02,b,c,d,e,f,g,h

→ **Example:** This example configures the printer for WEP 40-bit encryption using index key 1, open authentication, and a hexadecimal WEP key with a value of "A1B2C3D4F5."

```
^XA
^WX02,1,0,H,A1B2C3D4F5,,
^JUS
^XZ
```

Security Type 03: WEP 128-Bit

Format: ^WX03,b,c,d,e,f,g,h

→ **Example:** This example configures the printer for WEP 128-bit encryption using index key 2, open authentication, and four hexadecimal WEP keys.

```
^XA
^WX03,2,0,H,001122334455667788,112233445566778899,2233445566778899
900,334455667788990011
^JUS
^XZ
```

Security Type 04: EAP-TLS

Format: ^WX04,k

→ **Example:** This example configures the printer for EAP-TLS authentication with an optional private key password with a value of "private."

```
^XA
^WX04,private
^JUS
^XZ
```

Security Type 05: EAP-TTLS

Format: ^WX05,i,j

→ **Example:** This example configures the printer for EAP-TTLS authentication, including a user ID of “**user**” and a password of “**password**.”

```
^XA
^WX05,user,password
^JUS
^XZ
```

Security Type 06: EAP-FAST

Format: ^WX06,i,j,k

→ **Example:** This example configures the printer for EAP-FAST authentication, including a user ID of “**user**,” a password of “**password**,” and an optional private key of “**private**.”

```
^XA
^WX06,user,password,private
^JUS
^XZ
```

Security Type 07: PEAP

Format: ^WX07,i,j

→ **Example:** This example configures the printer for PEAP authentication, including a user ID with a value of “**user**” and a password with a value of “**password**.”

```
^XA
^WX07,user,password
^JUS
^XZ
```

Security Type 08: LEAP

Format: ^WX08,i,j

→ **Example:** This example configures the printer for LEAP authentication, including a user ID with a value of “**user**” and a password with a value of “**password**.”

```
^XA
^WX08,user,password
^JUS
^XZ
```

Security Type 09: WPA PSK



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments (R6x15.x, R53.15.x, ZSPx, and later.)

Format: ^WX09,n



Example: This example configures the printer for WPA PSK authentication with a PSK value of all zeroes (64 hexadecimal digits).

```
^XA
^WX09,00000000...
^JUS
^XZ
```

Security Type 10: WPA EAP-TLS



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Format: ^WX10,k



Example: This example configures the printer for WPA EAP-TLS authentication with an optional private key password with a value of “private.”

```
^XA
^WX10,private
^JUS
^XZ
```

Security Type 11: WPA EAP-TTLS



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Format: ^WX11,i,j



Example: This example configures the printer for WPA EAP-TTLS authentication, including a user ID with a value of “user” and a password with a value of “password.”

```
^XA
^WX11,user,password
^JUS
^XZ
```

Security Type 12: WPA EAP-FAST



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Format: ^WX12,i,j,k



Example: This example configures the printer for WPA EAP-FAST authentication, including a user ID of “**user**,” a password of “**password**,” and an optional private key of “**private**.”

```
^XA
^WX12,user,password,private
^JUS
^XZ
```

Security Type 13: WPA PEAP



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Format: ^WX13,i,j



Example: This example configures the printer for WPA PEAP authentication, including a user ID with a value of “**user**” and a password with a value of “**password**.”

```
^XA
^WX13,user,password
^JUS
^XZ
```

Security Type 14: WPA LEAP



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Format: ^WX14,i,j



Example: This example configures the printer for WPA LEAP authentication, including a user ID with a value of “**user**” and a password with a value of “**password**.”

```
^XA
^WX14,user,password
^JUS
^XZ
```

Security Type 15: Kerberos

Format: ^WX15,i,j,l,m



Example: This example configures the printer for Kerberos encryption, including a Kerberos user ID with a value of “**user**,” a Kerberos password with a value of “**password**,” a realm of “**zebra**,” and a KDC of “**krbtgt**.”

```
^XA  
^WX15,user,password,zebra,krbtgt  
^JUS  
^XZ
```

ZBI Commands

This section explains the Zebra Basic Interpreter, its commands, descriptions, formats, and parameters.

Contents

Introduction to Zebra Basic Interpreter (ZBI)	428
Command and Function Reference Format	429
Section Organization	430
Editing Commands.....	431
Running and Debugging Commands	439
Base Types and Expressions	450
Control and Flow	459
Input and Output.....	467
File System.....	488
Comma Separated Values (CSV)	493
Events	498
Systems.....	509
String Functions.....	520
Math Functions.....	536
Array Functions	544
Time and Date Functions.....	552
Set/Get/Do Interactions	557
Example Programs.....	559

Introduction to Zebra Basic Interpreter (ZBI)

What is ZBI and why is it for me?

ZBI is an "on-the-printer" programming language that offers many of the functions found in ANSI BASIC. The ZBI language allows the user to create applications that are run on the printer to manipulate data streams. By using ZBI, it is possible to have the printer perform the same functions that a computer or programmable terminal might otherwise be used for.

With the connectivity options available on Zebra printers, you may not need a separate computer. Simply load a ZBI program on your printers, add them to your network, and let the printers serve as the gateway for moving data.

Here are some of the applications that can be written using ZBI:

- Connect a barcode scanner to the printer. Based on scanned data, reprint tags, verify printed output, and manage a list of items.
- Connect a scale to the printer and print labels, tags, or receipts based on the weight of an item.
- Connect the printer to a PC-based database and send queries from the printer to retrieve or upload data.
- Convert incoming data into the commands that can be used to print a label. This is useful for replacing other brands of printers with new Zebra units.
- Provide fail-over to another printer when the target printer is in an error state.

Printers, ZBI Keys, & ZBI Versions

Information about ZBI 1.x and ZBI 2.x:

ZBI versions 1.0 through 1.5: ZBI 1.x was available on printers with X.10 or higher firmware (such as V48.10.x). To determine if the printer supports ZBI version 1, check the firmware version loaded on the printer. This can be determined by the absence of a "Z" in the firmware version number (for example, firmware V60.13.0.12 supports ZBI version 1, while V60.13.0.12Z does not). The following printers support the ZBI 1.x firmware:

- *LP/TLP 284x-Z and 384x-Z*
- *S300/S400/S500/S600*
- *Z4000/Z6000*
- *Z4M/Z6M*
- *Z4Mplus/Z6Mplus*
- *105SL*
- *PAX3*
- *X1I*
- *X1II*

ZBI-Developer can be used to create programs for use on printers that support ZBI version 1.x., however, the features that are only available in ZBI v2.x cannot be used with printers running ZBI v1.x. For example, “on-printer” debugging advanced file encryption and commands added in ZBI 2 are not supported in printers running ZBI 1.x. If you do not have a printer that meets this requirement, contact your reseller.



Note • Support for ZBI versions 1.0 through 1.5 is limited to syntax checking only. On-printer debugging is not supported for ZBI versions 1.0 through 1.5.



ZBI versions 2.0 and higher: Printers with firmware versions X.16 or later (for example, V60.16.x and V53.16.x) can support ZBI version 2.0 and later. The following printers support the ZBI 2.x firmware:

- *XIII Plus*
- Z4Mplus/Z6Mplus
- 105SL
- S4M
- PAX4
- ZM400/ZM600, RZ400/RZ600
- G-Series
- HC100
- Xi4, RXi4
- LP/TLP2824+
- KR403

These printers can be either ZBI-Ready or ZBI-Enabled, depending on whether or not a ZBI Key file has been loaded on the printer. ZBI Keys can be loaded onto printers during manufacturing or later purchased at www.zebrasoftware.com. A Downloader Utility/ZBI Key Manager software utility is available to assist in the task of sending ZBI Keys to printers.

The ZBI.nrd file is required to be present on the printer for ZBI 2.0 to be enabled. The ZBI Key is stored on the printer's E: memory location with the name ZBI.nrd. The file is persistent. It cannot be deleted even if the printer's memory is initialized. For example, if the `^JB` command is used to initialize the location, the ZBI Key file will not be deleted.

When a printer is ZBI-Ready but not ZBI-Enabled, the firmware version will display a "Z" at the end of the version string (for example, V60.16.0Z). Additionally, the printer's configuration label will show that the printer is not ZBI-Enabled.

When a printer is ZBI-Enabled, the firmware version will not display a "Z" at the end of the version string (for example, V60.16.0Z). Additionally, the printer's configuration label will show that the printer is ZBI-Enabled.



Note • Each single ZBI Key can only be used once. When multiple printers are to be ZBI-Enabled multiple Keys will be needed. The ZBI Key cannot be retrieved from printer to a host system.

Command and Function Reference Format

This section describes how commands and functions are presented in this document.

Command/Function NAME

Describes how the command is used, its capabilities, and its characteristics.

Format The Format section explains how the command is arranged and its parameters. For example, the **AUTONUM** command starts the auto-numbering option. The format for the command is **AUTONUM <A>,**. The **<A>** and **** are parameters of this command and are replaced with values determined by the user.

For functions, parameters are enclosed within parentheses and separated by commas, such as **EXTRACT\$(A\$, START\$, STOP\$)**.

Numeric parameters are written as a name, while string parameters are written as a name followed by a dollar sign.

Parameters If a command has parameters that make a command or function more specific, they are listed under this heading. Still using the **AUTONUM** example, the **<A>** parameter is defined as:

<A> = number used to start the auto-numbering sequence

Return Value (functions only)

The return value is the result of evaluating the function or expression.

Example When a command is best clarified in a programming context, an example of the ZBI code is provided. Text indicating parameters, exact code to be entered, or data returned from the host is printed in the **Courier** font to be easily recognizable.



Example: An example of **PRINT** code is:

```
10 PRINT "HELLO WORLD"  
RUN  
HELLO WORLD
```

Comments This section is reserved for notes that are of value to a programmer, warnings of potential command interactions, or command-specific information that should be taken into consideration. An example comment could be: This is a program command and must be preceded by a line number.

Function Rules

Functions built into this interpreter can be used in expressions only. The function names are not case sensitive.

If input parameters exist, they are enclosed in parentheses. If no parameters exist, no parentheses are used.

Variables referenced in the functions could be substituted by functions or expressions of the same type. If the function name ends with a \$, it returns a string value. Otherwise, it returns a numeric value.

Section Organization

The sections in this guide are arranged based on programming topics. A brief description of the sections is listed below.

Editing Commands This section describes the commands which are used to manipulate the interpreter and enter programs.

Running and Debugging Outlines the control commands used to run and debug programs.

Base Types and Expressions Fundamental structure for manipulating strings and computing numeric and boolean values.

Control and Flow Commands to conditionally execute code and control the flow of the program

Input and Output Outlines how to communicate with the physical ports, internal ports, and network.

File System Shows how programs and formats can be saved and recalled

Comma Separated Values Identifies how to load and store comma separated data

Events Explains how to capture and trigger internal events in the printer

Systems Contains miscellaneous systems interface functions

String Functions Handles string manipulation

Math Functions Handles mathematical calculations

Array Functions Describes how to search, resize, and query arrays

Time and Date Functions Functions to access the real time clock option

Set/Get/Do Interface Functions to directly interface with the Set/Get/Do system

Example Programs More examples to give a head start in creating your applications

Writing ZBI Programs

There are two main ways to develop ZBI programs. The preferred method is to use the ZBI-Developer application. ZBI-Developer allows you to create and test programs before a printer is even turned on. In addition, many features of this program allow for quicker program creation and more meaningful debugging. ZBI-Developer can be downloaded from the Zebra web site.

An alternate method for developing a program is through a direct connection to the printer using a terminal emulation program.

Editing Commands

This section details the Editing Commands. This section describes the commands which are used to manipulate the interpreter and enter programs. These commands are used while controlling the ZBI environment from a console connection. Here is a quick list of these commands:

NEW – Clears out the program and variables currently in memory

REM and ! – Comment commands

LIST – Lists the program currently in memory

AUTONUM – Automatically generates the next line number

RENUM – Renumbers the program currently in memory

ECHO – Controls whether characters received on the console are echoed back

If you are using ZBI-Developer, the commands that will be most useful are AUTONUM and REM/!.

The following example shows the use of Editing commands from within a console connection.

→ **Preview:**

```
NEW
AUTONUM 10,5
10 REM "Hello World" Application
15 PRINT "Hello World" ! comment...
20
```

Entered automatically when AUTONUM is used

A blank line stops AUTONUM

```
LIST
10 REM "Hello World" Application
15 PRINT "Hello World"
```

```
NEW
LIST
```

→ **Preview when viewed in ZBI-Developer**

```
AUTONUM 10,5
REM "Hello World" Application
PRINT "Hello World" ! comment...
```


NEW

This command clears the interpreter's memory, including the line buffer and variables, but not any open ports. Use this command when creating code to restart the coding process or before resending a program from a file to the interpreter.

Format NEW

Parameters N/A



Example: This is an example of how to use the NEW command:

```
10 PRINT "Hello World"
```

```
RUN
```

```
Hello World
```

```
LIST
```

```
10 PRINT "HeLlO WorLd"
```

```
NEW
```

```
LIST
```

Comments This is an interactive command that takes effect as soon as it is received by the printer.

REM

A numbered **remark** line starts with **REM** and includes text in any form after it. This line is ignored by the interpreter.

Format REM <comment>

Parameters The comment string can contain any character and is terminated by a carriage return.



Example 1: This is an example of how to use the REM command:

```
10 REM COMMAND LINES 20-100 PRINT A LABEL
```

Comments Remarks are used for program description and are included as a separate program line. To append a comment to the end of a program line, use the exclamation mark (!).

A useful method to keep comments in a stored file (but not in the printer) is to always start the REM line with the number 1. When all of the lines are sent to the printer, only the last REM line will stay resident in the printer. This will require less RAM for large programs.



Example 2: This is an example of how to re-use the REM command:

```
1 REM MYPROGRAM COPYRIGHT ME Inc. 2008
1 REM While debugging a port may be left open
5 CLOSE ALL
1 REM Open the ports this program will use
10 OPEN #0: NAME: "SER" ! Restart the console
```

! (EXCLAMATION MARK)

The exclamation mark is the marker for adding comments to the end of numbered programming lines. Any text following the ! is ignored when the line or command is processed.

Format !<comment>

Parameters The comment string can contain any character and is terminated by the carriage return.



Example: This is an example of how to use the ! (comments) command:

```
10 LET A=10 ! Indicates number of labels to print
```

Comments None

LIST

This command lists the program lines currently in memory.

Format

```
LIST
LIST <A>
LIST <A>-<B>
```

Parameters

default = lists all lines in memory
<A> = line to start listing the program
 = line to stop listing the program. If not specified, only the line at <A> will print.



Example: This is an example of how to use the LIST command:

```
1 REM MYPROGRAM COPYRIGHT ME Inc. 2008
1 REM While debugging a port may be left open
5 CLOSE ALL
1 rem Open the ports this program will use
10 OPEN #0: NAME: "SER" ! Restart the console
20 PRINT #0: "Hello World"
LIST
1 REM Open the ports this program will use
5 CLOSE ALL
10 OPEN #0: NAME: "SER" ! Restart the console
20 PRINT #0: "Hello World"

LIST 1
1 REM Open the ports this program will use

LIST 5-10
5 CLOSE ALL
10 OPEN #0: NAME: "SER" ! Restart the console
```

Comments The output of the LIST command may not match exactly what was entered. It is based on how the program lines are stored in memory. Notice that the last comment line the REM is entered in lower case characters. When it is listed, the REM is displayed in uppercase.

This is an interactive command that takes effect as soon as it is received by the printer.

AUTONUM

This command automatically generates sequential program line numbers.

Format AUTONUM <A>,

Parameters

A = the number used to start the auto-numbering sequence
B = the automatic increment between the new line numbers



Example: This example shows specifying the starting line number in the increment between new line number. Type the following at the prompt:

```
AUTONUM 10,5  
SUB START  
PRINT "HELLO WORLD"  
GOTO START
```

```
LIST
```

Will produce:

```
AUTONUM 10,5  
10 SUB START  
15 PRINT "HELLO WORLD"  
20 GOTO START
```

The three lines are automatically started with the **AUTONUM** parameters; in this case, the first line starts with 10 and each subsequent line increments by 5.

Comments This feature is disabled by overwriting the current line number and entering the desired interactive mode commands, or leaving the line blank.

Use of the **SUB** command allows for **GOTO** and **GOSUB** statements that do not require line numbers in your program.

This is an interactive command that takes effect as soon as it is received by the printer.

RENUM

This command renumbers the lines of the program being edited. **RENUM** can reorganize code when line numbers become over- or under-spaced. The line references following **GOTO** and **GOSUB** statements are renumbered if they are constant numeric values. Renumbering does not occur if the line numbers are outside of the range limits of 1 to 10000.

Format `RENUM <A>,`

Parameters

<A> = the number to start the renumbering sequence

 = the automatic increment between the new line numbers



Example: This is an example of how to use the `RENUM` command:

```
LIST
13 LET A=6
15 LET B=10
17 GOTO 13
RENUM 10,5
LIST
10 LET A=6
15 LET B=10
20 GOTO 10
```



Note • The target of the `GOTO` command changes from 13 to 10 to reflect the renumbering.

Comments This is an interactive command that takes effect as soon as it is received by the printer.

ECHO

When Console Mode is enabled, this command controls whether the printer echoes the characters back to the communications port. If **ECHO ON** is entered, keystroke results return to the screen. If **ECHO OFF** is entered, keystroke results do not return to the screen.

Format

ECHO ON
ECHO OFF

Parameters

<ON/OFF> = toggles the ECHO command on or off

Example N/A

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

Running and Debugging Commands

The following commands were written before the development of the ZBI-Developer application. With that application, and when using ZBI version 1, the following commands are essentially obsolete. However, for those who started developing ZBI applications before ZBI-Developer, the following reference will be helpful.

RUN – Starts executing the program currently in memory at the first line of the program

CTRL-C Sends an end-of-transmission character, **ETX**, to the console to terminate the ZBI program currently running.

RESTART – Starts executing the program currently in memory where it was last stopped

STEP – Executes one line of the program in memory where it was last stopped

DEBUG – This mode controls whether or not the **TRACE** and **BREAK** commands are processed

TRACE – Shows which lines have been executed and which variables have been changed

BREAK – Stops the currently running program

ADDBREAK – Adds a break to an existing line

DELBREAK – Deletes an existing break

ZPL Terminates and exits the ZBI environment.

This example shows many of the Running and Debug Commands in practice.



Example: Preview:

ZBI Program

```
10 PRINT "TEN"  
20 PRINT "TWENTY"  
30 PRINT "THIRTY"
```

```
RUN  
TEN  
TWENTY  
THIRTY
```

Runs the whole program

```
STEP  
TEN
```

Runs one line

```
RESTART  
TWENTY  
THIRTY
```

Completes running the program where STEP left off

```
ADDBREAK 20  
RUN  
TEN  
<Program Break> on line: 20
```

Adds a breakpoint on line 20

Turn Trace On

```
DEBUG ON  
TRACE ON  
RESTART  
<TRACE> 20  
TWENTY  
<TRACE> 30  
THIRTY
```


RUN

This command executes the current program, starting with the lowest line number. The interpreter will continue to execute the program lines in order unless a control statement directs the flow to a different point. When a higher line number does not exist or the END command is processed, the RUN command will stop.

Format RUN

Parameters N/A



Example: This is an example of how to use the RUN command:

```
10 PRINT "ZBI"  
20 PRINT "Programming"  
RUN  
ZBI  
Programming  
  
15 END  
RUN  
ZBI
```

Comments Ports that are open when the application is activated will remain open after the application has terminated. Variables also remain after the application has terminated.

To execute programs when the printer is powered on, use the ^JI command in the Autoexec.zpl file.

This is an interactive command that takes effect as soon as it is received by the printer.

CTRL-C

Sending an end-of-transmission character, **ETX** (3 in hex), to the console (port 0) terminates the ZBI program currently running.

Format N/A

Parameters N/A

Example N/A

Comments In most terminal programs, you terminate the program using the **Ctrl-C** key sequence. Another method is to store an ETX character in a file and have the terminal program send the file to the console port.



Note • It is not recommended to use **RESTART** after using a **CTRL-C** because a command may have been prematurely interrupted. Restarting will have an undefined result.

RESTART

If a program was halted by a break point or the **BREAK** command, the **RESTART** command can be used to reactivate the program at the point it stopped. **RESTART** functions similar to **RUN**, except the program attempts to restart from the point where it was last terminated. It also works in conjunction with the **STEP** command, picking up where the **STEP** command ended.

Format RESTART

Parameters N/A



Example: An example of the **RESTART** command:

```
10 PRINT "TEN"  
20 PRINT "TWENTY"  
30 PRINT "THIRTY"  
RUN  
TEN  
TWENTY  
THIRTY
```

```
STEP  
TEN
```

```
RESTART  
TWENTY  
THIRTY
```

```
ADDBREAK 20  
RUN  
TEN  
<Program Break> on Line: 20
```

```
DEBUG ON  
TRACE ON  
RESTART  
<TRACE> 20  
TWENTY  
<TRACE> 30  
THIRTY
```

Comments If the program has not been run or has finished, **RESTART** runs the program from the beginning.

This is an interactive command that takes effect as soon as it is received by the printer.

STEP

If a program was stopped by a **BREAK** command, **STEP** attempts to execute the program one line from where it last ended. If the program has not been run or has been completed, this executes the lowest numbered line.

Format STEP

Parameters N/A



Example: This is an example of how to use the **STEP** command:

```
10 PRINT "Hello World"
```

```
20 Print "TWENTY"
```

```
STEP
```

```
Hello World
```

```
STEP
```

```
TWENTY
```

Comments This is an interactive command that takes effect as soon as it is received by the printer.

DEBUG

DEBUG enables and disables the **TRACE** and **BREAK** commands.

Format

```
DEBUG ON  
DEBUG OFF
```

Parameters

ON = turns the debug mode on enabling the **TRACE** and **BREAK** commands to be processed.

OFF = turns the debug mode off. This disables the **TRACE** mode and causes **BREAK** commands to be ignored.



Example: See *TRACE on page 446* and *BREAK on page 447*.

Comments This command has no effect on the processing of break points in ZBI-Developer. It is recommended that you avoid using the **DEBUG** command when writing programs in the ZBI-Developer environment, instead use the Debug capabilities of ZBI-Developer.

TRACE

This command enables you to debug an application by outputting the executed line numbers and changed variables to the console.

Format

```
TRACE ON  
TRACE OFF
```

Parameters

<ON/OFF> = controls whether **TRACE** is active (ON) or disabled (OFF).

If **DEBUG** is activated and the **TRACE** command is on, trace details are displayed. When any variables are changed, the new value displays as follows:

```
<TRACE> Variable = New Value
```

Every line processed has its line number printed as follows:

```
<TRACE> Line Number
```



Example: An example of TRACE command in use:

```
10 LET A=5  
20 GOTO 40  
30 PRINT "Error"  
40 PRINT A  
DEBUG ON  
TRACE ON  
RUN  
<TRACE> 10  
<TRACE> A=5  
<TRACE> 20  
<TRACE> 40  
5
```

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

It is recommended that you avoid using the **TRACE** command when writing programs in the ZBI-Developer environment, instead use the Debug capabilities of ZBI-Developer.

BREAK

This command allows you to stop the program when the program reaches this line.

Format BREAK

Parameters N/A



Example: An example of BREAK command in use:

```
10 LET A=5
20 BREAK
30 PRINT A
DEBUG ON
TRACE ON
RUN
<TRACE> 10
<TRACE> A=5
<TRACE> 20
<USER BREAK>
```

Comments This command is available only when the **DEBUG** function has been activated. When **DEBUG** is on, **BREAK** halts processing. **RUN** starts the program from the beginning. **RESTART** allows the program to continue from where it left off.

When using ZBI-Developer, this command will interfere with the debugging operations built into the application.

This is a program command that must be preceded by a line number.

ADDBREAK



Description This command allows you to stop the program when the program reaches a specified line.

Format `ADDBREAK <A>`

Parameters

A = the line number to break on. If the number specified is not in the program, the program will not break.



Example: An example of the ADDBREAK command.

```
10 LET A=5
20 PRINT A
ADDBREAK 20
RUN
<PROGRAM BREAK> ON LINE:20

RESTART
5
```

Comments This command is available only when the `DEBUG` function has been activated. When `DEBUG` is on, `BREAK` halts processing. `RUN` starts the program from the beginning. `RESTART` allows the program to continue from where it left off.

This is the command used internally by ZBI-Developer when the user right-clicks over a program line and adds a Breakpoint via the "Toggle Breakpoint" selection.

It is the recommended method for setting breakpoints in ZBI.

A maximum of 16 breakpoints can be set in an application.

This is an interactive command that takes effect as soon as it is received by the printer.

DELBREAK



This command allows you to remove existing breakpoints.

Format DELBREAK <A>

Parameters A = the line number from which to remove the break. If 0 is specified, all break points will be removed. If the number specified is not a breakpoint, the command will have no effect.



Example: An example of the DELBREAK command:

```
10 LET A=5
20 PRINT A
ADDBREAK 20
DEBUG ON
TRACE ON
RUN
<TRACE> 10
<TRACE> A=5
<PROGRAM BREAK> ON LINE:20

RESTART
<TRACE> 20
5

DELBREAK 20
RUN
<TRACE> 10
<TRACE> A=5
<TRACE> 20
5
```

Comments This command is available only when the DEBUG function has been activated. When DEBUG is on, BREAK halts processing, RUN starts the program from the beginning, and RESTART allows the program to continue where it left off.

This is the command used internally by ZBI-Developer when the user right-clicks over a program line and removes a Breakpoint via the "Toggle Breakpoint" selection.

A maximum of 16 breakpoints can be set in an application.

This is an interactive command that takes effect as soon as it is received by the printer.

ZPL

This command terminates and exits the ZBI environment.

Format ZPL

Parameters N/A



Example: An example of the ZPL command.

```
ZPL  
ZBI TERMINATED
```

Comments This is an interactive command that takes effect as soon as it is received by the printer.

Base Types and Expressions

There are two base types in the ZBI language. These types are Integers and Strings. Integers are whole numbers that contain no fractional part. The range of values for integers is:

-2,147,483,648 to +2,147,483,647

Strings are character arrays. The string length is only limited by the amount of memory in the system (version 2.0 and higher). Each character can have a value between 0 and 255 (version 2.0 and higher).

The use of control characters (0-31) may be difficult to debug based on the handling of control characters in different communications programs. In addition the ETX (3) will terminate a ZBI application when it is received on the console port. Use the CHR\$ function when control characters must be placed into strings.



Note • In ZBI version 1.4 and lower, there was a string length limit of 255 characters.

This section is organized as follows:

- Variable Names
- Variable Declarations
- Constants
- Arrays
- Assignment
- Numeric Expressions
- String Concatenation (&)
- Sub-strings
- Boolean Expressions
- Combined Boolean Expressions

Variable Names

To distinguish strings from integers, string variable names must end in a \$. Variable names must start with a letter and can include any sequence of letters, digits, and underscores. Function and command names must not be used as a variable name. Variable names are not case sensitive and are converted to uppercase by the interpreter.

A common mistake is to use a command or function name as a variable. To avoid using these reserved words, ZBI-Developer can be a useful resource. Reserved words are highlighted making it easier to spot this occurrence and thus, saving debugging time.

Valid variable names:

I, J, K, VARNAME, VARSTR\$, MYSTR\$,MY_STR9\$

Invalid Names:

STR\$ = Reserved word

ORD = Reserved word

VAL = Reserved word

W# = Invalid character (#)

9THSTR = Variable can not start with a number

Variable Declarations

ZBI will allow storage of up to 255 variables. If more variables are needed, consider using arrays to store data. The base array will take up one of the 255 variable slots, but it can be declared to allow for many indices.

Variables can be declared explicitly or implicitly. If a variable has not been used before, it will be declared when used. The default value for an integer will be zero and the default value of a string will be an empty string.

Explicit:

```
DECLARE NUMERIC <variable_name>  
DECLARE STRING <variable_name$>
```

If the variable existed before the DECLARE statement, it will be defaulted.

Implicit:

```
LET <variable_name> = NUMERIC EXPRESSION  
LET <variable_name$> = STRING EXPRESSION
```

The Interpreter is limited to 255 variables. If more variables are required, consider using arrays.

Constants

Integers are represented simply by numbers, such as 5, -10, 10000. Do not use commas in integer constants. Strings are enclosed by quotes. If a quote is required in the string, use double quotes, such as "Look here->"<- would result in the string – Look here->"<-.

Arrays

An array is a collection of string or integer values used by a program. Array indices are accessed through parentheses. Array indices start at 1 and end at the length of an array (for example, MyArray(3) returns the value in the third location of the variable array). One- and two-dimensional arrays are allowed. Two-dimensional arrays are referenced with two indices in parentheses, separated by a comma.

Arrays must be allocated through the use of the **DECLARE** command. Arrays can be re-dimensioned by using **DECLARE**, however, this will replace the original array.

Array size is limited only by the size of the memory available.

Format

```
DECLARE STRING <ARRAYNAME$>(<SIZE>)
```

```
DECLARE STRING <ARRAYNAME$>(<ROWS>,<COLUMNS>)
```

```
DECLARE NUMERIC <ARRAYNAME>(<SIZE>)
```

```
DECLARE NUMERIC <ARRAYNAME>(<ROWS>,<COLUMNS>)
```

Parameters

<SIZE> = number of entries in a single dimension array

<ROWS> = number of rows in a two dimensional array

<COLUMNS> = number of columns in a two dimensional array



Example: An example of **ARRAY** code is:

```
10 DECLARE STRING INARRAY$(3)
20 FOR I = 1 TO 3
30 PRINT "Name "; I; ": ";
40 INPUT INARRAY$(I)
50 NEXT I
60 PRINT INARRAY$(1); ", "; INARRAY$(2); ", and "; INARRAY$(3);
70 PRINT " went to the park"
RUN
Name 1: Jim
Name 2: Jose
Name 3: Jack
Jim, Jose, and Jack went to the park
```

Comments If you attempt to access an array outside of its allocated bounds, an error will occur.

Assignment

All lines must start with a command. In order to assign a value to a variable, use the LET command. Multiple variables can be placed before the =. The variable types must match the expression type.

The right side of the assignment is always calculated completely before the assignment is made. This allows a variable to be the target and source of the assignment.

When a value is assigned to a string variable with a sub-string qualifier, it replaces the value of the sub-string qualifier. The length of the value of the string variable may change as a result of this replacement.



Example: An **ASSIGNMENT** example:

```
10 LET A=5  
20 LET B$="HELLO"  
30 LET B$(5:5)=B$
```

LET

The LET command is used to assign value to a specific variable. The expression is evaluated and assigned to each variable in the variable list. See *Assignment on page 452*.

Format

LET <variable> [,<variable>]* = <expression>

The variable types must match the expression type or an error message will be displayed.

Error: Poorly formed expression.

When a value is assigned to a string variable with a sub-string qualifier, it replaces the value of the sub-string qualifier. The length of the value of the string variable may change as a result of this replacement.

Parameters N/A



Example: This is an example of how to use the LET command:

```
10 LET A$= "1234"
15 LET A$(2:3)= "55" ! A$ NOW = 1554
20 LET A$(2:3)= "" ! A$ NOW = 14

10 LET A$= "1234"
15 LET A$(2:3)= A$(1:2) ! A$ NOW = 1124

10 LET A$= "1234"
15 LET A$(2:1)= "5" ! A$ NOW = 15234
```

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

Numeric Expressions

A base numerical expression can be either a constant, variable, or another numerical expression enclosed in parentheses. The five types used (addition, subtraction, multiplication, division, and exponentiation) are listed below. When evaluating an expression exceeding the maximum or minimum values at any point creates an undefined result. (maximum value: 2,147,487,647; minimum value: -2,147,483,648)

Floating point is not supported.

When using division, the number is always rounded down. For example, 5/2=2. Use **MOD** to determine the remainder.

Format

1. + (addition) Addition expressions use this format:

```
<A>+<B>
5+2 result = 7
VAL ("25")+2 result =27
```

2. – (subtraction) Subtraction expressions use this format:
 $\langle A \rangle - \langle B \rangle$
5-2 result = 3
VAL ("25") -2 result =23
3. * (multiplication) Multiplication expressions use this format:
 $\langle A \rangle * \langle B \rangle$
5*2 result = 10
VAL ("25") *2 result =50
4. / (division) Division expressions use this format:
 $\langle A \rangle / \langle B \rangle$
5/2 result = 2
VAL ("25") /2 result =12
5. ^ (exponentiation) Exponentiation expressions use this format:
 $\langle A \rangle ^ \langle B \rangle$
5^2 result = 25
VAL ("25") ^2 result =625

Order of Precedence

In mathematics, the order of precedence describes the sequence that items in an expression are processed. All expressions have a predefined order of precedence.

The order of precedence is listed below:

Functions
Parenthetical Expressions ()
^
* and /
+ and -

The * and / have the same precedence, and the + and - have the same precedence. Items with the same order of precedence are processed from left to right.

For example, this expression $5+(8+2)/5$ is processed as $8+2=10$, followed by $10/5=2$, then $5+2$ to give a result of 7.

Functions and parenthetical expressions always have the highest order of precedence, meaning that they are processed first.

String Concatenation (&)

The basic string expression may be either a constant or a variable, and concatenation (&) is supported. Using the concatenation operator (&) adds the second string to the first string.

`<A$> & <B$>`



Example: This is an example of how to use the STRING CONCATENATION (&) command:

```
10 LET A$= "ZBI- "
20 LET B$= "Programming"
30 LET C$= A$ & B$
40 PRINT C$
RUN
ZBI-Programming
```

Sub-strings

Using a sub-string operator on a string allows a specific portion of the string to be accessed. This portion may be the target of an assignment operation or a reference to a portion of the string. To determine the coordinates of the string portion to be used, count the characters from the beginning to the end of the string, including spaces.

Format

```
LET <STRVAR$>( <A> : <B> ) = <C$>
LET <C$> = <STRVAR$>( <A> : <B> )
```

Parameters

<A> = the position of the first character in the desired string

**** = the position of the last character in the desired string.

<STRVAR\$> = base string variable

If the **A** parameter is less than 1, it is automatically assigned a value of 1. Because the string is calculated starting with 1, the **A** parameter cannot be less than 1.

If **B** is greater than the length of the string, it is replaced with the length of the string.

If **A** is greater than **B**, a NULL string (" "), which points to the location of the smaller of **A** or the end of the string, is returned. This is used when adding a string in the middle of another string without removing a character.



Example 1: This is an example of a sub-string reference:

```
LET A$="Zebra Quality Printers"
LET B$=A$(1:13)
PRINT B$
Zebra Quality
```

This is an example of a sub-string assignment.

```
LET A$= "1234"
LET A$(2:3)= "55" ! A$ NOW = 1554
LET A$(2:3)= "" ! A$ NOW = 14

LET A$= "1234"
LET A$(2:3)= A$(1:2) ! A$ NOW = 1124

LET A$= "1234"
LET A$(2:1)= "5" ! A$ NOW = 15234
```

The best way to think of assignment to a sub-string is as follows: an assignment is like selecting a word, and pasting over the selection with the new string.

Boolean Expressions

A Boolean expression holds 0 (zero) as false and non-zero as true.

Formats

```
<STRING EXPRESSION> <BOOLEAN COMPARE> <STRING EXPRESSION>
<NUMERIC EXPRESSION> <BOOLEAN COMPARE> <NUMERIC EXPRESSION>
NOT(<BOOLEAN EXPRESSION>)
```

Parameters

```
<STRING EXPRESSION> = a string variable, string constant or any combination with
concatenation
<NUMERIC EXPRESSION> = any mathematical operation
```

Comments A numeric expression cannot be compared to a string expression.

Numeric expressions can substitute a Boolean expression where a value of 0 (zero) represents false and a non-zero value represents true.

Base Boolean expressions:

1. < (less than)

Expression	Result
1<2	true
2<2	false
2<1	false

2. <= (less than or equal to)

Expression	Result
1<=2	true
2<=2	true
2<=1	false

3. > (greater than)

Expression	Result
1 > 2	false
2>2	false
2>1	true

4. >= (greater than or equal to)

Expression	Result
1>=2	false
2>=2	true
2>=1	true

5. = (equal to)

Expression	Result
1=2	false
2=2	true
"A"="AA"	false
"A"="A"	true

6. <> (not equal to)

Expression	Result
1<>2	true
2<>2	false
"A"<>"AA"	true
"A"<>"A"	false

Combined Boolean Expressions

AND, **OR**, and **NOT** can be used in conjunction with base Boolean expressions to recreate expanded Boolean expressions.

1. **NOT** — Negate the target expression.

Expression	Result
NOT 1=2	true
NOT 1=1	false

2. **AND** — Both expressions must be true for a true result.

Expression	Result
1=2 AND 1=2	false
2=2 AND 1=2	false
1=2 AND 2=2	false
2=2 AND 2=2	true

3. **OR** — If either expression is true, the result will be true.

Expression	Result
1=2 OR 1=2	false
1=2 OR 2=2	true
2=2 OR 1=2	true
2=2 OR 2=2	true

Order of Precedence

The order of precedence is listed below:

Expressions and Functions
Parenthetical expressions ()
<, <=, <>, =, =>, >
NOT, AND, OR

Control and Flow

This section outlines the commands to conditionally execute code and control the flow of the program. Here is a quick list of these commands:

IF Statements Executes or skips a sequence of statements, depending on the value of a Boolean expression.

DO Loops Repeats instructions based on the results of a comparison.

FOR Loops A control flow statement which allows code to be executed iteratively.

GOTO/GOSUB Causes an unconditional jump or transfer of control from one point in a program to another.

SUB Allows you to “substitute” names instead of actual line numbers as the target of **GOSUBs** and **GOTOs**.

EXIT Used to exit the **DO** and **FOR** loops.

END Terminates any program currently running.

IF Statements

If the value of the **<Boolean expression>** in an **IF** statement is true and a program line follows the keyword **THEN**, this program line is executed. If the value of the Boolean expression is false and a program line follows the keyword **ELSE**, this program line is executed. If **ELSE** is not present, then execution continues in sequence, with the line following the **END IF** statement.

Nesting of blocks is permitted, subject to the same nesting constraints as **DO-LOOPS** (no overlapping blocks).

ELSE IF statements are treated as an **ELSE** line followed by an **IF** line, with the exception that the **ELSE IF** shares the **END IF** line of the original **IF** statement.

Format

```
IF <Boolean expression> THEN
  ~~BODY~~
[ELSE IF <Boolean expression> THEN
  ~~BODY~~]*
[ELSE
  ~~BODY~~]
END IF
```

Parameters N/A



Example: This is an example of how to use the **IF** statement command:

```
10 IF A$="0" THEN
20 PRINT "ZBI IS FUN"
30 ELSE IF A$="1" THEN
40 PRINT "ZBI IS EASY"
50 ELSE IF TIME=1 THEN
60 PRINT "It is one second past midnight"
70 ELSE
80 PRINT "X=0"
90 END IF
```

DO Loops

Processing of the loop is controlled by a **<WHILE/UNTIL>** expression located on the **DO** or **LOOP** line.

Processing a **WHILE** statement is the same on either the **DO** or **LOOP** lines. The Boolean expression is evaluated and if the statement is true, the **LOOP** continues at the line after the **DO** statement. Otherwise, the line after the corresponding **LOOP** is the next line to be processed.

Processing an **UNTIL** statement is the same on either the **DO** or **LOOP** lines. The Boolean expression is evaluated and if the statement is false, the **LOOP** continues at the line after the **DO** statement. Otherwise, the line after the corresponding **LOOP** is the next to be processed.

If **<WHILE/UNTIL>** is on the **LOOP** line, the **BODY** of the loop is executed before the Boolean expression is evaluated.

If neither the **DO** or **LOOP** line has a **<WHILE/UNTIL>** statement, the loop continues indefinitely.

Some notes about **DO-LOOPS**:

- can be nested
- cannot overlap
- have two formats

Format

```
DO [<WHILE/UNTIL> <Boolean expression>]
~~BODY~~
LOOP [<WHILE/UNTIL> <Boolean expression>]
```

➔ **Example:** This is an example of how to use the **DO-LOOP** command with the conditional on the **DO** line:

```
10 DO WHILE A$="70"
20 INPUT A$
30 LOOP
```

➔ **Example:** This is an example of how to use the **DO UNTIL LOOP** command with conditional on the **LOOP** line:

```
10 DO
20 INPUT A$
30 LOOP UNTIL A$="EXIT"
```

Comments This is a program command that is preceded by a line number.

FOR Loops

FOR loops are an easy way to iterate through a range of values and run a body of code for each value iterated.

Format

```
FOR <I> = <A> TO <B> [STEP <C>]
  ~~BODY~~
NEXT <I>
```

Parameters

<I> = indicates a numeric variable is used. <I> increments each time through the **FOR-LOOP**.

<A> = the value assigned to <I> the first time through the loop

 = the last value through the loop

<C> = (Optional) the amount <I> increments each time through the loop

Values of I for the following situations:

Statement	Result
FOR I=1 TO 10	{1, 2, 3, 4, 5, 6, 7, 8, 9, 10}
FOR I=10 TO 1	{10, 9, 8, 7, 6, 5, 4, 3, 2, 1}
FOR I=1 TO 10 STEP 2	{1, 3, 5, 7, 9}
FOR I=10 TO 1 STEP 2	{10, 8, 6, 4, 2}
FOR I=10 TO 1 STEP 2	{ } FOR LOOP skipped



Example: This is an example of how to use the **FOR LOOP** command:

```
10 FOR X=1 TO 10 STEP 1
20 PRINT X; ":ZBI IS FUN"
30 NEXT X
```

Comments **FOR** loops can be nested but cannot overlap. Variables cannot be reused by the nested loops.

GOTO/GOSUB

GOSUB is followed by a line number. The program will attempt to process the line the **GOSUB** command points to rather than the next line of the program. Upon executing the **GOSUB** statement, the interpreter continues running at the line number specified following **GOSUB**. If the line number referenced does not exist, an error will occur.

Before executing the next line, the **GOSUB** command stores the line number of the **GOSUB** line. When the **RETURN** statement is called, the program moves back to the next line following the **GOSUB**.

Executing a **RETURN** statement without a corresponding **GOSUB** statement causes an error.

GOSUB statements can be nested.

GOTO works the same way as **GOSUB** except that no return address will be stored.

Format

```
GOSUB <A>  
RETURN  
GOTO <A>
```

Parameters <A> = the program location executed immediately after the **GOTO** or **GOSUB**.



Example: This is an example of how to use the **GOSUB** command:

```
10 PRINT "Call Subroutine"  
20 GOSUB 1000  
30 PRINT "Returned from Subroutine"  
40 END  
1000 PRINT "In Subroutine"  
1010 RETURN
```

Example: This is an example of how to use the **GOTO** command:

```
10 PRINT "Prepare to Jump!"  
20 GOTO 1000  
30 PRINT "Jump Missed..."  
1000 PRINT "Jump Successful"  
1010 END
```

Comments These are program commands and must be preceded by line numbers.

SUB



This command allows you to use names instead of actual line numbers as the target of **GOSUBS** and **GOTOs**. **AUTONUM** can be used at the beginning of a file and there is no need to compute the line number where the jump will go.

Format 10 SUB <A>

Parameters <A> = the integer variable to use as a target for the **GOTO/GOSUB**



Example: This is an example of how to use the **SUB** command:

```
AUTONUM 1,1
GOSUB INITCOMM
DO
GOSUB GETINPUT
GOSUB PROCESSINPUT
LOOP
SUB INITCOMM
OPEN #1:NAME "SER"
RETURN
SUB GETINPUT
INPUT #1: A$
RETURN
SUB PROCESSINPUT
PRINT A$
RETURN
```

Comments <A> is a numeric variable. If this variable is changed in the program, any **GOSUB/GOTO** to this variable may fail.

EXIT

This command is used to exit the **DO** and **FOR** loops.

Format

```
EXIT DO
EXIT FOR
```

Parameters The specified loop type is exited. For the **DO** command, the program will continue execution on the line following the next **LOOP**. Likewise for the **FOR** command, the program will continue on the line after the next **NEXT** command.

Example N/A

Comments This is a program command that is preceded by a line number. To be explicit and reduce errors, it is recommended to use **GOTO** instead of **EXIT**.

END

The **END** command terminates any program currently running. When the **END** command is received, the interpreter returns to interpreting commands (>).

Format END

Parameters N/A



Example: This is an example of how to use the **END** command:

```
10 PRINT "THIS PROGRAM WILL TERMINATE"
20 PRINT "WHEN THE END COMMAND IS RECEIVED"
30 END
40 PRINT "THIS SHOULD NOT PRINT"
RUN
THIS PROGRAM WILL TERMINATE
WHEN THE END COMMAND IS RECEIVED
```

Comments This is a program command and is preceded by a line number.

Input and Output

This section outlines how to communicate with physical ports, internal ports, and the network.

ZBI allows access to the physical and network connections in the printer. Most ports are, by default, connected to the ZPL processor. When a port is opened in ZBI, the port will be disconnected from ZPL and connected into the interpreter. Depending on the type of connection, there are two methods you may use to start the connection. For the static connections, the **OPEN** command should be used. These are the connections that you open when starting your program and leave open for the duration of your program. For dynamic connections, servers and clients are set up following the "Sockets" model. On servers, the actual connections are started upon successful calls to **ACCEPT**. Below are the available connections that can be made and the preferred accessors.

Available Ports

Port/Connection	ZBI Name	Preferred Access Commands/Functions
Serial	"SER"	OPEN, CLOSE
Parallel	"PAR"	OPEN, CLOSE
USB	"USB"	OPEN, CLOSE
ZPL parser	"ZPL"	OPEN, CLOSE
TCP Server	"TCP", "TCPX"	SERVERSOCKET, SERVERCLOSE, ACCEPT, CLOSE
TCP Client	"TCP"	CLIENTSOCKET, CLOSE
UDP Server	"UDP"	SERVERSOCKET, SERVERCLOSE, ACCEPT, CLOSE

Note: TCPx will not work on PS2 or PS100 print servers.

Port/Connection	ZBI Name	Preferred Access Commands/Functions
UDP Client	"UDP"	CLIENTSOCKET, CLOSE
Email Sender	"EML"	OPEN, CLOSE
Bluetooth	"BLU"	OPEN, CLOSE

Note: TCPx will not work on PS2 or PS100 print servers.

Creating Connections

Here is a quick list of the commands in this section:

OPEN Opens a port for transmitting and receiving data.

CLOSE Closes specific ports that are in use.

DATAREADY Determines if there is data received on a specified port.

SERVERSOCKET Opens a listening socket for incoming UDP packets or TCP connections.

SERVERCLOSE Closes a listening server socket.

CLIENTSOCKET Creates an outgoing TCP connection or sets up UDP transmissions.

ACCEPT Accepts incoming TCP or UDP connections and assigns a channel for the connection.

OPEN

This command is used to open a port for transmitting and receiving data.

Format OPEN #<CHANNEL>: NAME <PORT\$>

Parameters

<CHANNEL> = a number to use as a handle to the port for all future communications

Values: 0 to 9

Default: a port must be specified

<PORT\$> = port name to open. See *Available Ports* [on page 467](#).



Example: This is an example of how to use the OPEN command:

```
10 OPEN #1: NAME "ZPL"
```

The port being opened no longer allows data to pass directly into its buffer, it disconnects, and the interpreter now controls the data flow.

Data already in the buffer stays in the buffer.

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

CLOSE

This command is implemented to close specific ports that are in use. If a port is open on a channel and the **CLOSE** command is entered, the port closes and returns to communicating with the ZPL buffer.

Format

```
CLOSE #<A>  
CLOSE ALL
```

Parameters

<A> = Numeric value of port to close

Values: 0 through 9

ALL = closes all open ports and network connections



Note • **CLOSE ALL** will close the console.



Example: This example shows the closing of channel 1:

```
10 CLOSE #1
```

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

DATAREADY

This function is used to determine if there is data received on a specified port.

Format DATAREADY (A)

Parameters A = the port to check

Returns 1 if there is data, 0 if there is no data.



Example: This is an example of how to check if there is a data on a port:

```
10 PRINT DATAREADY(0)
RUN
```

The result, assuming no data is waiting, is:

```
0
```

Comments If this command follows the **INPUT** command, it may return 1 if the line received was ended with a CRLF. In this case, **INBYTE** can be used to take the LF out of the buffer.

SERVERSOCKET



This function opens a listening socket for incoming UDP packets or TCP connections. It must be used in conjunction with the **ACCEPT** function.

Format SERVERSOCKET (TYPE\$,PORT)

Parameters

TYPE\$ = listens for any of the following communication protocols:

"TCP" = TCP – PORT parameter is ignored. The current port will be used.

"TCPX" = TCP – any open port

"UDP" = UDP – any open port

Returns NUMERIC = returns the handle of the server upon success.



Example: See the examples for *TCP Server* [on page 485](#) and *UDP Server* [on page 487](#).

Comments When using TCPX, care needs to be taken not to use a port that is already open on the printer. No error message will be returned until the **ACCEPT** function is called.

SERVERCLOSE



This function closes a listening server socket created by SERVERSOCKET.

Format SERVERCLOSE(SOCKET)

Parameters

SOCKET = the socket handle returned from a successful SERVERSOCKET invocation.

Returns Returns a 0 if the socket was already closed or a 1 if the socket was closed successfully.



Example: This example shows how to close a listening server socket.

```
10 LET SERVER_HANDLE = SERVERSOCKET("TCPX", 19100)
20 LET SCERR = SERVERCLOSE(SERVER_HANDLE)
```

CLIENTSOCKET



This function creates an outgoing TCP connection or sets up UDP transmissions. Once set up for UDP, packets can be sent by printing to the socket. Packets are sent when the size limit is met or a EOT character is written.

Format CLIENTSOCKET (TYPE\$, IPADDR\$, PORT)

Parameters

TYPE\$ = set to "UDP" or "TCP".

IPADDR\$ = connects to this address.

PORT = connects to this IP port.

Returns The port number assigned to the connection.



Example: See the examples for *TCP Server* [on page 485](#) and *UDP Server* [on page 487](#).

Comments Multiple communications connections can be made up to the maximum of 10. Each protocol may have a different limit based on the support of the print server used. Test the worst case situation based on your application's needs or use **ONERROR** to recover from failed connection attempts.

ACCEPT



This function will accept incoming TCP or UDP connections and assign a channel for the connection. **SERVERSOCKET** must be used to set up the listening socket before **ACCEPT** can be used.

Format **ACCEPT (SERVER, CLIENT_INFO\$)**

Parameters

SERVER = the handle returned by the **SERVERSOCKET** call.

CLIENT_INFO\$ = string variable will have the connecting client's IP address and port separated by a space when using UDP.

Returns The channel number to use to communicate with the client.



Example: See the examples for *TCP Server* [on page 485](#) and *UDP Server* [on page 487](#).

Comments It is best to poll this function at regular intervals. When there is no connection waiting, this function will trigger an error. Follow this function with the **ON ERROR** command to divert to a section of code that handles an unsuccessful connection.

ACCEPT can be called before closing a previous connection. This allows for processing multiple incoming streams of data. There are limits on the number of simultaneous incoming connections based on the print server model on the printer.

Connection closure can be detected when any input or output command to the port triggers an error. These commands should be followed by an **ON ERROR** statement to send the program into a recovery state and to shutdown the connection cleanly.

Reading and Writing

This manual has detailed various functions to read and write to all of the ports. The following section gives an overview of the commands, functions, and when each should be used.

To start, it is important to understand the term "blocking". In communications code, a function or command is "blocking" if it waits for all of the requested data to be received before it returns.

INPUT (blocking) Reads one line into each string specified.

PRINT (blocking) Simple method to write specified expressions out.

OUTBYTE (blocking) Writes one byte out.

INBYTE (blocking) Reads in one byte.

READ (non-blocking) Reads in all available data up to the maximum amount specified.

WRITE (non-blocking) Writes out as much data as possible up to a maximum specified amount.

SEARCHTO\$ (blocking) Reads in data (does not keep) until a search parameter is found. Non-matching data can be redirected to another port.

INPUT

If the variable is numeric and the value entered cannot be converted to a number, it writes as 0. This operation scans the data from left to right, shifting any number into the variable. It ignores any non-numeric character except the return character, which terminates the input, or Ctrl-C (^C) which terminates the program. The variable can be in string or numeric form.

Format

```
INPUT [<CHANNEL>:] <A$> [,<B$>]*
INPUT [<CHANNEL>:] <A>[,<B>]*
```

If the [<channel>:] is omitted, the default port, 0, will be used.

Parameters

<CHANNEL> = read data from this port. Default = 0.

<A,B,...,N> = variables to write.

When using multiple variables as targets, a corresponding number of lines are read.

String and numeric variables can be intermixed.



Example: This is an example of how to use the INPUT command:

```
10 OPEN #1: NAME "ZPL"
20 PRINT #1: "~HS"
30 FOR I = 1 TO 3
40 INPUT #1: A$
50 PRINT A$
60 NEXT I
```

In this example, a host status prints to the console after submitting the host status request ~HS to the ZPL port. The Input/Output command of the ZBI interpreter is limited to the communications ports. File I/O is not supported.

INPUT ends processing a line with a CR or LF. This leads to a tricky situation. There are many ways different systems end a line: CR, CRLF, LF. If the ZBI program only uses INPUT, the next execution of the INPUT command will remove the extra LF or CR, in case of LFCR. However, if the program instead uses INBYTE, DATAREADY or the other commands, the extra LF will show up on the port. Here's a simple workaround to explicitly look for the CRLF that is in use:

```
SEARCHTO(<PORT>,<CHR$(13)&CHR$(10)>,<INSTRING$>)
```



Note • The INPUT command does not accept control characters or the delete character. If these characters need to be processed, use the READ command.

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

If an invalid port is specified, **Error: Invalid port** is returned.



Example: This shows the input command reading in multiple lines.

```
10 INPUT A$,B,C,D$,E$
```

Five lines would be read in: 3 strings and 2 numbers.

PRINT

This command sends data to the printer to be printed.

Format PRINT [CHANNEL:] <expression> [,or; <expression>]* [;]

Parameters

<CHANNEL> = write data to this port
<expression> = the value to write

The expression can be either a string or a numeric expression.
Using a , to separate expressions adds a space between them.
Using a ; to separate expressions does not put a space between them.
Using a ; at the end of a line ends the print statement without adding a new line (CR/LF).



Example: This is an example of how to use the PRINT command:

```
10 LET A$ = "This is an example"  
20 LET B$ = "of the PRINT Command."  
30 PRINT A$, B$ ! adds a space between expressions  
40 PRINT A$; B$ ! no space added  
RUN
```

The result is:

This is an example of the PRINT Command.
This is an example of the PRINT Command.

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

OUTBYTE

This command outputs a byte to a port.

Format

```
OUTBYTE [<CHANNEL>:] <A>  
OUTBYTE [<CHANNEL>:] <A$>
```

Parameters

<CHANNEL> = sends the byte to this port. Default = 0.

<A> = This is a numeric expression.

Values: 0 through 255. If it is not within that range, it is truncated.

<A\$> = This is the string expression. The first character is used. In the case of a NULL string, 0 is sent.



Example: This is an example of how to use the OUTBYTE command:

```
LET A$="Hello"
```

```
OUTBYTE A$
```

This would only print the H character to the console.

```
OUTBYTE 4
```

This would print the control character **EOT** to the console. See an ASCII table for a list of the control characters.

Comments This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

INBYTE

This command forces the interpreter to pause until data is available. Use the **DATAREADY** function to determine if there is data on the port.

Format

```
INBYTE [<CHANNEL>:] <A>  
INBYTE [<CHANNEL>:] <A$>
```

Parameters

<CHANNEL> = reads from this port. Default = 0.

<A> = integer value is set to the byte received.

<A\$> = A single byte string is created with the byte received. The first character is used. In the case of a NULL string, 0 is sent.



Example: This is an example of how to use the `INBYTE` to create an echo program:

```
10 INBYTE A$ !Takes one byte (char) from port #0  
20 PRINT A$ !Prints the character to the console  
30 GOTO 10
```

In this example, the interpreter pauses until the data is entered, then continues processing. This command enters all bytes in a string or integer, including control codes.

Comments `INBYTE` will block until a byte is received on the specified port. This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

READ



Description This is a non-blocking input function. It will read in all of the bytes available on the specified port.

Format READ (<CHANNEL>, <A>, <MAXBYTES>)

Parameters

- <CHANNEL> = reads from this port. Default = 0.
- <A\$> = the string where the data will be placed
- <MAXBYTES> = the maximum number of bytes to read

Returns The number of bytes read.



Example: This is an example of the **READ** command:

```
1 CLOSE ALL
2 LET INPORT = CLIENTSOCKET("TCP", "192.168.0.1", 9100)
3 ON ERROR GOTO RECOVERY
4 LET WATERMARK = 5000
5 DO WHILE 1
6 IF LEN(DATA$) < WATERMARK THEN
7 LET BYTESREAD = READ(INPORT, DATA$, 500)
8 ON ERROR GOTO RECOVERY
9 END IF
10 IF (LEN(DATA$) > 0) THEN
11 LET BYTES_WRITTEN = WRITE(INPORT, DATA$, LEN(DATA$))
12 ON ERROR GOTO RECOVERY
13 LET DATA$(1, BYTES_WRITTEN) = ""
14 END IF
15 IF BYTESREAD = 0 AND BYTESWRITTEN = 0 THEN
16 SLEEP 1 ! DON'T BOMBARD IF IDLE
17 END IF
18 LOOP
19 SUB RECOVERY
20 CLOSE #INPORT
```


WRITE



Description This is a non-blocking output function. It will write as many bytes as the output buffer can hold.

Format WRITE (<CHANNEL>, <A>, <BYTES>)

Parameters

<CHANNEL> = reads from this port. Default = 0.

<A\$> = the string to write out.

<MAXBYTES> = The number of bytes to write

Returns The number of bytes written.



Example: This is an example of **WRITE** command:

```
1 CLOSE ALL
2 LET INPORT = CLIENTSOCKET("TCP", "192.168.0.1", 9100)
3 ON ERROR GOTO RECOVERY
4 LET WATERMARK = 5000
5 DO WHILE 1
6 IF LEN(DATA$) < WATERMARK THEN
7 LET BYTESREAD = READ(INPORT, DATA$, 500)
8 ON ERROR GOTO RECOVERY
9 END IF
10 IF (LEN(DATA$) > 0) THEN
11 LET BYTES_WRITTEN = WRITE(INPORT, DATA$, LEN(DATA$))
12 ON ERROR GOTO RECOVERY
13 LET DATA$(1, BYTES_WRITTEN) = ""
14 END IF
15 IF BYTESREAD = 0 AND BYTESWRITTEN = 0 THEN
16 SLEEP 1 ! DON'T BOMBARD IF IDLE
17 END IF
18 LOOP
19 SUB RECOVERY
20 CLOSE #INPORT
```

SEARCHTO\$

This function performs a search until a specified string is found. The string the search yields is displayed.

Format

```
SEARCHTO$(A, B$)
SEARCHTO$(A, B$, C)
SEARCHTO$(A$, B$)
SEARCHTO$(A$, B$, C$)
```

Parameters

A = port number (0 to 9) to which requested data is sent
A\$ = string to search for B\$
B\$ = string variable or string array. If B\$ is an array, this command searches for all non-null strings in the B\$ array.
C = a port in which the input is directed until B\$ is found
C\$ = a string in which the characters in A\$ are directed until B\$ is found

Returns The string found.



Example: This example shows how to use **SEARCHTO** to find a string on a port:

```
10 OPEN #1: NAME "SER"
20 LET A$ = SEARCHTO$(1, "^XA")
30 PRINT "FOUND:", A$
```



Example: This example shows how to search for an array of strings:

```
10 OPEN #1: NAME "SER"
20 DECLARE STRING FIND$(3)
30 LET FIND$(1) = "ONE"
40 LET FIND$(2) = "TWO"
50 LET FIND$(3) = "THREE"
60 LET A$ = SEARCHTO$(1, FIND$)
70 PRINT "FOUND:", A$
```



Example: This example shows unused data routed to a port.

```
10 OPEN #1: NAME "PAR"  
20 OPEN #2: NAME "SER"  
30 DECLARE STRING FIND$(3)  
40 LET FIND$(1) = "ONE"  
50 LET FIND$(2) = "TWO"  
60 LET FIND$(3) = "THREE"  
70 LET A$ = SEARCHTO$(1,FIND$,2)  
80 PRINT "FOUND:", A$
```



Example: This example shows how to use **SEARCHTO** to find a string within a string and direct the unused part of the string to another string:

```
10 LET A$ = "The faster you go, the shorter you are - Einstein"  
20 LET B$ = SEARCHTO$(A$,"you", C$)  
30 PRINT "FOUND:", B$  
40 PRINT "DISCARDED:", C$
```

Comments **SEARCHTO** will block (wait) until the search string is found. If you want to be able to run other code while doing something similar, consider using **READ** with **POS**.

When using **SEARCHTO** with ports, it will block (wait) until the search string is found. If you want to be able to run other code while doing something similar, consider using **READ** to place data into a string. That string can be passed to **SEARCHTO** for processing.

Port Usage Examples

Before diving into the syntax of all the commands, let's look at some simple applications using the different features of the communications systems in ZBI.

Physical Ports (Serial, Parallel, USB, Bluetooth®)

Though the types of devices interacting with the printer's ports may vary greatly, internal to the printer, the ports are all handled in the same way. These ports are opened with the ZBI **OPEN** command and closed with the ZBI **CLOSE** command. When one of these ports is opened, it is disconnected from the ZPL parser and any data in the buffer will be redirected to the ZBI environment.



Example: In the following example, "SER" could be replaced by "PAR", "USB", or "BLU" depending on the application.

```
10 CLOSE ALL
20 LET INPORT = 1
25 SLEEP 1
30 OPEN #INPORT: NAME "SER"
35 ON ERROR GOTO 25
40 PRINT #INPORT: "Enter your name:";
50 INPUT #INPORT: YOURNAME$
55 ON ERROR GOTO 70
60 PRINT #INPORT: "You entered: "; YOURNAME$
70 CLOSE #INPORT
```

ZPL Parser

To make a ZBI program print, it is necessary to create a connection from the program to the ZPL parser on the printer. The connection will function in the same way as a connection to a physical port, except that the connection will not automatically terminate. The ZPL parser in the printer can handle many incoming connections simultaneously. For example, a ZBI program could take control of the serial port and send label formats to the ZPL parser, while the parallel port (unopened by ZBI) could also be used to send label formats directly into the parser.



Note • The ZPL parser will lock onto one port once a format is started (via the **^XA** command). So, in some cases, is it desirable to start and stop your communications to ZPL in one continuous sequence.

Another use of ZBI is to check printer status, while another application prints to another port.



Example: Here is how that can be done:

```
10 OPEN #1: NAME "ZPL"
20 PRINT #1: "~HS"
30 FOR I = 1 TO 3
40 INPUT #1: A$
50 PRINT A$
60 NEXT I
```

TCP Client

There are two methods for making a TCP connection to another server. The first method uses the **OPEN** command while the second method uses the **CLIENTSOCKET** method.

CLIENTSOCKET is the preferred method.



Example: The following example demonstrates this method:

```
10 CLOSE ALL
20 LET INPORT = CLIENTSOCKET("TCP","192.168.0.1",9100)
40 LET OUTSTR$ = "REQUESTING SERVER NAME";
50 DO WHILE (LEN(OUTSTR$) > 0)
60 LET BYTES_WRITTEN = WRITE(INPORT,OUTSTR$,LEN(OUTSTR$))
70 ON ERROR GOTO RECOVERY
80 LET OUTSTR$ = OUTSTR$(1+BYTES_WRITTEN:LEN(OUTSTR$))
90 LOOP
100 INPUT #INPORT: YOURNAME$
110 PRINT #INPORT: "Server returned: "; YOURNAME$
120 CLOSE #INPORT
130 SUB RECOVERY
140 END
```

TCP Server

Setting up a listening server in the printer can be accomplished with the **SERVERSOCKET** function. To connect to incoming TCP sessions, use the **ACCEPT** function.

When starting the application, call **SERVERSOCKET**. This function will create a handle for this listening server. Check for incoming connections at regular intervals with the **ACCEPT** function. If there are no pending sessions, the **ACCEPT** function will return with an error. Handle the error using the **ON ERROR** command and continue looking for other sessions later.

Depending on how the program is set up, it is possible to handle one or more sessions at a time. If the program is configured to allow only one session, the other connections will remain pending until they are shut down by the requesting client or the ZBI program connects them.



Example: Here is an example of the **SERVERSOCKET** and **ACCEPT** commands:

```

10 CLOSE ALL
20 LET SERVER_HANDLE = SERVERSOCKET("TCPX",19100)
30 REM There are no connections yet we are just listening for them
40 REM Lets loop until we get a connection
50 SLEEP 1
60 LET INPORT = ACCEPT(SERVER_HANDLE,CLIENT_INFO$)
70 ON ERROR GOTO 50
80 PRINT #INPORT: "You have successfully connected!"
90 PRINT #INPORT: "Login:";
100 INPUT #INPORT: LOGIN$
110 PRINT #INPORT: "Password:";
120 INPUT #INPORT: PASSWORD$
130 REM We will not be nice and reject the connection
130 PRINT #INPORT: "Login failed"
140 CLOSE #INPORT
150 GOTO 60 ! Go look for the next connection
160 END

```

UDP Client

There are also two methods for making a UDP connection to another server. The first method uses the **OPEN** command, while the second method uses the **CLIENTSOCKET** method. UDP is a one way communication medium, thus, you can only use output commands. Because UDP is connectionless, the output will be queued up until an **EOT** character is written or the maximum packet size is exceeded. Once the **EOT** character is written, the packet is formatted and sent.

With UDP, it is important to be careful about understanding what the network being used will support.

In many cases, there will be a limit to the size of the packet that can be used, typically between 1000 and 1500 bytes, but some networks cut this down into the 500 to 600 byte range. To be safe, keep your packets less than 500 bytes.

UDP does not guarantee transmission. See UDP specifications for more details.



Example: Since **CLIENTSOCKET** is the preferred method, an example is shown below.

```

10 CLOSE ALL
20 LET INPORT = CLIENTSOCKET("UDP", "192.168.0.1", 22222)
30 LET EOT$ = CHR$(4)
40 PRINT #INPORT: "Packet #"; I; EOT$;
50 LET I = I + 1
60 SLEEP 1
70 GOTO 40

```

UDP Server

Setting up a listening server in the printer can be accomplished with the **SERVERSOCKET** function. Then, to connect to incoming UDP packets, use the function **ACCEPT**. When starting your application, call **SERVERSOCKET**. This function will create a handle for this listening server. Check for incoming packets at a regular interval with the **ACCEPT** function. If there are no pending sessions, the **ACCEPT** function will return with an error. Just handle the error using the **ON ERROR** command and continue looking for other sessions later. You will need to call **ACCEPT** for each incoming packet. When the accept is successful, all of the data will be available. Call **READ** with a **MAX** string size of 2000 and you will have the whole packet in your string. Close the port and wait for the next packet. You can only read in data using a UDP server.



Example: Here is an example of how to set up to receive UDP messages:

```

10 CLOSE ALL
20 LET ZPLPORT = 1
35 OPEN #ZPLPORT: NAME "ZPL"
40 LET SERVER_HANDLE = SERVERSOCKET("UDP",33333)
50 REM There are no connections yet: listening
60 REM Let's loop until we get a connection
70 SLEEP 1
80 LET INPORT = ACCEPT(SERVER_HANDLE,CLIENT_INFO$)
90 IF INPORT = -1 THEN
92 GOTO 70
94 END IF
100 LET PACKET_SIZE = READ(INPORT,PACKET$,2000)
110 PRINT #ZPLPORT: "^XA^F0100,100^A0N,40,40^FDPACKET FROM:";
115 PRINT #ZPLPORT: CLIENT_INFO$; "^FS"
120 PRINT #ZPLPORT: "^F0100,150^A0N,40,40^FDPACKET SIZE:";
125 PRINT #ZPLPORT: PACKET_SIZE; "^FS"
130 PRINT #ZPLPORT: "^F0100,200^A0N,40,40^FDPACKET DATA:";
135 PRINT #ZPLPORT: PACKET$; "^FS^XZ"
140 CLOSE #INPORT
150 GOTO 60 ! go look for the next connection
160 END

```

E-mail

ZBI can be used to enhance the printer's ability to send status via e-mail messages. The process is simple: open the email port "EML", send the recipient list, send the header, and send the body of the message.

The printer can only process a limited number of outgoing email messages at one time. For this reason, error handling should be used when opening the connection to wait for the printer to be ready to send the message. The EOT character is important for delimiting sections of the email message. If it is left out, the message will not be sent properly.

Before the following code will work, the email settings for the print server must be set up. Consult the print server manual to learn how to configure the unit.



Example: Here is an example of how to send e-mails:

```
1 REM EOT$ this is used to denote end of transmission
5 LET EOT$ = CHR$(4)
1 REM Open a connection to the e-mail port and if it errors
1 REM try again until complete
10 OPEN #1: NAME "EML"
15 ON ERROR GOTO 10
1 REM Specify address to send message to then end signal end
1 REM of recipients with EOT$
1 REM To send to multiple addressees separate addressees by
1 REM space
20 PRINT #1: "youraddress@yourdomain.com";EOT$;
1 REM Fill in the message information
30 PRINT #1: "From: HAL"
40 PRINT #1: "To: Dave"
50 PRINT #1: "Subject: A message from HAL"
60 PRINT #1: ""
70 PRINT #1: "Dave, I am sorry I can not let you do that."
80 PRINT #1: i
1 REM Terminate message
90 PRINT #1: "";EOT$
1 REM You must close the port, each open port is only good
1 REM for sending one message
100 CLOSE #1
```

File System

This section shows how programs and formats can be saved and recalled. Here's a quick list of these commands:

STORE Saves the program currently in memory as the specified file name.

LOAD Transfers a program file previously stored in the printer's memory and opens it in the ZBI Program Memory.

DIR With no filter included, prompts the printer to list all of the ZBI programs residing in all printer memory locations.

DELETE Removes a specified file from the printer's memory.

Runtime Access

The following example is a method to store runtime data in the printer memory. The file system in the printer is limited to writing one file at a time. Since only one component of the printer can have write access to the file system, the ZPL parser is the component with this access. For ZBI to use the ZPL parser as a gateway into printer memory, the ZPL comment command (^FX) is used.



Example:

```
AUTONOM 1,1
REM ***** TEST FOR SUBROUTINES *****
LET ZPLPORT = 1 OPEN #ZPLPORT: NAME "ZPL"
LET SIZE = 5
LET FILENAME$ = "R:TESTSYS.ZPL"
DECLARE STRING DATAIN$(SIZE)
LET DATAIN$(1) = "ONE"
LET DATAIN$(2) = "TWO"
LET DATAIN$(3) = "THREE"
LET DATAIN$(4) = "FOUR"
LET DATAIN$(5) = "FIVE"
GOSUB STOREDATA
GOSUB GETDATA
FOR I = 1 TO SIZE
IF DATAIN$(I) <> DATAOUT$(I) THEN
PRINT #ZPLPORT: "^XA^F0100,100^A0N,50,50^FDERROR:";
PRINT #ZPLPORT: DATAOUT$(I);"^XZ"
END IF
NEXT I
END
REM **** SUBROUTINE STOREDATA *****
REM INPUT: ZPLPORT, DATAIN$, SIZE, FILENAME$ *****
SUB STOREDATA
PRINT #ZPLPORT: "^XA^DF" & FILENAME$ & "^FS"
PRINT #ZPLPORT: "^FX"; SIZE; "^FS"
FOR I = 1 TO SIZE
PRINT #ZPLPORT: "^FX" & DATAIN$(I) & "^FS"
NEXT I
PRINT #ZPLPORT: "^XZ"
RETURN
REM **** SUBROUTINE GETDATA - *****
REM INPUT: ZPLPORT, FILENAME$ *****
REM ** OUTPUT: DECLARES AND FILLS DATAOUT$ AND FILLS SIZE
SUB GETDATA
PRINT #ZPLPORT: "^XA^HF" & FILENAME$ & "^XZ"
SLEEP 1
LET RESULT$ = ""
FOR J = 1 TO 25
LET A = READ(ZPLPORT,TEMP$,5000)
LET RESULT$ = RESULT$ & TEMP$
IF POS(RESULT$,"^XZ") <> 0 THEN
EXIT FOR
END IF
SLEEP 1
NEXT J
LET RESULT$(1:POS(RESULT$,"^FX")+2) = ""
LET SIZE = VAL(EXTRACT$(RESULT$,"","^"))
DECLARE STRING DATAOUT$(SIZE)
FOR I = 1 TO SIZE
LET RESULT$(1:POS(RESULT$,"^FX")+2) = ""
LET DATAOUT$(I) = EXTRACT$(RESULT$,"","^")
NEXT I
LET RESULT$ = ""
LET TEMP$ = ""
RETURN
```

STORE

This command saves the program currently in memory as the specified file name. The format listed below is used.

Format STORE <filename\$>

Parameters <filename\$> = the name of the file to be stored. Drive location and file name must be in quotation marks.



Example: This is an example of how to use the **STORE** command:

```
STORE "E:PROGRAM1.BAS"
```

Comments For a file name to be valid, it must conform to the 8.3 Rule: each file must have no more than eight characters in the file name and have a three-character extension. Here the extension is always **.BAS** (for example, **MAXIMUM8.BAS**).

This is an interactive command that takes effect as soon as it is received by the printer.

The ZBI-Developer IDE will take care of this for you with the **SEND TO** option on your program.

LOAD

This command transfers a program file previously stored in the printer's memory and opens it in the ZBI Program Memory.

If the program file does not exist, the ZBI Program Memory is cleared and no program is opened.

Format LOAD <filename\$>

Parameters <filename\$> = the file name to be loaded into memory. Drive location and file name must be in quotation marks. If the drive location is not specified, all drives will be searched.



Example: Here are examples of how to use the LOAD command:

```
LOAD "PROGRAM1.BAS"
```

```
LOAD "E:PROGRAM1.BAS"
```

Comments This is an interactive command that takes effect as soon as it is received by the printer.

DIR

This command, with no filter included, prompts the printer to list all of the ZBI programs residing in all printer memory locations.

Including a filter signals the printer to limit the search; including a drive location signals the printer to search in only one location.

Asterisks (*) are used as wild cards. A wild card (*) finds every incidence of a particular request. The example here, **DIR "B:* .BAS"**, signals the printer to search for every file with a **.BAS** extension in B: memory.


Format DIR [<filter\$>]

Parameters [<filter\$>] = the name of the file to be accessed (optional). Drive location and file name must be in quotation marks.

Default = **"*:* .bas"**



Important • Quotes must be around what you are doing. This shows you how to use the wildcard (*) to search for all **.BAS** files in **B:** memory:



Example N/A

Comments This is an interactive command that takes effect as soon as it is received by the printer.

DELETE

This command removes a specified file from the printer's memory.

Format DELETE <filename\$>

Parameters <filename\$> = the name of the file to be deleted. Drive location and filename must be in quotation marks.



Example: This is an example of deleting a specified file from printer memory:

```
DELETE "E:PROGRAM1.BAS"
```

Comments This is an interactive command that takes effect as soon as it is received by the printer.

Comma Separated Values (CSV)

Accessing Comma Separated Value (CSV) and Text File Functions

This section describes the functions to access CSV files and ASCII plain-text files. Here is a quick list of these commands:

CSVLOAD Loads the contents of a CSV file in a two dimensional string array.

CSVSTORE Stores the contents of a two dimensional string array in a CSV file.

TXTLOAD Loads the contents of an ASCII plain-text file into a string variable.

TXTSTORE Stores the contents of a string variable in an ASCII plain text file.

CSVLOAD



This function will load the delimited values from a CSV file, defined by **FILENAME\$**, and store them in the two-dimensional array, **DEST\$**.

Format

```
CSVLOAD(DEST$, FILENAME$)  
CSVLOAD(DEST$, FILENAME$, DELIM$)
```

Parameters

DEST\$ = two dimensional array that will hold the rows and columns from the CSV file specified by the **FILENAME\$** variable. If there is not enough room in **DEST\$**, or if it has the wrong size, it will be changed to fit the data from the file. The data originally in **DEST\$** will be overwritten.

FILENAME\$ = name of the file to load. Drive location and file name must be in quotation marks. The file extension must be either ".CSV" or ".TXT".

DELIM\$ = optional delimiter that is used in the CSV file instead of a comma. If **DELIM\$** is not provided a comma will be used by default. The delimiter must be a single character that is not a quote, carriage return, or newline.

Returns The number of elements in each row of the CSV file. The function will return 0 if errors were detected in the CSV file, or if the file could not be read.



Example: This example shows how to print the values in a CSV file with a comma delimiter.

```
10 DECLARE STRING CSVDB$(1,2)  
20 LET FILENAME$ = "E:RECORDS.CSV"  
30 LET NUMOFCOLS = CSVLOAD(CSVDB$, FILENAME$)  
40 LET NUMOFROWS = ROWSIZE(CSVDB$)  
100 FOR I = 1 TO NUMOFROWS STEP 1  
110     FOR J = 1 TO NUMOFCOLS STEP 1  
120         PRINT CSVDB$(I, J), " ";  
200     NEXT J  
210     PRINT ""  
300 NEXT I
```



Example: This example shows how to print the values in a CSV file that uses a '|' as a delimiter.

```
10 DECLARE STRING CSVDB$(1,2)
20 LET FILENAME$ = "E:EMPLOYEE.CSV"
30 LET NUMOFCOLS = CSVLOAD(CSVDB$, FILENAME$, "|")
40 LET NUMOFROWS = ROWSIZE(CSVDB$)
100 FOR I = 1 TO NUMOFROWS STEP 1
110     FOR J = 1 TO NUMOFCOLS STEP 1
120         PRINT CSVDB$(I, J), " ";
200     NEXT J
210     PRINT ""
300 NEXT I
```

Comments The maximum CSV file size supported will vary based upon available RAM within the printer.

CSV File Information

The file format should follow the rules in IETF RFC 4180: <http://tools.ietf.org/html/rfc4180>

The maximum number of columns per row in a CSV file is 256.

Each row must be 2048 characters or less including the delimiter. The carriage return/line feed (CRLF) does not count toward the limit.

Each row in the CSV file must have the same number of elements. If there are any missing elements in the CSV file (indicated by two adjacent commas or a comma at the end of a row), they will be represented as empty strings.

If an element in the CSV file contains a quote, it should be represented as two quotes. Additionally, if an element contains a quote, a new line, a carriage return, or the delimiter character, the element must be within quotes. For example, a value that is used to store a measurement in feet and inches (4' 5") must be formatted as "4' 5"" within the CSV file.

CSVSTORE



This function will store the values of a two dimensional array into a CSV file on the file system. Each element within the array is treated as a single value within the CSV file.

Format

```
CSVSTORE(SRC$, FILENAME$)  
CSVSTORE(SRC$, FILENAME$, DELIM$)
```

Parameters

SRC\$ = two dimensional array of strings to be written to a CSV file.

FILENAME\$ = name of the file to store the array contents. Drive location and file name must be in quotation marks. The file extension must be either ".CSV" or ".TXT".

DELIM\$ = optional delimiter that is used in the CSV file instead of a comma. If DELIM\$ is not provided a comma will be used by default. The delimiter must be a single character that is not a quote, carriage return, or newline.

Returns A 0 if there were no errors. A 1 is returned if **SRC\$** is not a string array, if the file could not be written, or if **SRC\$** contains errors that prevent the file from being stored.



Example: This example shows how to convert a comma delimited CSV file into a "^" delimited TXT file and print the contents.

```
10 DECLARE STRING CSVDB$(1,2)  
20 LET NUMOFCOLS = CSVLOAD(CSVDB$, "E:RECORDS.CSV")  
30 LET CSVERROR = CSVSTORE(CSVDB$, "E:NEWREC.TXT", "^")  
40 LET NUMOFCOLS = CSVLOAD(CSVDB$, "E:NEWREC.TXT", "^")  
50 LET NUMOFROWS = ROWSIZE(CSVDB$)  
100 FOR I = 1 TO NUMOFROWS STEP 1  
110     FOR J = 1 TO NUMOFCOLS STEP 1  
120         PRINT CSVDB$(I, J), " ";  
200     NEXT J  
210     PRINT ""  
300 NEXT I
```

Comments The elements of the array should follow the rules in IETF RFC 4180:
<http://tools.ietf.org/html/rfc4180>

There is no limit on the number of columns per row when storing to a CSV file. However, a file stored with rows that exceed the column limit imposed by **CSVLOAD** will not be loaded by the **CSVLOAD** function.

There is no limit on the size of a row when stored to a CSV file. However, a file stored with rows that exceed the size limit imposed by **CSVLOAD** will not be loaded by the **CSVLOAD** function.

TXTLOAD



This function will read the contents of an ASCII text file into a ZBI string variable.

Format TXTLOAD(DEST\$, FILENAME\$)

Parameters

DEST\$ = string to store the contents of **FILENAME\$**.

FILENAME\$ = name of the file to read. Drive location and file name must be in quotation marks. The file extension must be either ".CSV" or ".TXT".

Returns The number of bytes read from the file. The function will return 0 if the file could not be read.



Example: This example shows how to print out the contents of a file.

```
10 LET TXTSIZE = TXTLOAD(TXTDATA$, "E:MYDATA.TXT")
20 PRINT STR$(TXTSIZE), "bytes:", TXTDATA$
```

Comments The data originally in **DEST\$** will be overwritten upon completion of this function.

TXTSTORE



This function will store the contents of a ZBI string in an ASCII text file.

Format TXTSTORE(SRC\$, FILENAME\$)

Parameters

SRC\$ = string to store to **FILENAME\$**.

FILENAME\$ = name of the file to store. Drive location and file name must be in quotation marks. The file extension must be either ".CSV" or ".TXT".

Returns Returns a 0 if there were no errors, otherwise a 1 is returned.



Example: This example shows how to append a text file.

```

10 LET TXTSIZE = TXTLOAD(TXTDATA$, "E:MYDATA.TXT")
11 REM Append a date/time stamp to the file
20 LET TXTDATA$ = TXTDATA$ & " " & DATE$ & " " & TIME$
30 LET TXTSIZE = TXTSTORE(TXTDATA$, "E:MYDATA.TXT")
40 PRINT TXTDATA$

```

Events

This section explains how to capture and trigger internal events in the printer. Here's a quick list of these commands:

Available Events A table that correlates a ZBI event with an identification number.

ZBI Key Names Details the names of each printer's front panel buttons, ZBI names, and ZBI event ID.

REGISTEREVENT Sets up the **HANDLEEVENT** function to receive notification when the specified event has occurred.

UNREGISTEREVENT Allows events that are currently set to be captured by the program to no longer be captured.

HANDLEEVENT Once events have been registered, this function is used to see what events have occurred.

TRIGGEREVENT Allows for front panel buttons to be triggered programmatically.

There are certain events in the printer that a ZBI 2.0 program can receive. To do this, the program first registers for the event. On a regular basis, call a function to handle events. When an event occurs that the program is registered for, the function will return the event's identification number.

Available Events

ZBI Event ID	ZBI Event
1	menu key
2	pause key
3	feed key
4	cancel key
5	up arrow key
6	plus key
7	minus key
8	enter key
9	setup exit key
10	select key
11	cancel all event
12	config label
13	timer1
14	timer2
15	timer3
16	timer4
17	timer5
18	spare unused
19	previous key
20	next save key
21	calibrate key
22	paper out set
23	paper out clear
24	ribbon out set
25	ribbon out clear
26	head too hot set
27	head too hot clear
28	head cold set
29	head cold clear
30	head open set
31	head open clear
32	supply too hot set
33	supply too hot clear
34	ribbon in set

ZBI Event ID	ZBI Event
35	ribbon in clear
36	rewind full set
37	rewind full clear
38	cutter jammed set
39	cutter jammed clear
40	paused set
41	paused clear
42	pq completed set
43	pq completed clear
44	label ready set
45	label ready clear
46	head element bad set
47	head element bad clear
48	basic runtime set
49	basic runtime clear
50	basic forced set
51	basic forced clear
52	power on set
53	power on clear
54	clean printhead set
55	clean printhead clear
56	media low set
57	media low clear
58	ribbon low set
59	ribbon low clear
60	replace head set
61	replace head clear
62	battery low set
63	battery low clear
64	rfid error set
65	rfid error clear
66	any messages set
67	any messages clear
68	auto baud
69	factory default

ZBI Event ID	ZBI Event
70	networking default
71	networking factory
72	print width
73	darkness adjust
74	calibrate
75	scroll key
76	soft key 1
77	soft key 2

ZBI Key Names

This section details the names to use for each printer's front panel buttons when creating ZBI 2.0 programs to capture the buttons.

ZT200/ZT400/ZD500/QIn

ZT2X0	ZT400	ZD500	QIn	ZBI Event ID	ZBI Name
Left Soft button				76	soft key 1
Right Soft Button				77	soft key 2
Plus	Up Arrow			6	plus key
Minus	Down Arrow			7	minus key
Left Arrow				19	previous key
Right Arrow				20	next save key
Setup	OK	Check	OK	10	select key
Pause			no key	2	pause key
Feed				3	feed key
Cancel			no key	4	cancel key

Xi4/RXi4/XiIII Plus/PAX4/105SL/ZE500

XiIII Plus/PAX4/Xi4/RXi4/ ZE500/105SL Plus Front Panel Key	105SL Front Panel Key	ZBI Event ID	ZBI Name
Right Oval	Plus (+)	6	plus key
Left Oval	Minus (-)	7	minus key
Previous		19	previous key

XiiiPlus/PAX4/Xi4/RXi4/ ZE500/105SL Plus Front Panel Key	105SL Front Panel Key	ZBI Event ID	ZBI Name
Next/Save		20	next save key
Setup/Exit		9	setup exit key
Pause		2	pause key
Feed		3	feed key
Cancel		4	cancel key
Calibrate		21	calibrate key

HC100

Front Panel Key	ZBI Event ID	ZBI Name
Pause	2	pause key
Feed	3	feed key
Eject		eject key

ZM400/ZM600/RZ400/RZ600/Z4Mplus/Z6Mplus

Front Panel Key	ZBI Event ID	ZBI Name
Feed	3	feed key
Pause	2	pause key
Cancel	4	cancel key
Setup/Exit	9	setup exit key
Select	10	select key
Plus (+)	6	plus key
Minus (-)	7	minus key

S4M

Front Panel Key	ZBI Event ID	ZBI Name
Menu	1	menu key
Enter	8	enter key
Cancel	4	cancel key

Front Panel Key	ZBI Event ID	ZBI Name
Feed	3	feed key
Pause	2	pause key
Left Arrow	4	cancel key
Right Arrow	3	feed key
Up Arrow	5	up arrow key
Down Arrow	2	pause key

G-Series

Front Panel Key	ZBI Event ID	ZBI Name
Feed key	3	Feed key
Select key	10	Select key
Scroll key	75	Scroll key

KR403 / 2824 Plus Series

Front Panel Key	ZBI Event ID	ZBI Name
Feed key	3	Feed key

REGISTEREVENT



Description This function will set up the **HANDLEEVENT** function to receive notification when the specified event has occurred. Events can be registered for one time or until the program is exited.



Important • If an event occurs twice or more before the **HANDLEEVENT** function is called, only one event will be received.

Format

REGISTEREVENT(X)
REGISTEREVENT(X,Y)
REGISTEREVENT(X,Y,Z)

Parameters

(X) = This is the ID of the event being registered for.
(Y) = If Y=1: the event happens once; If Y=0: the event stays registered for the duration of the program, or until it is unregistered.
(Z) = For System Events: if Z=0, the event will still be handled by the printer. If Z=1, then only ZBI will receive the event.
For Timer Events: this is the timer interval in mSec. If the interval is less than 0 or greater than 1,000,000,000, it is set to 1000.

Returns The ID of the successfully registered event. If an event was not successfully registered, a -1 is returned.



Example: Here is an example of how to use the REGISTEREVENT command:

```
1 REM This example shows how to override the functionality of the
feed
1 REM key
1 REM using the event system. After all why waste a label when you
1 REM could put
1 REM valuable information there
AUTONUM 1,1
CLOSE ALL
LET ZPLPORT = 1
OPEN #ZPLPORT: NAME "ZPL"
LET FEEDKEY = 3
LET TMP = REGISTEREVENT(FEEDKEY, 0, 1)
DO WHILE 1 = 1
LET EVT = HANDLEEVENT()
IF EVT = FEEDKEY THEN
GOSUB PRINTINFO
END IF
SLEEP 1
LOOP
REM **** SUBROUTINE PRINTINFO *** expects ZPLPORT *****
SUB PRINTINFO
PRINT #ZPLPORT: "^XA"
PRINT #ZPLPORT: "^F030,30^A0N,50,50^FDZebra Technologies^FS"
PRINT #ZPLPORT: "^F030,85^A0N,35,35^FDwww.zebra.com^FS"
PRINT #ZPLPORT: "^F030,125^A0N,35,35^FDsupport.zebra.com^FS"
PRINT #ZPLPORT: "^F030,165^A0N,35,35^FDFW Version: "
PRINT #ZPLPORT: GETVAR$("appl.name") & "^FS"
PRINT #ZPLPORT: "^F030,205^A0N,35,35^FDPrinter Unique ID:"
PRINT #ZPLPORT: GETVAR$("device.unique_id") & "^FS"
PRINT #ZPLPORT: "^F030,245^A0N,35,35^FDActive Network: "
PRINT #ZPLPORT: GETVAR$("ip.active_network") & "^FS"
PRINT #ZPLPORT: "^F030,285^A0N,35,35^FDZBI Memory Usage: "
PRINT #ZPLPORT: GETVAR$("zbi.start_info.memory_alloc") & "^FS"
PRINT #ZPLPORT: "^F030,325^A0N,35,35^FDOdometer: "
PRINT #ZPLPORT: GETVAR$("odometer.total_print_length") & "^FS"
PRINT #ZPLPORT: "^XZ"
```

Comments None

UNREGISTEREVENT



Description This function allows events that are currently set to be captured by the program to no longer be captured. Once called events will return to the normal method of processing if the REGISTEREVENT function Z parameter was set to 1.

Format UNREGISTEREVENT(X)

Parameters (X) = the ID of the event to stop

Returns 0 if the event is a valid event to unregister. A -1 if the event does not exist.



Example: Here is an example of how to use the UNREGISTEREVENT command:

```
AUTONUM 1,1
LET OUTSTR$ = "Processing"
LET LOOPCTR = 200
LET TIMERS = 17
LET TMP = REGISTEREVENT(TIMERS, 0, 1000)
DO WHILE LOOPCTR > 0
LET EVT = HANDLEEVENT()
IF EVT = TIMERS THEN
LET A = SETVAR("device.frontpanel.line2",OUTSTR$)
LET OUTSTR$ = OUTSTR$ & "."
IF LEN(OUTSTR$) >16 THEN
LET OUTSTR$ = "Processing"
END IF
END IF
LET LOOPCTR = LOOPCTR - 1
SLEEP 1
LOOP
LET TMP = UNREGISTEREVENT(TIMERS)
LET A = SETVAR("device.frontpanel.line2","")
END
```

Comments None

HANDLEEVENT



Description Once events have been registered, this function is used to see what events have occurred.

Format HANDLEEVENT()

Parameters N/A

Returns The ID of the event that occurred. One event at a time will be returned through this function. The order of the events are based on priority. The priority is based on the ID number of the event, with the exception of the timer events, which have the highest priority.



Example: Here are examples of how to use the **HANDLEEVENT** command:

```

1 REM This example shows how to override the feed key functionality
1 REM using the event system. Why waste a label when you could put
1 REM valuable information there
AUTONUM 1,1
CLOSE ALL
LET ZPLPORT = 1
OPEN #ZPLPORT: NAME "ZPL"
LET FEEDKEY = 3
LET TMP = REGISTEREVENT(FEEDKEY, 0, 1)
DO WHILE 1 = 1
LET EVT = HANDLEEVENT()
IF EVT = FEEDKEY THEN
GOSUB PRINTINFO
END IF
SLEEP 1
LOOP
REM ***** SUBROUTINE PRINTINFO ***
REM *** expects ZPLPORT *****
SUB PRINTINFO
PRINT #ZPLPORT: "^XA"
PRINT #ZPLPORT: "^F030,30^A0N,50,50";
PRINT #ZPLPORT: "^FDZebra Technologies^FS"
PRINT #ZPLPORT: "^F030,85^A0N,35,35";
PRINT #ZPLPORT: "^FDwww.zebra.com^FS"
PRINT #ZPLPORT: "^F030,125^A0N,35,35";
PRINT #ZPLPORT: "^FDsupport.zebra.com^FS"
PRINT #ZPLPORT: "^F030,165^A0N,35,35";
PRINT #ZPLPORT: "^FDFW Version: ";
PRINT #ZPLPORT: GETVAR$("appl.name") & "^FS"
PRINT #ZPLPORT: "^F030,205^A0N,35,35";
PRINT #ZPLPORT: "^FDPrinter Unique ID:";
PRINT #ZPLPORT: GETVAR$("device.unique_id") & "^FS"
PRINT #ZPLPORT: "^F030,245^A0N,35,35";
PRINT #ZPLPORT: "^FDActive Network: ";
PRINT #ZPLPORT: GETVAR$("ip.active_network") & "^FS"
PRINT #ZPLPORT: "^F030,285^A0N,35,35";
PRINT #ZPLPORT: "^FDZBI Memory Usage: ";
PRINT #ZPLPORT: GETVAR$("zbi.start_info.memory_alloc") & "^FS"
PRINT #ZPLPORT: "^F030,325^A0N,35,35";
PRINT #ZPLPORT: "^FDOdometer: ";
PRINT #ZPLPORT: GETVAR$("odometer.total_print_length") & "^FS"
PRINT #ZPLPORT: "^XZ"

```

Comments None

TRIGGEREVENT



This function allows for front panel buttons to be triggered programmatically.

Format TRIGGEREVENT(X)

Parameters

X = the ID of the event from the possible event list to TRIGGER.

See the following printer tables for events that can be triggered by this command:

- *Xi4/RXi4/XiIIIPlus/PAX4/105SL/ZE500 on page 501*
- *105SL Front Panel Key on page 501*
- *ZM400/ZM600/RZ400/RZ600/Z4Mplus/Z6Mplus on page 502*
- *S4M on page 502*

Returns Always returns 0.



Example: Here are examples of how to use the **TRIGGEREVENT** command:

```
1 REM THIS IS AN EXAMPLE OF HOW TO TRIGGER AN EVENT
AUTONUM 1,1
LET PAUSEKEY = 2
DO WHILE 1 = 1
LET A = TRIGGEREVENT(PAUSEKEY)
LET A = SETVAR("device.frontpanel.line2",str$(A))
SLEEP 2
LOOP
```

Comments None

Systems

This section contain miscellaneous systems interface functions. Here's a quick list of these commands:

ISERROR Returns a non-zero value if there is an internal error set in the printer.

ISWARNING Returns a non-zero value if there is an internal warning set in the printer.

SLEEP Specifies the time that the interpreter pauses.

SETERR Sends a message to the printer to set the error flag.

CLRERR Sends a message to the printer to clear the error flag.

ON ERROR Prevents a program from halting in the event of an error.

ISERROR

This function returns a non-zero value if there is an internal error set in the printer. Otherwise, the numeral returned will 0.

Format ISERROR

Parameters N/A

Returns 0 for no errors; 1 if there is an error.



Example: Here is an example of the **ISERROR** command.

```
10 PRINT ISERROR  
RUN  
0
```

Comments None

ISWARNING

This function returns a non-zero value if there is an internal warning set in the printer. Otherwise, the numeral returned will 0.

Format ISWARNING

Parameters N/A

Returns 0 for no errors; 1 if there is an error.



Example: Here is an example of the ISWARNING command.

```
10 PRINT ISWARNING  
RUN  
0
```

Comments None

SLEEP

This command specifies the time that the interpreter pauses. This command could be sent to the printer after sending a label format to be printed. The interpreter pauses in its processing for the amount of time specified.

Format SLEEP <A>

Parameters <A> = the time in seconds (0 to 500) the interpreter pauses.



Example: This is an example of how to use the **SLEEP** command:

```
10 SLEEP 450
```

Comments If a timer is needed, use the **Event** system. The timer will allow for processing other items, where **SLEEP** will stop execution of any ZBI commands for the specified **SLEEP** period.

This is a program command and must be preceded by a line number.

Calling **SLEEP** with <A> set to zero will force the ZBI task to yield to the rest of the system and allow any pending tasks to run (e.g., pending ZPL commands). If there are no pending tasks, ZBI will sleep for a minimum of 8 milliseconds.

SETERR

This command sends a message to the printer to set the error flag. A logical interpreter flag is triggered in the printer. This error is referenced as a BASIC Forced Error.

Format SETERR

Parameters N/A



Example: An example of the **SETERR** and **CLRERR** commands.

```
AUTONUM 1,1
OPEN #1:NAME "ZPL"
PRINT #1: "^XA^SXO,A,Y,Y^XZ"
CLOSE #1
FOR I=1 TO 10
SLEEP 5
IF MOD(I,2)=1 THEN
SETERR
ELSE
CLRERR
ENDIF
NEXT I
```

Comments This is a program command and must be preceded by a line number.

CLRERR

This command sends a message to the printer to clear the error flag. A logical interpreter flag is cleared in the printer. This error is referenced as a BASIC Forced Error.

Format 10 CLRERR

Parameters N/A



Example: See [SETERR on page 514](#).

Comments This is a program command that is preceded by a line number.

ON ERROR

The **ON ERROR** command can be used to prevent a program from halting in the event of an error. If an error occurs in a previous line during program execution, the **ON ERROR** statement calls the **GOTO** or **GOSUB** statement and allows the program to continue.

Format

```
ON ERROR GOTO <A>
ON ERROR GOSUB <A>
```

Parameters <A> = the destination location in the program should an error be triggered on the previous line.



Example: This is an example of how to use the **ON ERROR** command:

```
30 LET A = B/C
40 ON ERROR GOTO 100
...
100 PRINT "DIVIDE BY ZERO OCCURRED"
110 LET A = 0
120 GOTO 50
...
```

Example: See *TCP Server* [on page 485](#) or *UDP Server* [on page 487](#).

Comments

If there is no error, this line is ignored.

This is a program command that is preceded by a line number.

Applicator Functions

The printer applicator port option can be controlled in part or completely by ZBI 2. When ZBI takes control of a pin, the printer's built-in applicator functionality will not have access to that pin. This function will allow the printer to perform some of the functionality that a programmable logic controller (PLC) could.

AUXPORT_STEALPIN Takes control of a pin and allows ZBI to perform other actions on the pin.

AUXPORT_SETPIN Sets the output level on an applicator pin.

AUXPORT_GETPIN Retrieves the state of the applicator pin.

AUXPORT_RELEASEPIN Returns a pin controlled by ZBI to normal printer operation.

AUXPORT_STEALPIN



This function will take control of a pin and allow ZBI to perform other actions on the pin.

Format AUXPORT_STEALPIN(X)

Parameters X = perform action on this applicator port pin.

Returns This function returns -1 upon failure and 0 upon success.



Example: This is an example of the AUXPORT_STEALPIN command:

```
1 REM Demo applicator to show control of applicator pins
1 REM on the printer
1 REM The application is to create a light pole with an
1 REM external feed button
AUTONUM 1,1
LET RED = 9
LET YELLOW = 10
LET GREEN = 11
LET BUTTON = 4
LET FEED_KEY = 3
LET TMP = AUXPORT_STEALPIN(RED)
LET TMP = AUXPORT_STEALPIN(YELLOW)
LET TMP = AUXPORT_STEALPIN(GREEN)
LET TMP = AUXPORT_STEALPIN(BUTTON)
DO WHILE 1 = 1
SLEEP 1
IF ISERROR = 1 THEN
LET TMP = AUXPORT_SETPIN(RED,1)
LET TMP = AUXPORT_SETPIN(YELLOW,0)
LET TMP = AUXPORT_SETPIN(GREEN,0)
ELSE IF ISWARNING = 1 THEN
LET TMP = AUXPORT_SETPIN(RED,0)
LET TMP = AUXPORT_SETPIN(YELLOW,1)
LET TMP = AUXPORT_SETPIN(GREEN,0)
ELSE
LET TMP = AUXPORT_SETPIN(RED,0)
LET TMP = AUXPORT_SETPIN(YELLOW,0)
LET TMP = AUXPORT_SETPIN(GREEN,1)
END IF
IF AUXPORT_GETPIN(BUTTON) = 1 THEN
LET A = TRIGGEREVENT(FEED_KEY)
END IF
LOOP
```

Comments If this pin is not controlled via ZBI (power pin), this function will return -1.

AUXPORT_SETPIN



This function sets the output level on an applicator pin.

Format AUXPORT_SETPIN(X,Y)

Parameters

X = perform action on this applicator port pin.

Y = The value to set on the pin (1 = high, 0 = low).

Returns This function returns -1 upon failure and 0 upon success.



Example: See *AUXPORT_STEALPIN* on page 517.

Comments If this pin is not controlled via ZBI (power pin), this function will return -1. See *AUXPORT_STEALPIN* on page 517.

AUXPORT_GETPIN



Description This function will retrieve the state of the applicator pin.

Format AUXPORT_GETPIN(**X**)

Parameters **X** = perform action on this applicator port pin.

Returns This function returns 1 if pin is in high state, 0 in low state, and -1 upon failure.



Example: See *AUXPORT_STEALPIN* on page 517.

Comments If this pin is not controlled via ZBI (power pin), this function will return -1. See *AUXPORT_STEALPIN* on page 517.

AUXPORT_RELEASEPIN



Description This function returns a pin controlled by ZBI to normal printer operation.

Format AUXPORT_RELEASEPIN(X)

Parameters X = perform action on this applicator port pin.

Returns This function returns -1 upon failure and 0 upon success.



Example: This is an example of the AUXPORT_RELEASEPIN command:
90 LET TMP = AUXPORT_RELEASEPIN(X)

Comments If this pin is not controlled via ZBI (power pin), this function will return -1. See [AUXPORT_STEALPIN](#) on page 517.

String Functions

This section identifies how to handle string manipulation. Here is a quick list of these commands:

LCASE\$ Converts a string to all lowercase characters.

CHR\$ Takes a value between 0 and 255 and puts that value into a string.

LTRIM\$ Removes leading spaces from a string.

REPEAT\$ Creates multiple copies of a string combined into a new string.

RTRIM\$ Returns a string with trailing spaces removed

SPLIT Splits a string into sub-strings

SPLITCOUNT Returns the number of sub-strings that would be returned by the SPLIT function.

UCASE\$ Converts a string to all uppercase characters

EXTRACT\$ Searches for a string based on a starting and ending string.

ORD Returns the ASCII value of the first character of string A\$.

POS Returns the location of the first occurrence of a search string in the target string.

LEN Returns the length of a string.

LCASE\$

This function will convert a string to all lowercase characters.

Format LCASE\$ (A\$)

Parameters (A\$) = the string that will be converted

Returns The characters in A\$ converted to lowercase.



Example: This is an example of how to use the **LCASE\$** command.

```
10 LET B$=LCASE$ ("Hello World")
```

```
20 PRINT B$
```

```
RUN
```

```
hello world
```

Comments This will only work on non-accented Latin characters, A-Z.

CHR\$

This function takes a value between 0 and 255 and puts that value into a string.

Format CHR\$(VAL)

Parameters (VAL)= The numeric value of the string character.

Returns A single character string containing the value entered.



Example: This is an example of how to use the CHR\$ command to easily put control characters into strings:

```
10 LET NULL$=CHR$(0)
```

```
20 LET STX$=CHR$(2)
```

```
30 LET ETX$=CHR$(3)
```

```
40 LET EOT$=CHR$(4)
```

Comments None

LTRIM\$

This function removes leading spaces from a string.

Format LTRIM\$(A\$)

Parameters (A\$) = the string to convert.

Returns The string in A\$ with no spaces.



Example: This is an example of how to use the LTRIM\$(A\$) command:

```
10 LET A$=" Hello"  
20 PRINT LTRIM$(A$)  
RUN  
Hello
```

Comments None

REPEAT\$

This function creates multiple copies of a string combined into a new string.

Format REPEAT\$(A\$,M)

Parameters

A\$ = the base string to duplicate

M = the number of times to duplicate A\$

Returns A string containing M copies of A\$. **Note:** When M=0, an empty string is returned.



Example: This is an example of how to use the REPEAT\$ (A\$, M) command:

```
10 PRINT REPEAT$("Hello",3)
```

```
RUN
```

```
HelloHelloHello
```

Comments None

RTRIM\$

This function returns a string with trailing spaces removed.

Format RTRIM\$(A\$)

Parameters (A\$) = the base string

Returns A\$ with trailing spaces removed.



Example: This is an example of how to use the RTRIM\$(A\$) command:

```
10 LET A$="Hello "  
20 LET B$="World"  
30 PRINT A$ & B$  
40 PRINT RTRIM$(A$)& B$  
RUN  
Hello World  
HelloWorld
```

Comments None

SPLIT



Description This function allows a string to be split into sub-strings

Format

```
SPLIT(DEST$, SOURCE$, DELIMITER$)  
SPLIT(DEST$, SOURCE$, DELIMITER$, MAXCOUNT)
```

Parameters

DEST\$ = the array to populate with the sub-strings created by the split

SOURCE\$ = the string that will be searched for the provided delimiter

DELIMITER\$ = the delimiter string (may be more than one character) to search for

MAXCOUNT = the maximum number of sub-strings the string should be split into. A negative value will return every sub-string created by the split. A value of zero will return empty strings in the array. If not specified, the limit will be the maximum size of the array.

Returns The number of sub-strings placed into the DEST\$ array. If the number of sub-strings is less than the size of DEST\$, the remaining elements of the array will be set to empty strings.

Table 26:**Example 1:** This is an example of how to use the SPLIT command:

```

1 REM Example - This example show how the SPLIT and SPLITCOUNT
1 REM commands can be
1 REM used to merge a comma separated variable string(CSV)
1 REM into a stored format
AUTONUM 1,1
SLEEP 10
DECLARE STRING TESTDATA$(5)
REM data format = <Format Name>,<VAR 1>,<VAR 2>,...,<VAR N>
LET TESTDATA$(1) = "E:PRICETAG.ZPL,FRED'S OATS,$1.25,C:126789:325,123456789"
LET TESTDATA$(2) = "E:PRICETAG.ZPL,FRED'S OATS,$2.25,C:126789:325,123456789"
LET TESTDATA$(3) = "E:PRICETAG.ZPL,FRED'S OATS,$3.25,C:126789:325,123456789"
LET TESTDATA$(4) = "E:PRICETAG.ZPL,FRED'S OATS,$4.25,C:123489:325,123456789"
LET TESTDATA$(5) = "E:PRICETAG.ZPL,FRED'S OATS,$5.25,C:123459:325,123456789"
LET ZPLPORT = 2
OPEN #ZPLPORT: NAME "ZPL"
FOR T = 1 TO 5
LET DATA$ = TESTDATA$(T)
GOSUB CSVPRINTER
NEXT T
END
REM ***** Subroutine CSVPRINTER, expects DATA$ and ZPLPORT *****
SUB CSVPRINTER
LET CNT = SPLITCOUNT(DATA$, ",")
DECLARE STRING SPLITSTRING$(CNT)
ON ERROR GOTO RECOVERY
LET CNT = SPLIT(SPLITSTRING$,DATA$,",")
PRINT #ZPLPORT: "^XA^XF";SPLITSTRING$(1);"^FS"
IF CNT >= 2 THEN
FOR I = 2 TO CNT
PRINT #ZPLPORT: "^FN";I-1;"^FD";SPLITSTRING$(I);"^FS"
NEXT I
END IF
PRINT #ZPLPORT: "^XZ"
SUB RECOVERY
RETURN

```



Example 2: This is an example of how to use the `SPLIT` command:

```

1 REM Example - Shows how the SPLIT and SPLITCOUNT commands can be used to
1 REM merge a comma separated variable string(CSV) into a stored format
AUTONUM 1,1
SLEEP 10
DECLARE STRING TESTDATA$(5)
REM data format = <Format Name>,<VAR 1>,<VAR 2>,...,<VAR N>
LET F$="E:PRICETAG.ZPL"
LET TESTDATA$(1) = F$&" ,FRED'S ROLLED OATS,$1.25,C:123456789:325,123456789"
LET TESTDATA$(2) = F$&" ,FRED'S ROLLED OATS,$2.25,C:123456789:325,123456789"
LET TESTDATA$(3) = F$&" ,FRED'S ROLLED OATS,$3.25,C:123456789:325,123456789"
LET TESTDATA$(4) = F$&" ,FRED'S ROLLED OATS,$4.25,C:123456789:325,123456789"
LET TESTDATA$(5) = F$&" ,FRED'S ROLLED OATS,$5.25,C:123456789:325,123456789"
LET ZPLPORT = 2
OPEN #ZPLPORT: NAME "ZPL"
FOR T = 1 TO 5
LET DATA$ = TESTDATA$(T)
GOSUB CSVPRINTER
NEXT T
END
REM ***** Subroutine CSVPRINTER, expects DATA$ and ZPLPORT *****
SUB CSVPRINTER
LET CNT = SPLITCOUNT(DATA$, ",")
DECLARE STRING SPLITSTRING$(CNT)
ON ERROR GOTO RECOVERY
LET CNT = SPLIT(SPLITSTRING$,DATA$,",")
PRINT #ZPLPORT: "^XA^XF";SPLITSTRING$(1);"^FS"
IF CNT >= 2 THEN
FOR I = 2 TO CNT
PRINT #ZPLPORT: "^FN";I-1;"^FD";SPLITSTRING$(I);"^FS"
NEXT I
END IF
PRINT #ZPLPORT: "^XZ"
SUB RECOVERY
RETURN

```

Comments If the delimiter is an empty string, or does not appear in the **SOURCE\$** string, the first entry of the array will be the source string and all other elements will be empty strings.

When the **SPLIT** function encounters a delimiter at the beginning or end of the source string, or two delimiters in a row, it populates the corresponding array element with an empty string.

If **MAXCOUNT** is larger than the number of returned sub-strings (N), the last **MAXCOUNT** - N array elements will be empty strings. If **MAXCOUNT** is larger than the destination array or is negative, the size of the array will be used as the **MAXCOUNT**. Therefore, the smallest value among the value of **MAXCOUNT**, the size of the return array, or the number of sub-strings found determines the maximum number of sub-strings that will be returned.

If **MAXCOUNT** is less than the number of delimiters in a string the last string in the array will hold the end of the string starting from where the last delimiter was found. For example, if **SOURCE\$** = "one,two,three,four,five", **DELIMITER\$** = ",", and **MAXCOUNT** = 2, the output would be two strings: "one" and "two,three,four,five".

If a two dimensional array is provided for **DEST\$**, the array will be filled linearly. For example, an array that is 2 x 3 (for example, **DECLARE STRING MYARRAY\$(2,3)**) will be filled from (0,0), then (0,1) up to (2,3).

SPLITCOUNT



Description This function returns the number of sub-strings that would be returned by the SPLIT function.

Format SPLITCOUNT(SOURCE\$, DELIMITER\$)

Parameters

SOURCE\$ = the string that will be searched for the provided delimiter.

DELIMITER\$ =5

Returns The number of sub-strings that would be returned by the SPLITCOUNT function.



Example: This function shows how to determine the number of sub-strings that the SPLITCOUNT command would produce

```
10 LET CNT = SPLITCOUNT("ONE,,FOUR,FIVE,,SEVEN,", ",")
20 PRINT "Number of sub-strings returned is", STR$(CNT)
RUN
Number of sub-strings returned is 8
```

Comments None

UCASE\$

This function converts a string to all uppercase characters.

Format UCASE\$(A\$)

Parameters A\$ = the base string to convert

Returns A\$ converted to uppercase.



Example: This is an example of how to use the UCASE\$(A\$) command:

```
10 LET A$="Zebra Technologies"  
20 PRINT UCASE$(A$)  
RUN  
ZEBRA TECHNOLOGIES
```

Example: This is an example of how to capitalize a line.

```
10 LET A$="The Cow jUmped Over THE Moon."  
20 LET A$=LCASE$(A$)  
30 LET A$(1:1)=UCASE$(A$(1:1))  
40 PRINT A$  
RUN  
The cow jumped over the moon.
```

Comments This will only convert non-accented Latin characters, a-z.

EXTRACT\$

This function searches for a string based on a starting and ending string. When these two strings are found, the string between them is returned.

Table 27:



Important • If the `EXTRACT$` command encounters a carriage return line feed before encountering the beginning character or the ending character, it returns null.

Format

```
EXTRACT$ (CHANNEL, START$, STOP$)
EXTRACT$ (A$, START$, STOP$)
```

Parameters

CHANNEL = extracts data from this channel

A\$ = the source string

START\$ = Once this string is found, the extract pulls characters immediately following.

STOP\$ = the extraction stops when this string is found



Example: This example shows how to extract the word `Technologies` from this string: `Zebra,Technologies,Corporation.`

This is what the program looks like to accomplish this:

```
10 LET A$ = "Zebra,Technologies,Corporation,"
20 LET DATA$ = EXTRACT$(A$,"","","")
```



Example: This example shows how the `EXTRACT$` command works from an open port:

```
10 OPEN #1: NAME "SER"
20 LET DATA$ = EXTRACT$(1,"","","")
```

Notice how the quotes are used to show a literal character, in this case a comma.



Example: This example shows how the start and stop points are variable; a variable name is used instead of the literal:

```
10 LET B$ = ","
20 LET A$ = "Zebra,Technologies,Corporation"
30 LET DATA$ = EXTRACT$(A$,B$,B$)
40 PRINT DATA$
RUN
Technologies
```



Example: This example shows how an empty string can be used to extract from the start of the input string to the end string:

```
10 LET IN$ = "BLAH BLAH <END>"
20 LET B$ = EXTRACT$(IN$, "", "<END>")
30 PRINT B$
RUN
BLAH BLAH
```



Example: This example will use an empty string to extract to the end of a line:

```
10 LET IN$ = "BLAH <START> THE DATA"
20 LET B$ = EXTRACT$(IN$, "<START>", "")
30 PRINT B$
RUN
THE DATA
```

Comments EXTRACT\$ reads in and discards data until the start criteria is met. Then, all data is returned up to the stop criteria.

ORD

This function returns the ASCII value of the first character of string A\$.

Format ORD(A\$)

Parameters A\$ = Input string: only the first character will be used.

Returns The ASCII value of the first character.



Example: This is an example of how to use the ORD (A\$) command:

```
10 LET A$="ABC"  
20 PRINT ORD(A$)  
RUN  
65
```

Comments None

POS

This function returns the location of the first occurrence of a search string in the target string. It can be assigned an index.

Format

```
POS(A$,B$)
POS(A$,B$,M)
```

Parameters

A\$ = the target string to search

B\$ = the search string to find in **A\$**

M = The index to start looking for **B\$**. If omitted, the search will start at the beginning of the string. **M** must be greater than zero.

Returns The location of the string. If the string is not found, this will return 0.



Example: This is an example of how to use the POS command:

```
10 LET A$="Hello World"
20 LET B$="o"
30 PRINT POS(A$,B$)
40 PRINT POS(A$,B$,1)
50 PRINT POS(A$,B$,6)
RUN
5
5
8
```

Comments None

LEN

This function returns the length of a string.

Format LEN(A\$)

Parameters A\$ = the target string from which to determine the length.

Returns The length of the string.



Example: This example identifies the length of a string. Hello World is 11 characters, as follows:

```
10 LET A$="Hello World"  
20 PRINT LEN(A$)  
RUN  
11
```

Comments None

Math Functions

This section identifies how to handle mathematical calculations. Here is a quick list of these commands:

STR\$ Converts a number to a string.

MAX Returns the greater value between two numbers.

MIN Returns the smaller value of two numbers.

MAXNUM returns the largest number permitted by this machine.

MOD Computes the remainder from division.

VAL Evaluates the number represented by a string.

INTTOHEX\$ Takes a numeric value and converts it into a hexadecimal string.

HEXTOINT Converts hexadecimal strings to integers.

STR\$

This function converts a number to a string.

Format STR\$(X)

Parameters X = the number to convert to a string

Returns A string representing X.



Example: This is an example of how to use the STR\$(X) command:

```
10 LET A=53
20 PRINT STR$(A)
RUN
53
```

Comments None

MAX

This function returns the greater value between two numbers.

Format MAX(X,Y)

Parameters

X = the first number to compare

Y = the second number to compare

Returns The greater of X or Y.



Example: This is an example of how to use the MAX (X , Y) command:

```
10 LET A=-2
20 LET B=1
30 PRINT MAX(A,B)
RUN
1
```

Comments None

MIN

This function returns the smaller value of two numbers.

Format MIN(X,Y)

Parameters

X = the first number to compare

Y = the second number to compare

Returns The smaller of X or Y.



Example: This is an example of how to use the MIN (X , Y) command:

```
10 LET A=-2
20 LET B=0
30 PRINT MIN(A,B)
RUN
-2
```

Comments None

MAXNUM

This function returns the largest number permitted by this machine: 2,147,483,647.

Format MAXNUM

Parameters N/A

Returns The largest number that the NUMERIC type can handle (2,147,483,647).



Example: This is an example of how to use the MAXNUM command:

```
10 PRINT MAXNUM
```

```
RUN
```

```
2147483647
```

Comments None

MOD

This function computes the remainder from division. (This is known as the modulus.)

Format MOD(X,Y)

Parameters

- X = the value to be modulated (numerator).
- Y = the base number or divisor (denominator).

Returns The remainder of the division (X/Y).



Example: This is an example of how to use the MOD (X , Y) command:

```
10 PRINT MOD(25,10)
20 PRINT MOD(2,1)
30 PRINT MOD(3,2)
40 PRINT MOD(9,2)
50 PRINT MOD(-2,9)
60 PRINT MOD(2,0)
RUN
5
0
1
1
-2
ERROR OCCURRED ON LINE 60:DIVIDE BY ZERO
```

Comments None

VAL

This function evaluates the number represented by a string.

Format VAL(A\$)

Parameters A\$ = This is the input string to pull the number from. Non-numbers are ignored.

Returns The numeric representation of the string.



Example: This is an example of how to use the VAL (A\$) command:

```
10 LET A$="123"  
20 LET C=VAL(A$)  
30 PRINT C  
RUN  
123  
  
PRINT VAL("321A123")  
321123
```

Comments None

INTTOHEX\$



Description This function will take a numeric value and convert it into a hexadecimal string. The range of values for integers is:

-2,147,483,648 to +2,147,483,647

Format INTTOHEX\$(A)

Parameters A = The numeric value to convert.

Returns A string representing the integer in hex.



Example: These print statements show the output of the **INTTOHEX\$** function given different values.

```
PRINT INTTOHEX$(1)
```

```
1
```

```
PRINT INTTOHEX$(10)
```

```
A
```

```
PRINT INTTOHEX$(16)
```

```
10
```

```
PRINT INTTOHEX$(20)
```

```
14
```

```
PRINT INTTOHEX$(30)
```

```
1E
```

```
PRINT INTTOHEX$(100)
```

```
64
```

```
PRINT INTTOHEX$(123124)
```

```
1E0F4
```

```
PRINT INTTOHEX$(-5)
```

```
0
```

```
PRINT INTTOHEX$(-99)
```

```
0
```

Comments Negative values will be returned as 0.

HEXTOINT



This function will convert hexadecimal strings to integers.

Format HEXTOINT(A\$)

Parameters A\$ = The hex string to convert.

Returns A integer string computed from the hexadecimal string.



Example: These print statements show the output of the **INTTOHEX** function given different values.

```
PRINT HEXTOINT("0")
0

PRINT HEXTOINT("A")
10

PRINT HEXTOINT("a")
10

PRINT HEXTOINT("1A")
26

PRINT HEXTOINT("10")
16

PRINT HEXTOINT("AaAa")
43690

PRINT HEXTOINT("AAAA")
43690

PRINT HEXTOINT("-1")
0

PRINT HEXTOINT("-A")
0
```

Comments Negative values will be returned as 0.

Array Functions

This section describes the functions to search, resize, and query arrays.

REDIM Changes the size of an array.

INSERTROW Inserts a new row into an existing array.

DELROW Deletes a new row from an existing array

ROWSIZE Returns the number of rows in an array.

COLUMNSIZE Returns the number of columns in an array.

FIND Searches a string array for an occurrence of a sub-string.

REDIM



This command will change the dimensions of an array.

Format

```
REDIM <ARRAYNAME>(<SIZE>)
REDIM <ARRAYNAME>(<ROWS>,<COLUMNS>)
REDIM <ARRAYNAME$>(<SIZE>)
REDIM <ARRAYNAME$>(<ROWS>,<COLUMNS>)
```

Parameters

<SIZE> = new number of entries in a single dimension array.
 <ROWS> = new number of rows in a two dimensional array.
 <COLUMNS> = new number of columns in a two dimensional array.



Example: This example shows how to change a one dimensional numeric array.

```
10 DECLARE NUMERIC SCORES(3)
20 LET SCORES(1) = 85
30 LET SCORES(2) = 92
40 LET SCORES(3) = 98
50 REDIM SCORES(2) ! Discard the last one
```



Example: This example shows how to change a two dimensional string array.

```
10 DECLARE STRING NAMEAGES$(3,2)
20 LET NAMEAGES$(1,1) = "Abraham"
30 LET NAMEAGES$(1,2) = "Lincoln"
40 LET NAMEAGES$(2,1) = "Dwight"
50 LET NAMEAGES$(2,2) = "Eisenhower"
60 LET NAMEAGES$(3,1) = "Theodore"
70 LET NAMEAGES$(3,2) = "Roosevelt"
80 REDIM NAMEAGES$(5,2) ! Make room for more
```

Comments The **REDIM** must have the same number of dimensions as the original declaration of the array.

- If the array has two dimensions, the second array bound cannot change. It must have the same value as the original declaration.
- If **REDIM** makes an array smaller, elements (or rows, for a two dimensional array) at the end of the array are discarded.
- If **REDIM** makes an array larger, elements (or rows) are added at the end of the array, and initialized as they would be with a **DECLARE**.

This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

INSERTROW



This command will insert a new row into an existing array.

Format INSERTROW (<ARRAYNAME>, <INDEX>)

Parameters

<ARRAYNAME> = array where the row will be inserted

<INDEX> = index of the row in the array that the new row will be inserted before



Example: This example shows how to insert a row into the middle of an array.

```
10 DECLARE NUMERIC SCORES(3)
20 LET SCORES(1) = 85
30 LET SCORES(2) = 92
40 LET SCORES(3) = 98
50 INSERTROW(SCORES, 2)
60 LET SCORES(2) = 100
```



Example: This example shows how to add a row into the end of an array.

```
10 DECLARE NUMERIC SCORES(3)
20 LET SCORES(1) = 85
30 LET SCORES(2) = 92
40 LET SCORES(3) = 98
50 INSERTROW(SCORES, 4)
60 LET SCORES(4) = 100
```

Comments Inserting a row increases the size of the array by one row, and moves all the rows from **INDEX** to the end of the array up one row, leaving an empty row at position **INDEX**.

INDEX cannot be any larger the number of rows in the array plus one. If the number of rows plus one is provided, the new row will be added to the end of the array.

This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

DELROW



This command will delete a row from an existing array.

Format DELROW (<ARRAYNAME>, <INDEX>)

Parameters

<ARRAYNAME> = the array where the row will be deleted

<INDEX> = index of the row to delete from the array



Example: This example shows how to delete a row from the middle of an array.

```
10 DECLARE NUMERIC SCORES(5)
20 LET SCORES(1) = 85
30 LET SCORES(2) = 92
40 LET SCORES(3) = 98
50 LET SCORES(4) = 45
60 LET SCORES(5) = 100
70 DELROW(SCORES, 4) ! Remove the low score
```

Comments This decreases the size of A by one row, and moves all the rows from INDEX to the end of the array down by one, overwriting the row at position INDEX.

INDEX cannot be any larger the number of rows in the array.

If the array only has one row, that row may not be deleted.

This can be an interactive command that takes effect as soon as it is received by the printer, or a program command that is preceded by a line number.

ROWSIZE



This function will return the number of rows in an array.

Format

```
ROWSIZE(A)  
ROWSIZE(A$)
```

Parameters

A = integer array to query for the number of rows.
A\$ = string array to query for the number of rows.

Returns Returns a 0 if the variable is not an array. Returns the number of elements in the array if the array has only one dimension. Returns the size of the first dimension if the array has two dimensions.



Example: This example shows how to determine the number of elements in a one dimensional string array.

```
10 DECLARE STRING NAMES$(3)  
20 LET NAMES$(1) = "Fred"  
30 LET NAMES$(2) = "Wilma"  
40 LET NAMES$(3) = "Barney"  
50 REDIM NAMES$(4) ! Make room for Betty  
60 LET NAMES$(4) = "Betty"  
70 LET NUMOFNAMES = ROWSIZE(NAMES$)  
80 PRINT NUMOFNAMES
```



Example: This example shows how to determine the number of rows in a two dimensional numeric array.

```
10 DECLARE NUMERIC SQROFTWOLOOKUP(3,2)  
20 LET SQROFTWOLOOKUP (1,1) = 1  
30 LET SQROFTWOLOOKUP (1,2) = 2  
40 LET SQROFTWOLOOKUP (2,1) = 2  
50 LET SQROFTWOLOOKUP (2,2) = 4  
60 LET SQROFTWOLOOKUP (3,1) = 3  
70 LET SQROFTWOLOOKUP (3,2) = 8  
80 LET NUMOFSQRS = ROWSIZE(SQROFTWOLOOKUP)  
90 PRINT NUMOFSQRS
```

COLUMNSIZE



This function will return the number of columns in an array.

Format

```
COLUMNSIZE(A)  
COLUMNSIZE(A$)
```

Parameters

A = integer array to query for the number of columns.
A\$ = string array to query for the number of columns.

Returns A 0 if the variable is not an array. Returns 1 if the array has only one dimension. Returns the size of the second dimension if the array has two dimensions.



Example: This example shows how to determine the number of elements in a one dimensional string array.

```
10 DECLARE STRING NAMES$(3)  
20 LET NAMES$(1) = "Fred"  
30 LET NAMES$(2) = "Wilma"  
40 LET NAMES$(3) = "Barney"  
50 REDIM NAMES$(4) ! Make room for Betty  
60 LET NAMES$(4) = "Betty"  
70 LET NUMOFCOLS = COLUMNSIZE(NAMES$)  
80 PRINT NUMOFCOLS
```



Example: This example shows how to determine the number of columns in a two dimensional numeric array.

```
10 DECLARE NUMERIC SQROFTWOLOOKUP(3,2)  
20 LET SQROFTWOLOOKUP (1,1) = 1  
30 LET SQROFTWOLOOKUP (1,2) = 2  
40 LET SQROFTWOLOOKUP (2,1) = 2  
50 LET SQROFTWOLOOKUP (2,2) = 4  
60 LET SQROFTWOLOOKUP (3,1) = 3  
70 LET SQROFTWOLOOKUP (3,2) = 8  
80 LET COLCNT = COLUMNSIZE(SQROFTWOLOOKUP)  
90 PRINT COLCNT
```

FIND



This function will find an element of a string array that contains an identified search string.

Format

```
FIND(A$, B$)
FIND(A$, B$, START)
FIND(A$, COLUMN, B$)
FIND(A$, COLUMN, B$, START)
```

Parameters

A\$ = string array to search for B\$.
B\$ = string to search for within A\$.
START = index within a single dimensional array, or row for a two dimensional array, to start the search.
COLUMN = column to isolate search to in a two dimensional array. This must be supplied if A\$ is a two dimensional array.

Returns Returns a 0 if B\$ is not found or if there was an error. Otherwise, returns the index that contains the first occurrence of the string B\$ (the element index for one dimensional arrays, the row for two dimensional arrays).



Example: This example shows how to find a string in a one dimensional array.

```
10 DECLARE STRING NAMES$(4)
20 LET NAMES$(1) = "Fred"
30 LET NAMES$(2) = "Wilma"
40 LET NAMES$(3) = "Barney"
50 LET NAMES$(4) = "Betty"
60 LET BARNEYIX = FIND(NAMES$, "Bar")
70 PRINT "Found Barney in element "; STR$(BARNEYIX)
```



Example: This example shows how to find a string that occurs more than once in a two dimensional array.

```

10 DECLARE STRING CLOTHING$(5,2)
20 LET TYPECOL      = 1
30 LET MATERIALCOL = 2
40 LET CLOTHING$(1,1) = "Gloves"
50 LET CLOTHING$(1,2) = "Knit"
60 LET CLOTHING$(2,1) = "Pants"
70 LET CLOTHING$(2,2) = "Cotton"
80 LET CLOTHING$(3,1) = "Gloves"
90 LET CLOTHING$(3,2) = "Leather"
100 LET CLOTHING$(4,2) = "Shirts"
110 LET CLOTHING$(4,2) = "Polyester"
120 LET CLOTHING$(5,2) = "Pants"
130 LET CLOTHING$(5,2) = "Denim"
140 LET GLOVEIX = 1
150 DO
160 LET GLOVEIX = FIND(CLOTHING$, TYPECOL, "Gloves", GLOVEIX)
170 IF NOT GLOVEIX = 0 THEN
180 PRINT CLOTHING$(GLOVEIX, MATERIALCOL), "gloves are available"
190 LET GLOVEIX = GLOVEIX + 1
200 END IF
210 LOOP WHILE NOT GLOVEIX = 0

```

Comments COLUMN must be greater than 0.

If START is given, it must be greater than 0.

FIND will match the first occurrence of B\$, even if it is a substring of a string within the A\$ array. For example, "Coat" will be found in both locations 1 and 4.

```

5 DECLARE STRING A$(5)
10 LET A$(1) = "Over Coat"
20 LET A$(2) = "Hat"
30 LET A$(3) = "Jacket"
40 LET A$(4) = "Coat"
50 LET A$(5) = "Boots"

```

If an exact match is needed, FIND should be called until 0 is returned or the item is found and confirmed. To confirm, check the item against the expected item, it should match exactly. See CSV Program [on page 560](#) for an example showing how to do this.

Time and Date Functions

This section describes the functions to access the real time clock option. Here is a quick list of these commands:

DATE\$ Returns the date as a string

TIME\$ Returns the current time in a string.

DATE Gets the current date as a number.

TIME Gets the current time as a number.

DATE\$

This function returns the date as a string.

Format DATE\$

Parameters N/A

Returns The current date in string form YYYYMMDD. If the Real-Time Clock is not installed, an empty string is returned.



Example: This is an example of how to use the DATE\$ command:

```
10 PRINT DATE$  
RUN
```

The result, assuming the date is January 1, 2003 is:

```
20030101
```

Example: This is another example of the DATE\$ command used with the sub-string operator to get the day of the month:

```
10 LET A$=DATE$(7:8)  
20 IF A$ <> DATE$(7:8)  
30 LET A$=DATE$(7:8)  
40 IF A$="01"  
50 PRINT "IT IS THE FIRST OF THE MONTH"  
60 END IF  
70 END IF  
80 SLEEP 100  
90 GOTO 20
```

Comments None

TIME\$

This function returns the current time in a string.

Format TIME\$

Parameters N/A

Returns This function returns the time of day in format HH:MM:SS (hours:minutes:seconds). If the Real-Time Clock is not installed, an empty string is returned.



Example: This is an example of how to use the TIME\$ command:

```
10 PRINT TIME$  
RUN  
10:00:00
```

Comments None

DATE

This function gets the current date as a number.

Format DATE

Parameters N/A

Returns This function returns the current date in YYYYDDD format, where YYYY is the year and DDD is the number of days since the beginning of the year. If the Real-Time Clock is not installed, 0 is returned.



Example: This example assumes the current date is January 1, 2003:

```
10 PRINT DATE
RUN
2003001
```

Comments None

TIME

This function gets the current time as a number.

Format TIME

Parameters N/A

Returns This function returns the time past midnight (2400h) in seconds. If the Real-Time Clock is not installed, 0 is returned.



This is an example of how to use the TIME command [assuming the time is one minute past midnight]:

Example:

```
10 PRINT TIME
RUN
60
```

Comments None

Set/Get/Do Interactions

The printer's Set/Get/Do data can be directly accessed via ZBI. For a complete listing of what can be accessed, see *SGD Printer Commands* on page 571, or type the following:

```
! U1 getvar "allcv"
```

Here's a quick list of these commands:

SETVAR Allows the direct setting of printer parameters.

GETVAR\$ Retrieves printer parameters.

SETVAR



Description SETVAR allows the direct setting of printer parameters.

Format SETVAR (PARAM\$, VALUE\$)

Parameters

PARAM\$ = The printer parameter to set.
VALUE\$ = the value to set

Returns Parameter dependent.

Table 28:



Example: This is an example of the SETVAR command:

```
AUTONUM 1,1
LET OUTSTR$ = "Processing"
LET LOOPCTR = 200
LET TIMER5 = 17
LET TMP = REGISTEREVENT(TIMER5, 0, 1000)
DO WHILE LOOPCTR > 0
LET EVT = HANDLEEVENT()
IF EVT = TIMER5 THEN
LET A = SETVAR("device.frontpanel.line2",OUTSTR$)
LET OUTSTR$ = OUTSTR$ & "."
IF LEN(OUTSTR$) >16 THEN
LET OUTSTR$ = "Processing"
END IF
END IF
LET LOOPCTR = LOOPCTR - 1
SLEEP 1
LOOP
LET TMP = UNREGISTEREVENT(TIMER5)
LET A = SETVAR("device.frontpanel.line2","")
END
```

Comments None

GETVAR\$



This function retrieves printer parameters.

Format GETVAR\$ (PARAM\$)

Parameters

PARAM\$ = the printer parameter to get.

Returns The value of the parameter. Refer to *SGD Printer Commands on page 571* for specific parameters.

Table 29:



Example: This is an example of the **GETVAR\$** command:

```

AUTONUM 1,1
LET SGDCOUNT = 7
DECLARE STRING SGDQUERY$(2,SGDCOUNT)
LET SGDQUERY$(1,1) = "appl.name"
LET SGDQUERY$(1,2) = "device.printhead.serialnum"
LET SGDQUERY$(1,3) = "internal_wired.ip.addr"
LET SGDQUERY$(1,4) = "internal_wired.ip.netmask"
LET SGDQUERY$(1,5) = "internal_wired.ip.gateway"
LET SGDQUERY$(1,6) = "internal_wired.ip.port"
LET SGDQUERY$(1,7) = "internal_wired.mac_addr"
FOR I = 1 TO SGDCOUNT
LET SGDQUERY$(2,I) = GETVAR$(SGDQUERY$(1,I))
NEXT I
OPEN #1: NAME "ZPL"
PRINT #1: "^XA"
FOR I = 1 TO SGDCOUNT
PRINT #1: "^FO50,";50*I;"^A0N,25,25^FD";SGDQUERY$(1,I);"=";
PRINT #1: SGDQUERY$(2,I);"^FS"
NEXT I
PRINT #1: "^XZ"

```

Comments None

Example Programs

The next section provides example programs of common tasks using ZBI commands. These programs are also available for download at: <http://www.zebra.com/zbi>

Array Program

This program prompts a user to enter first a name; when it is entered, it is added to an array of all names entered. The user is then prompted to enter an address, which is then added to an array of all addresses entered. After the user enters a total of five names and addresses, the program uses the arrays to print the entered data on five labels.



Example: This is an example of Array

```

1 rem *****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of using arrays to store and use data within 1 rem ZBI.
1 rem *****
1 rem close all ports except for the console
1 rem*****
10 for i = 1 to 9 step 1
20   close #i
30   next i
1 rem *****
1 rem open a port to the print engine
1 rem *****
40 open #1: name "ZPL"
1 rem *****
1 rem create string arrays five elements in size to hold names and
1 rem addresses
1 rem *****
50 declare string name$(5)
60 declare string address$(5)
1 rem *****
1 rem infinite loop to put name and address data from console into
1 rem arrays
1 rem *****
70 do
80 for i = 1 to 5 step 1
90   print "PLEASE ENTER THE NAME"
1 rem *****
1 rem get data from console; input command looks for CRLF
1 rem *****
100  input name$(i)
1 rem *****
1 rem if the user inputs end or END, the program will end
1 rem *****
110  if name$(i) = "END" or name$(i) = "end" then
120    end
130  end if
140  print "PLEASE ENTER THE ADDRESS"
150  input address$(i)
160  if address$(i) = "END" or address$(i) = "end" then
170    end
180  end if
190 next i
200 for index = 1 to 5 step 1 ! For loop To Print data no label
1 rem *****
1 rem semicolon at the end prints with no CRLF
1 rem *****
210  print #1: "^XA^F030,30^A0N,30,30^FD"&NAME$(INDEX)&"^FS";
1 rem *****
1 rem ampersand used to concatenate data into strings
1 rem *****
220  print #1: "^F030,70^A0N,30,30^FD"&ADDRESS$(INDEX)&"^FS^XZ"
230 next index
240 loop ! loops back To Line 60
250 end

```

CSV Program

The following program will initialize and then execute continuously, repeating the same series of operations; process events, read input from the serial port, write any processed data out to the ZPL port, and then process the data read from the serial port.

The program first loads the CSV database E:PRODUCTS.CSV (in PROGRAMINIT subroutine). Then, data read from the serial port is compared against the first column in the database. If an entry is found in the first column of a row (in FINDITEM subroutine), the data for the respective row is inserted into the ZPL format E:PRICELBL.ZPL and printed on a label.



Example 1: This is an example of a CSV program.

```

1 REM SUBROUTINES BELOW...
2 REM
3 REM *****
4 REM             MAIN LOOP - DO NOT MODIFY
5 REM *****
6 REM
7 GOSUB PROGRAMINIT
8 DO WHILE 1 = 1
9 GOSUB PROCESSEVENTS
10 GOSUB GETINPUT
11 GOSUB WRITEOUTPUT
12 GOSUB PROCESSDATA
13 LOOP
14 REM SUBROUTINES BELOW...
15 REM
16 REM *****
17 REM             Program Init
18 REM *****
19 REM
20 SUB PROGRAMINIT
21 LET INPORT = 1
22 LET OUTPORT = 2
23 LET ENDLINE$ = CHR$ ( 13 ) & CHR$ ( 10 )
24 OPEN # INPORT : NAME "SER"
25 OPEN # OUTPORT : NAME "ZPL"
26 DECLARE STRING DATABASE$ ( 1 , 1 )
27 LET COLUMNCOUNT = CSVLOAD ( DATABASE$ , "E:PRODUCTS.CSV" )
28 LET OUTDATA$ = "TABLE WITH " & STR$ ( COLUMNCOUNT ) & " COLUMNS LOADED" & ENDLINE$
29 RETURN
30 REM
31 REM *****
32 REM             Process Events
33 REM *****
34 REM
35 SUB PROCESSEVENTS
36 RETURN
37 REM
38 REM *****
39 REM             Get Input
40 REM
41 REM Writes All Data from the serial port to the string INDATA$
42 REM *****
43 REM
44 SUB GETINPUT
45 IF LEN ( INDATA$ ) < 5000 THEN
46 LET INCOUNT = READ ( INPORT , A$ , 1024 )
47 LET INDATA$ = INDATA$ & A$
48 END IF
49 RETURN
50 REM
51 REM *****
52 REM             Write Output
53 REM
54 REM Writes All Data from the string OUTDATA$ to the ZPL Port
55 REM *****
56 REM
57 SUB WRITEOUTPUT
58 LET OUTCOUNT = WRITE ( OUTPORT , OUTDATA$ , LEN ( OUTDATA$ ) )
59 IF OUTCOUNT > 0 THEN
60 LET OUTDATA$ ( 1 : OUTCOUNT ) = ""
61 END IF
62 RETURN
63 REM
64 REM *****
65 REM             Process Data
66 REM
67 REM Parse the data in the string INDATA$ and write output to OUTDATA$
68 REM *****
69 REM
70 SUB PROCESSDATA
71 IF LEN ( OUTDATA$ ) > 1000 THEN
72 RETURN

```

```

73 END IF
74 REM REMOVE ALL LINE FEEDS
75 DO
76 LET LOC = POS ( INDATA$ , CHR$ ( 10 ) )
77 LET INDATA$ ( LOC : LOC ) = ""
78 LOOP WHILE LOC > 0
79 REM COMPLETED LINE FEED REMOVAL
80 LET LOC = POS ( INDATA$ , CHR$ ( 13 ) ) ! Line ends with CR
81 IF LOC > 0 THEN
82 LET INLINE$ = INDATA$ ( 1 : LOC - 1 )
83 LET INDATA$ ( 1 : LOC ) = ""
84 GOSUB FINDITEM
85 IF ROW > 0 THEN
86 LET OUTDATA$ = OUTDATA$ & "^XA^XFE:PRICELBL.ZPL^FS" & ENDLIN$
87 LET OUTDATA$ = OUTDATA$ & "^FN1^FD" & DATABASE$ ( ROW , 1 ) & "^FS" & ENDLIN$
88 LET OUTDATA$ = OUTDATA$ & "^FN2^FD" & DATABASE$ ( ROW , 2 ) & "^FS" & ENDLIN$
89 LET OUTDATA$ = OUTDATA$ & "^FN3^FD" & DATABASE$ ( ROW , 3 ) & "^FS^XZ" & ENDLIN$
90 END IF
91 END IF
92 RETURN
93 REM
94 REM *****
95 REM Find Item
96 REM
97 REM Search the first column of the database for the exact item requested
98 REM *****
99 REM
100 SUB FINDITEM
101 LET ROW = 0
102 LET EXPECTED$ = INLINE$
103 DO
104 LET FOUNDENTRY$ = ""
105 LET ROW = FIND ( DATABASE$ , 1 , EXPECTED$ , ROW + 1 )
106 IF ROW <> 0 THEN
107 LET FOUNDENTRY$ = DATABASE$ ( ROW , 1 )
108 END IF
109 LOOP WHILE ( ROW <> 0 AND FOUNDENTRY$ <> EXPECTED$ )
110 RETURN

```

DPI Conversion Program

This program converts a ZPL format being sent to the printer on the parallel port to 300 dpi (dots per inch) from 200 dpi (dots per inch). This is done by searching for and extracting ZPL commands with resolution-dependent arguments and scaling the arguments for a 300 dpi printer.



Example: This is an example of dpi conversion:

```

1 rem *****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of converting a printer from 200 dpi (dots
1 rem per inch
1 rem to 300 dpi. This example covers only some of the ZPL commands
1 rem that
1 rem could be affected by converting from 200 to 300 dpi printing.
1 rem *****
1 rem open the ports for input and output
1 rem *****
10 close #1
20 close #2
30 open #1 : name "PAR"
40 open #2 : name "ZPL"
1 rem *****
1 rem create an array with the search parameters
1 rem *****
50 declare string find$(20)
60 let find$(1) = "^FO"
70 let find$(2) = "^A0"
80 let find$(3) = "^GB"
90 let find$(4) = "^XZ"
100 let find$(5) = "^A@"
110 let find$(6) = "^LL"
120 let find$(7) = "^LH"
130 let find$(8) = "FO"

```

```

140 let find$(9) = "A0"
150 let find$(10) = "GB"
160 let find$(11) = "XZ"
170 let find$(12) = "A@"
180 let find$(14) = "LH"
190 let find$(15) = "^BY"
200 let find$(16) = "BY"
210 let find$(17) = "^B3"
220 let find$(18) = "B3"
1 rem *****
1 rem search for the parameters
1 rem *****
300 do
310   let in$ = searchto$(1, find$, 2)
1 rem *****
1 rem once a parameter is found, determine how to handle it
1 rem *****
320   if in$ = "^F0" or in$ = "F0" then
330     gosub 520
340   else if in$ = "^LH" or in$ = "LH" then
350     gosub 520
360   else if in$ = "^A0" or in$ = "A0" then
370     gosub 700
380   else if in$ = "^A@" or in$ = "A@" then
390     gosub 700
400   else if in$ = "^GB" or in$ = "GB" then
410     gosub 1100
420   else if in$ = "^LL" then
430     gosub 1300
440   else if in$ = "^BY" or in$ = "BY" then
450     gosub 1400
460   else if in$ = "^B3" or in$ = "B3" then
470     gosub 1600
480   else if in$ = "^XZ" then
490     print #2: in$;
500   end if
510 loop
1 rem *****
1 rem convert the ^F0 and ^LH commands from 200 to 300 dpi
1 rem *****
520 inbyte #1: a$
530 let a = ord(a$)
540 if a >= 65 then
550   print #2: in$&a$;
560   goto 660
570 end if
580 let x$ = extract$(1, "", ", ")
590 let x2$ = a$&x$
600 let y$ = extract$(1, "", "^")
610 let x = val(x2$)
620 let y = val(y$)
630 let x2 = (x/2)+x
640 let y2 = (y/2)+y
650 print #2: in$; x2; ", "; y2; "^";
660 return
1 rem *****
1 rem convert the ^A0 and ^A@ commands from 200 to 300 dpi
1 rem *****
700 inbyte #1: a$
710 let a = ord(a$)
720 let b = 0
730 let c = 0
740 if a >= 65 then
750   print #2: in$&a$; ", ";
760   let b = 1
770 end if
780 inbyte #1: a$
790 let h$ = extract$(1, "", ", ")
800 if in$ = "^A@" or in$ = "A@" then
810   let c = 1
820   let w$ = extract$(1, "", ", ")
830   let m$ = extract$(1, "", "^")
840 else
850   let w$ = extract$(1, "", "^")
860 end if
870 let h = val(h$)
880 let w = val(w$)
900 let h2 = (h/2) + h
910 let w2 = (w/2) + w
920 if b = 1 then
930   print #2: h2; ", "; w2;
940 else

```

```

950   print #2: in$&"N,"; h2; ","; w2;
960 end if
970 if c = 1 then
980   print #2: ","; m$;
990 end if
1000 print #2: "^";
1010 return
1 rem *****
1 rem convert the ^GB command from 200 to 300 dpi
1 rem *****
1020 let w$ = extract$(1, ",", ", ")
1030 let h$ = extract$(1, ",", ", ")
1040 let t$ = extract$(1, ",", "^")
1050 let h = val(h$)
1060 let w = val(w$)
1070 let t = val(t$)
1080 let h2 = (h/2)+ h
1090 let w2 = (w/2)+ w
1100 let t2 = (t/2)+ t
1110 print #2: in$; w2; ","; h2; ","; t2; "^";
1120 return
1 rem *****
1 rem convert the ^LL command from 200 to 300 dpi
1 rem *****
1300 let l$ = extract$(1, ",", "^")
1310 let l = VAL(l$)
1320 let l2 = (l/2) + l
1330 print #2: in$; l2; "^";
1340 return
1 rem *****
1 rem convert the ^BY command from 200 to 300 dpi
1 rem *****
1400 inbyte #1: a$
1410 let a = ord(a$)
1420 if a >= 48 and a <= 57 then
1460   let x$ = extract$(1, ",", ", ")
1470   let x2$ = a$&x$
1480   let x = val(x2$)
1490   let x2 = (x/2) + x
1500   if x2 > 10 then
1510     let x2 = 10
1520   end if
1530   print #2: in$; x2; ",";
1540 else
1550   print #2: in$; a$;
1560 end if
1570 return
1 rem *****
1 rem convert the ^B3 command from 200 to 300 dpi
1 rem *****
1600 let o$ = extract$(1, ",", ", ")
1610 let e$ = extract$(1, ",", ", ")
1620 let h$ = extract$(1, ",", ", ")
1630 let h = val(h$)
1640 let h2 = (h/2) + h
1650 print #2: in$; o$; ","; e$; ","; h2; ",";
1660 return

```

Email Program

This program sends a simple email message to user@domain.com, assuming a valid email server is set up by identifying the SMTP server on the print server. In order to write email via ZBI, the port written to must be named "EML".



Example: This is an example of email

```

1 rem *****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of connecting to an email server to send
1 rem email.
1 rem *****
1 rem EOT$ is the special character used to denote end of transmission
1 rem *****

```

```

5 let EOT$ = chr$(4)
1 rem *****
1 rem Open a connection to the email port; if there is an error, try
1 rem again
1 rem *****
10 open #1: name "EML"
15 on error goto 10
1 rem *****
1 rem Specify address to send message to, signal end of recipients
1 rem with EOT$
1 rem Note: To send to multiple addressees, separate addressees with
1 rem a space
1 rem *****
20 print #1: "user@domain.com";EOT$;
1 rem *****
1 rem Fill in the message information
1 rem *****
30 print #1: "From: Sample User"
40 print #1: "To: Recipient"
50 print #1: "Subject: This is a test"
60 print #1: ""
70 print #1: "Hello!"
80 print #1: i
1 rem *****
1 rem Terminate message
1 rem *****
90 print #1: "";EOT$
1 rem *****
1 rem Close the port, since each open port is only good for sending
1 rem one message
1 rem *****
100 close #1
110 sleep 2
120 let i = i + 1
130 goto 10

```

Extraction 1 Program

This program finds and stores data of interest, which in this case is found in a format after the string "DATA = ". The extract command is used to get the data from the input stream, and it is inserted into a simple ZPL format to be printed.



Example: This is an example of Extraction 1.

```

1 rem *****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of using ZBI for data extraction.
1 rem There are two methods for doing extraction; this example shows
1 rem data extraction using a string.
1 rem
1 rem The data to extract is as follows:
1 rem START
1 rem DATA = "hello":
1 rem DATA = "goodbye":
1 rem END
1 rem *****
1 rem close ports except console, open channels to parallel and serial
1 rem ports
1 rem *****
05 for i = 1 to 9 step 1
10   close #i
20 next i
30 open #1: name "PAR"
40 open #2: name "ZPL"
1 rem *****
1 rem create string array to hold data
1 rem *****
50 declare string format$(3)
60 let format$(1) = "START"
70 let format$(2) = "END"
80 let format$(3) = "DATA"
1 rem *****

```

```

1 rem main program; look for "START" keyword, if found print ^XA to ZPL port
1 rem *****
90 do
100 let begin$ = searchto$(1,format$,2)
110 if begin$ = "START" then
120 print #2: "^XA";
1 rem *****
1 rem if "DATA" keyword is found, get two data strings
1 rem *****
130 else if begin$ = "DATA" then
140 input #1: data_string1$
150 input #1: data_string2$
1 rem *****
1 rem get data from between quotes and print to ZPL port with formatting
1 rem *****
160 let extracted_data1$ = extract$(data_string1$,"\"", "\"")
170 let extracted_data2$ = extract$(data_string2$,"\"", "\"")
180 print #2:"^F030,30^A0N,30,30^FD"&extracted_data1$&"^FS";
190 print #2:"^F030,70^A0N,30,30^FD"&extracted_data2$&"^FS";
200 else if begin$ = "END" then
210 print #2: "^XZ"
220 end if
230 loop

```

Extraction 2 Program

This program finds and stores data of interest, which in this case is found in a format after the string "DATA = ". The input command is used to get the data from the input stream, and it is inserted into a simple ZPL format to be printed.



Example: This is an example of Extraction 2.

```

1 rem*****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of using ZBI for data extraction.
1 rem There are two methods for doing extraction; this example shows
1 rem data extraction from the port directly.
1 rem
1 rem The data to extract is as follows:
1 rem START
1 rem DATA = "hello":
1 rem DATA = "goodbye":
1 rem END
1 rem*****
1 rem close ports except console, open channels to parallel and serial ports
1 rem*****
05 for i = 1 to 9 step 1
10 close #i
20 next i
30 open #1: name "PAR"
40 open #2: name "ZPL"
1 rem*****
1 rem create string array to hold data
1 rem*****quotes and print to ZPL port with formatting
1 rem*****

50 declare string format$(3)
60 let format$(1) = "START"
70 let format$(2) = "END"
80 let format$(3) = "DATA"
1 rem*****
1 rem main program; look for "START" keyword, if found print ^XA to ZPL port
1 rem*****

90 do
100 let begin$ = searchto$(1, format$, 2)
110 if begin$ = "START" then
120 print #2: "^XA";
1 rem*****
1 rem if "DATA" keyword is found, get two data strings
1 rem*****
130 else if begin$ = "DATA" then

```

```

1 rem*****
1 rem get data from between q
140     let extracted_data1$ = extract$(1,"","")
150     input #1: junk$
170     let extracted_data2$ = extract$(1,"","")
180     print #2:"^F030,30^A0N,30,30^FD" &extracted_data1$& "^FS";
190     print #2:"^F030,70^A0N,30,30^FD" &extracted_data2$& "^FS";
200     else if begin$ = "END" then
210         print #2: "^XZ"
220     end if
230 loop

```

Front Panel Control

This example shows how to intercept front panel button presses and write to the display to create a simple menu. The buttons used in this demo are set up for a Z4M/Z6M, ZM400/ZM600, or RZ400/RZ600. This could be reconfigured to work with any other printer.



Example: This is an example of front panel control.

```

1 REM This example shows how to override the functionality of the feed key
1 REM and use the front panel display to show a option list
AUTONUM 1,1
REM CLOSE ALL
DECLARE STRING OPTIONS$(5)
FOR I = 1 TO 5
LET OPTIONS$(I) = "Option " & STR$(I)
NEXT I
LET ZPLPORT = 1
OPEN #ZPLPORT: NAME "ZPL"
LET FEEDKEY = 3
LET SELECTKEY = 10
LET PLUSKEY = 6
LET MINUSKEY = 7
LET EXITKEY = 9
LET TMP = REGISTEREVENT(FEEDKEY, 0, 1)
SUB NORMALLOOP
DO WHILE 1 = 1
LET EVT = HANDLEEVENT()
IF EVT = FEEDKEY THEN
LET INDEX = 1
GOSUB REGISTERKEYS
GOSUB SHOWMENU
GOTO FEEDLOOP
END IF
SLEEP 1
LOOP
SUB FEEDLOOP
DO WHILE 1 = 1
LET EVT = HANDLEEVENT()
IF EVT = FEEDKEY THEN
GOSUB RELEASEKEYS
GOSUB HIDEMENU
GOTO NORMALLOOP
ELSE IF EVT = SELECTKEY THEN
GOSUB HANDLEOPTION
ELSE IF EVT = PLUSKEY THEN
LET INDEX = INDEX + 1
IF INDEX > 5 THEN
LET INDEX = 1
END IF
GOSUB SHOWMENU
ELSE IF EVT = MINUSKEY THEN
LET INDEX = INDEX - 1
IF INDEX < 1 THEN
LET INDEX = 5
END IF
GOSUB SHOWMENU
ELSE IF EVT = EXITKEY THEN
GOSUB RELEASEKEYS
GOSUB HIDEMENU
GOTO NORMALLOOP
END IF
SLEEP 1
LOOP

```

```

REM ***** SUBROUTINE SHOWMENU ***
SUB SHOWMENU
LET LINE1$ = "FEED DISPLAY"
LET LINE2$ = OPTIONS$(INDEX)
GOSUB UPDATEDISPLAY
RETURN
REM ***** SUBROUTINE HIDEMENU ***
SUB HIDEMENU
LET LINE1$ = ""
LET LINE2$ = ""
GOSUB UPDATEDISPLAY
RETURN
SUB UPDATEDISPLAY
LET A = SETVAR("device.frontpanel.line1",LINE1$)
LET A = SETVAR("device.frontpanel.line2",LINE2$)
RETURN
SUB REGISTERKEYS
LET TMP = REGISTEREVENT(SELECTKEY, 0, 1)
LET TMP = REGISTEREVENT(PLUSKEY, 0, 1)
LET TMP = REGISTEREVENT(MINUSKEY, 0, 1)
LET TMP = REGISTEREVENT(EXITKEY, 0, 1)
RETURN
SUB RELEASEKEYS
LET TMP = UNREGISTEREVENT(SELECTKEY)
LET TMP = UNREGISTEREVENT(PLUSKEY)
LET TMP = UNREGISTEREVENT(MINUSKEY)
LET TMP = UNREGISTEREVENT(EXITKEY)
RETURN
SUB HANDLEOPTION
PRINT #ZPLPORT: "^XA^F0100,100^A0N,100,100^FD"; OPTIONS$(INDEX);"^XZ"
RETURN

```

Recall Program

This program searches for a ZPL format named "FORMAT.ZPL" that is already saved in printer memory. If the format is found, a number within the format is extracted and shown on the console. The user is then prompted to enter a new number, which is then substituted into the format.



Example: This is an example of Recall.zpl

```

1 rem *****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of recalling a ZPL format and extracting data
1 rem from it.
1 rem *****
1 rem close ports except console, open ZPL port and declare search
1 rem array
1 rem *****
10 for i = 1 to 9 step 1 ! Close all ports
20   close #i
30 next i
40 let zplport = 2
50 open #zplport: name "ZPL"
60 declare string search_zpl$(2)
70 let search_zpl$(1) = chr$(03)
80 let search_zpl$(2) = "FORMAT.ZPL"
1 rem *****
1 rem main program; look for format to recall on printer
1 rem *****
90 do
100  print #zplport: "^XA^HWE:*.ZPL^FS^XZ"
110   let present = 0
115   let find$ = ""
120   do until find$ = chr$(03)
130     let find$ = searchto$(zplport, search_zpl$)
140     if find$ = "FORMAT.ZPL" then
150       let present = 1 ! format is present
160     end if
170   loop

1 rem *****
1 rem if format is not found, create a format and set data value to
1 rem 000

```



```

1 rem *****
180 if present = 0 then
190   print #zplport:"^XA^DFE:FORMAT.ZPL^FS";
200   print #zplport:"^FX000^FS^XZ"
210   let counter$ = "000"
1 rem *****
1 rem if format is found, extract the data from ^FX field
1 rem *****
220 else
230   print #zplport:"^XA^HFE:FORMAT.ZPL^FS^XZ"
240   let stop$ = searchto$(zplport, "^FX")
250   let counter$ = extract$(zplport, "", "^FS")
260   let stop$ = searchto$(zplport, "^XZ")
270 end if
1 rem *****
1 rem print current data value, prompt user to replace data
1 rem *****
280 print ""
290 print "Current number in format is " & counter$
300 print "Please enter new number (type EXIT to end) ";
310 input new_counter$
320 if new_counter$ = "EXIT" then
330   print "Program ending"
340   end
350 else
360   print #zplport:"^XA^DFE:FORMAT.ZPL^FS";
370   print #zplport:"^FX" & new_counter$ & "^FS^XZ"
380 end if
390 loop
  
```

Scale Program

This program reads data from a scale connected to the serial port by sending a "W" to the scale and waiting for a weight to be returned. When the weight is received, it is inserted into a simple label format and printed.



Example: This is an example of Scale

```

1 rem *****
1 rem Zebra Technologies ZBI Sample Program
1 rem
1 rem Professional programming services are available. Please contact
1 rem ZBI-Experts@zebra.com for more information.
1 rem
1 rem This is an example of using ZBI to read scale data from the
1 rem serial port.
1 rem *****
1 rem close all ports except console, open channels to parallel and
1 rem serial ports
1 rem *****
05 for i = 1 to 9 step 1
10   close #i
20   next i
30 open # 2 : name "SER"
40 open # 1 : name "ZPL"
1 rem *****
1 rem main program; send serial port a 'W' in order to get a weight
1 rem *****
50 do
60   do
70     sleep 1 ! sleep so scale is not bombarded with incoming
1 rem data
80     print # 2 : "W" ; ! semicolon ends sent W without a CRLF
1 rem *****
1 rem get response from scale; note that input requires a CRLF to be
1 rem entered
1 rem *****
90   input # 2 : a$
100   if a$ = "EXIT" then! back door exit - if EXIT is received, ZBI ends
110     close # 2
120     print #1: "^XZ"
130     close #1
140   end
150   end if
  
```

```

1 rem *****
1 rem loop until valid weight is received, then print on label
1 rem *****
160 loop while pos ( a$ , "000.00" ) = 1 or pos ( a$ , "?" ) = 1
170 print # 1 : "~SD25^XA^FS";
180 print # 1 : "^LH0,0^FS";
190 print # 1 : "^F056,47^A0N,69,58^FDThis weighs^FS";
1 rem *****
1 rem print weight on label; & character concatenates strings
1 rem *****
200 print # 1 : "^F056,150^A0N,69,58^FD" & A$ & " lbs^FS";
210 print # 1 : "^PQ1,0,0,N";
220 print # 1 : "^XZ"
1 rem *****
1 rem loop until weight is off scale, then repeat for next item
1 rem weighed
1 rem *****
230 do
240     print # 2 : "W" ;
250     input # 2 : A$
260     loop until pos(A$ , "000.00") = 1 or pos(A$ , "?") = 1
270 loop

```

SGD Printer Commands

This chapter provides a high-level overview of printer setting Set / Get / Do (SGD) commands. For printer support of these SGD commands, see [SGD Command Support on page 1393](#).



SGD commands are available in printers with the following firmware versions or later:

- V66.17.4Z or later
- V61.15.xZ or later
- V60.16.2Z or later
- V60.15.xZ or later
- V50.15.xZ or later
- V56.15.xZ or later
- V53.16.x or later
- V53.15.2Z or later
- R53.16.3Z or later
- R60.15.8Z or later
- R62.15.8Z or later
- R63.15.8Z or later
- R65.15.8Z or later



Important • These are important points to note when using ZPL and SGD commands:

- SGD commands are case-sensitive.
- ZPL and SGD commands should be sent to the printer as separate files.
- Certain settings can be controlled by both ZPL and SGD. Configuration changes made in ZPL can affect configuration changes made in SGD.
- Changes made with one command type (ZPL or SGD) will affect the data returned to the host in response to both ZPL and getvar commands. The command type (ZPL or SGD) that was sent last determines the current setting.
- Some RF cards do not support all of the SGD commands.



Important • These are important points to note when using a Zebra G-Series printer:

- You can send instructions to the printer using multiple programming languages: EPL, ZPL, or SGD. EPL and ZPL commands configure the printer, print labels, and get device status information. SGD commands set and get configuration details. These three languages can be used without the need to send the printer instructions to switch from one language to another.
- EPL, ZPL, and SGD commands must be sent to the printer as separate files. They cannot be used together in one format, or set of commands. For example, if you send a series of SGD commands to the printer and they are followed by a printable format, this needs to be done using separate files.

Overview

This section describes how and why to use the Set / Get / Do (SGD) commands. It also provides an example of a typical command structure.

SGD commands are commands that allow you to configure all printers with firmware versions V60.15.xZ, V50.15.xZ, V61.15.xZ, V56.15.xZ, V53.15.xZ, or later. The printer performs the specified function immediately after receiving the command. The commands are:

- setvar
- getvar
- do



Important • SGD commands must be terminated by a carriage return or a space and line feed, and the command, attributes, and values must be specified in lower case.

setvar Command

Setvar commands:

- are used to configure printer settings to specific values by setting them in the printer
- must be terminated by a space character or a CR/ LF (0x0D, 0x0A)

getvar Command

Getvar commands:

- are used to get the current value of the printer settings
- must be terminated by a space character or CR/LF (0x0D, 0x0A)

The printer responds with the printer setting of “?” if:

- the printer setting does not exist (usually due to incorrect spelling of the printer setting)
- it has not been configured yet

do Command

Do commands:

- are used to instruct the printer to perform predefined actions
- must be terminated by a space character or a CR/LF (0x0D, 0x0A)

Some Do commands require additional settings which must be enclosed in double quotes.

Command Structure

It is important to understand the structure of the command and its components. A command structure illustration is provided for each command in this guide.

➔ **Example:** This is an example of a command structure illustration:

```
! U1 setvar "ip.addr" "value"
```

1
2
3

1	Command—always preceded with an exclamation point (!) and must be specified in lower case. A space resides between the ! and U1 and between U1 and the command (setvar or getvar).
2	Attribute—always in double quotes and must be specified in lower case.
3	Chosen value—always in double quotes. Only applicable for setvar and do .

This command must be terminated by a space character or a CR/ LF (0x0D, 0x0A).

How to Send Multiple SGD Commands

For any **getvar**, **setvar**, or **do** command, if you issue the syntax without the "1" and use the **END** command followed by a space, multiple SGD commands are sent simultaneously.

➔ **Example:** This syntax shows how you can send multiple **getvar** commands:

```
1 → ! U getvar "ip.telnet.enable"
2 →   getvar "ip.dhcp.enable"
   →   getvar "ip.dhcp.cid_prefix"
3 →   END
```

1	The command portion of the string does not use the "1" after the "! U".
2	Commands issued after the first command do not require the "! U".
3	The string of commands is terminated by the word "END" with a space after the word, and by a carriage return/ line feed.

JSON (JavaScript Object Notation)

JSON (JavaScript Object Notation) is an open standard format that uses human- and machine-readable text for device management. It transmits data objects consisting of elements as attribute-value pairs.

You can use JSON as an alternative to using the SGD (Set-Get-Do) mechanism when reading or writing parameters on QLn and iMz mobile printers. JSON is a popular open standard for exchanging data objects and is well suited to this task.

The main settings channel for JSON is TCP port 9200, but other ports can be used. JSON commands are processed when received. Up to eight connections are allowed, and all connected ports are active, and the JSON commands will work while the printer is printing.

The port used for JSON can be changed or disabled using [ip.port_json_config on page 1152](#).



Note • JSON is available on all communications ports, unless **line_print** is enabled, in which case you must use the main TCP JSON port, 9200. If you connect to port 9200, the printer ONLY accepts JSON commands. CPCL, SGD, ZPL, and other command languages are not supported.

Configuring JSON Usage for Communications

All JSON commands should follow the JSON specification for escaping, spacing, etc. All JSON commands are prefixed by `{}`. Refer to <http://www.json.org/> for full details on JSON formatting.

By enclosing a variable's value in curly braces, it indicates that the value is an object. Inside the object, you can declare any number of properties using a **"name": "value"** pairing, separated by colons. Multiple pairings are separated by commas.

Use the SGD variable name in the JSON command structure. To configure JSON usage for communication, refer to the following examples.

Getvar using JSON



Example 1 • To do a getvar in SGD you use the format:

```
! U1 getvar "sgd.name"  
! U1 getvar "ip.port"  
! U1 getvar "device.location"
```

To get a variable value using JSON:

```
{{"sgd.name":null} returns {"sgd.name":"value"}  
{{"ip.port":null} returns {"ip.port":"9100"}  
{{"device.location":null} returns {"device.location":"my desk"}}
```



Example 2 • You can get several values as follows:

```
{{"device.friendly_name":null, "device.company_name":null,  
"device.company_contact":null, "device.location":null}}
```

The response is:

```
{"device.friendly_name":"XXQLJ120900310",  
"device.company_name":"Zebra Technologies",  
"device.company_contact":"123-555-1212",  
"device.location":"My Desk"}
```

Setvar using JSON

→ **Example 1** • To do a setvar in SGD you use the format:

```
! U1 getvar "sgd.name" "value"
! U1 getvar "ip.port" "9200"
! U1 setvar "device.location" "my desk"
```

To set a variable value using JSON:

```
{}"sgd.name": "value"} sets the variable value to "value"
{"ip.port": "1234"} sets the variable value to "1234"
{"device.location": "my desk"} sets the variable value to "my desk"
```



Note • When you set an SGD value, it will return the value that was set, or the old value if the set failed. If:

```
{}"sgd.name": "new_value"} fails, the variable value remains "old_value"
```

→ **Example 2** • To set several values at once:

```
{}"device.friendly_name": "XXQLJ120900310",
"device.company_contact": "123-555-1212", "device.location": "My
Desk"}
```

The response is:

```
{"device.friendly_name": "XXQLJ120900310",
"device.company_contact": "123-555-1212", "device.location": "My
Desk"}
```

Get an SGD Branch

You can retrieve all branch values by specifying the branch.

→ **Example:**

```
{}"bluetooth": null} returns all SGDs in branch and their values.
```

Get an allvalues Report

You can request an **allvalues** report with just the values for all settings with characteristics. This will return all SGDs and their values.

→ **Example:**

```
{}"allvalues":
{"ip.port": "6101", "ip.port_alternate": "9100",
"ip.sgd_json_port": "9200",
...
}}
```

Get an allconfig Report

You can request an allconfig report using JSON, and it will return all settings with characteristics.



Example 1 • To get all SGDs and their values along with various other information including defaults:

```
{ }{"allconfig":null}
```



Note • For the "allconfig" response, it will start with

```
{"allconfig":{  
and end with  
}}
```



Example 2 • If you do an allconfig, you can get the setting attributes for all settings as follows:

```
{"allconfig": {"ip.port":{"value":"6101","type":"integer","range":"0-  
65535","clone":true,  
"archive":true,"access":"RW"},  
"ip.port_alternate":{"value":"9100","type":"integer","range":"0-  
65535","clone":true,  
"archive":true,"access":"RW"},  
"ip.sgd_json_port":{"value":"9200","type":"integer","range":"0-  
65535","clone":true,  
"archive":true,"access":"RW"}, another setting, ... the last setting}}
```

where:

- "value" = indicates the current value stored in the setting.
- "type" = indicates the type of value. Possible values are integer, enum, bool, string, double, ipv4-address, ipv6- address.
- "range" = indicates the range of a setting. For strings this is the range of the string length. For enums it is the possible enum values.
- "clone" = indicates if it is safe to store this setting and apply it to another link-os printer.
- "archive" = indicates if is safe to store this setting and apply it to same link-os printer at a later time.
- "access" = indicates if the setting is RW (read/write), R (read-only), or W (write-only).



Example 3 • If you do an allconfig, you can get the setting attributes for all settings as follows:

```
{ }{"allconfig":null}
```

For the values used above it returns these entries:

```
"device.friendly_name":{"value":"XXQLJ120900310","type":"string","range":  
"0-17","clone":false,"archive":true,"access":"RW"},  
"device.company_contact":{"value":"123-555-1212","type":"string","range":  
"0-128","clone":true,"archive":true,"access":"RW"},  
"device.location":{"value":"my desk","type":"string","range":  
"0-128","clone":true,"archive":true,"access":"RW"},
```


alerts.add

This command is used to configure the ZebraNet Alert System. It allows Zebra software to add new alerts without having to use the ZPL ^SX command. This allows software to configure printers which do not have ZPL on them, and it provides the software with a single way in for configuring alerts. It also allows the software to configure alerts via local ports such as USB and serial.

The format is similar to the ^SX command. It can delete the alert when both the set and clear flags are set to FALSE.

Commands	Details
setvar	<p>This command instructs the printer to add the new alert with the configuration specified in the comma delimited list.</p> <p>The parameter is a comma delimited list of the following:</p> <ul style="list-style-type: none"> • The alert condition. This can be any of the values returned from alerts.conditions on page 578. • The alert destination type. This can be any of the value returned from alerts.destinations on page 580. • On Set - Set to Y if the alert should be sent when the event is set • On Clear - Set to Y if the alert should be sent when the event is cleared • Destination address - applies to TCP,UDP,EMAIL,SNMP, SDK, and HTTP POST destination types. The maximum length of this address is 255 characters. • Port - Applies to TCP and UDP types • Quelling - When set to "Y" it prevents the alert from being sent. "N" is the default. • SGD Name - the name of the SGD command to be added. This is valid only when the alert condition is SGD_SET. <p>Format: ! U1 setvar "alerts.add" "[condition],[destination],[set],[clear],[destination_address],[port],[quelling],[SGD_name]"</p> <p>Values: Defined via alerts.conditions on page 578: PAPER OUT, RIBBON OUT, HEAD TOO HOT, HEAD COLD, HEAD OPEN, SUPPLY TOO HOT, RIBBON IN, REWIND, CUTTER JAM, MED, PRINTER PAUSED, PQ JOB COMPLETED, LABEL READY, HEAD ELEMENT BAD, BASIC RUNTIME, BASIC FORCED, POWER ON, CLEAN PRINthead, MEDIA LOW, RIBBON LOW, REPLACE HEAD, BATTERY LOW, RFID ERROR, ALL MESSAGES, COLD START, SGD SET</p> <p>Default: NA</p>
do	<p>This command has the same functionality as the setvar.</p> <p>Format: ! U1 do "alerts.add" "[condition],[destination],[set],[clear],[destination_address],[port],[quelling],[SGD_name]"</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example shows a "Paper Out" alert sent via the serial port, with no destination address specified.

```
! U1 setvar "alerts.add" "PAPER OUT,SERIAL,Y,N,,0,,"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.conditions

This command lists the available conditions that can be specified in the first parameter of the `alerts.add` SGD. See [alerts.add](#) on page 577 for information on the various parameters.

Commands	Details
<code>getvar</code>	<p>This command retrieves the list of available alert conditions for the printer.</p> <p>Format: ! U1 getvar "alerts.conditions"</p> <p>Values: PAPER OUT, RIBBON OUT, HEAD TOO HOT, HEAD COLD, HEAD OPEN, SUPPLY TOO HOT, RIBBON IN, REWIND, CUTTER JAM, MED, PRINTER PAUSED, PQ JOB COMPLETED, LABEL READY, HEAD ELEMENT BAD, BASIC RUNTIME, BASIC FORCED, POWER ON, CLEAN PRINthead, MEDIA LOW, RIBBON LOW, REPLACE HEAD, BATTERY LOW, RFID ERROR, ALL MESSAGES, COLD START, SGD SET</p> <p>Default: ""</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

alerts.configured

This command creates a list of all the alerts that are configured on the printer. The alerts are delimited by the '|' character.



Important • Writing to this SGD will clear out the old alerts and setup the new ones.

Commands	Details
setvar	<p>Creates the list of alerts configured on the printer.</p> <p>Format: ! U1 setvar "alerts.configured" "<a ' ' delimited list of configured alerts>"</p> <p>Values: A list of alerts to be setup on the printer. See alerts.add for the format of the individual alerts.</p> <p>Default: "COLD START,SNMP,Y,N,255.255.255.255,162,N"</p>
getvar	<p>Retrieves the currently configured alerts on the printer.</p> <p>Format: ! U1 getvar "alerts.configured"</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.destinations

This command lists the available destinations that can be specified in the first parameter of the `alerts.add` SGD. See the [alerts.add](#) on page 577 for information on the various parameters.

Commands	Details
<code>getvar</code>	This command returns a comma-delimited list of available alert destinations. Format: ! U1 getvar "alerts.destinations" Values: SERIAL, PARALLEL, E-MAIL, TCP, UDP, SNMP, USB, HTTP-POST, BLUETOOTH, SDK Default: NA

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

alerts.http.authentication.add

This command allows the user to add a single server/username/password triplet into the list of authentication entries.

When the printer attempts to connect to the URL in the HTTP POST alert, the server may require HTTP authentication (such as digest, basic, DNS, etc.). There may be multiple authentication requests along the route to the destination (for example, a local server first requires HTTP authentication as well as on the remote server). For each HTTP authentication request received while attempting to connect, the printer will enumerate the authentication entries and attempt to satisfy the request with the username/password pair provided for the respective server. The server name in the entry is what determines which username/password pair should be used for which authentication request. Both DNS names and IP addresses are acceptable.

The server, username, and password are separated by a single space (not a tab or other white space character). The server name is the only required field. If no username is supplied, but a password is, there must be two spaces between the server and the password fields. If there is a username but no password, or simply just the servername, no space is required at the end of the entry.

Commands	Details
setvar	This command adds server/username/password triplet into the list of authentication entries. Format: ! U1 setvar "alerts.http.authentication.add" "servername[username][password]" Values: Maximum string of 2048 characters. Default: NA
do	This command has the same settings as the setvar . Format: ! U1 do"alerts.http.authentication.add" "servername[username][password]" Values: Maximum string of 2048 characters. Default: NA

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example 1 • A username and a password is supplied:

```
! U1 setvar "alerts.http.authentication.add" "my.server.lan johndoe password"
```



Example 2 • No password is supplied:

```
! U1 setvar "alerts.http.authentication.add" "my.server.lan johndoe"
```

alerts.http.authentication.addalerts.http.authentication.add



Example 3 • No username is supplied (note the double space):
! U1 setvar "alerts.http.authentication.add"
"my.server.lan password"



Example 4 • No username or password is supplied:
! U1 setvar "alerts.http.authentication.add" "my.server.lan"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1493](#).

alerts.http.authentication.entries

This command lists the server names added to the authentication entries list via **alerts.http.authentication.add**.

Only the server names will be shown; the username and passwords will not be shown. The server names are separated by a `\r\n` so that each shows up on its own line and is easier to read.

Commands	Details
getvar	<p>This command lists the server names added to the authentication entry list.</p> <p>Format: ! U1 getvar "alerts.http.authentication.entries"</p> <p>Values: A list of server names.</p> <p>Default: NA</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1383](#).

alerts.http.authentication.remove

This command allows the user to remove a single server/username/password triplet from the list of authentication entries. To remove an entry, only the server name is supplied, and the entire entry will be removed. If an invalid entry is supplied no action is taken.

Note that the list of authentication triplets will be updated (and saved over a reset) but this SGD is just a command and doesn't have state. Therefore the persistent and restore defaults do not apply. The internal list that this command removes from, however, is persistent and defaultable (defaults to an empty list).

Commands	Details
setvar	Removes a server/username/password triplet into the list of authentication entries. Format: ! U1 setvar "alerts.http.authentication.remove" "servername" Values: Maximum string of 2048 characters. Default: NA
do	This command has the same settings as the setvar . Format: ! U1 do "alerts.http.authentication.remove" "servername" Values: Maximum string of 2048 characters. Default: NA

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: A username and a password is supplied

```
! U1 setvar "alerts.http.authentication.remove" "my.server.lan"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1383](#).

alerts.http.logging.clear

This command clears the weblink alerts log entries. It does not disable logging. Setting this command to any value, including an empty string, will clear the weblink log entries.

Commands	Details
setvar	This command clears the weblink alerts log entries. Format: ! U1 setvar "alerts.http.logging.clear" "value" Values: Any string value, including an empty string. Default: NA
do	This command clears the weblink alerts log entries. Format: ! U1 do "alerts.http.logging.clear" "value" Values: Any string value, including an empty string. Default: NA

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example clears the log entries with an empty string value.
 ! U1 setvar "alerts.http.logging.clear" ""



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1383](#).

alerts.http.logging.entries

This command returns the N number of entries in the http log, where N has a maximum value that is set by `alerts.http.logging.max_entries`.

The alerts http log is a collection of events related to sending HTTP POST messages. The log entries range anywhere from general status to errors that prevented a successful connection. Each log entry contains a timestamp for when it was logged by the system. The newest events will appear at the bottom of the list.

Commands	Details
getvar	This command returns the number of entries in the HTTP log. Format: ! U1 getvar "alerts.http.logging.entries" Values: NA Default: NA

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example shows the result from `alerts.http.logging.entries`:

```
[01-03-2013 12:48:59.964] [http] Connected to 10.3.4.58 (10.3.4.58)
port 80
[01-03-2013 12:48:59.978] [http] HTTP/1.1 100 Continue
[01-03-2013 12:49:01.999] [http] Closing connection
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1383](#).

alerts.http.logging.max_entries

This command specifies the maximum number of individual log entries that will be stored in the `alert.http.logging.entries` command.



Important • Changes to this command are immediate and may result in some log entries being lost. If there are N log entries currently in the log, the user sets the `max_entries` to M, where M is less than N, the oldest (N-M) log entries will be removed.

Commands	Details
<code>setvar</code>	This command sets the maximum number of log entries that will be stored. Format: ! U1 getvar "alerts.http.logging.max_entries" "value" Values: 0 - 10000 Note • Setting the value to 0 disables logging. Default: "0"
<code>getvar</code>	This command returns the setting for the maximum number of log entries that will be stored. Format: ! U1 getvar "alerts.http.logging.max_entries"
<code>do</code>	This command sets the maximum number of log entries that will be stored. Format: ! U1 do "alerts.http.logging.max_entries" "value" Values: 0 - 10000 Note • Setting the value to 0 disables logging. Default: "0"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: In this example, `alert.http.logging.max_entries` is then set to 2.

```
[01-03-2013 12:48:59.964] [http] Connected to 10.3.4.58 (10.3.4.58)
port 80
[01-03-2013 12:48:59.978] [http] HTTP/1.1 100 Continue
[01-03-2013 12:49:01.999] [http] Closing connection
```

When it is set to 2

```
[01-03-2013 12:48:59.978] [http] HTTP/1.1 100 Continue
[01-03-2013 12:49:01.999] [http] Closing connection
```



Note

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1383](#).

alerts.http.proxy

This command assigns the URL of the proxy for any HTTP POST alerts. The proxy server protocol, port, domain, username, and password are all encoded into the URL via the format outlined in RFC2396 (<http://www.ietf.org/rfc/rfc2396.txt>).

The username and password must avoid the invalid characters listed in RFC2396 (e.g. ':', '@', '/', etc). If an invalid character must be used it needs to be escaped using '%' as described in RFC2396.

When the setting is changed, the next HTTP POST alert will use the new value.

Commands	Details
setvar	<p>This command assigns the proxy URL for HTTP POST alerts.</p> <p>Format: ! U1 setvar "alerts.http.proxy" "http://username:password@mydomain.com:3128/"</p> <p>Values: Any valid URL up to 2048 characters URL format expected: http://[user:pass@]domain[:port]/[path]</p> <p>Default:</p> <ul style="list-style-type: none"> • The user:pass, port, and path are all optional. • The default port is 1080. • The default is to omit the username and password.
getvar	<p>This command retrieves the proxy URL for HTTP POST alerts.</p> <p>Format: ! U1 getvar "alerts.http.proxy"</p>
do	<p>This command assigns the proxy URL for HTTP POST alerts.</p> <p>Format: ! U1 do "alerts.http.proxy" "http://username:password@mydomain.com:3128/"</p> <p>Values: Any valid URL up to 2048 characters URL format expected: http://[user:pass@]domain[:port]/[path]</p> <p>Default:</p> <ul style="list-style-type: none"> • The user:pass, port, and path are all optional. • The default port is 1080. • The default is to omit the username and password.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: Examples of how to connect to various proxy servers:

```
http://username:password@mydomain.com:3128/
http://mydomain.com/
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).
- For details on HTTP POST, see [HTTP POST Alerts on page 1383](#).

alerts.tracked_settings.clear_log

This command clears the `alerts.tracked_settings.log`. Setting this command to any value, including an empty string, will clear the `tracked_sgds` log entries.

Commands	Details
<code>setvar</code>	This command clears the <code>tracked_sgds</code> log entries. Format: <code>! U1 setvar "alerts.tracked_settings.clear_log" "value"</code> Values: Any string value, including an empty string. Default: NA
<code>do</code>	This command clears the <code>tracked_sgds</code> log entries. Format: <code>! U1 do "alerts.tracked_settings.clear_log" "value"</code> Values: Any string value, including an empty string. Default: NA

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example clears the log entries with an empty string value.

```
! U1 setvar "alerts.tracked_settings.clear_log" ""
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.tracked_settings.log_tracked

This command creates a comma-delimited list of settings for which sets should be logged.

Commands	Details
setvar	This command sets the list of settings for which sets should be logged. Format: ! U1 setvar "alerts.tracked_settings.log_tracked" "settings.name1,settings.name2..." Values: Settings with commas between names. Default: ""
getvar	This command returns a comma-delimited lists of settings being logged. Format: ! U1 getvar "alerts.tracked_settings.log_tracked"
do	This command sets the list of settings for which sets should be logged. Format: ! U1 do "alerts.tracked_settings.log_tracked" "settings.name1,settings.name2..." Values: Settings with commas between names. Default: ""

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.tracked_settings.max_log_entries

Sets or retrieves the maximum number of entries to be shown in the `alerts.tracked_settings.log`.

Commands	Details
setvar	<p>Format: ! U1 setvar "alerts.tracked_settings.max_log_entries" "value" ! U1 do "alerts.tracked_settings.max_log_entries" "value"</p> <p>Values: 0 - 10000 Default: 100</p>
getvar	<p>Format: ! U1 getvar "alerts.tracked_settings.max_log_entries"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520, ZQ530
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.tracked_sgds.log

This command reports the log of the settings listed in `alerts.tracked_settings.log_tracked`. The log entries will be fully JSON compliant.

Commands	Details
getvar	This command retrieves the current log. Format: ! U1 getvar "alerts.tracked_sgds.log"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: Sending ! U1 getvar "alerts.tracked_settings.log" returns:

```
:[{"settingsName":"newValue","timestamp":  
:"06-24-2012 19:51:28.641"}]" for 1 entry or  
"[{"settingsName":"newValue","timestamp"  
:"06-24-2012  
19:51:28.641"},\r\n{"settingsName2":"newValue2","timestamp":"06-24-2012  
19:51:30.641"}]" for 2 entries.
```

Note • When the log is empty, the result will be:

```
""
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.tracked_sgds.max_log_entries

This command sets the maximum number of entries to be shown in `alerts.tracked_settings.log`.

Commands	Details
<code>setvar</code>	<p>This command sets the maximum number of alert log entries that will be stored.</p> <p>Format: ! U1 setvar "alerts.tracked_sgds.max_log_entries" "value"</p> <p>Values: 0 - 10000</p> <p>Default: "100"</p> <p>Note • Setting the value to 0 disables logging.</p>
<code>getvar</code>	<p>This command returns the setting for the maximum number of alert log entries that will be stored.</p> <p>Format: ! U1 getvar "alerts.tracked_sgds.max_log_entries"</p>
<code>do</code>	<p>This command sets the maximum number of alert log entries that will be stored.</p> <p>Format: ! U1 setvar "alerts.tracked_sgds.max_log_entries" "value"</p> <p>Values: 0 - 10000</p> <p>Default: "100"</p> <p>Note • Setting the value to 0 disables logging.</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example sets the maximum log entries to 50.

```
! U1 setvar "alerts.tracked_sgds.max_log_entries" "50"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

alerts.tracked_sgds.zbi_notified

This command provides a comma-delimited list of settings for which ZBI should be notified when the value is set.

Commands	Details
setvar	This command sets the list of the settings for which ZBI will be notified when the setting is set. Format: ! U1 setvar "alerts.tracked_settings.zbi_notified" "settings.name1,settings.name2,etc." Values: A comma delimited list of settings names Default: ""
getvar	This command retrieves the list of the settings for which ZBI will be notified when the value is set. Format: U1 getvar "alerts.tracked_settings.zbi_notified"
do	This command sets the list of the settings for which ZBI will be notified when the value is set. Format: ! U1 do "alerts.tracked_settings.zbi_notified" "settings.name1,settings.name2,etc." Values: A comma delimited list of settings names Default: ""

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

apl.enable

The setvar enables or disables a Virtual Device. The getvar returns the currently enabled Virtual Device.

Commands	Details
setvar, do	<p>Format: ! U1 setvar "apl.enable" "value" ! U1 do "apl.enable" "value"</p> <p>Values: none, apl-d, apl-i, apl-e, apl-l, apl-m, apl-mi, apl-o, apl-t</p> <p>Default: NA</p> <p>Example: ! U1 setvar "apl.enable" "apl-o"</p>
getvar	<p>Format: ! U1 getvar "apl.enable"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230, ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

apl.framework_version

Returns the revision number of the Virtual Device framework.

Commands	Details
getvar	Format: ! U1 getvar "apl.framework_version"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230, ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

apl.version

This command returns the revision number of the Virtual Device system.

Commands	Details
getvar	Displays the revision number of the Virtual Device system. Format: ! U1 getvar "apl.version"

Supported Devices

- Link-OS printers with firmware Vxx.19.7Z and later.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

appl.link_os_version

This command lists the version of the Link-OS™ feature set that is supported by the printer.

Commands	Details
getvar	This command retrieves the Link-OS™ version of the printer. Format: ! U1 getvar "appl.link_os_version"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: In this example, the `getvar` command returns version 1.0 of Link-OS™.

```
! U1 getvar "appl.link_os_version"
returns
1.0
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

appl.option_board_version

This command returns the version number of the firmware running on the wireless option board. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command returns the version number of the firmware running on the wireless option board. Format: ! U1 getvar "appl.option_board_version"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This command returns the version number of the firmware running on the wireless option board.

```
! U1 getvar "appl.option_board_version"  
"0.0.0 *"
```

appl.bootblock

This command refers to the bootblock version. On the configuration label, the bootblock number is identified as the hardware ID. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command returns the bootblock version number that appears on the configuration label . Format: ! U1 getvar "appl.bootblock"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` returns the bootblock version number.
! U1 getvar "appl.bootblock"

appl.date

This command refers to the date the firmware was created. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	The printer will respond with the date the firmware was created in the mm/dd/yy format. Format: ! U1 getvar "appl.date"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` returns the date the firmware was created.
! U1 getvar "appl.date"

Result: "01/29/10"

appl.name

This command refers to the printer's firmware version. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command returns the printer's firmware version. Format: ! U1 getvar "appl.name"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` returns the printer's firmware version.
! U1 getvar "appl.name"

capture.channel1.count

This command indicates the number of times that `capture.channel1.delimiter` was seen on the port specified in `capture.channel1.port`. Additionally, it indicates how many times `capture.channel1.data.raw` has been updated with user data as well as the number of times we reached the `capture.channel1.max_length`.

This will be shown in the HZA response under the capture data section.

Commands	Details
getvar	This command returns the number of times that <code>capture.channel1.delimiter</code> was seen on the port specified in <code>capture.channel1.port</code> as well as the number of times we reached the <code>capture.channel1.max_length</code> . Format: ! U1 getvar "capture.count"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

capture.channel1.data.mime

This command provides a view to the data captured on the port specified by `capture.channel1.port` in a mime/base64 encoded format.

Commands	Details
<code>getvar</code>	This command retrieves the data captured on the port specified by <code>capture.channel1.port</code> . Format: ! U1 getvar "capture.channel1.data.mime" Result: Data in mime-encoded format.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

capture.channel1.data.raw

This command retrieves the user data captured off of the port specified in `capture.channel1.port`.

Any binary zeros in the capture.data stream will be replaced with the escaped representation of NULL ("\000"). The delimiter data is not stored as part of the captured data.

This will be shown in the HZA output within capture data section.

Commands	Details
<code>getvar</code>	This command retrieves the user data captured off of the port specified in <code>capture.channel1.port</code> . Format: ! U1 getvar "capture.channel1.data.raw"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

capture.channel1.delimiter

This command stores the delimiter used to partition data received on the port specified by `capture.channel1.port` and stored in `capture.channel1.data.raw` and `capture.channel1.data.mime`.

This will be reported in the data capture section of the HZA response.

Commands	Details
setvar	<p>This command sets the delimiter used to partition data received on the <code>capture.channel1.port</code>.</p> <p>Format: ! U1 setvar "capture.channel1.delimiter" "delimiter"</p> <p>Values: Any character set up to a maximum of 64 characters in length.</p> <p> Note • Binary data can be used in the delimiter. To do this enter a '\ ' and then the 3 digit octal value of the character. "\\ \" = '\ ' in some tools, so to get \002 you may need to enter "\\002". Escaped octal characters count as a single character and not 4 (e.g. a delimiter of "\\001\000\002" is 3 characters, not 12)</p> <p>Default: "\012"</p>
getvar	<p>This command retrieves the delimiter.</p> <p>Format: ! U1 getvar "capture.channel1.delimiter"</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: Binary data can be used in the delimiter. To do this enter a '\ ' and then the 3 digit octal value of the character. Note: "\\ \" = '\ ' in some tools, so to get \002 you may need to enter "\\002".

"\000" = NULL (single character)

"end\015\012\000" = 'e'+ 'n'+ 'd'+ '\r'+ '\n'+ NULL (total of 6 characters)



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

capture.channel1.max_length

This command sets a length indicating when to copy captured data to the data SGD if the delimiter has not been seen yet.

If the delimiter and the max_length are reached at the same time, the delimiter will not be part of the captured data. If only part of the delimiter has been received, then the part of the delimiter we have received, will be part of the capture data.

When the max_length is changed, any data currently in the buffer will be thrown away, and the new value of max_length will be used.

The Capture Port shall be defaulted to 1000 bytes by any mechanism (including ^JUF, ^JUN, ^JUA, and device.restore_defaults).

Commands	Details
setvar	This command instructs the printer to set a default data capture length. Format: ! U1 setvar "capture.channel1.max_length" "value" Values: 1-3000 Default: "1000"
getvar	This command retrieves the default data capture length. Format: ! U1 getvar "capture.channel1.max_length"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

capture.channel1.port

This command determines the port that should be monitored for user data. This allows the user to attach an external device, such as a keyboard or barcode scanner, and have input captured into the `capture.channel1.data.raw` command. Once the data is in the SGD they can use it as they would any other SGD (this includes functionality that allows users to be sent an alert when an SGD value changes).

The data received on the specified port will be read until the value in `capture.channel1.delimiter` is seen, at which point the data received until (but not including) the delimiter will be stored in `capture.channel1.data.raw`.

For the port specified in `capture.channel1.port`, no data will be sent to any of the parsers on that port. All data received is assumed to be user input that is to be placed in `capture.channel1.data.raw`. To disable the data capture functionality, set `capture.channel1.port` to "off"

- The delimiter will not be stored in `capture.channel1.data.raw`.
- The port will be shown in the data capture portion of the HZA response.
- The capture port shall be defaulted to "off" by any mechanism (including ^JUF, ^JUA, and `device.restore_defaults`).

Commands	Details
setvar	<p>This command sets the port to be monitored for user data.</p> <p>Format: ! U1 setvar "capture.channel1.port" "value"</p> <p>Values: off,serial,usb,bt,usb_host</p> <ul style="list-style-type: none"> • off - no data is stored in <code>capture.channel1.data.raw</code> and all data is sent to the parsers - normal operation • serial - Data is read off the serial port. No data sent to the parsers on this port. • usb - Data is read off the usb port. No data sent to the parsers on this port. • bt - Data is read off the Bluetooth® port. No data sent to the parsers on this port. • usb_host - not yet supported. reserved for when usb host is implemented. <p>Default: "off"</p>
getvar	<p>This command retrieves the printer's current port being monitored for user data.</p> <p>Format: ! U1 getvar "capture.channel1.port"</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example sets the command value to "off", preventing it from capturing data.

```
! U1 setvar "capture.channel1.port" "off"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

CISDFCRC16

Download Files

The **CISDFCRC16** command downloads supported files types to the printer.



Note • When using certificate files, your printer supports:

- Using Privacy Enhanced Mail (PEM) formatted certificate files.
- Using the client certificate and private key as two files, each downloaded separately.
- Using exportable PAC files for EAP-FAST.



Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation. Each line should be terminated with a CR/LF.

Type

```
! CISDFCRC16
<crc>
<filename>
<size>
<checksum>
<data>
```

Parameters	Details
<crc> = CRC value	Values: a four digit CRC value in hexadecimal. If 0000 is entered, then the CRC validation is ignored. For examples, see below.
<filename> = file name	Values: file name that is stored on the printer's file system. An extension must be specified. Files must be saved to the E: drive.
<size> = file size	Values: an eight digit file size specified in hexadecimal which indicates the number of bytes in the <data> section.
<checksum> = checksum value	Values: a four digit checksum value in hexadecimal. If 0000 is entered, then the CRC validation is ignored. The checksum value is calculated using the sum of the bytes in the <data> section. For examples, see below.
<data> = data	Values: Binary data saved on the printer's file system as <filename>. Number of bytes in this field must match the <size> parameter.



Note • This command can be used in place of the **~DG** and **~DY** command for more saving and loading options. **~DY** is the preferred command to download TrueType fonts on printers with firmware later than X.13. The **CISDFCRC16** command also supports downloading wireless certificate files.



Example 1 • This example shows the **CISDFCRC16** command used to download a private key file (**privkey.nrd**) to the printer. The different sections of the command are on separate lines.

```
! CISDFCRC16
BA0B
privkey.nrd
0000037B
E3AF
-----BEGIN RSA PRIVATE KEY-----
MIICXgIBAAKBgQDQXu/E9YuG1ScfWQepZa8Qe/1mJRpmk8oPhPVvam/4M5/WaWQp
3/p1f8J17/hDH8fFq5Dnx3/tHaU7A4SK08GeghX5hnp/mt4tuQEvsXkCrcgS1puz
z5db07ThhuzxYClnr7uiXPvSRXawgWDPas+0q/6gHeUSXtA0EofuIyv7wIDAQAB
AoGBAJPnf3wn6wT5pE59DJiyakRiLmkt1wK0zv0bJfgS7i2Yv1EbeAy9PnPe3vKG
Bovm6A+oi2/qTSTLUTiFc7QHxJPVxLmRiHmbf1Q8j+VJkGTpwt8EY/Px+HSM2HAP
jqd+Im0IiE9RQPsxwQH9UaauF6n15gIFMF74BIPsVzFXLFfxAkeA6zSrCKCycE/P
14cjzibnLiWxdL3U3I9eWuhmIS37RB6UJFBCWUPWr26H1HzOKqhOUMbFf5hOmvkZ
gciN9A8kxwJBAOLK7Gyorre8iK9IMMwc70IJC7H8pH1y/N20tyaC1XuPfqz0H4PH
w2W2m3BhZ7ggHJLLiiFVF+Hr5X7cibFD05kCQQDFe51HSzXHWxvViN/N+0gL1RYk
Q0cisTW1+n8Vyle5wDr+Km0q6eytq44mvIuWAW6QH/TfZxBIynICKFQX4UctAkAm
P80iAkz9RfnTfhxjp7S35poxoYdodPU6tLAK+ZnhrfDSYJXUFuPYirSqfnMMtbW7
+EICnyRZAP0CqVU7pUm5AkEAnH206dKvUvwoEX+CscVATRrejKLCeJ+6YZWqiD9X
0XGJgrHNXGpDtQiVSGM59p0XnHTZJYjvVNdnOMnhg333nQ==
-----END RSA PRIVATE KEY-----
```



Example 2 • These are examples of CRC and checksum values:

CRC example

The value of the `<crc>` field is calculated the CRC-16 for the contents of a specified file using the CRC16-CCITT polynomial which is $x^{16} + x^{12} + x^5 + 1$. It is calculated using an initial CRC of 0x0000.

checksum example

Given 4 bytes of data : 0x25, 0x62, 0x3F, 0x52:

1. Adding all bytes together gives 0x118.
2. Drop the carry nibble to get 0x18.
3. Get the two's complement of the 0x18 to get 0xE8.
This is the checksum byte.



Note

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

comm.baud

This command refers to the printer's comm (cable) baud rate. For printer support, see [SGD Command Support on page 1393](#).



Important • Once the printer's communication port parameters have been changed, the host terminal must also be configured to match the new printer settings before the host can communicate again.

Commands	Details
setvar	<p>This command instructs the printer to change the baud rate.</p> <p>Format: ! U1 setvar "comm.baud" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "9600" "19200" "38400" "57600" "115200" <p>Default: "19200"</p>
getvar	<p>This command instructs the printer to respond with the currently set printer baud rate.</p> <p>Format: ! U1 getvar "comm.baud"</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • In this example, the `getvar` retrieves the current baud rate.

```
! U1 getvar "comm.baud"
```



Example 2 • This `setvar` example sets the communications baud rate to 19200 BPS.

```
! U1 setvar "comm.baud" "19200"
```

comm.halt

This command halts all communications to the serial port if an error condition occurs.

Commands	Details
setvar	This command instructs the printer to halt communication to the printer. Format: ! U1 setvar "comm.halt" "value" Values: "yes" "no" Default: "yes"
getvar	This command returns the current value. Format: ! U1 getvar "comm.halt" Values: "yes" "no"



Example: This setvar example sets the value set to "yes".
! U1 setvar "comm.halt" "yes"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

comm.pnp_option

The `comm.pnp_option` command configures the RS-232 Serial Port Plug and Play setting on the printer. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
<code>setvar</code>	<p>This command instructs the printer to change the <code>comm.pnp_option</code> setting.</p> <p>Format: <code>! U1 setvar "comm.pnp_option" "value"</code></p> <p>Values:</p> <ul style="list-style-type: none"> <code>"off"</code> = sets the printer to not attempt Plug and Play via serial at startup <code>"on"</code> = sets the printer to attempt Plug and Play via serial at startup <p>Default: <code>"off"</code></p>
<code>getvar</code>	<p>This command causes the printer to return the current setting for the <code>comm.pnp_option</code> setting.</p> <p>Format: <code>! U1 getvar "comm.pnp_option"</code></p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `setvar` sets the serial port communications state to `"on"`.

```
! U1 setvar "comm.pnp_option" "on"
```

When the `setvar` value is set to `"on"`, the `getvar` result is `"on"`.



Note • Not all Operating Systems and computer hardware support Plug and Play over RS-232 Serial port connections.

comm.type

This printer setting determines the behavior of the serial port interface. It selects one of three serial communication states: DTE, DCE or Autodetect. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to change the serial port interface type.</p> <p>Format: ! U1 setvar "comm.type" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "auto" = Autodetect "dte" = Force DTE (Tx on pin 2) "dce" = Force DCE (Rx on pin 2) <p>Default: "auto"</p>
getvar	<p>This command instructs the printer to respond with the current serial port interface type.</p> <p>Format: ! U1 getvar "comm.type"</p>

Supported Devices

- LP 2824 Plus



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • In this example, the `getvar` retrieves the serial port communications state.

```
! U1 getvar "comm.type"
```



Example 2 • This `setvar` example sets the communications port state to Autodetect.

```
! U1 setvar "comm.type" "auto"
```

comm.parity

This command sets the printer's communication parity. For printer support, see [SGD Command Support on page 1393](#).



Important • Once the printer's communication port parameters have been changed, the host terminal must also be configured to match the new printer settings before the host can communicate again.

Commands	Details
setvar	<p>This command instructs the printer to set the communication port parity.</p> <p>Format: ! U1 setvar "comm.parity" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "N" — None "E" — Even "O" — Odd <p>Default: "N"</p>
getvar	<p>This command instructs the printer to respond with the currently set printer parity.</p> <p>Format: ! U1 getvar "comm.parity"</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • In this example, the `getvar` retrieves the currently set printer parity.

```
! U1 getvar "comm.parity"
```



Example 2 • This `setvar` example sets the parity to None.

```
! U1 setvar "comm.parity" "N"
```

comm.stop_bits

This command refers to the printers's communication port stop bits. For printer support, see [SGD Command Support on page 1393](#).



Important • Once the printer's communication port parameters have been changed, the host terminal must also be configured to match the new printer settings before the host can communicate again.

Commands	Details
setvar	This command instructs the printer to configure the comm.port stop bit value. Format: ! U1 setvar "comm.stop_bits" "value" Values: "1" "2" Default: "1"
getvar	This command instructs the printer to respond with the currently set stop bit value. Format: ! U1 getvar "comm.stop_bits"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • In this example, the `getvar` retrieves the currently set stop bit value.
! U1 getvar "comm.stop_bits"



Example 2 • This `setvar` example configures the comm.port for 1 stop bit.
! U1 setvar "comm.stop_bits" "1"

cradle.comm.baud

Sets or retrieves the cradle serial USB port baud rate.

Commands	Details
setvar	Format: ! U1 setvar "cradle.comm.baud" "value" Values: 300,1200,2400,4800,9600,19200,38400,57600,115200,230400,460800,921600 Default: "115200"
getvar	Format: ! U1 getvar "cradle.comm.baud"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

cradle.comm.handshake

Sets or retrieves the cradle serial USB port handshake mode.

Commands	Details
setvar	Format: ! U1 setvar "cradle.comm.handshake" "value" Values: "rts/cts" = use hardware handshake via the request-to-send/clear-to-send pins "xon/xoff" = use software handshake "none" = no flow control Default: "rts/cts"
getvar	Format: ! U1 getvar "cradle.comm.handshake"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

cutter.clean_cutter

This command determines if the clean cutter option is enabled or disabled. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to set the clean cutter option. Format: ! U1 setvar "cutter.clean_cutter" Values: "on" = turns on clean cutter "off" = turns off clean cutter Default: "on"
getvar	This command retrieves the status of the clean cutter option. Format: ! U1 getvar "cutter.clean_cutter"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "on".
 ! U1 setvar "cutter.clean_cutter" "on"
 When the setvar value is set to "on", the getvar result is "on".

device.applicator.data_ready

This command will specify if a "high" or "low" value is required for the applicator to indicate it is ready to receive data.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.data_ready" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.data_ready"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.end_print

This command allows you to control an online verifier or applicator device. This command is similar to the **b** parameter for [^JJ on page 237](#).

Commands	Details
setvar	<p>This command sets the value for the applicator port mode</p> <p>Format: ! U1 setvar "device.applicator.end_print" "value"</p> <p>Values: off</p> <p>1 =End Print signal normally high, and low only when the printer is moving the label forward.</p> <p>2 = End Print signal normally low, and high only when the printer is moving the label forward.</p> <p>3 = End Print signal normally high, and low for 20 ms when a label has been printed and positioned.</p> <p>4 = End Print signal normally low, and high for 20 ms when a label has been printed and positioned.</p> <p>Default: off</p>
getvar	<p>This command instructs the printer to respond with the currently set value.</p> <p>Format: ! U1 getvar "device.applicator.end_print"</p>

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.feed

This command will specify if a "high" or "low" value is required for an applicator to feed media.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.feed" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.feed"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.media_out

This command will specify if a "high" or "low" value is required for an applicator to indicate that the media has run out.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.media_out" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.media_out"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- XiIIPlus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.pause

This command will specify if a "high" or "low" value is required for an applicator to pause printing.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.pause" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.pause"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.reprint

This command will specify if a "high" or "low" value is required for an applicator to reprint a label. This command is similar to [~PR on page 300](#).

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.reprint" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.reprint"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.rfid_void

This command will specify if a "high" or "low" value is used for the RFID void signal, which occurs when an RFID label is voided by the printer.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.rfid_void" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.rfid_void"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.ribbon_low

This command will specify if a "high" or "low" value is required for an applicator to indicate that the ribbon is running out.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.ribbon_low" "value" Values: high, low Default: high
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.ribbon_low"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- XiIIPlus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.ribbon_out

This command will specify if a "high" or "low" value is required for an applicator to indicate that the ribbon has run out.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.ribbon_out" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.ribbon_out"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- XiIIPlus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.service_required

This command will specify if a "high" or "low" value is required for an applicator to indicate that maintenance is required.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.service_required" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.service_required"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.start_print

This command will specify if a "high" or "low" value is required for an applicator to start printing.

Commands	Details
setvar	This command sets the value. Format: ! U1 setvar "device.applicator.start_print" "value" Values: high, low Default: low
getvar	This command instructs the printer to respond with the currently set value. Format: ! U1 getvar "device.applicator.start_print"

Supported Devices

- ZE500™ series
- PAX4™ series
- Xi4™ series
- Xi11Plus™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.bluetooth_installed

Determines if there is a Bluetooth radio installed in the printer.

Commands	Details
getvar	Format: ! U1 getvar "device.bluetooth_installed" Result: "yes" - a Bluetooth radio is installed in the printer. "no" - no Bluetooth radio is installed.

Supported Devices

- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT410, ZT420, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.command_override.active

This command enables or disables the device.command_override function. When enabled, the printer will ignore the list of commands previously specified using the device.command_override.add. Use of this command does not modify the list.

Commands	Details
setvar	This command sets the the printer to turn on/off device.command_override. Format: ! U1 setvar "device.command_override.active" "value" Values: yes = active no = inactive Default: yes
getvar	This command returns the active/inactive state of device.command_override. Format: ! U1 getvar "device.command_override.active" Values: yes = active no = inactive Default: yes



Examples:

```
! U1 setvar "device.command_override.active" "yes"  
! U1 setvar "device.command_override.active" "no"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.command_override.add

This command adds a specified command to the list of commands that will be ignored by the printer. The list is saved when the printer is powered off. The list is not cleared when the printer is defaulted.

- If there are items in the list and the `device.command_override.active` is set to "yes", then the config label will show **ACTIVE COMMAND OVERRIDE**.
- If there are no items in the list or `device.command_override.active` is set to "no", then the config label will show **INACTIVE COMMAND OVERRIDE**.

Commands	Details
setvar	<p>The add command instructs the printer to add a specified command to the list of override commands..</p> <p>Format: ! U1 setvar "device.command_override.add" "command"</p> <p>Values: any ZPL or Set/Get/Do command</p> <p>Default: NA</p>

➔ **Example:** When specifying a ZPL command, the command must be preceded by the current format or control prefix character (e.g. ^ or ~). Multiple commands must be declared with its own setvar declaration.

```
! U1 setvar "device.command_override.add" "^MN"
! U1 setvar "device.command_override.add" "^PR"
! U1 setvar "device.command_override.add" "comm.baud"
! U1 setvar "device.command_override.add" "device.reset"
```

➔ **Example:** The following example would **NOT** be valid.

```
! U1 setvar "device.command_override.add" "~HI,~HS,^MN"
and would have to be re-sent as
```

```
! U1 setvar "device.command_override.add" "~HI"
! U1 setvar "device.command_override.add" "~HS"
! U1 setvar "device.command_override.add" "^MN"
```



Important • You can not add "device.command_override.clear" to the list of accepted override commands.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.command_override.clear

This command clears all commands from the command override list.

Commands	Details
setvar	<p>The <code>clear</code> command clears the list of override commands specified in device.command_override.list on page 635.</p> <p>Format: ! U1 setvar "device.command_override.clear" "value"</p> <p>Values: NA</p> <p>Default: NA</p>



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

device.command_override.list

This command returns to the host a list of the current set of commands that the printer will ignore.

Commands	Details
getvar	The <code>list</code> command prints a comma-delimited list of override commands. Format: ! U1 getvar "device.command_override.list" Values: NA Default: NA

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.company_contact

This command sets the company contact information, which can be accessed from the server/sysinfo.htm webpage.

Commands	Details
setvar	Sets the company contact information. Format: ! U1 setvar "device.company_contact" "value" Values: Any string up to 128 characters in length Default: ""
getvar	Displays the current company contact information. Format: ! U1 getvar "device.company_contact"

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.



Example: This setvar example shows the value set to "Zebra".

```
! U1 setvar "device.company_contact" "Zebra"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.configuration_number

Returns the current SKU number of the printer.

Commands	Details
getvar	Format: ! U1 getvar "device.configuration_number"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.cpcl_synchronous_mode

This command enables/disables CPCL synchronous mode. When the printer is in sync mode, parsing will "lock" while printing is going on, allowing behavior similar to that of the legacy SH3 mobile printers.

Commands	Details
setvar	This command sets the the printer to turn on/off <code>device.cpcl_synchronous_mode</code> . Format: ! U1 setvar "evice.cpcl_synchronous_mode" "value" Values: on = puts the printer in CPCL synchronous mode off = puts the printer in default mode Default: off
getvar	This command returns the the current value of the setting. Format: ! U1 getvar "evice.cpcl_synchronous_mode"

Supported Devices QLn™ series



Consider issuing a label immediately followed by an SGD request. When sync mode is "off", the SGD will be returned nearly immediately after submitting the label. When sync mode is "on", the SGD will be returned after the label has printed.

Examples:

```
! U1 setvar "evice.cpcl_synchronous_mode" "on"  
! U1 setvar "evice.cpcl_synchronous_mode" "off"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.cutter_installed

This command reports if a cutter unit is installed.

Commands	Details
getvar	This command checks if a cutter is installed. Format: ! U1 getvar "device.cutter_installed" Values: Yes or No Default: No



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.download_connection_timeout

This command instructs the printer to abort a firmware download if the printer fails to receive any download data in the set amount of seconds. If the set amount of seconds is exceeded, the download will be aborted, and the printer automatically restarts. This command prevents the printer from being locked into the downloading state, if the communication to the host is interrupted. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to abort a firmware download if the printer fails to receive any download data in the set amount of seconds. Format: ! U1 setvar "device.download_connection_timeout" "value" Values: "0" through "65535" Default: "0" ("0" disables this feature)
getvar	This command retrieves the connection time out value (in seconds). Format: ! U1 getvar "device.download_connection_timeout"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "0".

```
! U1 setvar "device.download_connection_timeout" "0"
```

When the setvar value is set to "0", the getvar result is "0".

device.ep1_legacy_mode

This command places the printer in a 2824/2844 compatibility mode for vertical registration.

Commands	Details
setvar*	<p>This command instructs the printer to change the ep1_legacy_mode setting.</p> <p>Format: ! U1 setvar "device.ep1_legacy_mode" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> off = ep1_legacy_mode not active registration = EPL legacy registration mode on print orientation = EPL legacy print orientation mode on all = all EPL legacy modes on <p>Default: "off"</p>
getvar	<p>This command causes the printer to return the current setting for the device.ep1_legacy_mode setting.</p> <p>Format: ! U1 getvar "device.ep1_legacy_mode"</p>

Supported Devices

- G-Series printers
- LP2824 Plus and TLP 2824 Plus



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • This setvar example shows the value set to "registration".

```
! U1 setvar "device.ep1_legacy_mode" "registration"
```

Example 2 • This setvar example shows the value set to "print_orientation".

```
! U1 setvar "device.ep1_legacy_mode" "print_orientation"
```

Example 3 • This getvar example shows the response when the value was set to "registration" and "print_orientation".

```
! U1 getvar "device.ep1_legacy_mode"
"registration, print_orientation"
```

Example 4 • This getvar example shows the response when value was set to "all"

```
! U1 getvar "device.ep1_legacy_mode"
"all"
```

These are the possible responses to getvar "device.ep1_legacy_mode"

- "off"
- "registration"
- "print_orientation"
- "registration, print_orientation"
- "all"



Note • This setting is not defaulted as part of a factory default (^JUF or ^default). The setting is persistent across a power cycle or rest (~JR or device.reset).

When setting the "registration" mode, the "print_orientation" mode is not changed. Likewise, when setting the "print_orientation" mode, the "registration" mode is not changed. Using "off" or "all" changes all modes.

Print Orientation Mode



Note • When the printer is powered on, the print orientation defaults to ^PON (EPL ZB mode). The print orientation setting is not saved across power cycles. This is different than TLP2844, LP2844, TLP2824, LP2824, and TLP3842 printers. Those printers have a default of ZB (ZPL ^PON mode) and the print orientation setting is saved across power cycles. To make the printer have the print orientation behavior of the TLP2844, LP2844, TLP2824, LP2824, and TLP3842 printers, set the epl_legacy_mode to "print_orientation".

Registration Mode



Note • When printing labels using EPL commands, printing starts 1mm from the top edge of the label (from the gap). This is known as the "no print zone". When printing in ZT mode, the "no print zone" starts at the gap on the leading edge of the label. When printing in ZB mode, the "no print zone" starts from the gap on the trailing edge of the label. In the TLP2844, LP2844, TLP2824, LP2824, and TLP3842 printers, the distance from gap to start of print (the "no print zone") is not always 1mm.

The table below shows the nominal distance.

Distance from Edge of Label to First Print Line (No Print Zone)			
Legacy Printer Model	New Printer Model	ZT Mode	ZB Mode
LP2844	GX420, GK420 (direct thermal)	1.9 mm	0.0 mm
TLP2844	GX420, GK420 (thermal transfer)	0.4 mm	1.6 mm
TLP3842	GX430 (thermal transfer)	0.0 mm	1.2 mm
LP2824	LP 2824 Plus (direct thermal)	1.5 mm	0.4 mm
TLP2824	TLP 2824 Plus (thermal transfer)	0.1 mm	1.8 mm

af. Setting epl_legacy_mode to "registration" selects the distance shown in the table.

ag. Setting epl_legacy_mode to "off" selects a no print zone distance of 1mm.

device.feature.bluetooth_le

Indicates whether or not the printer supports Bluetooth LE.

Commands	Details
getvar	Format: ! U1 getvar "device.feature.bluetooth_le" Values: "present" = a Bluetooth LE radio is installed "not present" = no Bluetooth LE radio is installed "not available" = Bluetooth LE radio is not available on this printer

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.feature.mcr

Indicates if the magnetic card reader is installed and available.

Commands	Details
getvar	<p>Format: ! U1 getvar "device.feature.mcr"</p> <p>Values: "not available" = the magnetic card reader is not available on the printer "not present" = the magnetic card reader is available but not installed "present" = the magnetic card reader is both available and installed on the printer</p> <p>Default: NA</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338, ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.feature.nfc

Indicates if the printer supports the optional Active Near Field Communication (NFC) feature, and if it is currently installed.

Commands	Details
getvar	Format: ! U1 getvar "device.feature.nfc" Values: "not available" = active NFC is not supported. "not present" = active NFC is supported, but no reader is installed. "present" = active NFC is supported with a reader is installed. Default: NA

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338, ZR638, ZR628
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.feature.ribbon_cartridge

Indicates if the printer can accept a ribbon cartridge, and if so, if one is installed.

Commands	Details
getvar	<p>Format: ! U1 getvar "device.feature.ribbon_cartridge"</p> <p>Result:</p> <ul style="list-style-type: none">"not available" - the ribbon cartridge is not available on the platform"not present" - the printer is capable of accepting a ribbon cartridge, but one is not currently installed"present" - a ribbon cartridge is installed

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338, ZR638, ZR628
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.friendly_name

This command shows the name assigned to the printer. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command sets the printer's name. Format: ! U1 setvar "device.friendly_name" "value" Default: "xxxxxxxx" ("xxxxxxxx" represents the main logic board serial number)
getvar	This command retrieves the name assigned to the printer. Format: ! U1 getvar "device.friendly_name"



Note • For details on SGD command structure, see [Command Structure on page 986](#).



Example: This setvar example shows the value set to "xxxxxxxx".

```
! U1 setvar "device.friendly_name" "xxxxxxxx"
```

When the setvar value is set to "xxxxxxxx", the getvar result is "xxxxxxxx".

device.frontpanel.feedenabed

This command can be used to enable or disable the FEED key or any other key on the printer. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to change the <code>front_panel.feedenabed</code> setting.</p> <p>Format: <code>! U1 setvar "device.frontpanel.feedenabed"</code></p> <p>Values:</p> <ul style="list-style-type: none"> "yes" = Front Panel keys are enabled "no" = Front Panel keys are disabled <p>Default:</p> <ul style="list-style-type: none"> "no" = for GX420s printers "yes" = all supported printers except GX420s <p>Power On Default:</p> <ul style="list-style-type: none"> "no" = for GX420s printers "yes" = all supported printers except GX420s
getvar	<p>This command retrieves the current setting for the <code>front_panel.feedenabed</code> command:</p> <p>Format: <code>! U1 getvar "device.frontpanel.feedenabed"</code></p>

Supported Devices

- GK420
- GX420, GX430, GX420s
- LP/TLP 2824 Plus,



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `setvar` sets the value to "no".
`! U1 setvar "device.frontpanel.feedenabed" "no"`



Note • On GX420 printers with an LCD display, there is a **SCROLL** and **SELECT** key in addition to the **FEED** key. Both the **SCROLL** and **SELECT** keys are enabled or disabled when the **FEED** key is enabled or disabled using this command.



Note • On power up, for model GX420s printer, the command value is set to "no". For all other printers, on power up, the command value is set to "yes".

device.frontpanel.key_press

This command instructs the printer to press a button on the front panel. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details		
setvar	<p>This command instructs the printer to press a button on the front panel.</p> <p>Format: ! U1 setvar "device.frontpanel.key_press"</p> <p>Values: The values vary per printer, as follows:</p> <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top; width: 50%;"> <p>ZM400, Z4M/Z6M, and RZ400/RZ600:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Minus "F" = Select "G" = Plus</p> <p>Xillplus:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Previous "F" = Next/Save "G" = Minus "H" = Plus "I" = Calibrate</p> </td> <td style="vertical-align: top; width: 50%;"> <p>S4M:</p> <p>"A" = Pause "B" = Feed "C" = Up Arrow "D" = Cancel "E" = Menu "F" = Enter</p> <p>Xi4, RXi4:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Previous "F" = Next/Save "G" = Minus "H" = Plus "I" = Calibrate</p> </td> </tr> </table>	<p>ZM400, Z4M/Z6M, and RZ400/RZ600:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Minus "F" = Select "G" = Plus</p> <p>Xillplus:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Previous "F" = Next/Save "G" = Minus "H" = Plus "I" = Calibrate</p>	<p>S4M:</p> <p>"A" = Pause "B" = Feed "C" = Up Arrow "D" = Cancel "E" = Menu "F" = Enter</p> <p>Xi4, RXi4:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Previous "F" = Next/Save "G" = Minus "H" = Plus "I" = Calibrate</p>
<p>ZM400, Z4M/Z6M, and RZ400/RZ600:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Minus "F" = Select "G" = Plus</p> <p>Xillplus:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Previous "F" = Next/Save "G" = Minus "H" = Plus "I" = Calibrate</p>	<p>S4M:</p> <p>"A" = Pause "B" = Feed "C" = Up Arrow "D" = Cancel "E" = Menu "F" = Enter</p> <p>Xi4, RXi4:</p> <p>"A" = Pause "B" = Feed "C" = Cancel "D" = Setup/Exit "E" = Previous "F" = Next/Save "G" = Minus "H" = Plus "I" = Calibrate</p>		



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "A".

```
! U1 setvar "device.frontpanel.key_press" "A"
```

device.frontpanel.line1

This command overrides the content that is shown on the first line of the front panel when the printer is showing the idle display. Use of the `getvar` function is dependent on first using the `setvar` function. For example, to have the first line of the idle display to show HELLO, you must first send a `setvar` command; then a `getvar` command can be sent to retrieve the value HELLO. For printer support, see [SGD Command Support on page 1393](#). For details on the supported character set, see [Character Set on page 1389](#).

Commands	Details
<code>setvar</code>	<p>This command instructs the printer to set the content that is shown on line one of the front panel.</p> <p>Format: <code>! U1 setvar "device.frontpanel.line1" "value"</code></p> <p>Values: The maximum amount of alphanumeric ASCII characters available for line 1 on the printer's front panel</p> <p>Default: ""</p>
<code>getvar</code>	<p>This command retrieves the content that is shown on line one of the front panel.</p> <p>Format: <code>! U1 getvar "device.frontpanel.line1"</code></p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This `setvar` example shows the value set to "sample line 1".

```
! U1 setvar "device.frontpanel.line1" "sample line 1"
```

When the `setvar` value is set to "sample line 1", the `getvar` result is "sample line 1".

device.frontpanel.line2

This command overrides the content that is shown on the second line of the front panel when the printer is showing the idle display. Use of the `getvar` function is dependent on using the `setvar` function. For example, to have the second line of the idle display show HELLO, you must first send a `setvar` command; then a `getvar` command can be sent to retrieve the value HELLO. For printer support, see [SGD Command Support on page 1393](#). For details on the supported character set, see [Character Set on page 1389](#).

Commands	Details
<code>setvar</code>	<p>This command instructs the printer to set the content that shows on line two of the front panel.</p> <p>Format:</p> <pre>! U1 setvar "device.frontpanel.line2" "value"</pre> <p>Values: The maximum amount of alphanumeric ASCII characters available for line two on the printer's front panel</p> <p>Default: ""</p>
<code>getvar</code>	<p>This command retrieves the content that shows on line two of the front panel.</p> <p>Format: <code>! U1 getvar "device.frontpanel.line2"</code></p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This `setvar` example shows the value set to "sample line 2".

```
! U1 setvar "device.frontpanel.line2" "sample line 2"
```

When the `setvar` value is set to "sample line 2", the `getvar` result is "sample line 2".

device.frontpanel.xml

This command retrieves the current content of the front panel in an XML format. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the file that determines the representation of the front panel. Format: ! U1 getvar "device.frontpanel.xml"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` shows the status of the LEDs and the two lines of the front panel in XML formatted text. The text below is formatted for easy reading. When you use this command the response will not contain line feeds.

```
! U1 getvar "device.frontpanel.xml"
```

```
<FRONT-PANEL>  
  <LCD>  
    <LINE1>PRINTER READY</LINE1>  
    <LINE2>V53.16.0</LINE2>  
  </LCD>  
  <LEDS>  
    <PAUSE-LED>STEADY-OFF</PAUSE-LED>  
    <DATA-LED>STEADY-OFF</DATA-LED>  
    <ERROR-LED>STEADY-OFF</ERROR-LED>  
  </LEDS>  
</FRONT-PANEL>
```

device.host_identification

This command is designed to be sent from the host to the Zebra printer to retrieve information. Upon receipt, the printer responds with information on the model, software version, dots-per-millimeter setting, memory size, and any detected options.

This command is equivalent to the ~HI ZPL command.

Commands	Details
getvar	<p>This command displays information about the printer.</p> <p>Format: ! U1 getvar "device.host_identification"</p> <p>Result: xxxxxx,v1.0.0,dpm,000KB,x</p> <p>Values:</p> <p>XXXXXX = model of Zebra printer</p> <p>V1.0.0 = version of software</p> <p>dpm = dots/mm</p> <p>6, 8, 12, or 24 dots/mm printheads</p> <p>000KB = memory</p> <p>512KB = 1/2 MB</p> <p>1024KB = 1 MB</p> <p>2048KB = 2 MB</p> <p>4096KB = 4 MB</p> <p>8192KB = 8 MB</p> <p>x = recognizable options</p> <p>only options specific to printer are shown (cutter, options, et cetera.)</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.host_status

When this command is sent to the printer, the printer sends three data strings back. To avoid confusion, the host prints each string on a separate line.

This command is similar to the **~HS** ZPL command.

The response for this SGD command does not include the **STX** at the beginning of each data line and does not include the **ETX** at the end of each data line as found in the **~HS** response. Additionally, the first and second response lines for the SGD command contain a **CR/LF** at the end of each line.



Note • When the command is sent, the printer will not send a response to the host if the printer is in one of these conditions:

- MEDIA OUT
- RIBBON OUT
- HEAD OPEN
- REWINDER FULL
- HEAD OVER-TEMPERATURE

Commands	Details
getvar	<p>Format: ! U1 getvar "device.host_status"</p> <p>Result: Three strings, each on their own line.</p> <pre>"aaa,b,c,dddd,eee,f,g,h,iii,j,k,l mmm,n,o,p,q,r,s,t,uuuuuuuu,v,www xxxx,y"</pre> <p>Values: See definitions for String 1, String 2, and String 3 below.</p>

String 1 "aaa,b,c,dddd,eee,f,g,h,iii,j,k,l"

aaa	=	communication (interface) settings ^a
b	=	paper out flag (1 = paper out)
c	=	pause flag (1 = pause active)
dddd	=	label length (value in number of dots)
eee	=	number of formats in receive buffer
f	=	<i>buffer full</i> flag (1 = receive buffer full)
g	=	<i>communications diagnostic mode</i> flag (1 = diagnostic mode active)
h	=	<i>partial format</i> flag (1 = partial format in progress)
iii	=	unused (always 000)
j	=	<i>corrupt RAM</i> flag (1 = configuration data lost)
k	=	temperature range (1 = under temperature)
l	=	temperature range (1 = over temperature)

ah. This string specifies the printer's baud rate, number of data bits, number of stop bits, parity setting, and type of handshaking. This value is a three-digit decimal representation of an eight-bit binary number. To evaluate this parameter, first convert the decimal number to a binary number.

The nine-digit binary number is read according to this table:

aaa = a ⁸ a ⁷ a ⁶ a ⁵ a ⁴ a ³ a ² a ¹ a ⁰	
a ⁷ = Handshake 0 = Xon/Xoff 1 = DTR	a ⁸ a ² a ¹ a ⁰ = Baud 0 000 = 110 0 001 = 300 0 010 = 600 0 011 = 1200 0 100 = 2400 0 101 = 4800 0 110 = 9600 0 111 = 19200 1 000 = 28800 (available only on certain printer models) 1 001 = 38400 (available only on certain printer models) 1 010 = 57600 (available only on certain printer models) 1 011 = 14400
a ⁶ = Parity Odd/Even 0 = Odd 1 = Even	
a ⁵ = Disable/Enable 0 = Disable 1 = Enable	
a ⁴ = Stop Bits 0 = 2 Bits 1 = 1 Bit	
a ³ = Data Bits 0 = 7 Bits 1 = 8 Bits	

String 2 "mmm,n,o,p,q,r,s,t,uuuuuuu,v,www"

mmm	= function settings ^b
n	= unused
o	= <i>head up</i> flag (1 = head in up position)
p	= <i>ribbon out</i> flag (1 = ribbon out)
q	= <i>thermal transfer mode</i> flag (1 = Thermal Transfer Mode selected)
r	= Print Mode
	0 = Rewind
	1 = Peel-Off
	2 = Tear-Off
	3 = Cutter
	4 = Applicator
	5 = Delayed cut
	6 = Reserved ^c
	7 = Reserved ^c
	8 = Reserved ^c
	9 = RFID
s	= print width mode
t	= <i>label waiting</i> flag (1 = label waiting in Peel-off Mode)
uuuuuuuu	= labels remaining in batch
v	= <i>format while printing</i> flag (always 1)
www	= number of graphic images stored in memory

ai. This string specifies the printer's media type, sensor profile status, and communication diagnostics status. As in String 1, this is a three-digit decimal representation of an eight-bit binary number. First, convert the decimal number to a binary number.

aj. These values are only supported on the Xi4, RXi4, ZM400/ZM600, RZ400/RZ600, and ZT200 Seriesprinters.

The eight-digit binary number is read according to this table:

mmm = m7 m6 m5 m4 m3 m2 m1 m0	
m7 = Media Type 0 = Die-Cut 1 = Continuous	m4 m3 m2 m1 = Unused 0 = Off 1 = On
m6 = Sensor Profile 0 = Off	m0 = Print Mode 0 = Direct Thermal 1 = Thermal Transfer
m5 = Communications Diagnostics 0 = Off 1 = On	

String 3 "xxxx,y"

xxxx	=	password
y	=	0 (static RAM not installed) 1 (static RAM installed)



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.idle_display_format

Retrieves and sets the front panel's idle display format.

Commands	Details
setvar	<p>Format: ! U1 setvar "device.idle_display_format" "value"</p> <p>Values: fw-version,ip-address,mm/dd/yy-24-hr,mm/dd/yy-12-hr,dd/mm/yy-24-hr,dd/mm/yy-12-hr</p> <p>Default: "fw-version" (firmware version)</p>
getvar	<p>Format: ! U1 getvar "device.idle_display_format"</p> <p>Result: fw-version,ip-address,mm/dd/yy-24-hr,mm/dd/yy-12-hr,dd/mm/yy-24-hr,dd/mm/yy-12-h</p>

Supported Devices

- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.idle_display_value

Returns the printer's current front panel idle display information.

Type	Details
getvar	Format: ! U1 getvar "device.idle_display_value" Result: A firmware version, the printer's IP address, or the date.

Supported Devices

- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420





Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.internal_wired_setting_location

This command identifies the location from where internal_wired network specific settings should be retrieved.

Commands	Details
setvar*	<p>This command specifies the location from where internal_wired network specific settings should be retrieved.</p> <p>Format: ! U1 setvar "device.internal_wired_setting_location" "value"</p> <p>Values: "network card" "printer"</p> <p> Note • "printer" is the only valid option for the QLn series and ZD500 series printers.</p> <p>Default: "network_card"</p>
getvar	<p>This command displays the location where internal_wired network specific settings are retrieved from.</p> <p>Format: ! U1 getvar "device.internal_wired_setting_location"</p> <p> Note • "printer" is the only valid getvar option for the QLn series and ZD500 series printers.</p>

Supported Devices

- ZT200™ series
- ZD500™ series
- QLn™ series



Note • For details on SGD command structure, see [Command Structure](#) on page 573. For printer support, see [SGD Command Support](#) on page 1393.

device.jobs_print

This command identifies the number of jobs to be printed. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the number of jobs to be printed. Format: ! U1 getvar "device.jobs_print"



Note • For details on SGD command structure, see [Command Structure on page 573](#).





Example: In this example, the `getvar` retrieves the jobs currently being printed or last printed.

```
! U1 getvar "device.jobs_print"
```

```
"1"
```

device.languages

This command identifies the programming language that the printer is currently using.

Commands	Details
setvar	<p>This command instructs the printer to set the printer to the required programming language.</p> <p>Format: ! U1 setvar "device.languages" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "ep1" = Eltron Programming Language "ep1_zp1" = Eltron Programming Language and Zebra Programming Language "zp1" = Zebra Programming Language "hybrid_xml_zp1" = XML and ZPL Programming Languages "ap1-d" = Virtual Device-D (only Link-OS printers) "ap1-t" = Virtual Device-T (only desktop and table top printers with Link-OS) "ap1-e" = Virtual Device-E (only mobile printers with Link-OS) "ap1-o" = Virtual Device-O (only mobile printers with Link-OS) "ap1-i" = Virtual Device-I (only Link-OS printers) <p> Important • Not all values are accepted on all printers. Use the ! U1 getvar "allcv" command to see the range of values that your printer supports. Values other than those listed may be available depending on the firmware version being used.</p> <p> Note • "zp1" and "hybrid_xml_zp1" are equivalent. When the setvar is set to "zp1", the getvar result will always be "hybrid_xml_zp1".</p> <p>Default: "ep1_zp1"</p>
getvar	<p>This command retrieves the programming language that the printer is currently using.</p> <p>Format: ! U1 getvar "device.languages"</p>



Example: This setvar example sets the programming language to "hybrid_xml_zp1" using the shorter value of "zp1".

```
! U1 setvar "device.languages" "zp1"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.light.cover_open_brightness

This command sets the brightness level for the Cover Open light.

Commands	Details
setvar	Sets the brightness level for the cover open LEDs. Format: ! U1 setvar "device.light.cover_open_brightness" "value" Values: "high" = the LEDs display at maximum brightness when the cover is open "medium" = the LEDs display at medium brightness when the cover is open "low" = the LEDs display at lowest brightness when the cover is open "off" = the LEDs remain off at all times Default: "high"
getvar	Retrieves the current brightness level setting for the cover open LEDs. Format: ! U1 getvar "device.light.cover_open_brightness"

Supported Devices ZT400 series



Example: This setvar example shows the value set to "low".

```
! U1 setvar "device.light.cover_open_brightness" "low"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.light.head_open_brightness

This command sets the brightness level for the Head Open light.

Commands	Details
setvar	<p>Sets the brightness level for the head open LEDs.</p> <p>Format: ! U1 setvar "device.light.head_open_brightness" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "high" = the LEDs display at maximum brightness when the head is open "medium" = the LEDs display at medium brightness when the head is open "low" = the LEDs display at lowest brightness when the head is open "off" = the LEDs remains off at all times <p>Default: "high"</p>
getvar	<p>Retrieves the current brightness level setting for the head open LEDs.</p> <p>Format: ! U1 getvar "device.light.head_open_brightness"</p>

Supported Devices ZT400 series



Example: This setvar example shows the value set to "medium".
! U1 setvar "device.light.head_open_brightness" "medium"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.location

Sets the system location, which is used on the "server/sysinfo.htm" webpage.

Commands	Details
setvar	Format: ! U1 setvar "device.location" "value" Values: Any ASCII string up to 128 characters. Default: "" (empty string)
getvar	Format: ! U1 getvar "device.location"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.ltu_installed

This command checks to see if a Liner Take-Up unit is installed.

Commands	Details
getvar	Format: ! U1 getvar "device.ltu_installed" Values: Yes No Default: No



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.orientation

This printer setting determines the installation orientation of the KR403 printer, either horizontal or vertical. It is intended for use only by the system integrator. Modification by an end user can result in unexpected printer behaviour.

Commands	Details
setvar	<p>This command instructs the printer to change the presenter loop length.</p> <p>Format: ! U1 setvar "device.orientation" "value"</p> <p><i>Values:</i></p> <ul style="list-style-type: none"> 0 = printer is installed horizontally 1 = is installed vertically <p><i>Default:</i></p> <ul style="list-style-type: none"> 0 = printer is installed horizontally (original factory default only, value will not change when defaulting the printer with ^JUF)
getvar	<p>This command instructs the printer to respond with the currently set presenter loop length.</p> <p>Format: ! U1 getvar "device.orientation"</p>

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure](#) on page 573.

device.pause

This command stops printing after the current label is complete (if one is printing) and places the printer in Pause Mode.

This command is equivalent to ~PP.

Commands	Details
setvar	This command stops printing and puts the printer in Pause Mode. Format: ! U1 SETVAR "device.pause" "" Values: NA Default: NA
do	This command stops printing and puts the printer in Pause Mode. Format: ! U1 D0 "device.pause" "" Values: NA Default: NA



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.pnp_option

This command defines the type of Plug and Play response that is sent by the printer after the printer is started. The printer must be restarted for a new PNP string to be reported. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to select the desired Plug and Play response option.</p> <p>Format: ! U1 setvar "device.pnp_option" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "ep1" = Eltron Programming Language "zpl" = Zebra Programming Language <p>Default: "zpl"</p>
getvar	<p>This command retrieves the Plug and Play option setting.</p> <p>Format: ! U1 getvar "device.pnp_option"</p>



Note • For GT800 printers only: when the printer's Plug and Play string is set to EPL, the KDU Plus displays 'ONNECTION - EPL Printer (DTE) even when set to ZPL Forms mode. This behavior only affects the display, not the functionality.



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "zpl".

```
! U1 setvar "device.pnp_option" "ep1"
```

When the setvar value is set to "ep1", the getvar result is "ep1".

device.pmcu.revision

Retrieves the Power Micro-Controller Unit's (PMCU) current revision number.

Commands	Details
getvar	Format: ! U1 getvar "device.pmcu.revision"

Supported Devices

- ZD410, ZD420
- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.position.accuracy

This printer setting retrieves/sets the accuracy of the geographic position values.

The units of the value depend upon the location provider that was used to determine the geographic coordinates. Usually, this is specified as a radius, in meters, of confidence around the location coordinates. Often, the radius represents a radius of 68% confidence that the true location lies within the circle, representing one standard deviation.



Note • These settings hold the value to which they are set, within the range restrictions. The printer does not perform any calculations, nor associate any meaning such as “meters” or “feet” to the values. The values can be determined by a number of methods, including an Android® or iOS® application communicating with the printer using the smart phone’s geolocation device.

Commands	Details
setvar	<p>This command sets the accuracy of the geographic position values.</p> <p>Format: ! U1 setvar "device.position.accuracy" "value"</p> <p>Values: A decimal number with 6 decimal places, e.g. 25.370000. The value is saved as a double precision floating point number.</p> <ul style="list-style-type: none"> • Minimum: 0 • Maximum: 406700000
getvar	<p>This command retrieves the accuracy of the geographic position values.</p> <p>Format: ! U1 getvar "device.position.accuracy"</p>



Example:

```
! U1 setvar "device.position.accuracy" "25.37"
```



Note • For details on SGD command structure, see [Command Structure](#) on page 573.

device.position.altitude

This printer setting retrieves the altitude above sea level.

The value is in meters above sea level. A positive number indicates a position above sea level. A negative number indicates a position below sea level. The position of sea level depends upon the system used to provide a nominal sea level reference position. This is often the World Geodetic System WGS 84 standard but depends upon the location provider.

Commands	Details
setvar	This command sets the altitude of the printer above sea level. Format: ! U1 setvar "device.position.altitude" "value" Values: A decimal number with 6 decimal places, e.g. 305.100000 The value is saved as a double precision floating point number. <ul style="list-style-type: none">• Minimum: -10000• Maximum: 406700000 Default: 0.0
getvar	This command retrieves the altitude above sea level. Format: ! U1 getvar "device.position.altitude"

**Example:**

```
! U1 setvar "device.position.altitude" "305.1"
```



Note • For details on SGD command structure, see [Command Structure](#) on page 573.

device.position.latitude

This printer setting retrieves/sets the geographic latitudinal position.

Commands	Details
setvar	This command sets the latitude position of the printer. Format: ! U1 setvar "device.position.latitude" "value" Values: The value is in decimal degrees from 0.0 to +/-90.0. Default: 0.0
getvar	This command retrieves the latitude position of the printer. Format: ! U1 getvar "device.position.latitude" Values: The value is returned with 6 decimal places. A value of 0.000001 degree is on the order of 0.1 meter of distance on the earth's surface. (The correspondence between degrees and length on the earth's surface varies because the earth is an irregular ellipsoid.)

**Example:**

```
! U1 setvar "device.position.latitude" "6.123456"
```



Note • For details on SGD command structure, see [Command Structure](#) on page 573.

device.position.longitude

This printer setting retrieves/sets the geographic longitudinal position.

Commands	Details
setvar	<p>This command sets the longitudinal position of the printer.</p> <p>Format: ! U1 setvar "device.position.longitude" "value"</p> <p>Values: The value is in decimal degrees from 0.0 to +/-180.0. The value is saved as a double precision floating point number.</p> <p>Default: 0.0</p>
getvar	<p>This command retrieves the longitudinal position of the printer. .</p> <p>Format: ! U1 getvar "device.position.longitude"</p> <p>Values: The value is returned with 6 decimal places. A value of 0.000001 degree is on the order of no more than 0.1 meter of distance on the earth's surface. (The correspondence between degrees and length on the earth's surface varies from approximately 0.1 meter at the equator to 0.0 at the poles.)</p>

**Example:**

```
! U1 setvar "device.position.longitude" "25.123456"
```



Note • For details on SGD command structure, see [Command Structure](#) on page 573.

device.print_2key

Causes the printer to print the mobile configuration report (commonly known as a 2key report).

Commands	Details
setvar	Format: ! U1 setvar "device.print_2key" "" (the set value is ignored)
do	Format: ! U1 do "device.print_2key"

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZQ510, ZQ520
- ZR638, ZR628



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.print_reprogram_2key

This command determines whether the printer will print a configuration label or 2key report after the printer restarts following a firmware update.

When set to "off" the printer will not print the configuration label or 2key report after the printer is updated.

Commands	Details
setvar	<p>This command sets whether a two-key report is printed or not.</p> <p>Format: ! U1 setvar "device.print_reprogram_2key" "value"</p> <p>Values: "yes" "no"</p> <p>Default: "no"</p>
getvar	<p>This command retrieves the current setting for processing two-key report after printer firmware is reprogrammed.</p> <p>Format: ! U1 getvar "device.print_reprogram_2key"</p> <p>Result: yes no</p>



Example: This example disables printing of the two-key report after printer firmware is reprogrammed.

```
! U1 setvar "device.print_reprogram_2key" "no"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.product_name_submodel

Retrieves the product name submodel, which is derived from the Printer Configuration Code (PCC, also known as the SKU).

Commands	Details
getvar	Format: ! U1 getvar "device.product_name_submodel" Result: "hc" = QLn Healthcare printers "none" = QLn Standard printers and all other printers

Supported Devices

- ZD500R
- iMZ 220, iMZ 320
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZQ510, ZQ520
- ZR628, ZR638



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.prompted_network_reset

Reinitializes the wireless radio card and the print server (wired or wireless) when the Wireless or Wireless Plus print server is running. The command also causes any wireless radio card in the printer to re-associate to the wireless network.

This command is equivalent to the [~WR on page 416](#) command.

Commands	Details
setvar	Format: ! U1 setvar "device.prompted_network_reset" "value" Values: "yes" = causes the network to reset "no" = no changes to the network

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500, ZD500R
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.reset

This command instructs the printer to perform a soft reset. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to perform a soft reset. Format: ! U1 setvar "device.reset" ""



Note • For details on SGD command structure, see [Command Structure on page 986](#).



Example: In this example, the `setvar` performs a soft reset.
! U1 setvar "device.reset" ""

device.restore_defaults

This command restores to the default of all settings within the specified SGD branch. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command restores to the default of all settings within the specified branch. Format: ! U1 setvar "device.restore_defaults" "value" Values: "ip" = default all parameters in the IP branch "wlan" = default all parameters in the wlan branch "internal_wired" = default all parameters in the internal wired branch
do	This command restores the default setting for all items within the specified branch. Format: ! U1 do "device.restore_defaults" "value" Values: "ip" = default all parameters in the ip branch "wlan" = default all parameters in the wlan branch "internal_wired" = default all parameters in the internal wired branch



Note • For details on SGD command structure, see [Command Structure on page 1053](#).



Example: These **do** and **setvar** examples restore the network card's wlan parameters to their default values.

```
! U1 do "device.restore_defaults" "wlan"
! U1 setvar "device.restore_defaults" "wlan"
```

device.rewinder_installed

Determines if a rewind option is installed on the printer.



Note • The Rewind Option is not the same as the Liner Take-Up Option.

Commands	Details
getvar	Format: ! U1 getvar "device.rewinder_installed" Result: "yes" = a rewind option is installed "no" = no rewind option installed

Supported Devices

- QLn320, QLn220
- ZQ510, ZQ520
- ZR638, ZR628
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.save_2key

Sets or retrieves the current device.save_2key setting.



Note • The two-key report is a configuration listing originally used on legacy mobile printers.

Commands	Details
setvar	<p>Format: ! U1 setvar "device.save_2key" "value"</p> <p>Values: "on" = Two-key diagnostics reports will be saved to Flash memory whenever a two-key report is printed. The file will be named 2KEY.TXT. "off" = Two-key reports will not be saved to Flash memory. "now" = This choice can be used to generate a two-key diagnostics report on demand and save it to Flash memory (save only, does not print). This choice does not alter the "on"/"off" state of this SGD. Default: "on"</p>
getvar	<p>Format: ! U1 getvar "device.save_2key"</p>

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220, QLn420
- ZQ510, ZQ520
- ZR638, ZR628



Example: This example instructs the printer to generate a two-key diagnostics report and save it to Flash memory.

```
! U1 setvar "device.save_2key" "now"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.sensor_select

Determines which media sensor will be used.

This command is similar to the ^JS ZPL command.

Commands	Details
setvar	Format: ! U1 setvar "device.sensor_select" "value" Values: "reflective" "transmissive" Default: "reflective"
getvar	Format: ! U1 getvar "device.sensor_select"

Supported Devices

- ZD410, ZD420
- ZD500
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.serial_number.option_board_date

Returns the date the option board was made.



Note • This command is functional only on printers that had their option board manufacturing date programmed when they were created. Older printers that do not have the option board creation date programmed will return a "?" or empty string.

Commands	Details
getvar	<p>Format: ! U1 getvar "device.serial_number.option_board_date"</p> <p>Result: a date in mm/dd/yyyy format.</p>

Supported Devices

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZQ510, ZQ520
- ZT210, ZT220, ZT230



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.serial_numbers.control_panel_date

Returns the date the control panel was made.



Note • This command is functional only on printers that had their control panel manufacturing date programmed when they were created. Older printers that do not have the control panel creation date programmed will return a "?" or empty string.

Commands	Details
getvar	Format: ! U1 getvar "device.serial_numbers.control_panel_date" Result: a date in mm/dd/yyyy format.

Supported Devices

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZQ510, ZQ520
- ZT210, ZT220, ZT230



Note

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.serial_numbers.mlb_date

Returns the date the main logic board (MLB) was made.



Note • This command is functional only on printers that had their MLB manufacturing date programmed when they were created. Older printers that do not have the MLB creation date programmed will return a "?" or empty string.

Commands	Details
getvar	<p>Format: ! U1 getvar "device.serial_numbers.mlb_date"</p> <p>Result: a date in mm/dd/yyyy format.</p>

Supported Devices

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZQ510, ZQ520
- ZT210, ZT220, ZT230



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.serial_numbers.processor

Returns the unique main processor ID.

Getvar

To have the printer return the current setting value:

```
! U1 getvar "device.serial_numbers.processor"
```

Supported Printers

- ZD410, ZD420
- ZD500R, ZD510, ZD511
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZT210, ZT220, ZT230,
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

device.set_clock_to_build_date

Enables or disables a lower bound of the firmware build date for the rtc.date SGD.

If enabled, when the printer powers up and it finds an RTC date earlier than the firmware build date, it will set the RTC date to the firmware build date.

Commands	Details
setvar	! U1 setvar "device.set_clock_to_build_date" "value" Values: "enabled" "disabled" Default: "enabled"
getvar	! U1 getvar "device.set_clock_to_build_date"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZQ510, ZQ520
- ZD620
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.slot_1

This command retrieves the type of board installed in the bottom slot of a ZT400 series printer, or in the single expansion slot of a ZT200 series printer.

Commands	Details
getvar	<p>This command retrieves the type of board installed in the bottom slot of a ZT400 series printer, or the expansion slot of a ZT200 series printer..</p> <p>Format: ! U1 getvar "device.slot_1"</p> <p>Values:</p> <ul style="list-style-type: none">"empty" = no board installed"parallel" = a parallel communications board is installed"wired" = a wired PrintServer board is installed"wireless" = a wireless PrintServer board is installed

Supported Devices

- ZT400 series
- ZT200 series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.slot_2

This command retrieves the type of board installed in the bottom slot of a ZT400 series printer.

Commands	Details
getvar	<p>This command retrieves the type of board installed in the bottom slot.</p> <p>Format: ! U1 getvar "device.slot_2"</p> <p>Values:</p> <ul style="list-style-type: none"> "empty" = no board installed "parallel" = a parallel communications board is installed "wired" = a wired PrintServer board is installed "wireless" = a wireless PrintServer board is installed



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.super_host_status

This command returns printer description information in XML format. The printer returns information on format parameters, object directories, individual object data, and print status information.

This command is equivalent to the ^HZA ZPL command.

Commands	Details
getvar	Format: ! U1 getvar "device.super_host_status" Result: Information on format parameters, object directories, individual object data, and print status information.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.syslog.clear_log

This setting clears the local syslog.entries SGD. Any log messages previously sent to an ip address are not changed.

Commands	Details
setvar	<p>Clears the local syslog file.</p> <p>Format: ! U1 setvar "device.syslog.clear_log" ""</p> <p>Values: NA</p> <p>Default: NA</p>
do	<p>Clears the local syslog file.</p> <p>Format: ! U1 do "device.syslog.clear_log" ""</p> <p>Values: NA</p> <p>Default: NA</p>

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.syslog.configuration

This setting specifies the location for the syslog messages to be recorded. The location may be either on the printer, or a syslog server IP address.

Commands	Details
setvar	<p>Specifies the location for the syslog messages to be recorded.</p> <p>Format: ! U1 setvar "device.syslog.configuration" "value"</p> <p>Values: A list of configuration entries, limited to 1000 characters. Entries must be in the form of "severity,destination" and delimited with a semi-colon.</p> <ul style="list-style-type: none"> SEVERITY - The severity levels, in decreasing severity order, are: <ul style="list-style-type: none"> emerg alert crit err warning notice info debug <p>When you specify the severity level, the lowest specified severity and all severity levels above it will be recorded. For example, if you specify debug, you will get all severity level reports. If you specify crit, you will get only crit, alert, and emerg severity reports.</p> DESTINATION - "local" or a syslog server IP address <p> Note • When configuring the local syslog report, the first local entry is used and duplicate requests to local are ignored. To configure remote syslog messages you will first need a syslog server to accept them.</p> <p>Default: ""</p>
getvar	<p>Retrieves the configuration string setting.</p> <p>Format: ! U1 getvar "device.syslog.configuration"</p>

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.

- ➔ **Example 1** • This example has emergency syslog messages being sent to an IP location, debug (and all higher severity) syslog messages to another IP address, and critical and higher syslog messages to local storage (either a file or SGD).

```
! U1 setvar "device.syslog.configuration"
"emerg,128.168.0.1;debug,192.168.0.2;crit,local;"
```
- ➔ **Example 2** • This example will only report emergency syslog messages to the local file, and ignore the duplicate location request for critical and higher reports.

```
! U1 setvar "device.syslog.configuration" "emerg,local;crit,local;"
```
- ➔ **Example 3** • This is an example of a syslog report stored at E:SYSLOG.TXT. Note that `device.syslog.save_local_file` must be enabled.

```
Feb 17 14:28:17: [Power][Informational][0X14] Power On
Feb 17 14:28:19: [Print][Informational][0XF] PQ Job Completed
Feb 17 14:28:20: [Print][Informational][0XF] PQ Job Completed
Feb 17 14:28:20: [Weblink][Informational][0X1005] Weblink disabled
Feb 17 14:28:34: [Network][Notice][0X1C] Cold Start
```



Example 4 • This is an example of a syslog report from a syslog server application monitoring an IP address.

Received	Source IP	Source Name	Facility	Severity	Timestamp	Tag	Origin	Message
3/17/2014 4:13:59.590 PM	3.5.62	18j131600029	local 0	Notice	Feb 09 19:42:33			[Print][Notice][0XE] Printer Unpaused
3/17/2014 4:13:57.365 PM	3.5.62	18j131600029	local 0	Notice	Feb 09 19:42:31			[Print][Notice][0X8] Head Closed
3/17/2014 4:13:56.237 PM	3.5.62	18j131600029	local 0	Warning	Feb 09 19:42:30			[Print][Warning][0XA] Ribbon In
3/17/2014 4:13:56.230 PM	3.5.62	18j131600029	local 0	Notice	Feb 09 19:42:30			[Print][Notice][0XD] Printer Paused
3/17/2014 4:13:56.224 PM	3.5.62	18j131600029	local 0	Error	Feb 09 19:42:30			[Print][Error][0X7] Head Open



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.syslog.enable

This printer setting enables syslog messages.



Important • The destination of syslog messages is specified in device.syslog.configuration.

Commands	Details
setvar	Enables or disables syslog. Format: ! U1 setvar "device.syslog.enable" "value" Values: "on" "off" Default: "off"
getvar	Displays whether syslog is enabled. Format: ! U1 getvar "device.syslog.enable"

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.



Example: This setvar example shows the value set to "on".

```
! U1 setvar "device.syslog.enable" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.syslog.entries

This printer setting displays previously sent syslog messages. If there are no previously sent syslog messages, an empty string is returned.



Important • The destination of syslog messages is specified in device.syslog.configuration.

Commands	Details
getvar	<p>Displays previously sent syslog messages.</p> <p>Format: ! U1 getvar "device.syslog.entries"</p> <p>The format of each syslog message includes the printer feature, the severity level, the unique message code, and the unique English message. This allows for more advanced systems administrators to filter particular messages of interest. Syslog currently supports unique messages for most printer alerts, WebLink, and some USB Host messages.</p>

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.



Example: This `getvar` example shows the value of the syslog file.

```
! U1 getvar "device.syslog.entries"
```

returns

```
Feb 17 14:28:17: [Power][Informational][0X14] Power On
Feb 17 14:28:19: [Print][Informational][0XF] PQ Job Completed
Feb 17 14:28:20: [Print][Informational][0XF] PQ Job Completed
Feb 17 14:28:20: [Weblink][Informational][0X1005] Weblink disabled
Feb 17 14:28:34: [Network][Notice][0X1C] Cold Start
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.syslog.log_max_file_size

This printer setting specifies the maximum size of the local syslog file.

Commands	Details
setvar	Sets the maximum syslog file size to the specified value. Format: ! U1 setvar "device.syslog.log_max_file_size" "value" Values: A numerical value between 10000 and 400000 Default: "10000"
getvar	Returns the maximum allowed size of the syslog file. Format: ! U1 getvar "device.syslog.log_max_file_size"

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.



Example: This setvar example shows the value set to "200000".
! U1 setvar "device.syslog.log_max_file_size" "200000"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.syslog.save_local_file

This command saves the contents of the local syslog to E:SYSLOG.TXT.



Important • The local destination must be specified in device.syslog.configuration.

Commands	Details
setvar	Specifies whether to save the contents of the local syslog file to E:SYSLOG.TXT. Format: ! U1 setvar "device.syslog.save_local_file" "value" Values: "yes" = the local syslog is saved to E:SYSLOG.TXT "no" = the local syslog is not saved Default: "no"
getvar	Displays the setting for saving the local syslog file to E:SYSLOG.TXT. Format: ! U1 getvar "device.syslog.save_local_file"

Supported Devices Link-OS printers with firmware Vxx.19.7Z and later.



Example: This setvar example shows the value set to "yes".
! U1 setvar "device.syslog.save_local_file" "yes"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.data_ready_activation

Sets whether the applicator port DATA READY signal is asserted for all formats, or only for printing formats.

Commands	Details
setvar	Format: ! U1 setvar "device.applicator.data_ready_activation" "value" Values: "print" = indicates the data ready signal is activated on printing labels only. "format" = indicates the data ready signal is activated on all formats. Default: "format" Example: ! U1 setvar "device.applicator.data_ready_activation" "print"
getvar	Format: ! U1 getvar "device.applicator.data_ready_activation" Result: "print"

Supported Devices

- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.error_on_pause

Sets whether device applicator errors will be displayed.

Commands	Details
setvar	Format: ! U1 setvar "device.applicator.error_on_pause" "value" Values: "enabled" = device applicator errors will be displayed, and SERVICE REQUIRED will be asserted. "disabled" = device applicator errors will not be displayed. Default: "enabled" Example: ! U1 setvar "device.applicator.error_on_pause" "enabled"
getvar	Format: ! U1 getvar "device.applicator.error_on_pause" Result: "enabled"

Supported Devices

- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.start_print_mode

Selects the applicator port START PRINT mode of operation.

Related ZPL Command: ^JJ

Commands	Details
setvar	<p>Format: ! U1 setvar "device.applicator.start_print_mode" "value"</p> <p>Values:</p> <ul style="list-style-type: none">"level" = the Start Print signal does not need to be de-asserted to print the next label. As long as the Start Print signal is low and a label is formatted, a label prints."pulse" = the Start Print signal must be de-asserted before it can be asserted for the next label <p>Default: "pulse"</p> <p>Example: ! U1 setvar "device.applicator.start_print_mode" "level"</p>
getvar	<p>Format: ! U1 getvar "device.applicator.start_print_mode"</p> <p>Result: "level"</p>

Supported Devices

- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.applicator.voltage

Sets the output voltage of the applicator board. The value will not take effect until a reboot.

Commands	Details
setvar	Format: ! U1 setvar "device.applicator.voltage" "value" Values: "0" = off "5" = 5V "24" = 24V Default: "disabled" Example: ! U1 setvar "device.applicator.voltage" "5"
getvar	Format: ! U1 getvar "device.applicator.voltage" Result: "5"

Supported Devices

- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.unique_id

This command retrieves the printer identifier. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the established printer identifier. Format: ! U1 getvar "device.unique_id"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, assuming the printer's unique ID is 12345, the `getvar` shows "12345".
! U1 getvar "device.unique_id"

device.unpause

This command causes a printer in Pause Mode to resume printing. The operation is identical to pressing **PAUSE** on the control panel of the printer when the printer is already in Pause Mode.

This command is equivalent to **~PS**.

Commands	Details
setvar	Format: ! U1 SETVAR "device.pause" "" Values: NA Default: NA
do	Format: ! U1 D0 "device.unpause" "" Values: NA Default: NA



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.uptime

This command identifies the amount of time the printer has been powered on. The string format is: xx days, xx hours, xx minutes, and xx seconds. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the amount of time the print has been powered on. It responds in the following format (days, hours, minutes, and seconds). Format: ! U1 getvar "device.uptime"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` retrieves the amount of time the printer has been turned on.

```
! U1 getvar "device.uptime"
```

```
"00 days 02 hours 45 mins 30 secs"
```


device.user_p1

This command saves and retrieves user specified values. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to set user parameters. Format: ! U1 setvar "device.user_p1" "value" Values: alphanumeric text string (1 - 20) Default: ""
getvar	This command saves and retrieves user specified parameters. Format: ! U1 getvar "device.user_p1"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "test".

```
! U1 setvar "device.user_p1" "test"
```

When the setvar value is set to "test", the getvar result is "test".

device.user_p2

This command saves and retrieves user specified values. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to set user parameters. Format: ! U1 setvar "device.user_p2" "value" Values: alphanumeric text string (1 - 20) Default: ""
getvar	This command saves and retrieves user specified parameters. Format: ! U1 getvar "device.user_p2"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "test".

```
! U1 setvar "device.user_p2" "test"
```

When the setvar value is set to "test", the getvar result is "test".

device.user_vars.set_range

This command compliments the `device.user_vars.create` command, allowing a user to change the range of a user-created SGD variable. It has a similar syntax to `device.user_vars.create` with the exception that no default is specified.

Commands	Details
setvar	<p>This command allows the user to change the range of a user-created variable.</p> <p>Format: ! U1 setvar "device.user_vars.set_range" "name:type:range"</p> <p>Values:</p> <ul style="list-style-type: none"> • name = the name of the SGD to modify • type = Must be the same type for 'name' as when it was created • range = x-y (for all but UPDOWNCHOICES and CHOICES) or a,b,c,d (for CHOICES and UPDOWNCHOICES) • If no range is specified then it will delete whatever range is currently specified. <p>Default: NA</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: This example modifies my_var to:

```
device.user_vars.my_var : b , Choices: a,b,c,d,e
```

```
! U1 setvar "device.user_vars.set_range" "my_var:CHOICES:a,b,c,d,e"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.user_vars.create

This command creates a user variable with the specified name, type, range, and default value. The root SGD location for user variables is "device.user_vars".

Commands	Details
setvar	<p>This command instructs the printer to create a user variable with the specified parameters.</p> <p>Format: ! U1 setvar "device.user_vars.create" "name:type:range:defaultValue"</p> <p>Values:</p> <ul style="list-style-type: none"> • name = the name of the SGD to appear in device.user_vars. The name can be anything from 1 to 64 printable ASCII characters. Any '.' within the name will be replaced with '_'. (e.g. "john.doe" will be changed to "john_doe". The name must be unique in the device.user_vars branch or it will not be created. The name will be converted to lower case. • type = one of STRING, INTEGER, DOUBLE, CHOICES, UPDOWNCHOICES, UPDOWNINTEGER, UPDOWNDOUBLE. The type must be one of these types or the variable will not be created. <ul style="list-style-type: none"> • STRING - For strings the range indicates the min/max length of the data that can be stored. If the range is left blank, the default range is a string length of 0-1024. There is no maximum string length, however, if large data is placed into the variables the user should be aware that system memory and performance will be affected. Strings larger than available system memory will not be stored. Values should attempt to stay around, or below, 5K. • INTEGER/UPDOWNINTEGER - For integers the range can be any number expressed by a 32-bit integer, signed or unsigned. If the range is left blank then a range of -32768 to 32767 will be used. • DOUBLE/UPDOWNDOUBLE - A double can be any value within the range of +/-1.7e308. If the range is left blank then a range of -32768.0 to 32767.0 will be used. • CHOICES/UPDOWNCHOICES - Choices must be specified in a comma delimited list. The range cannot be blank if the type is CHOICES or UPDOWNCHOICES. • range = Expressed as x-y. The range of a variable depends upon the type. Some types will create default ranges, while others will fail to be created if the range is invalid or not specified. • default = the default value for the variable. The value must fall within the range specified or the variable will not be created. If the type is INTEGER, UPDOWNINTEGER, DOUBLE, UPDOWNDOUBLE the default value will be 0 if not specified. For STRING the default value will be an empty string if it is not specified. CHOICES and UPDOWNCHOICES must have a default value and it must be one of the choices within the specified range. • All four parts of the creation string must be present (some can be empty) meaning that there must be three delimiter characters (':') present. There is no error shown or indicated otherwise when the variable is not created for some reason. If the variable is not created one of the rules listed above has been violated. • Any user variables will be deleted from the device.user_vars branch on a power cycle (they won't be recreated on the next power up). • Defaulting the user_vars branch will restore the consumers back to their defaulted values and will not remove them from the user_vars branch. <p>Default: NA</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™



Example: To create a user variable named `userVar1` that is an integer with a minimum of 1, a maximum of 10, and a default/initial value of 5, issue this command:

```
! U1 setvar "device.user_vars.create" "userVar1:INTEGER:1-10:5"
```

After issuing the above "create" command the `device.user_vars.userVar1` SGD will be present in an ALLCV response.

After issuing the above "create" command the `device.user_vars.userVar1` SGD may be set via:

```
! U1 setvar "device.user_vars.userVar1" "2"
```

After issuing the above "create" command the "device.user_vars.userVar1" SGD may be retrieved via:

```
! U1 getvar "device.user_vars.userVar1"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.xml.enable

This command enables and disables language parsing support for XML. When enabled (on), the printer will parse both ZPL and XML. When disabled (off), the printer will not parse XML data. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to disable or enable the language parsing support for XML. Format: ! U1 getvar "device.xml.enable" "value" Values: "on" = enables language parsing support for XML "off" = disables language parsing support for XML Default: on
getvar	This command enables and disables language parsing support for XML. Format: ! U1 getvar "device.xml.enable"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the language parsing support for XML set to "on".

```
! U1 setvar "device.xml.enable" "on"
```

When the setvar value is set to "on", the getvar result is language parsing support for XML set to "on".

device.feature.lighted_arrows

Indicates if the Lighted Arrows hardware is installed.

Commands	Details
getvar	<p>Format: ! U1 getvar "device.feature.lighted_arrows"</p> <p>Result:</p> <p>"not available" = lights are not available for this printer "present" = lights are installed "not present" = lights are not installed</p> <p>****</p> <p>Note •</p>

Supported Devices

- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.light.ribbon_path_brightness

Sets the brightness level for the ribbon path LED.

Commands	Details
setvar	<p>Format: ! U1 setvar "device.light.ribbon_path_brightness" "value"</p> <p>Values:</p> <ul style="list-style-type: none">"off""low""medium""high" <p>Default: "high"</p> <p>Example: ! U1 setvar "device.light.ribbon_path_brightness" "low"</p>
getvar	<p>Format: ! U1 getvar "device.light.ribbon_path_brightness"</p> <p>Result: "low"</p>

Supported Devices

- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

device.light.media_path_brightness

Sets the brightness level for the media path LED.

Commands	Details
setvar	<p>Format: ! U1 setvar "device.light.media_path_brightness" "value"</p> <p>Values: "off" "low" "medium" "high"</p> <p>Default: "high"</p> <p>Example: ! U1 setvar "device.light.media_path_brightness" "low"</p>
getvar	<p>Format: ! U1 getvar "device.light.media_path_brightness"</p> <p>Result: "low"</p>

Supported Devices

- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.backlight

This parameter determines if the printer display backlight will be active. Valid only on printers with a display installed.

Commands	Details
setvar	This command instructs the printer to turn on or off the backlight display. Format: ! U1 setvar "display.backlight" "value" Values: on, off Default: on
getvar	This command returns if the display backlight is on or off.. Format: ! U1 getvar "display.backlight"



Example: This example sets the backlight display to "on".

```
! U1 setvar "display.backlight" "on"
```




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.backlight_on_time

This command sets the amount of time before the backlight turns off. Valid only on printers with a display installed.

Commands	Details
setvar	<p>This command sets the display length in seconds.</p> <p>Format: ! U1 setvar "display.backlight_on_time" "time"</p> <p>Values: 0-8191</p> <p>Default: 0</p> <p> Note • If the value is set to 0, the backlight will remain on.</p>
getvar	<p>This command returns the display length in seconds.</p> <p>Format: ! U1 getvar "display.backlight_on_time"</p>



Example: This setvar example shows the value set to one minute (60 seconds).

```
! U1 setvar "display.backlight_on_time" "60"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.batch_counter

Sets whether batch counters will be displayed on the printer's control panel.

Commands	Details
setvar	Format: ! U1 setvar "display.batch_counter" "value" Values: "enabled" = batch counters will be displayed "disabled" = batch counters will not be displayed Default: "disabled" Example: ! U1 setvar "display.batch_counter" "enabled"
getvar	Format: ! U1 getvar "display.batch_counter" Result: "enabled"

Supported Devices

- QLn220, QLn320, QLn420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.language

This command sets the display language for the control panel. This is equivalent to the ^*KL ZPL command.

Commands	Details
setvar	<p>This command sets the display language for the front panel.</p> <p>Format: ! U1 setvar "display.language" "language"</p> <p>Values:</p> <ul style="list-style-type: none"> "english" "spanish" "french" "german" "italian" "norwegian" "portuguese" "swedish" "danish" "spanish2" (<i>same as Spanish</i>) "dutch" "finnish" "japanese" "korean" "simplified chinese" "traditional chinese" "russian" "polish" "czech" "romanian" <p>Default: "english"</p>
getvar	<p>This command returns the currently set display language.</p> <p>Format: ! U1 getvar "display.language"</p>

ak. These values are only supported on the ZT200 Series, Xi4, RXi4, ZM400/ ZM600, and RZ400/RZ600 printers.



Example: This setvar example shows the value set to "dutch".

```
! U1 setvar "display.language" "dutch"
```




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.load_card

This command loads a specific card from a WML file.

Commands	Details
setvar	<p>Format: ! U1 setvar "display.load_card" "value"</p> <p>Values: A valid WML filename and card within the WML filename.</p> <p> Note • The card name is case sensitive.</p>



Example:

```
! U1 setvar "display.load_card" "BLUETOOTH.WML#bluetooth2"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.password.level

Controls when to display the password WML card on the LCD display.

Commands	Details
setvar	<p>Format: ! U1 setvar "display.password.level" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "all" - The user will always be prompted to enter a password when a field is to be modified. "none" - The user will not be prompted to enter a password on the LCD display. "selected" - The user will be prompted to enter a password only if the WML card contains a password ="on" attribute and the user attempts to change a setting. <p>Default:</p> <ul style="list-style-type: none"> "selected" - QLn420, QLn320 Healthcare, and QLn220 Healthcare "none" - all other platforms
getvar	<p>Format: ! U1 getvar "display.password.level"</p>

Supported Devices

- QLn220, QLn320, QLn420
- ZT230
- ZT410, ZT420
- ZD500



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.root_wml

This command specifies which control file is first processed by the printer's front panel.

Commands	Details
setvar	<p>Format: ! U1 setvar "display.root_wml" "value"</p> <p>Values: Any file name with a maximum of 128 characters in length.</p> <p>Default:</p> <ul style="list-style-type: none">• Z:INDEX420.WML for the QLn420 printers• Z:INDEX320.WML for the QLn220 and QLn320 printers• Z:INDEX.WML for all other printers <p>If the value is "" on power-up, then Z:INDEX.WML is used.</p>
getvar	<p>Format: ! U1 getvar "display.root_wml"</p>

Supported Devices

- QLn220, QLn320, QLn420
- ZR638
- ZR628



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

display.text

This command retrieves the text data that is being used on the printer's LCD. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the text data that appears on the printer's LCD. Format: ! U1 getvar "display.text"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` displays text content that appears on the printer's LCD.

```
! U1 getvar "display.text"
```

```
"PRINTER READY V60.16.4Z"
```

file.capture_response.destination

Sets whether batch counters will be displayed on the printer's control panel.

Commands	Details
setvar	Format: ! U1 setvar "file.capture_response.destination" "value" Values: "printer_file" = captured files will be written to the printer's memory "usb_file" = captured files will be written to a USB storage device Default: "printer_file" Example: ! U1 setvar "file.capture_response.destination" "usb_file"
getvar	Format: ! U1 getvar "file.capture_response.destination" Result: "usb_file"

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

head.resolution.in_dpi

Returns the resolution of the print head in dots per inch as an integer.

Commands	Details
getvar	Format: ! U1 getvar "head.resolution.in_dpi" Values: '203', '300', or '600'

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.head_close_action

This command sets what happens to the media after the printhead is closed and the printer is taken out of pause.

This command is similar to the ^MF ZPL command.

Commands	Details
setvar	<p>This command instructs the printer on which action to perform when the printhead is closed.</p> <p>Format: ! U1 setvar "ezpl.head_close_action" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "feed" = feed to the first web after sensor "calibrate" = is used to force a label length measurement and adjust the media and ribbon sensor values. "length" = is used to set the label length. Depending on the size of the label, the printer feeds one or more blank labels. "no motion" = no media feed "short cal" = short calibration <p>Default: "calibrate"</p>
getvar	<p>This command returns the currently set action to be performed when the printhead is closed.</p> <p>Format: ! U1 getvar "ezpl.head_close_action"</p>



Example: This setvar example sets the calibration method to short calibration.

```
! U1 setvar "ezpl.head_close_action" "short cal"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.label_length_max

This command sets the maximum label length in inches.

This command is equivalent to the ^ML ZPL command.

Commands	Details
setvar	This command sets the maximum label length in inches. Format: ! U1 setvar "ezpl.label_length_max" "value" Values: 1.0 to 39.0 Default: "39"
getvar	This command retrieves the current maximum label length setting in inches. Format: ! U1 getvar "ezpl.label_length_max"



Example: This example sets the label length to 6.2 inches.

```
! U1 setvar ezpl.label_length_max" "6.2"
```

```
! U1 setvar ezpl.label_length_max" "14"
```

Note • Values can be expressed to one decimal place.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.label_sensor

This command sets the paper out threshold value.

Commands	Details
setvar	This command sets the paper out threshold value. Format: ! U1 setvar "ezpl.label_sensor" "value" Values: "0" to "255", interger values only Default: "70"
getvar	This command retrieves the currently set paper out threshold value. Format: ! U1 getvar "ezpl.label_sensor"



Example: This setvar example shows the value set to 50.

```
! U1 setvar "ezpl.label_sensor" "50"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.manual_calibration

This command initiates a manual calibration sequence.

Commands	Details
setvar	This command instructs the printer to initiate a manual calibration. Format: ! U1 setvar "ezpl.manual_calibration" "" Values: NA Default: NA
do	This command instructs the printer to initiate a manual calibration. Format: ! U1 do "ezpl.manual_calibration" "" Values: NA Default: NA



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.media_type

This command specifies the media type being used.

This command is similar to the ^MN ZPL command.

Commands	Details
setvar	This command sets the media type used in the printer. Format: ! U1 setvar "ezpl.media_type" "value" Values: "continuous" "gap/notch" "mark" Default: "gap/notch"
getvar	This command returns the current media type setting. Format: ! U1 getvar "ezpl.media_type"



Example: This setvar example sets the media type to "continuous".

```
! U1 setvar "ezpl.media_type" "continuous"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.power_up_action

This command sets what happens to the media when the printer is powered on.

This command is similar to the ^MF ZPL command.

Commands	Details
setvar	<p>This command sets the media motion and calibration setting at printer power up.</p> <p>Format: ! U1 setvar "ezpl.power_up_action" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "calibrate" "feed" "length" "no motion" "short cal" <p>Default:</p> <p>"calibrate"</p>
getvar	<p>This command returns the current power up media motion and calibration settings.</p> <p>Format: ! U1 getvar "ezpl.power_up_action"</p>



Example: This setvar example sets the power up calibration setting to "length".

```
! U1 setvar "ezpl.power_up_action" "length"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.print_method

This command sets the print method.

This command is similar to ^MT.

Commands	Details
setvar	This command sets the print method. Format: ! U1 setvar "ezpl.print_method" "value" Values: "thermal trans" "direct thermal" Default: "thermal trans"
getvar	This command retrieves the current print method setting. Format: ! U1 getvar "ezpl.print_method"



Example: This setvar example sets the print method to "direct thermal".

```
! U1 setvar ezpl.print_method "direct thermal"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.print_width

This command sets the print width of the label.

Commands	Details
setvar	This command sets the print width.. Format: ! U1 setvar "ezpl.print_width" "value" Values: any printhead width Default: the width of the printhead
getvar	This command retrieves the current print width setting. Format: ! U1 getvar "ezpl.print_width"



Example: This setvar example sets the print width value to 3.

```
! U1 setvar "ezpl.print_width" "3"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.reprint_mode

This command turns on/off the reprint mode.

Commands	Details
setvar	This command instructs the printer to turn on or off reprint mode. Format: ! U1 setvar "ezpl.reprint_mode" "value" Values: "on" "off" Default: "off"
getvar	This command retrieves the current setting for reprint mode. Format: ! U1 getvar "ezpl.reprint_mode"

Supported Devices

- iMZ220 / iMZ320
- QLn220 / QLn320
- ZD500
- ZT200 series
- ZT400 series



Example: This setvar example turns reprint mode on.

```
! U1 setvar "ezpl.reprint_mode" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.take_label

This command sets the take label position.

Commands	Details
setvar	This command sets the take label position . Format: ! U1 setvar "ezpl.take_label" "value" Values: "0" to "255" Default: "50"
getvar	This command retrieves the take label position. Format: getvar "ezpl.take_label"



Example: This example sets the take label position to 175.

```
! U1 setvar "ezpl.take_label" "175"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ezpl.tear_off

This command retrieves the tear-off position.

Commands	Details
setvar	This command sets the tear-off position. Format: ! U1 setvar "ezpl.tear_off" "value" Values: "-120" to "120" Default: "0"
getvar	This command retrieves the currently set tear-off position. Format: ! U1 getvar "ezpl.tear_off"



Example: This setvar example sets the tear-off value to 110.

```
! U1 setvar "ezpl.tear_off" "110"
```




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

file.delete

This command instructs the printer to delete specified files. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
do	<p>This command instructs the printer to delete specified files.</p> <p>Format: ! U1 do "file.delete" "value"</p> <p>Values: file name</p> <p> Important • Be sure to always specify the memory location.</p>



Note • For details on SGD command structure, see [Command Structure on page 986](#).






Example: This do example shows the specified file to delete.

```
! U1 do "file.delete" "e:abcd.zpl"
```

file.dir

This command displays a directory listing on the same port the command was received. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command sets the directory name from which to retrieve files.</p> <p>Format: ! U1 setvar "file.dir" "value"</p> <p>Values: directory letter</p> <p> Important • Be sure to always specify the memory location.</p>
getvar	<p>This command retrieves a directory listing of the specified directory.</p> <p>Format: ! U1 getvar "file.dir"</p> <p> Important • Be sure to always specify the memory location.</p>
do	<p>This command sets the directory name from which to retrieve files.</p> <p>Format: ! U1 do "file.dir" "value"</p> <p>Values: directory letter</p> <p> Important • Be sure to always specify the memory location.</p>



Note • For details on SGD command structure, see [Command Structure on page 986](#).



Example: This do example shows the directory listing of the specified directory.

```
! U1 do "file.dir" "R:"

- DIR R:*. *
- 11172192 bytes free R: RAM
```


file.dir_format

This command controls the output format of the `file.dir` Set/Get/Do command.

Commands	Details
setvar	This command sets the output format. Format: ! U1 setvar "file.dir_format" "value" Values: "cpl" "zpl"
getvar	This command retrieves the current setting for the output format. Format: ! U1 getvar "file.dir_format" Result: "cpl" "zpl"
do	This command sets the output format. Format: ! U1 do "file.dir_format" "value" Values: "cpl" "zpl"



Example: This `do` example sets the directory format to CPCL.
! U1 do "file.dir_format" "cpl"





Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

file.type

This command displays the contents of the specified file. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to display the content of a file on the same port the command was received.</p> <p>Format: ! U1 setvar "file.type" "value"</p> <p>Values: the drive letter, file name, file extension, such as R:TEST.ZPL</p> <p> Important • Be sure to always specify the memory location.</p>
do	<p>This command displays the content of a file on the same port the command was received.</p> <p>Format: ! U1 do "file.type" "value"</p> <p>Values: the drive letter, file name, file extension, such as R:TEST.ZPL</p> <p> Important • Be sure to always specify the memory location.</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).





Example: This setvar example shows the value set to "R:TEST.ZPL".

```
! U1 setvar "file.type" "R:TEST.ZPL"
```

When the setvar value is set to "R:TEST.ZPL", the contents of the file TEST.ZPL located on the R: drive will be displayed.

file.run

This command instructs the printer to send a specified file to the parser. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to send a specified file to the parser.</p> <p>Format: ! U1 setvar "file.run" "values"</p> <p>Values: drive:filename.extension</p> <p> Important • Be sure to always specify the memory location.</p>
do	<p>This command instructs the printer to send a specified file to the parser.</p> <p>Format: ! U1 do "file.run" "value"</p> <p>Values: drive:filename.extension</p> <p> Important • Be sure to always specify the memory location.</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example will send the file "text.zpl" stored in RAM to the parser.
! U1 setvar "file.run" "R:text.zpl"

formats.cancel_all

The ~JA command cancels all format commands in the buffer. It also cancels any batches that are printing.

This command is equivalent to the ~JA ZPL command.

Commands	Details
setvar	This command cancels all format commands in the buffer. Format: ! U1 setvar "formats.cancel_all" "" Values: NA Default: NA
do	This command cancels all format commands in the buffer. Format: ! U1 do "formats.cancel_all" ""



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

head.darkness_switch_enable

Enables the darkness switch on desktop printers.

Commands	Details
setvar	! U1 setvar "head.darkness_switch_enable" "value" Values: "on" = enables the darkness switch "off" = disables the darkness switch Default: "on"
getvar	! U1 getvar "head.darkness_switch_enable."

Supported Devices

- ZD410, ZD420
- ZD620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

742 | head.darkness_switch_enable

head.darkness_switch

Indicates the value to which the darkness switch is set on the printer.

Commands	Details
getvar	<pre>! U1 getvar "head.darkness_switch"</pre> <p>Values: (looking at the switch from the rear of the printer) "low" = darkness switch is on the left "medium" = darkness switch is in the middle "high" = darkness switch is on the right</p>

Supported Devices

- ZD410, ZD420
- ZD620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

head.element_test

This command will cause the printer to immediately run the head test on all printhead elements. The command can also display the result of the last head element test.

Commands	Details
do	Format: ! U1 do "head.element_test" ""
getvar	Format: ! U1 getvar "head.element_test" Values: The possible getvar responses include: "Head Elements OK" - All head elements passed the test. "n, n..." - a comma-separated list of elements that failed the test. "Initialization Failed" - the test could not start. "Failed to Attach" - the test could not start. "Please Run Test" - default response if there are no results to display. "In Progress" - The element test has been started but not completed yet. Default: "Please Run Test"

Supported Devices

- ZQ510, ZQ520



Example: This example shows a single element that failed the test.
"86"

Example: This example shows a list of elements that failed the test.
"75,309,456,778,779"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

head.latch

This command identifies if the printhead is open or closed. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the status of the printhead, open or closed. Format: ! U1 getvar "head.latch" Values: "ok" = closed "open" = open



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` retrieves the status of the print head.

```
! U1 getvar "head.latch"
```

```
"ok"
```

input.capture

This parameter allows capturing input data in diagnostics mode. Input capture has three modes: "print", "run", and "off". The "print" and "run" modes can be used to examine data received by the printer.

When in "print" mode the printer will save incoming data to files named "**in???.dmp**", where ??? is a number between 001 to 999. The printer will then print the text and hexadecimal representation of data bytes received instead of printing the formatted labels which that data might represent. When in "run" mode the printer will save captured incoming data to files as above, but will otherwise run the incoming data/commands normally.

The capture files should be deleted from printer memory after retrieving them. Leaving the printer in "**print**" or "**run**" mode and not deleting the capture files will reduce the printer's available flash memory.

The "**off**" mode is the printer's normal operating mode. Cycling power will also return the printer to "**off**" mode.



Note • This command does not capture a network packet trace.

Commands	Details
setvar	This command sets the directory name from which to retrieve files. Format: ! U1 setvar "input.capture" "value" Values: "print" "run" "off" Default: "off"
getvar	This command retrieves the current <code>input.capture</code> setting value. Format: ! U1 getvar "input.capture"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.arp_interval

This command changes the arp interval.

Commands	Details
setvar	<p>This command retrieves the gateway address of the active print server.</p> <p>Format: ! U1 getvar "interface.network.active.arp_interval" "value"</p> <p>Values: integer values from "0" to "30"</p> <p>Default: "0"</p>
getvar	<p>This command retrieves the current arp interval setting, shown in minutes.</p> <p>Format: ! U1 getvar "interface.network.active.arp_interval"</p>



Example: In this example, the setvar changes the arp interval to three minutes.

```
! U1 getvar "interface.network.active.arp_interval" "3"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.cable_type

This command returns the cable type of the active network, either 10/100BaseT, Wireless 802.11b/g, or Wireless 802.11n.



Note • This command will only give a valid response once an IP address has been established.

Commands	Details
getvar	This command retrieves the current cable type of the active network. Format: ! U1 getvar "interface.network.active.cable_type" Values: "10/100BaseT" "Wireless 802.11b/g" "Wireless 802.11n" Default: NA



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.dhcp_received_host_name

This command reports the Host Name as assigned by the DHCP Server. If one is not assigned, or DHCP is not used, then the field will be blank.



Note • This command will only give a valid response once an IP address has been established.

Commands	Details
getvar	This command reports the host name.. Format: ! U1 getvar "interface.network.active.dhcp_received_host_name"



Example:

```
! U1 getvar "interface.network.active.dhcp_received_host_name"
```

Result:

```
"Zebra Printer on shelf 2112"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.gateway

This command retrieves the gateway address of the active print server. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the gateway address of the active print server. Format: ! U1 getvar "interface.network.active.gateway"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` retrieves the gateway address of the active print server.

```
! U1 getvar "interface.network.active.gateway"
```

```
"10.3.5.1"
```

interface.network.active.ip_addr

This command retrieves the IP address of the active print server. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the IP address of the active print server. Format: ! U1 getvar "interface.network.active.ip_addr"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` retrieves the IP address of the active print server.

```
! U1 getvar "interface.network.active.ip_addr"
```

```
"10.3.5.92"
```

interface.network.active.mac_addr

This command retrieves the MAC address of the active print server. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the MAC address of the active print server. Format: ! U1 getvar "interface.network.active.mac_addr"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` retrieves the MAC address of the active print server.

```
! U1 getvar "interface.network.active.mac_addr"
```

```
"00:07:4d:24:08:ff"
```


interface.network.active.mac_raw

This command identifies the RAW MAC address of the active print server. The raw mac address is the mac address without the colons (":"). For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the RAW MAC address of the active print server. Format: ! U1 getvar "interface.network.active.mac_raw"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the getvar retrieves the RAW MAC address of the active print server.

```
! U1 getvar "interface.network.active.mac_raw"
```

```
"00074d2408ff"
```

interface.network.active.netmask

This command retrieves the netmask of the active print server. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the netmask of the active print server. Format: ! U1 getvar "interface.network.active.netmask"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` retrieves the netmask of the active print server.

```
! U1 getvar "interface.network.active.netmask"
```

```
"255.255.255.0"
```

interface.network.active.protocol

This command retrieves IP protocol of the active print server. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the IP protocol of the active print server. Format: ! U1 getvar "interface.network.active.protocol"



Note • For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.protocol_error

This command returns the last error reported by the active print server.

Commands	Details
getvar	This command returns the last error reported by the active print server. Format: ! U1 getvar "interface.network.active.protocol_error"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.rx_errors

This command returns the current number of packet receive errors on the active network interface.

Commands	Details
getvar	<p>This command returns the current number of packet receive errors.</p> <p>Format: ! U1 getvar "interface.network.active.rx_errors"</p> <p>Result: The current number of errors.</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.rx_packets

This command returns the number of packets received on the active network interface since the last power cycle.

Commands	Details
getvar	This command returns the number of packets received on the active network interface since the last power cycle. Format: ! U1 getvar "interface.network.active.rx_packets" Result: An integer.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.server_address

This command returns the network IP address of the server that provided the printer's IP address.

Commands	Details
getvar	<p>This command returns the network IP address of the server providing the printer's IP address.</p> <p>Format: ! U1 getvar "interface.network.server_address"</p> <p>Result: an IP address</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.protocol_error

This command returns the last error reported by the print server.

Commands	Details
getvar	This command returns the last error reported by the print server. Format: ! U1 getvar "interface.network.active.protocol_error" Result: WINS Name in Conflict



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.speed

This command returns the speed in megabits per second of the active print server network since the last power cycle.

Commands	Details
getvar	This command returns the active print server network speed since the last power cycle. Format: ! U1 getvar "interface.network.active.speed" Result: A number indicating megabits/second



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.tx_errors

This command returns the number of packet transmit errors on the active print server network since the last power cycle.

Commands	Details
getvar	This command returns the number of packet transmit errors on the active print server network since the last power cycle. Format: ! U1 getvar "interface.network.active.tx_errors" Result: An integer number



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.tx_packets

This command returns the number of packets transmitted on the active print server network since the last power cycle.

Commands	Details
getvar	<p>This command returns the number of packets transmitted on the active print server network since the last power cycle.</p> <p>Format: ! U1 getvar "interface.network.active.tx_packets"</p> <p>Result: A number.</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.active.wins_addr

This command sets and retrieves the active WINS address.

Commands	Details
setvar	This command sets the WINS address of the active print server. Format: ! U1 setvar "interface.network.active.wins_addr" "value" Values: "0.0.0.0" - "255.255.255.255"
getvar	This command retrieves the WINS address of the active print server. Format: ! U1 getvar "interface.network.active.wins_addr" Result: a WINS address



Example: In this example, the setvar sets the Wins address of the active print server.
! U1 setvar "interface.network.active.wins_addr" "10.3.5.120"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

interface.network.settings_require_reset

Displays whether or not the network system has to be reset for a new configuration setting to take effect.

Commands	Details
getvar	<p>Format: ! U1 getvar "interface.network.settings_require_reset"</p> <p>Values:</p> <p>"no" = no settings have been changed that require a reset to take effect.</p> <p>"yes" = one or more settings has been changed that requires a reset to take effect.</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.firewall.whitelist_in

Returns a comma-separated list of IP addresses and/or IP address ranges that will be allowed to communicate with the printer. If the list is empty then the firewall will be disabled.

Setvar

To set the command:

Format: ! U1 setvar "ip.firewall.whitelist_in" "value"

Values:

The value is a string of up to 256 alphanumeric characters.

Default:

""

Examples:

Single IP address:

```
! U1 setvar "ip.firewall.whitelist_in" "192.168.1.20"
```

Multiple IP addresses:

```
! U1 setvar "ip.firewall.whitelist_in" "192.168.1.20,192.168.100.21"
```

IP address ranges:

```
! U1 setvar "ip.firewall.whitelist_in" "192.168.1.20-192.168.1.100"
```

IP ranges and Single/Multiple IPs

```
"ip.firewall.whitelist_in" "192.168.1.20-192.168.1.40, 192.168.1.50,  
192.168.1.75"
```

Format:

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.firewall.whitelist_in"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.https.enable

Enables/disables the HTTPS web connections.

IMPORTANT: A network or printer reset is required for this setting to take effect.

Setvar

To set the command:

Format: ! U1 setvar "ip.https.enable" "value"

Values:

- off = disables HTTPS protocol
- on = enables HTTPS protocol

Default:

"on"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.https.enable"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.https.port

Sets the port that will listen for HTTPS connections.

Setvar

To set the command:

Format: ! U1 setvar "ip.https.port" "value"

Values:

Any valid https port from 0-65535.

Default:

"443"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.https.port"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.ping_gateway_interval

Determines the interval in minutes at which to send ICMP PING packets to the default gateway.

Setvar

To set the command:

Format: ! U1 setvar "ip.ping_gateway_interval" "value"

Values:

The value is an integer from 0-30.

0 — disabled

Default:

"0"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.ping_gateway_interval"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.pop3.print_body

Determines if the email body will be printed when the email is retrieved via POP3. This only applies if ip.pop3.enable is set to "on".

Setvar

To set the command:

Format: ! U1 setvar "ip.pop3.print_body" "value"

Values:

- on
- off

Default:

"off"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.pop3.print_body"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.pop3.print_headers

Determines if the email header will be printed when the email is retrieved via POP3. This only applies if ip.pop3.enable is set to "on".

Setvar

To set the command:

Format: ! U1 setvar "ip.pop3.print_headers" "value"

Values:

- on
- off

Default:

"off"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.pop3.print_headers"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.pop3.save_attachments

Determines if the email attachments are to be saved to the flash file system when the email is retrieved via POP3. This only applies if ip.pop3.enable is set to "on".

Setvar

To set the command:

Format: ! U1 setvar "ip.pop3.save_attachments" "value"

Values:

- on
- off

Default:

"on"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.pop3.save_attachments"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.pop3.verbose_headers

Instructs the printer to respond with the POP3 verbose header value.

Setvar

To set the command:

Format: ! U1 setvar "ip.pop3.verbose_headers" "value"

Values:

- on
- off

Default:

"off"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.pop3.verbose_headers"

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.tls.enable

Enables the TLS connections to the encrypted channels on the printer specified by **ip.tls.port** and **ip.tls.port_json_config**.

Setvar

To set the command:

Format: ! U1 setvar "ip.tls.enable" "value"

Values:

- on
- off

Default:

"on"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.tls.enable"

Example

This example disables the TLS port.

Format: ! U1 setvar "ip.tls.enable" "off"

Related SGDs

- ip.tls.port
- iip.tls.port_json_config

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- iMZ 220, iMZ 320
- QLn220, QLn320, QLn420
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420

- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.tls.port

Sets the port number to which encrypted connections can be made to communicate with the printing channel.

Setvar

To set the command:

Format: ! U1 setvar "ip.tls.port" "value"

Values:

Any valid https port from 0-65535.

Default:

"9143"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.tls.port"

Related SGDs

- ip.tls.enable
- iip.tls.port_json_config

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZQ610, ZQ620, ZQ630
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

ip.tls.port_json_config

Sets the port number used to create an encrypted connection to the JSON configuration channel.

Setvar

To set the command:

Format: ! U1 setvar "ip.tls.port_json_config" "value"

Values:

Any valid https port from 0-65535.

Default:

"9243"

Getvar

To have the printer return the current setting value:

Format: ! U1 getvar "ip.tls.port_json_config"

Related SGDs

- ip.tls.enable
- ip.tls.port

Supported Printers

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500R, ZD510, ZD511
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

log.reboot.code

Causes the printer to return a one-character value which indicates the reason for the last printer reboot.

Commands	Details
getvar	<p>Format: ! U1 getvar "log.reboot.code"</p> <p>Result: A one-character code indicating the reason for the reboot.</p> <p>Values:</p> <ul style="list-style-type: none"> "0" - Other "1" - device.reset command "2" - Mirror reset – new files "3" - DTR off "4" - Low-battery timeout "5" - Low-battery shutdown "6" - power.shutdown command "7" - Idle timeout "8" - Printer OS update "9" - Reserved "a" - Reserved "b" - Off key "f" - No data

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Example:

```
! U1 getvar "log.reboot.code"
```

Result: 4

The result indicates that the device rebooted because the battery timed out.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

log.reboot.codes

Causes the printer to return a list of one-character values which indicates the reasons for the last 32 printer reboots.

Commands	Details
getvar	<p>Format: ! U1 getvar "log.reboot.codes"</p> <p>Result: A string of one-character codes indicating the reason for the reboots. A total of 32 reboot events are stored; if less than 32 reboots have occurred, "f" is stored in any unpopulated event slot, indicating "no data" for that event.</p> <p>Values:</p> <ul style="list-style-type: none"> "0" - Other "1" - device.reset command "2" - Mirror reset – new files "3" - DTR off "4" - Low-battery timeout "5" - Low-battery shutdown "6" - power.shutdown command "7" - Idle timeout "8" - Printer OS update "9" - Reserved "a" - Reserved "b" - Power Switch / Off Key "f" - No data



Example:

! U1 getvar "log.reboot.codes"

Result: "bb338bbbbbb3bbbbbbbbb1bb"

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

log.reboot.reason

Returns the reason for the last printer reboot, based on the `log.reboot.code`.

Commands	Details
getvar	<p>Format: ! U1 getvar "log.reboot.reason"</p> <p>Result: The reason for the last reboot.</p> <p>Values: "Other" "device.reset command" "Mirror reset - new files" "DTR off" "Low-battery timeout" "Low-battery shutdown" "power.shutdown command" "Idle timeout" "New OS reprogramming" "Unknown-1" "Unknown-2" "Off key" "No data"</p>

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

log.reboot.report

Causes the printer to return a list of values which indicate the reasons for the last 32 printer reboots.

Commands	Details
getvar	<p>Format: ! U1 getvar "log.reboot.report"</p> <p>Result: The recorded reboot reasons as a list, starting with the most recent reboot reason first. A total of 32 reboot events are stored; if less than 32 reboots have occurred, "f" is stored in any unpopulated event slot, indicating "no data" for that event.</p> <p>Values: "Other" "device.reset command" "Mirror reset - new files" "DTR off" "Low-battery timeout" "Low-battery shutdown" "power.shutdown command" "Idle timeout" "New OS reprogramming" "Unknown-1" "Unknown-2" "Off key" "No data"</p>



Example: ! U1 getvar "log.reboot.report"
Result: A list of 32 codes, in a carriage-return delimited list:

```
"Off key
Off key
Off key
.
.
.
No data
"
```

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

mcr.crypt.enabled

Retrieves the MCR encryption-enabled status.

Commands	Details
getvar	Format: ! U1 getvar "mcr.crypt.enabled" Values: "off" = mcr encryption is not enabled "on" = mcr encryption is enabled

Supported Devices

- ZQ510
- ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

mcr.cancel

Cancels the magnetic card read operation currently in progress.

Commands	Details
setvar	Format: ! U1 setvar "mcr.cancel" "" Values: No value needs to be specified. Default: NA

Supported Devices

- ZQ510
- ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

mcr.crypt.key_mgmt

Retrieves the MCR encryption key management algorithm for a fixed key or DUKPT (Derived Unique Key Per Transaction). The return value applies only if "mcr.crypt.enabled" is "on".

Commands	Details
getvar	Format: ! U1 getvar "mcr.crypt.key_mgmt" Values: "" = fixed key algorithm "dukpt" = derived unique key per transaction Default: N/A

Supported Devices

- ZQ510
- ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

mcr.crypt.algorithm

Retrieves the MCR encryption algorithm. The return value applies only if "mcr.crypt.enabled" is "on".

Commands	Details
getvar	Format: ! U1 getvar "mcr.crypt.algorithm" Values: "" "3des" "aes" Default: N/A

Supported Devices

- ZQ510
- ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

mcr.out

Specifies the communication port which MCR (Mag Card Reader) output is sent to.

Commands	Details
setvar	<p>Format: ! U1 setvar "mcr.out" "value"</p> <p>Values:</p> <p>"active" = the data is sent out over the same port that the command was received on.</p> <p>Note • If "multiple" is specified in the option string of the mcr.enable command, data will continue to be sent to the port defined by this command.</p> <p>"alert" = the data will be forwarded as a weblink alert.</p> <p>Default: "active"</p>

Supported Devices

- ZQ510
- ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

mcr.revision

Returns the revision of the MCR (magnetic card reader).

Commands	Details
getvar	Format: ! U1 getvar "mcr.revision" Result: "ID TECH TM3 SecureHead RS232 Reader V 5.14"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

media.bar_location

Allows the user to configure the printer to look for a black mark bar on the front or back of the media.



Note • This command works only with printers that have a front media sensor.

Commands	Details
setvar	<pre>! U1 setvar "media.bar_location" "value"</pre> <p>Values:</p> <ul style="list-style-type: none"> • front = use media with bars on the front. • back = use media with bars on the back • Options available by printer: iMZ220, iMZ320, QLn220, QLn320, QLn420, ZR318, ZR328 = "front" ZQ310, ZQ320, ZQ510, ZQ520 = "front", "back" All other printers = "back" <p>Default:</p> <ul style="list-style-type: none"> • iMZ220, iMZ320, QLn220, QLn320, QLn420, ZR318, ZR328 = "front" • ZQ310, ZQ320 with optional back bar sensor = "back" • ZQ310, ZQ320 with no back bar sensor = "front" • All other printers = "back"
getvar	<pre>! U1 getvar "media.bar_location"</pre>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

media.cartridge.part_number

This printer command retrieves the part number of the media cartridge used in the printer.

Commands	Details
getvar	This command instructs the printer to respond with the media cartridge part number currently being used by the printer. Format: ! U1 getvar "media.cartridge.part_number"

Supported Devices

- HC100



Note • For details on SGD command structure, see [Command Structure](#) on page 573.




Example: In this example, the getvar returns the part number of the media cartridge.

```
! U1 getvar "media.cartridge.part_number" "10006999"
```

media.cut_now

This command instructs the printer cycle the media cutter. If the printer is in Print Mode Kiosk (media.printmode "K") then the cutter will execute a cut based on the value of media.present.cut_amount – either a normal cut or a partial cut. If the printer is not in Print Mode Kiosk (media.printmode "K"), this command does nothing. See [media.present.cut_amount](#) on page 798.

Commands	Details
setvar	<p>This command instructs the printer to cycle the media cutter.</p> <p>Format: ! U1 setvar "media.cut_now" ""</p> <p> Note • See media.present.cut_amount on page 798.</p>
do	<p>This command instructs the printer to cycle the media cutter.</p> <p>Format: ! U1 do "media.cut_now" ""</p>

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure](#) on page 573.

media.darkness_mode

This command instructs the printer to set the darkness mode. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to set the darkness mode.</p> <p>Format:</p> <pre>! U1 setvar "media.darkness_mode" "value"</pre> <p>Values:</p> <ul style="list-style-type: none">"cartridge" = cartridge mode (no changes allowed)"user" = user mode (Darkness is set by the user, and the cartridge value is ignored. This value is used for all cartridges inserted in the printer)."relative" = relative mode (the specified darkness value is added to the cartridge default value) <p>Default: "cartridge"</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the darkness mode set to "cartridge".

```
! U1 setvar "media.darkness_mode" "cartridge"
```


media.draft_mode

This command puts the printer into draft mode setting.



Note • Setting the printer to draft mode may result in poorer print quality depending on print speed, label configurations, etc.

Commands	Details
setvar	<p>This command sets the value.</p> <p>Format: ! U1 setvar "media.draft_mode" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> enabled = faster ramp (acceleration) speed disabled = normal ramp (acceleration) speed <p>Default: disabled</p>
getvar	<p>This command instructs the printer to respond with the currently set value.</p> <p>Format: ! U1 getvar "media.draft_mode"</p>

Supported Devices ZE500-4



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

media.feed_skip

This command only applies to labels created with CPCL commands. It controls the same setting as the second parameter of the CPCL SETFF command.

Commands	Details
setvar	<p>Format: ! U1 setvar "media.feed_skip" "value"</p> <p>Values: a numeric value from 0 to 50.</p> <p>Default:</p> <p>5 - for QLn and ZQ series printers 35 - for iMZ and ZR series printers</p>
getvar	<p>Format: ! U1 getvar "media.feed_skip"</p> <p>Result: a numeric value from 0 to 50.</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

media.media_low.external

This printer setting gets the status of the external media_low warning. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	<p>This command instructs the printer to respond with the currently set media print mode.</p> <p>Format:</p> <pre>! U1 getvar "media.media_low.external"</pre> <p>Values:</p> <ul style="list-style-type: none"> 0 = Paper present at sensor position 1 = No paper present <p> Note • The status of the sensor is sampled every time the printout is cut. If three succeeding samples show "no paper", the status reply changes to 1. This is to prevent a false alarm if the side of the paper roll is not clean. If the current status of the sensor is required, use ~HQES and extract the paper near-end sensor bit.</p>

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.media_low.warning

This command retrieves the value of, or enables or disables the Supplies Warning system. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command enables or disables the Supplies Warning System. Format: ! U1 setvar "media.media_low.warning" "value" Values: "disabled" = not active "enabled" = active Default: "disabled"
getvar	This command retrieves the setting for the Supplies Warning system. Format: ! U1 getvar "media.media_low.warning"

Supported Devices

- Xi4
- RXi4



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • This setvar example disables the Supplies Warning system.
! U1 setvar "media.media_low.warning" "disabled"



Example 2 • This setvar example enables the Supplies Warning system.
! U1 setvar "media.media_low.warning" "enabled"

media.part_number

Sets the media's part number.

Commands	Details
setvar	<p>Format: ! U1 setvar "media.part_number" "value"</p> <p>Values: an alpha-numeric string between 0 and 64 characters</p> <p>Default: NA</p> <p>Example: ! U1 setvar "media.part_number" "123AB987"</p>
getvar	<p>Format: ! U1 getvar "media.part_number"</p> <p>Result: "123AB987"</p>

Supported Devices

- ZD410, ZD420



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

media.present.cut_amount

This printer setting determines the type of cut made by the printer cutter (normal or partial) and, if partial, the length of the partial cut on each side, in mm. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to change the media cut amount. Format: ! U1 setvar "media.present.cut_amount" "value" Values: 0 = normal cut 10-60 = partial cut, value = mm of media left uncut
getvar	This command instructs the printer to respond with the currently set media cut amount. Format: ! U1 getvar "media.present.cut_amount"

Supported Devices


- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.eject

This command instructs the printer to eject the document through the presenter module. The value is the amount to eject, in mm. The value of [media.present.length_addition](#) gets added to the value to determine the total length of media ejected. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to eject the document through the presenter module.</p> <p>Format: ! U1 setvar "media.present.eject" "value"</p> <p>Values: 0 - 255 = amount of media to eject in mm</p> <p> Note • See media.present.length_addition on page 800.</p>
do	<p>This command instructs the printer to eject the document through the presenter module.</p> <p>Format: ! U1 do "media.present.eject" "value"</p>

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.length_addition

This printer setting adds an additional amount to how far the paper is ejected during a present cycle. A standard amount of 50mm is always added to clear the kiosk wall. This amount is added to that 50mm. The total amount of media ejected this command is executed, then, is 50mm + media.present.length_addition + media.present.eject. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to change the media present length addition. Format: ! U1 setvar "media.present.length_addition" "value" Values: 0-255 = additional mm of media to eject
getvar	This command instructs the printer to respond with the currently set media present length addition. Format: ! U1 getvar "media.present.length_addition"

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.loop_length

This printer setting determines the length of the presenter loop. If loop_length is greater than loop_length_max (see media.present.loop_length_max) then it will be set equal to loop_length_max. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to change the presenter loop length.</p> <p>Format:</p> <pre>! U1 setvar "media.present.loop_length" "value"</pre> <p>Values:</p> <p>0 = paper is fed straight through the presenter</p> <p>3-1023 = loop length in mm.</p> <p>Default:</p> <p>400 = gives a loop of approximately 400mm</p>
getvar	<p>This command instructs the printer to respond with the currently set presenter loop length.</p> <p>Format: ! U1 getvar "media.present.loop_length"</p>

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.loop_length_max

This printer setting determines the maximum allowed length of the presenter loop. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to change the presenter loop length.</p> <p>Format:</p> <pre>! U1 setvar "media.present.loop_length_max" "value"</pre> <p>Values:</p> <ul style="list-style-type: none">0 = paper is fed straight through the presenter3-1023 = loop length in mm. <p>Default:</p> <ul style="list-style-type: none">400 = gives a loop of approximately 400mm
getvar	<p>This command instructs the printer to respond with the currently set presenter loop length.</p> <p>Format:</p> <pre>! U1 getvar "media.present.loop_length_max"</pre>

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.cut_margin

This printer setting determines the margin between the cutter and the printhead. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to change the media cut amount. Format: ! U1 setvar "media.present.cut_margin" "value" Values: 2 - 9 = mm of distance Default: 9 = mm of distance
getvar	This command instructs the printer to respond with the currently set media cut margin amount. Format: ! U1 getvar "media.present.cut_margin"

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.present_timeout

This printer setting determines how long the printer will wait after a present event to clear the label. See ^KV ZPL command. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to change the presenter function mode. Format: ! U1 setvar "media.present.present_timeout" "value" Values: 0 - 300 = If label is not taken, retract label when timeout expires. Timeout is in seconds. Zero (0) indicates that there is no timeout. The label will stay presented until removed manually or a new label is printed.
getvar	This command instructs the printer to respond with the currently set presenter function mode. Format: ! U1 getvar "media.present.present_timeout"

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.present.present_type

This printer setting determines the way that the printer performs a present command. See ^KV ZPL command. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to change the presenter function mode. Format: ! U1 setvar "media.present.present_type" "value" Values: 0 = Eject page when new page is printed 1 = Retract page when new page is printed 2 = Do nothing when new page is printed
getvar	This command instructs the printer to respond with the currently set presenter function mode. Format: ! U1 getvar "media.present.present_type"

Supported Devices

- KR403



Note • For details on SGD command structure, see [Command Structure on page 573](#).

media.printmode

This printer setting determines the action the printer takes after a label or group of labels has printed. For printer support, see [SGD Command Support on page 1393](#). This command is equivalent to [^MM on page 275](#).

Commands	Details
setvar	<p>This command instructs the printer to change the media print mode.</p> <p>Format: ! U1 setvar "media.printmode" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "T" = Tear-off <i>al</i> "P" = Peel-off (not available on S-300) <i>al, am</i> "R" = Rewind (depends on printer model) "A" = Applicator (depends on printer model) <i>al</i> "C" = Cutter (depends on printer model) <i>am</i> "D" = Delayed cutter <i>al, am</i> "F" = RFID <i>al, am</i> "L" = Linerless Peel <i>am, an</i> "U" = Linerless Rewind <i>am, an</i> "K" = Kiosk <i>ao</i> "V" = Linerless Tear <i>am</i> "S" = Stream <i>ap</i>
getvar	<p>This command instructs the printer to respond with the the currently set media print mode.</p> <p>Format: ! U1 getvar "media.printmode"</p>

- al.** This value is not supported on the KR403 printer.
- am.** This value is not supported on the ZE500 printer.
- an.** This value is supported only on the ZM400/ZM600 and RZ400/RZ600 printers.
- ao.** This value is supported only on the KR403 printer.
- ap.** This value is supported only on the ZE500 printer.



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "T".

```
! U1 setvar "media.printmode" "T"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "tear off".

For more details on how each setvar value relates to the getvar responses, see [Table 26, Setvar / Getvar Relation on page 806](#).

Table 26 • Setvar / Getvar Relation

If the setvar is set to ...	Then the getvar response and control panel display is ...
"T"	TEAR OFF
"P"	PEEL OFF
"R"	REWIND

If the setvar is set to ...	Then the getvar response and control panel display is ...
"A"	APPLICATOR
"C"	CUTTER
"D"	DELAYED CUT
"L"	RESERVED
"U"	RESERVED
"K"	KIOSK

media.speed

This command specifies media print speed in inches per second (ips). For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to set the media print speed.</p> <p>Format: ! U1 setvar "media.speed" "value"</p> <p>Values: 2-12 ips "up" = increments the printer speed by one unit "down" = decrements the speed by one unit</p> <p>Default: "2"</p>
getvar	<p>This command retrieves the currently set media print speed.</p> <p>Format: ! U1 getvar "media.speed"</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example 1 • This setvar example shows the value set to "2".

```
! U1 setvar "media.speed" "2"
```

When the setvar value is set to "2", the getvar result is "2".



Example 2 • This setvar example shows the value set to "up".

```
! U1 setvar "media.speed" "up"
```

If the current print speed is 2: When the setvar value is set to "up", the getvar result is "3".



Example 3 • This setvar example shows the value set to "down".

```
! U1 setvar "media.speed" "down"
```

If the current print speed is 2: When the setvar value is set to "down", the getvar result is "1".

media.serial_number

Sets the media's serial number.

Commands	Details
setvar	<p>Format: ! U1 setvar "media.serial_number" "value"</p> <p>Values: an alpha-numeric string between 0 and 64 characters</p> <p>Default: NA</p> <p>Example: ! U1 setvar "media.serial_number" "A34567BC6789"</p>
getvar	<p>Format: ! U1 getvar "media.serial_number"</p> <p>Result: "A34567BC6789"</p>

Supported Devices

- ZD410, ZD420



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

memory.flash_free

This parameter returns the amount of available Flash memory. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	Format: ! U1 getvar "memory.flash_free"



Note • For details on SGD command structure, see [Command Structure on page 573](#).

memory.flash_size

This parameter returns the total amount of Flash memory. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	Format: ! U1 getvar "memory.flash_size"



Note • For details on SGD command structure, see [Command Structure on page 573](#).

memory.ram_free

This parameter returns the amount available Random Access Memory (RAM). For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	Format: ! U1 getvar "memory.ram_free"



Note • For details on SGD command structure, see [Command Structure on page 573](#).

memory.ram_size

This parameter returns the total amount of Random Access Memory (RAM).

Commands	Details
getvar	Format: ! U1 getvar "memory.ram_size"

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.agent_addr

This parameter obtains or changes the Network Management agent IP address.

Commands	Details
setvar	This command sets the Network Management Agent IP address . Format: ! U1 setvar "netmanage.avalanche.agent_addr" "value" Values: any valid IP address Default: "0.0.0.0"
getvar	This command retrieves the current Network Management IP address. Format: ! U1 getvar "netmanage.avalanche.agent_addr"



Example:

```
! U1 setvar "netmanage.avalanche.agent_addr" "10.14.2.200"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.available_agent

This command returns the current IP address of the remote agent found during the Agent Discovery Phase.

Commands	Details
getvar	<p>This command obtains the IP address of the remote agent found during the Agent Discovery Phase.</p> <p>Format: ! U1 getvar "netmanage.avalanche.available_agent"</p> <p>Result: An IP address</p>



Example:

```
! U1 getvar "netmanage.avalanche.available_agent"
```

Result:

```
"10.3.4.128"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.available_port

This command returns the available port of the remote agent found during the Agent Discovery Phase.

Commands	Details
setvar	This command sets the available port of the remote agent found during the Agent Discovery Phase. Format: ! U1 setvar "netmanage.avalanche.available_port" "value" Values: "0" to "65535" Default: "0"
getvar	This command retrieves the current port setting of the remote agent found during the Agent Discovery Phase. Format: ! U1 getvar "netmanage.avalanche.available_port"



Example:

```
U1 setvar "netmanage.avalanche.available_port" "1800"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.encryption_type

This parameter sets and gets the Network Management Encryption type to be used.

Commands	Details
setvar	<p>This command sets the Network Management Encryption type to be used.</p> <p>Format: ! U1 setvar "netmanage.avalanche.encryption_type" "value"</p> <p>Values: "0" = None "1" = Limburger "2" = AES128S</p> <p>Default: "0"</p>
getvar	<p>This command retrieves the currently set Network Management Encryption type.</p> <p>Format: ! U1 getvar "netmanage.avalanche.encryption_type"</p>



Example: This example sets the value to Limburger (1) encryption type.

```
! U1 getvar "netmanage.avalanche.encryption_type" "1"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.interval

This parameter obtains or sets the Network Management Update Interval time stored in the printer. Time is measured in milliseconds (e.g., a setting of "2000" equals 2 seconds).

Commands	Details
setvar	This command sets the Network Management Update Interval. Format: ! U1 setvar "netmanage.avalanche.interval" "value" Values: any integer value from "0" to "4294967295" (4,294,967,295 milliseconds) Default: "0"
getvar	This command retrieves the current Network Management Update Interval. Format: ! U1 getvar "netmanage.avalanche.interval"



Example: This example sets the interval value to 3 seconds.
! U1 setvar "netmanage.avalanche.interval" "3000"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.interval_update

This parameter turns on or off the Network Management Update Interval. This command is related to [netmanage.avalanche.interval](#) on page 818.

Commands	Details
setvar	<p>This command turns on or off the network management interval update.</p> <p>Format: ! U1 setvar "netmanage.avalanche.interval_update" "value"</p> <p>Values: "off" "on"</p> <p>Default: "off"</p>
getvar	<p>This command retrieves the current network management interval update setting.</p> <p>Format: ! U1 getvar "netmanage.avalanche.interval_update"</p>



Example: This example sets the device's Network Management Interval Update setting to "on".

```
! U1 setvar "netmanage.avalanche.interval_update" "on"
```



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

netmanage.avalanche.model_name

This command obtains or sets the current Network Management Device Model Name stored in the printer.

Commands	Details
setvar	This command sets the current Network Management Device model name. Format: ! U1 setvar "netmanage.avalanche.model_name" "value" Values: a string up to 31 characters in length. Default: NA
getvar	This command retrieves the current Network Management Device model name. Format: ! U1 getvar "netmanage.avalanche.model_name"



Example:

```
! U1 setvar "netmanage.avalanche.model_name" "ZT230"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.set_property

This parameter sets Network Management Device Side Property (custom).

Commands	Details
setvar	This parameter sets Network Management Device Side Property (custom). Format: ! U1 setvar "netmanage.avalanche.set_property" "value" Values: A string in the format of "AAAA=XXXXXXXX"
getvar	This parameter retrieves the current Network Management Device Side Property value. Format: ! U1 getvar "netmanage.avalanche.set_property"

➔ **Example 1** • This example will be viewed as a property under the general property tree in avalanche console.
! U1 setvar netmanage.avalanche.set_property "ZebraLocation=VH"

➔ **Example 2** • This example will be viewed as a property under the Zebra tree in avalanche console.
! U1 setvar netmanage.avalanche.set_property "Zebra.Location=VH"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.startup_update

This parameter sets and retrieves the Network Management Start Up Update setting.

Commands	Details
setvar	This command sets the device's Network Management Start Up Update setting. Format: <code>! U1 setvar "netmanage.avalanche.startup_update" "value"</code> Values: "off" "on" Default: "off"
getvar	This command retrieves the device's current Network Management Start Up Update setting. Format: <code>! U1 getvar "netmanage.avalanche.startup_update"</code>



Example:

```
! U1 setvar "netmanage.avalanche.startup_update" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.tcp_connection_timeout

This command sets the Network Management Timeout used for establishing a TCP connection to an Agent. Time is set in milliseconds.

Commands	Details
setvar	<p>This command sets the Network Management Timeout used for establishing a TCP connection to an Agent.</p> <p>Format: ! U1 setvar "netmanage.avalanche.tcp_connection_timeout" "value"</p> <p>Values: any integer value from "0" to "4294967295" (<i>4,294,967,295 milliseconds</i>)</p> <p>Default: "0"</p>
getvar	<p>This command retrieves the current Network Management Timeout used for establishing a TCP connection to an Agent.</p> <p>Format: ! U1 getvar "netmanage.avalanche.tcp_connection_timeout"</p>



Example: This examples sets the connection timeout to 2000 milliseconds (2 seconds).

```
! U1 setvar "netmanage.avalanche.tcp_connection_timeout" "2000"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.terminal_id

Sets or retrieves the Terminal ID of the Avalanche server. This value is typically assigned by the Avalanche server.

Commands	Details
setvar	Format: ! U1 setvar "netmanage.avalanche.terminal_id" "value" Values: "0" - "402653183" Default: "0"
getvar	Format: ! U1 getvar "netmanage.avalanche.terminal_id"

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.text_msg.beep

This parameter sets and gets Network Management Text Message Beep enable setting.

Commands	Details
setvar	This command sets Network Management Text Message Beep enable setting. Format: ! U1 setvar "netmanage.avalanche.text_msg.beep" "value" Values: "off" "on" Default: "off"
getvar	This command retrieves the Network Management Text Message Beep enable setting. Format: ! U1 getvar "netmanage.avalanche.text_msg.beep"



Example:

```
! U1 setvar "netmanage.avalanche.text_msg.beep" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.text_msg.display

This command turns on and off the Network Management Text Message Display setting.

Commands	Details
setvar	This command retrieves the device's Network Management Text Message Display enable setting. Format: ! U1 setvar "netmanage.avalanche.text_msg.display" "value" Values: "off" "on" Default: "off"
getvar	This command returns the current Network Management Text Message Display enable setting. Format: ! U1 getvar "netmanage.avalanche.text_msg.display"



Example:

```
! U1 setvar "netmanage.avalanche.text_msg.display" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.text_msg.print

This command turns on and off the Network Management Text Message Print setting.

Commands	Details
setvar	<p>This command retrieves the device's Network Management Text Message Print enable setting.</p> <p>Format: ! U1 setvar "netmanage.avalanche.text_msg.print" "value"</p> <p>Values: "off" "on"</p> <p>Default: "off"</p>
getvar	<p>This command returns the current Network Management Text Message Print enable setting.</p> <p>Format: ! U1 getvar "netmanage.avalanche.text_msg.print"</p>



Example:

```
! U1 setvar "netmanage.avalanche.text_msg.print" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.avalanche.udp_timeout

This command sets the device's Network Management UDP timeout. Time is set in milliseconds.

Commands	Details
setvar	This command sets the device's Network Management UDP timeout. Format: <code>! U1 setvar "netmanage.avalanche.udp_timeout" "value"</code> Values: any integer value from "0" to "4294967295" (4,294,967,295 milliseconds) Default: "0"
getvar	This command returns the current Network Management UDP timeout setting. Format: <code>! U1 getvar "netmanage.avalanche.udp_timeout"</code>



Example: This example sets the timeout value to .4 seconds (400 milliseconds).

```
! U1 setvar "netmanage.avalanche.udp_timeout" "400"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.error_code

This parameter refers to Avalanche client error code.

Commands	Details
getvar	Format: ! U1 getvar "netmanage.error_code" Result: "0"

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.state_code

This parameter refers to Avalanche client state code.

Commands	Details
getvar	Format: ! U1 getvar "netmanage.state_code" Result: "0"

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

netmanage.status_code

This parameter refers to Avalanche client status code.

Commands	Details
getvar	Format: ! U1 getvar "netmanage.status_code" Result: "0"

Supported Devices

- iMZ220, iMZ320
- QLn320, QLn220
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.cut_marker_count

Returns the number of cuts incurred by the cutter or resets the counter to "0". This command tracks the same events as [odometer.total_cuts](#), which cannot be reset.

Commands	Details
setvar	Format: ! U1 setvar "odometer.cut_marker_count" "value" Values: "0" - resets the counter to 0.
getvar	Format: ! U1 getvar "odometer.cut_marker_count" Result: an integer value of "0" or greater.

Supported Devices

- ZD410, ZD420
- ZD500
- ZT210, ZT220, ZT230
- ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.headclean

This printer setting refers to the head clean odometer count. This counter tracks how many inches and centimeters have passed through the printer since the head was last cleaned.

Commands	Details
setvar	This command instructs the printer to reset the head clean counter. Format: ! U1 setvar "odometer.headclean" "value" Values: "0" = reset the head clean counter Default: must be an accepted value or it is ignored
getvar	This command instructs the printer to retrieve the values for the head clean counter. Format: ! U1 getvar "odometer.headclean"



Example: This example shows how to get the odometer head clean, how to reset it, and how to confirm the settings changed.

1. To see the current settings, type:
! U1 getvar "odometer.headclean"
Something similar to this is shown:
"1489 INCHES, 3784 CENTIMETERS"
2. To reset the these values to 0, type:
! U1 setvar "odometer.headclean" "0"
3. To confirm this settings were reset, type:
! U1 getvar "odometer.headclean"
If the resetting was successful, this is shown:
"0 INCHES, 0 CENTIMETERS"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.headnew

This printer setting refers to the head replaced odometer count. This counter tracks how many inches and centimeter passed through the printer since the head was last replaced.

Commands	Details
setvar	This command instructs the printer to reset the head new counter. Format: ! U1 setvar "odometer.headnew" "value" Values: "0" = resets the head new counter Default: must be an accepted value or it is ignored
getvar	This command instructs the printer to retrieve the values for the head new counter. Format: ! U1 getvar "odometer.headnew"



Example: This example shows how to get the odometer head new, how to reset it, and how to confirm the settings changed:

1. To see the current settings, type:
! U1 getvar "odometer.headnew"
Something similar to this is shown:
"1489 INCHES, 3784 CENTIMETERS"
2. To reset the these values to 0, type:
! U1 setvar "odometer.headnew" "0"
3. To confirm this settings were reset, type:
! U1 getvar "odometer.headnew"
If the resetting was successful, this is shown:
"0 INCHES, 0 CENTIMETERS"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.label_dot_length

This command returns the length of the last label printed or fed (in dots).

Commands	Details
getvar	This command returns the length of the last label printed or fed (in dots). Format: ! U1 getvar "odometer.label_dot_length"



Example: This is an example of how to reset the length using the ^LL command and how to use the getvar to confirm the change. For the ^LL command to work the printer must be in continuous mode.

1. To change the odometer label dot length, type:

```
^XA  
^LL500  
^XZ
```

2. To get the current odometer label dot length, type:

```
! U1 getvar "odometer.label_dot_length"
```

Something similar to this is shown:

```
"500"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.media_marker_count

This command refers to the non-resettable media marker count. The media marker counter keeps track of how many labels have passed through the printer by counting the bar sense marks on the back of the media or the gap in gap media. Labels are counted whether or not they have been printed.

Commands	Details
setvar	Format: ! U1 setvar "odometer.media_marker_count" "value" Values: "0" to "4294967295" Default: "0"
getvar	Format: ! U1 getvar "odometer.media_marker_count" Example: "105"

Supported Devices

- S4M
- Z4MPlus, Z6MPlus
- 105SL
- 110XIIIPlus, 140XIIIPlus, 170XIIIPlus, 220XIIIPlus
- 110Xi4, 140Xi4, 170Xi4
- 110PAX4
- GK420t, GK420d, GK888t
- LP 2824 Plus
- QL420+



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.media_marker_count1

This printer setting refers to the value of the first (count1) user resettable counter. The user resettable counters track how much media has passed through the printer in both inches or centimeters.

Commands	Details
setvar	<p>This command instructs the printer to reset the first user resettable counter.</p> <p>Format: ! U1 setvar "odometer.media_marker_count1" "value"</p> <p>Values: "0" = reset the counter</p> <p>Default: must be an accepted value or it is ignored</p>
getvar	<p>This command instructs the printer to return the current value of the first (count1) user resettable counter in both inches and centimeters.</p> <p>Format: ! U1 getvar "odometer.media_marker_count1"</p>



Example: This example shows how to get the first user resettable counter, how to reset it, and how to confirm the settings have changed:

1. To see the current settings, type:
! U1 getvar "odometer.media_marker_count1"
Something similar to this is shown:
"8516 INCHES, 21632 CENTIMETERS"
2. To reset these values to 0, type:
! U1 setvar "odometer.media_marker_count1" "0"
3. To confirm these settings were reset, type:
! U1 getvar "odometer.media_marker_count1"
If the resetting was successful, this is shown:
"0 INCHES, 0 CENTIMETERS"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.media_marker_count2

This printer setting refers to the value of the second (count2) user resettable counter. The user resettable counters track how much media has passed through the printer in both inches or centimeters.

Commands	Details
setvar	<p>This command instructs the printer to reset the second user resettable counter.</p> <p>Format: ! U1 setvar "odometer.media_marker_count2" "value"</p> <p>Values: "0" = reset the counter</p> <p>Default: must be an accepted value or it is ignored</p>
getvar	<p>This command instructs the printer to return the current value of the second (count2) user resettable counter in both inches and centimeters.</p> <p>Format: ! U1 getvar "odometer.media_marker_count2"</p>



Example: This example shows how to get the second user resettable counter, how to reset it, and how to confirm the settings have changed:

1. To see the current settings, type:
! U1 getvar "odometer.media_marker_count2"
Something similar to this is shown:
"8516 INCHES, 21632 CENTIMETERS"
2. To reset these values to 0, type:
! U1 setvar "odometer.media_marker_count2" "0"
3. To confirm these settings were reset, type:
! U1 getvar "odometer.media_marker_count2"
If the resetting was successful, this is shown:
"0 INCHES, 0 CENTIMETERS"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.retracts_count

This printer value records the number of times a label has been retracted since the last time the counter has been reset.

Commands	Details
setvar	This command instructs the printer to reset the current count of retractions. Format: <code>! U1 setvar "odometer.retracts_count" "value"</code> <i>Values:</i> 0 = reset the counter <i>Default:</i> none
getvar	This command instructs the printer to respond with the current number of retractions that have happened since the last time the counter was reset. Format: <code>! U1 getvar "odometer.retracts_count"</code>

Supported Devices

- KR403



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.rfid.valid_resetable

This command resets the RFID valid label counter to zero.

Commands	Details
setvar	This command instructs the printer to set the RFID valid counter to zero. Format: ! U1 setvar "odometer.rfid.valid_resetable" "value" Values: (ZD500R only) "0" (other RFID printers) "reset"
getvar	This command instructs the printer to respond with the current RFID valid counter value. Format: ! U1 getvar "odometer.rfid.valid_resetable"

➔ **Example:** This setvar example shows how the counter portion of the printer configuration labels looks when the RFID valid counter is reset by sending:

ZD500R only:

! U1 setvar "odometer.rfid.valid_resetable" "0"

Other RFID printers:

! U1 setvar "odometer.rfid.valid_resetable" "reset"

Before

```

TM:M6E MICRO..... RFID READER
20.00.00.01..... RFID HW VERSION
01.01.00.EA..... RFID FW VERSION
USA/CANADA..... RFID REGION CODE
USA/CANADA..... RFID COUNTRY CODE
RFID OK..... RFID ERR STATUS
16..... RFID READ PWR
16..... RFID WRITE PWR
F0..... PROG. POSITION
507..... RFID VALID CTR
4..... RFID VOID CTR
    
```

After

```

TM:M6E MICRO..... RFID READER
20.00.00.01..... RFID HW VERSION
01.01.00.EA..... RFID FW VERSION
USA/CANADA..... RFID REGION CODE
USA/CANADA..... RFID COUNTRY CODE
RFID OK..... RFID ERR STATUS
16..... RFID READ PWR
16..... RFID WRITE PWR
F0..... PROG. POSITION
0..... RFID VALID CTR
4..... RFID VOID CTR
    
```


odometer.rfid.void_resetable

This command resets the RFID void label counter to zero.

Commands	Details
setvar	This command instructs the printer to set the RFID void counter to zero. Format: ! U1 setvar "odometer.rfid.void_resetable" "value" Values: (ZD500R only) "0" (other RFID printers) "reset"
getvar	This command instructs the printer to respond with the current RFID void counter value. Format: ! U1 getvar "odometer.rfid.void_resetable"

➔ **Example:** This setvar example shows how the counter portion of the printer configuration labels looks when the RFID void counter is reset by sending:

ZD500R only:

! U1 setvar "odometer.rfid.valid_resetable" "0"

Other RFID printers:

! U1 setvar "odometer.rfid.valid_resetable" "reset"

Before

```

TM:M6E MICRO..... RFID READER
20.00.00.01..... RFID HW VERSION
01.01.00.EA..... RFID FW VERSION
USA/CANADA..... RFID REGION CODE
USA/CANADA..... RFID COUNTRY CODE
RFID OK..... RFID ERR STATUS
16..... RFID READ PWR
16..... RFID WRITE PWR
F0..... PROG. POSITION
507..... RFID VALID CTR
4..... RFID VOID CTR
    
```

After

```

TM:M6E MICRO..... RFID READER
20.00.00.01..... RFID HW VERSION
01.01.00.EA..... RFID FW VERSION
USA/CANADA..... RFID REGION CODE
USA/CANADA..... RFID COUNTRY CODE
RFID OK..... RFID ERR STATUS
16..... RFID READ PWR
16..... RFID WRITE PWR
F0..... PROG. POSITION
507..... RFID VALID CTR
0..... RFID VOID CTR
    
```

odometer.total_cuts

Displays the total number of cuts incurred by the cutter.

getvar	Format: ! U1 getvar "odometer.total_cuts" Values: an integer
--------	---

Supported Devices

- ZD410, ZD420
- ZD500
- ZT210, ZT220, ZT230
- ZT410



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.total_print_length

This command returns the total length of all media movement over the life of the printer.



Note • The number returned includes all media movement including backfeeds.

Commands	Details
getvar	Format: ! U1 getvar "odometer.total_print_length" Default: 0



Example: To get the total length of media printed to date:

```
! U1 getvar "odometer.total_print_length"
```

Result: (*sample*) "8560 INCHES, 21744 CENTIMETERS"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.total_label_count

This command returns the total number of labels printed over the life of the printer.



Note • The number returned does not include form feeds or calibration labels.

Commands	Details
getvar	Format: ! U1 getvar "odometer.total_label_count"



Example: To get the total number of labels printed to date:

```
! U1 getvar "odometer.total_label_count"
```

Result: (*sample*) "31084"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.user_label_count

Returns the number of labels printed since the last odometer set command.



Note •

setvar	<p>Format: ! U1 setvar "odometer.user_label_count" "value"</p> <p>Values: 0 to 65000</p> <p>Related ZPL Commands: ~R0 1</p>
getvar	<p>Format: ! U1 getvar "odometer.user_label_count"</p> <p>Values: 0 to 65000</p>



Example: To get the total number of labels printed to date:

```
! U1 getvar "odometer.user_label_count"
```

Result: (sample) "7544"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.user_label_count[1|2]

Returns the number of labels printed since the last reset of each resettable odometer.

setvar	Resets the counter value to 0. Values: ! U1 setvar "odometer.user_label_count1" "value" Format: ! U1 setvar "odometer.user_label_count2" "value" Values: 0 Related ZPL Commands: ~R0
getvar	Format: ! U1 getvar "odometer.user_label_count1" Format: ! U1 getvar "odometer.user_label_count2" Values: 0 to 4294967295 Related ZPL Commands: ~R0



Example: To get the total number of labels printed on to date:

```
! U1 getvar "odometer.user_label_count1"
```

Result: (*sample*) "164"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

odometer.latch_open_count

Returns the number of times the latch for the printhead has been opened.

Commands	Details
setvar	Format: ! U1 setvar "odometer.latch_open_count" "value" Values: 0 to 4294967295
getvar	Format: ! U1 getvar "odometer.latch_open_count"

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

parallel_port.mode

This command sets the mode type for the parallel port.

Commands	Details
setvar	This command sets the mode type for the parallel port. Format: ! U1 setvar "parallel_port.mode" "value" Values: "bidirectional" "unidirectional" Default: "bidirectional"
getvar	This command retrieves the current mode type setting for the parallel port. Format: ! U1 getvar "parallel_port.mode"



Example:

```
! U1 setvar "parallel_port.mode" "bidirectional"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

parallel_port.present

This command reports if there is a parallel port in the printer.

Commands	Details
getvar	This command reports if there is a parallel port in the printer. Format: ! U1 getvar "parallel_port.present" Result: "present" "not installed"

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.average_current

Returns the battery pack average current value for mA for printers supporting Power Precision Plus batteries.

Commands	Details
getvar	! U1 getvar "power.average_current" Values: any integer value

Supported Devices

- ZQ310, ZQ320



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.battery_led_blink_rate

Sets the Extended Smart Battery LED blink rate. The rate is set in multiples of 0.5 seconds.

Commands	Details
setvar	Format: ! U1 setvar "power.battery_led_blink_rate" "value" Values: a number from 0 to 127. The rate is set in multiples of 0.5 seconds. Default: "2"
getvar	Format: ! U1 getvar "power.battery_led_blink_rate" Result: a number from 0 to 127. The rate is set in multiples of 0.5 seconds.

Supported Devices

- ZQ510
- ZQ520



Example: The rate is set in multiples of 0.5 seconds.

To achieve an On time of 1 second, and Off time of 4.5 seconds one would use the following configuration:

On Duration = 2 (2 * 0.5 = 1 second) (xref power.battery_led_on_duration)

Off Duration = 9 (9 * 0.5 = 4.5 seconds) (xref power.battery_led_off_duration)

Blink Rate = 2 (2 * 0.5 = 1 second)



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.battery_led_enable

This command will enable or disable the illumination of the Extended Smart battery LED when one or more of the `power.battery` thresholds have been reached.

Commands	Details
setvar	Format: ! U1 setvar "power.battery_led_enable" "value" Values: "on" = enables the Extended Smart battery LED "off" = disables the Extended Smart battery LED Default: "on"
getvar	Format: ! U1 getvar "power.battery_led_enable"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.battery_led_off_duration

Sets the Extended Smart Battery Led Off duration. The rate is set in multiples of 0.5 seconds.

Commands	Details
setvar	Format: ! U1 setvar "power.battery_led_off_duration" "value" Values: A number between 0 and 255. The rate is set in multiples of 0.5 seconds. Default: "9"
getvar	Format: ! U1 getvar "power.battery_led_off_duration"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.battery_led_on_duration

Sets the Extended Smart Battery Led On duration. The rate is set in multiples of 0.5 seconds.

Commands	Details
setvar	<p>Format: ! U1 setvar "power.battery_led_on_duration" "value"</p> <p>Values: A number between 0 and 255. The rate is set in multiples of 0.5 seconds.</p> <p>Default: "2"</p>
getvar	<p>Format: ! U1 getvar "power.battery_led_on_duration"</p>

Supported Devices

- ZQ510. ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.battery_replacement_cyclecount_threshold

This printer setting configures when the Extended Smart Battery's LED will illuminate, based upon the charge cycle count. The LED illuminates when the cycle count for the battery reaches the value set by this command.

Commands	Details
setvar	Format: ! U1 setvar "power.battery_replacement_cyclecount_threshold" "value" Values: 100 to 2450 Default: "551"
getvar	Format: ! U1 getvar "power.battery_replacement_cyclecount_threshold"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.dtr_power_off

This command refers to the remote printer power control, and is used for power management. When Data Terminal Ready (DTR) is enabled the printer can be powered on and off via the Data Set Ready (DSR) signal. When DTR power off is enabled, a low to high transition will cause the printer to turn ON and a high to low transition will cause the printer to turn OFF.



Note • The inactivity time-out is disabled while DSR is active.

Commands	Details
setvar	This command instructs the printer to turn DTR power on or off. Format: ! U1 setvar "power.dtr_power_off" "value" Values: "off" "on" Default: "on"
getvar	This command retrieves the current DTR power-off setting. Format: ! U1 getvar "power.dtr_power_off"



Example:

```
! U1 setvar "power.dtr_power_off" "off"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.energy_star.enable

Enables the EnergyStar functionality. For more information on Energy Star, see <http://www.energystar.gov>.

Commands	Details
setvar	! U1 setvar "power.energy_star.enable" "value" Values: "on" = enables the EnergyStar functionality "off" = disables the EnergyStar functionality Default: "on"
getvar	! U1 getvar "power.energy_star.enable"

Supported Devices

- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.energy_star.timeout

Sets the amount of idle time before EnergyStar mode is invoked. The time is specified in seconds. For more information on Energy Star, see <http://www.energystar.gov>.

Commands	Details
setvar	! U1 setvar "power.energy_star.timeout" "value" Values: 180 to 65535 Default: "180"
getvar	! U1 getvar "power.energy_star.timeout"

Supported Devices

- ZT510
- ZT610, ZT620



Example: This setvar example shows the value set to "260".

```
! U1 setvar "power.energy_star.timeout" "260"
```

The setvar value is the getvar result. In this example, the getvar result is "260".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.label_queue.shutdown

Specifies if the printer should wait to shut down until all labels in its internal queue have been printed.

Commands	Details
setvar	<p>Format: ! U1 setvar "power.label_queue.shutdown" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "yes" = printer will wait to shut down until all labels in its internal queue have been printed "no" = printer will not wait to shut down until all labels in its internal queue have been printed <p>Default: "no"</p>
getvar	<p>Format: ! U1 getvar "power.label_queue.shutdown"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.power_on_mode

Indicates if the printer will power on automatically when power is applied, i.e., when the power supply is plugged in.

Commands	Details
getvar	<p>! U1 getvar "power.power_on_mode"</p> <p>Values:</p> <p>"auto" = jumper is present on option card, which makes the printer power on automatically when power is applied</p> <p>"manual" = jumper is not present on option card or the option card doesn't support auto-power on, so the printer will power on only when the user presses the power button.</p> <p>"not available" = not an option on the printer.</p> <p>Default: "on"</p>

Supported Devices

- ZD410, ZD420
- ZD620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

power.shutdown

Instructs the printer to shut down.

Commands	Details
do	Format: ! U1 do "power.shutdown" ""

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

print.tone

This command specifies the printer darkness.

Commands	Details
setvar	<p>This command instructs the printer to set the darkness and relative darkness.</p> <p>Format: ! U1 setvar "print.tone" "value"</p> <p>Values: "0.0" to "30.0" = darkness "-0.1" to "-30.0" and "+0.1" to "+30.0" = incremental adjustments</p> <p>Default: "4.0"</p>
getvar	<p>This command retrieves the printer's current darkness setting.</p> <p>Format: ! U1 getvar "print.tone"</p>



Example: This setvar example shows the value set to "4.0".

```
! U1 setvar "print.tone" "4.0"
```

When the setvar value is set to "4.0", the getvar result is "4.0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

print.troubleshooting_label_print

Sets whether batch counters will be displayed on the printer's control panel.

Commands	Details
setvar	Format: ! U1 setvar "print.troubleshooting_label_print" "value" Values: "enabled" = batch counters will be displayed "disabled" = batch counters will not be displayed Default: "disabled" Example: ! U1 setvar "print.troubleshooting_label_print" "enabled"
getvar	Format: ! U1 getvar "print.troubleshooting_label_print" Result: "enabled"

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620





Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.adaptive_antenna

This command enables or disables adaptive antenna selection.

If the printer cannot find RFID tags with the antenna element specified during the number of retries specified (if applicable), the printer may try neighboring antenna elements. If the printer is unsuccessful communicating with the RFID tag after trying the neighboring antenna elements, the printer voids the label.

Commands	Details
setvar	<p>Enables or disables the adaptive antenna feature.</p> <p> Note •</p> <ul style="list-style-type: none"> • This command is valid only on R110Xi4 and ZT400 printers with a label that is 2 in. (51 mm) or longer. • Activating this feature may slow throughput on damaged or weak RFID tags. <p> Note •</p> <ul style="list-style-type: none"> • This feature does not apply to ZD500R printers, which always use an antenna element value of A1. • The label length must be 2 in. (51 mm) or greater. • Activating this feature may slow throughput on damaged or weak RFID tags. <p>Format: ! U1 setvar "rfid.adaptive_antenna" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> none = The printer uses only the current antenna element selection. neighbors = The printer attempts to read the tag using the antenna elements to the left/right and above/below the current antenna. The antenna element that is successful is used for all subsequent RFID commands until the next unsuccessful attempt. <p>Default: none</p>
getvar	<p>Retrieves the current adaptive antenna setting.</p> <p>Format: ! U1 getvar "rfid.adaptive_antenna"</p>





Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.antenna_sweep

This command enables/disables the antenna sweep feature.

If the RFID media loaded in the printer is known to be in range of an antenna at the F0 programming position, you can avoid RFID calibration by using the RFID antenna sweep feature. With this feature enabled, when the first RFID format is sent after a printer powerup or printhead close, the printer scans through the antennas to find the optimal antenna element.

Commands	Details
setvar	<p>Enables or disables the antenna sweep feature.</p> <p> Note • This command is valid only on R110Xi4 and ZT400 printers with a label that is 2 in. (51 mm) or longer and when using a program position of F0.</p> <p> Note •</p> <ul style="list-style-type: none"> • This feature does not apply to ZD500R printers, which always use an antenna element value of A1. • The label length must be 2 in. (51 mm) or greater, and the programming position must be F0. <p>Format: ! U1 setvar "rfid.antenna_sweep" "value" Values: on, off Default: on</p>
getvar	<p>Retrieves the current antenna sweep setting.</p> <p>Format: ! U1 getvar "rfid.adaptive_antenna"</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

DNP - rfid.calibration_maximum_power

Limits the maximum power used during RFID calibration, enabling the printer to compensate for RFID tags which require less power to be encoded. In this state, the printer is less likely to detect RFID chips that are not in the optimal programming position.

Commands	Details
setvar	! U1 setvar "rfid.calibration_maximum_power" "value" Values: "0" to "30" Default: "30"
getvar	! U1 getvar "rfid.calibration_maximum_power"

Supported Devices

- NEED TO CHECK THESE!!!! LINK-OS PRINTERS ONLY
- Only supported in legacy fw
- rxi4, ze500r, Z4m/Z6M



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.country_code

This command sets or returns the RFID reader country code. The country code is restricted based on the region code assigned to the reader and, in some instances, cannot be modified. You can check the countries available for your region through the control panel menu items on your printer.

Commands	Details
setvar	Sets the RFID reader's current country code. Format: ! U1 setvar "rfid.country_code" "value" Values: The country code choices available will vary depending on the region for which your printer is configured.
getvar	Retrieves the RFID reader's current country code. Format: ! U1 getvar "rfid.country_code"



Example: In this example, the `setvar` sets the country code to USA/Canada.

```
! U1 setvar "rfid.country_code" "usa/canada"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.enable

This command instructs an RFID printer to enable or disable RFID functionality. You must restart the printer for the command to take effect.



Note • When this function is set to "on," changes are made to normal printer functionality. Loading printer defaults does NOT:

- Default the sensor select setting
- Default media tracking sensor settings
- Default label length
- Perform an auto calibration

Commands	Details
setvar	Enables or disables RFID functionality. Format: ! U1 setvar "rfid.enable" "value" Values: on = enables RFID functionality off = disables RFID functionality Default: on



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.error.response

This command can be used to retrieve the RFID status, including any error codes or messages.

Commands	Details
getvar	Retrieves any active RFID error messages. Format: ! U1 getvar "rfid.error.response"



Example: This `getvar` example shows responses that you may get in different situations:

```
! U1 getvar "rfid.error.response"
```

If no RFID tag is present, you get the following response:

```
NO TAG FOUND
```

If an RFID tag is present and there are no errors, you get the following response:

```
RFID OK
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.hop_table_version

This command retrieves the RFID reader's hop table version.

Commands	Details
getvar	Retrieves the RFID reader's hop table version. Format: ! U1 getvar "rfid.hop_table_version"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.position.program

This command sets the read/write position of the RFID tag (programming position).



Important • If this command is used to specify a value for the programming position, this value will be used for the programming position for all labels until a new position is specified or until the tag calibration procedure is run.

Commands	Details
setvar	<p>This command instructs the printer to set the read/write position of the RFID tag.</p> <p>Format: ! U1 setvar "rfid.position.program" "value"</p> <p>Values:</p> <p>For the ZD500R only:</p> <p>F0 to Fxxx (where xxx is the label length in millimeters or 999, whichever is less) The printer prints the first part of a label until it reaches the specified distance and then begins programming. After programming, the printer prints the remainder of the label.</p> <p>B0 to B30 The printer backfeeds the label for the specified distance and then begins programming. To account for the backfeed, allow empty media liner to extend out of the front of the printer when using a backward programming position.</p> <p>up = move to the next value down = move to the previous value</p> <p>For other RFID printers:</p> <p><i>Absolute Mode</i> (all firmware versions): xxxx = 0 to label length (in dot rows). Move the media to the specified position xxxx on the label, measured in dot rows from the label top, before encoding. Set to 0 (no movement) if the tag is already in the effective area without moving the media.</p> <p><i>Relative Mode</i> (firmware versions V53.17.6 and later):</p> <p>F0 to Fxxx (where xxx is the label length in millimeters or 999, whichever is less) The printer prints the first part of a label until it reaches the specified distance and then begins programming. After programming, the printer prints the remainder of the label.</p> <p>B0 to B30 (Does not apply to the RP4T printer.) The printer backfeeds the label for the specified distance and then begins programming. To account for the backfeed, allow empty media liner to extend out of the front of the printer when using a backward programming position.</p>
setvar (continued)	<p>Default:</p> <p>For the R2844-Z and RPAX: 0 (no movement)</p> <p>For printers using V53.17.7 and later: F0 (which moves the leading edge of the label to the print line)</p> <p>For all other printers or firmware: label length minus 1 mm (1/16 in.)</p>
getvar	<p>This command instructs the printer to respond with the current programming position.</p> <p>Format: ! U1 getvar "rfid.position.program"</p>



Example: This example shows the programming position being set at 15 mm from the leading edge of the label.

! U1 setvar "rfid.position.program" "F15"

When the setvar value is set to "F15", the getvar result is F15.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.reader_1.antenna_port

This command specifies the RFID antenna to be used for RFID operation.





Note • Some printers automatically select the best antenna element and read/write power levels for the media during RFID transponder calibration. Ty may also set the levels during an adaptive antenna sweep. Use the `~HL` command (see [^HL or ~HL on page 353](#)) to view the antenna element and power settings being used.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

Commands	Details
setvar	<p>Sets the antenna port.</p> <p>Format: ! U1 setvar "rfid.reader_1.antenna_port" "value"</p> <p>ZD500R: This printer only has one antenna element, so the value used is always A1. Default: A1</p> <p>ZT400: This parameter selects an antenna element from the printer's antenna array.</p> <p>Values: E1, E2, E3, E4 D1, D2, D3, D4 C1, C2, C3, C4 B1, B2, B3, B4 A1, A2, A3, A4</p>  <p>Default: A4</p> <p>(Continued on next page)</p>

Commands	Details
<p>setvar</p>	<p>(Continued from previous page)</p> <p>R110Xi4 (V53.17.5 and later): Values: a two-digit antenna value: A1, A2, A3, A4, B1, B2, B3, B4, C1, C2, C3, C4, D2, D3, D4, E2, E3, E4, F2, F3, F4 (combinations D1, E1, and F1 are invalid)</p>  <p>Default: A4</p> <p>R110Xi HF (R65.X): Values: 1 = antenna port 1 2 = antenna port 2 Default: 1</p>
<p>getvar</p>	<p>Retrieves the current antenna port. Format: ! U1 getvar "rfid.reader_1.antenna_port"</p>



Example: This setvar example shows the selection of antenna port D3.
 ! U1 setvar "rfid.reader_1.antenna_port" "D3"
 When the setvar value is set to "D3", the getvar result is "D3".

rfid.reader_1.power.read

This command sets the RFID reader power level for reading RFID tags.



Note • The R110Xi4 printer automatically selects the best antenna element and read/write power levels for the media during RFID transponder calibration. It may also set the levels during an adaptive antenna sweep. Use the `~HL` command (see [^HL or ~HL on page 353](#)) to view the antenna element and power settings being used.

Commands	Details		
setvar	<p>This command instructs the printer to set the antenna's read power level. Format: ! U1 setvar "rfid.reader_1.power.read" "value"</p> <table border="0"> <tr> <td style="vertical-align: top;"> <p>R53.16.3Z: Values: 0 to 30 Default: 16</p> <p>RP4T (all firmware versions), R53.16.4Z, V53.17.7, V74.19.6Z, and later: Values: • 0 to 30 • up = increase the current value by 1 • down = decrease the current value by 1 Default: "16"</p> </td> <td style="vertical-align: top;"> <p>R60.16.x, R62.16.x, R63.16.x, R65.16.x, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values: • 0 to 30 • high • medium • low Default: low</p> <p>Older firmware: Values: • high • medium • low Default: low</p> </td> </tr> </table>	<p>R53.16.3Z: Values: 0 to 30 Default: 16</p> <p>RP4T (all firmware versions), R53.16.4Z, V53.17.7, V74.19.6Z, and later: Values: • 0 to 30 • up = increase the current value by 1 • down = decrease the current value by 1 Default: "16"</p>	<p>R60.16.x, R62.16.x, R63.16.x, R65.16.x, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values: • 0 to 30 • high • medium • low Default: low</p> <p>Older firmware: Values: • high • medium • low Default: low</p>
<p>R53.16.3Z: Values: 0 to 30 Default: 16</p> <p>RP4T (all firmware versions), R53.16.4Z, V53.17.7, V74.19.6Z, and later: Values: • 0 to 30 • up = increase the current value by 1 • down = decrease the current value by 1 Default: "16"</p>	<p>R60.16.x, R62.16.x, R63.16.x, R65.16.x, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values: • 0 to 30 • high • medium • low Default: low</p> <p>Older firmware: Values: • high • medium • low Default: low</p>		
getvar	<p>Retrieves the antenna's current read power level. Format: ! U1 getvar "rfid.reader_1.power.read"</p>		



Example: This setvar example sets the antenna to power setting 16 for reading RFID tags.

```
! U1 setvar "rfid.reader_1.power.read" "16"
```

When the setvar value is set to "16", the getvar result is 16.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.reader_1.power.write

Use this command to set the RFID write power levels if the desired levels are not achieved through RFID tag calibration. If not enough power is applied, the tag may not have sufficient power for programming, and tag data will fail to encode. If too much power is applied, the extra power may cause data communication errors or may cause the wrong tag to be programmed.



Note • The R110Xi4 printer automatically selects the best antenna element and read/write power levels for the media during RFID transponder calibration. It may also set the levels during an adaptive antenna sweep. Use the `~HL` command (see [^HL or ~HL on page 353](#)) to view the antenna element and power settings being used.



Note • This parameter is ignored on the R110Xi HF printer because read and write powers cannot be specified separately. See [rfid.reader_1.power.single_power on page 881](#) to set the power level for the R110Xi HF printer.

Commands	Details		
setvar	<p>This command instructs the printer to set the antenna's read power level.</p> <p>Format: ! U1 setvar "rfid.reader_1.power.read" "value"</p> <table border="0"> <tr> <td style="vertical-align: top;"> <p>R53.16.3Z: Values: 0 to 30 Default: 16</p> <p>RP4T (all firmware versions), R53.16.4Z, V53.17.7, V74.19.6Z, and later: Values:</p> <ul style="list-style-type: none"> • 0 to 30 • up = increase the current value by 1 • down = decrease the current value by 1 <p>Default: "16"</p> </td> <td style="vertical-align: top;"> <p>R60.16.x, R62.16.x, R63.16.x, R65.16.x, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values:</p> <ul style="list-style-type: none"> • 0 to 30 • high • medium • low <p>Default: low</p> <p>Older firmware: Values: high , medium , low Default: low</p> </td> </tr> </table>	<p>R53.16.3Z: Values: 0 to 30 Default: 16</p> <p>RP4T (all firmware versions), R53.16.4Z, V53.17.7, V74.19.6Z, and later: Values:</p> <ul style="list-style-type: none"> • 0 to 30 • up = increase the current value by 1 • down = decrease the current value by 1 <p>Default: "16"</p>	<p>R60.16.x, R62.16.x, R63.16.x, R65.16.x, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values:</p> <ul style="list-style-type: none"> • 0 to 30 • high • medium • low <p>Default: low</p> <p>Older firmware: Values: high , medium , low Default: low</p>
<p>R53.16.3Z: Values: 0 to 30 Default: 16</p> <p>RP4T (all firmware versions), R53.16.4Z, V53.17.7, V74.19.6Z, and later: Values:</p> <ul style="list-style-type: none"> • 0 to 30 • up = increase the current value by 1 • down = decrease the current value by 1 <p>Default: "16"</p>	<p>R60.16.x, R62.16.x, R63.16.x, R65.16.x, SP994Q, SP999G, SP1027G, SP1056F, SP1082G, and later: Values:</p> <ul style="list-style-type: none"> • 0 to 30 • high • medium • low <p>Default: low</p> <p>Older firmware: Values: high , medium , low Default: low</p>		
getvar	<p>Retrieves the antenna's current write power level.</p> <p>Format: ! U1 getvar "rfid.reader_1.power.write"</p>		



Example: This setvar example sets the antenna to power setting 16 for writing to RFID tags.

```
! U1 setvar "rfid.reader_1.power.write" "16"
```

When the setvar value is set to "16", the getvar result is 16.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.reader_1.power.single_power

This command sets the RFID reader power level for reading and writing to RFID tags for readers with a single power level.



Note • This command applies only to the R110Xi HF printer, firmware version R65.X.

Commands	Details
setvar	<p>This command instructs the printer to set the power level for reading and writing.</p> <p>Format: ! U1 setvar "rfid.reader_1.power.single_power" "value"</p> <p>Values: high medium low</p> <p>Default: low</p>
getvar	<p>This command instructs the printer to respond with the current power level.</p> <p>Format: ! U1 getvar "rfid.reader_1.power.single_power"</p>



Example: This setvar example sets the antenna to high power for writing to RFID tags.

```
! U1 setvar "rfid.reader_1.power.single_power" "high"
```

When the setvar value is set to "high", the getvar result is "high".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.reader_1.firmware_version

This command returns the RFID reader firmware version.

Commands	Details
getvar	Format: ! U1 getvar "rfid.reader_1.firmware_version"



Example: This example shows responses that you get in different situations:

! U1 getvar "rfid.reader_1.firmware_version"

If an RFID reader is present and connected, you get the firmware version in the following format:

xx.xx.xx.xx

If there is no RFID reader or if the reader is not connected correctly, the response is blank.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.reader_1.hardware_version

This command returns the RFID reader hardware version.

Commands	Details
getvar	Format: ! U1 getvar "rfid.reader_1.hardware_version"



Example: This example shows responses that you get in different situations:

! U1 getvar "rfid.reader_1.hardware_version"

If an RFID reader is present and connected, you get the hardware version in the following format:

xx.xx.xx.xx

If there is no RFID reader or if the reader is not connected correctly, the response is blank.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.reader_1.model

This command returns the printer's RFID reader model number. Possible values are as follows:

- M6E MICRO

Commands	Details
getvar	Format: ! U1 getvar "rfid.reader_1.model"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.recipe_version

The RFID recipe file controls how the printer manages RFID tag encoding, according to the type of tag in use.

This command returns the version number of the RFID recipe file currently in use. The RFID recipe file is named RFIDRCPE.XML. The default location for this file is Z:RFIDRCPE.XML. If a file using the same name is stored in the E: memory location, it will be used instead of the file stored in the Z: memory location.

Commands	Details
getvar	Format: ! U1 getvar "rfid.recipe_version"

Supported Devices ¹

- ZD500
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

1.

rfid.region_code

This command returns the region code assigned to the printer's RFID device. Possible values are as follows:

- not available
- usa/canada
- japan
- rest of world

Commands	Details
getvar	Retrieves the RFID region code. Format: ! U1 getvar "rfid.region_code"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.calibrate

Use this command to initiate tag calibration for RFID media. During the process, the printer moves the media, calibrates the RFID tag position, and determines the optimal settings for the RFID media being used. Depending on the printer, these settings include the programming position, the antenna element to use, and the read/write power level to use.

For more information about RFID tag calibration, refer to the *RFID Programming Guide* for your printer. A copy is available online at <http://www.zebra.com/manuals>.

Commands	Details
setvar	Initiates tag calibration for RFID media. Format: ! U1 setvar "rfid.tag.calibrate" "value" Values: restore run

➔ **Example 1** • This setvar example restores the programming position back to the printer's default value.

```
! U1 setvar "rfid.tag.calibrate" "restore"
```

➔ **Example 2** • This setvar example performs RFID tag calibration.

```
! U1 setvar "rfid.tag.calibrate" "run"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.data

This command tells the RFID reader to attempt to read a tag over the RFID antenna, even if the printhead is open. Results are returned to the host.

Before running this command, position an RFID label over the printer's RFID antenna.

For more information about this option and for the location of the RFID antenna, refer to the *RFID Programming Guide* for your printer. A copy is available online at <http://www.zebra.com/manuals>.

Commands	Details
getvar	This command instructs the printer to respond with the current tag's data. Format: ! U1 getvar "rfid.tag.data"



Example 1 • This `getvar` example gets the current tag's data, assuming that an RFID label with data "0123456789ABCDEF12345678" is in place over the antenna.

```
! U1 setvar "rfid.tag.data"
```

The printer responds with `0123456789ABCDEF12345678`.



Example 2 • This `getvar` example gets the current tag's data, assuming that no tag data can be read or that no tag is present.

```
! U1 setvar "rfid.tag.data"
```

The printer responds with `NO DATA`.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.read.content

This command instructs the printer which data to read from the tag with the `rfid.tag.read.execute` command. (See [rfid.tag.read.execute](#) on page 890.)

Commands	Details
setvar	<p>Instructs the printer which data to read from the tag with the <code>rfid.tag.read.execute</code> command.</p> <p>Format: ! U1 setvar "rfid.tag.read.content" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> <code>epc</code> = reads the EPC data based on the EPC size specified in the RFID tag's protocol bits, up to 160 bits <code>tid information</code> = reads the first 32 bits of the TID (Tag ID) <code>password status</code> = reads the tag's access and kill passwords <code>protocol bits</code> = reads the protocol bits from the EPC memory banks and converts that value to the EPC size <code>memory bank sizes</code> = reads the EPC, TID, and user memory banks sizes <code>up</code> = sets the command to the previous test <code>down</code> = sets the command to the next test <p>Default: epc</p>
getvar	<p>Retrieves the current setting.</p> <p>Format: ! U1 getvar "rfid.tag.read.content"</p>



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

rfid.tag.read.execute

This command reads the data specified by the `rfid.tag.read.content` command. (See [rfid.tag.read.content](#) on page 889.)

Commands	Details
setvar	Reads the specified data. Format: ! U1 setvar "rfid.tag.read.execute"



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

rfid.tag.read.result_line1

This command reports the results of the `rfid.tag.read.execute` command.

Commands	Details
getvar	Retrieves the results of the <code>rfid.tag.read.execute</code> command. Format: ! U1 getvar "rfid.tag.read.result_line1"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.read.result_line2

This command reports the results of the `rfid.tag.read.execute` command.

Commands	Details
getvar	Retrieves the results of the <code>rfid.tag.read.execute</code> command. Format: ! U1 setvar "rfid.tag.read.result_line2"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.read.result_line1_alternate

This command reports the results of the `rfid.tag.read.execute` command.

Commands	Details
getvar	Retrieves the results of the <code>rfid.tag.read.execute</code> command. Format: ! U1 setvar "rfid.tag.read.result_line1_alternate"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.read.result_line2_alternate

This command reports the results of the `rfid.tag.read.execute` command.

Commands	Details
getvar	Retrieves the results of the <code>rfid.tag.read.execute</code> command. Format: ! U1 getvar "rfid.tag.read.result_line2_alternate"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.test

This command performs an RFID test. In the RFID test, the printer attempts to read and write to a transponder that you place over the RFID antenna. Results are displayed on the printer's control panel display. For more information about the RFID antenna location, refer to the *RFID Programming Guide* for your printer. A copy is available online at <http://www.zebra.com/manuals>.

In the slow version of the RFID test, the printer first displays the hardware version, the reader firmware version, and the program position. For printer support, see [SGD Command Support on page 1393](#).



Note • This command is valid only on RP4T printers.

Commands	Details
setvar	This command instructs the printer to set the programming position. Format: ! U1 setvar "rfid.tag.test" "value" Values: quick slow



Example 1 • This `setvar` example performs a quick RFID test, which shows a pass or fail message.

```
! U1 setvar "rfid.tag.test" "quick"
```



Example 2 • This `setvar` example performs a slow RFID test, which shows the success or failure of each read or write tag operation.

```
! U1 setvar "rfid.tag.test" "slow"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.test.content

This command instructs the printer which test to perform on the tag with the `rfid.tag.test.execute` command. (See [rfid.tag.test.execute](#) on page 897.)

Commands	Details
setvar	<p>Instructs the printer which test to perform on the tag with the <code>rfid.tag.test.execute</code> command.</p> <p>Format: ! U1 setvar "rfid.tag.test.content" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> quick = performs a read EPC test and a write EPC test (using random data) read = performs a read EPC test write = performs a write EPC test (using random data) up = sets the command to the previous test down = sets the command to the next test <p>Default: quick</p>
getvar	<p>Retrieves the current setting.</p> <p>Format: ! U1 getvar "rfid.tag.test.content"</p>



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

rfid.tag.test.execute

This command tests the data specified by the `rfid.tag.test.content` command. (See [rfid.tag.test.content](#) on page 896.)

Commands	Details
setvar	Tests the specified data. Format: ! U1 setvar "rfid.tag.test.execute"



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

rfid.tag.test.result_line1

This command reports the results of the `rfid.tag.test.execute` command.

Commands	Details
getvar	Retrieves the results of the <code>rfid.tag.test.execute</code> command. Format: ! U1 setvar "rfid.tag.test.result_line1"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.test.result_line2

This command reports the results of the `rfid.tag.test.execute` command.

Commands	Details
getvar	Retrieves the results of the <code>rfid.tag.test.execute</code> command. Format: ! U1 setvar "rfid.tag.test.result_line2"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

rfid.tag.type

This command sets the reader's RFID tag type.

Commands	Details
setvar	<p>This command instructs the printer to set the reader's tag type. For the supported tag types, see Table 27 on page 901.</p> <p>Format: ! U1 setvar "rfid.tag.type" "value"</p> <p>Values:</p> <p>UHF Printers</p> <ul style="list-style-type: none"> none = None class0 = EPC Class 0 class0+ = EPC Class 0 Plus class1_64bit = EPC Class 1 64-bit class1_96bit = EPC Class 1 96-bit ucode_epc_1_19 = UCODE EPC 1.19 class0+_impinj = Impinj Class 0 Plus ISO18000A = ISO 18000-06A gen2 = EPC Class 1, Generation 2 (Gen 2) ISO18000B = ISO 18000-06B <p>HF Printers</p> <ul style="list-style-type: none"> none = None detect = Auto detect (query tag to determine) tagit = Tag*It (Texas Instruments Tagit tags) icode = I*code (Phillips Icode tags) pico = Pico Tag (Inside Technology's) ISO15693 = ISO 15693 EPC = EPC tag (13.56 MHz) UIC = UID Tag mifare_ultralight = Mifare UltraLight
getvar	<p>This command instructs the printer to respond with the reader's current tag type.</p> <p>Format: ! U1 getvar "rfid.tag.type"</p>



Example: This setvar example shows the reader's tag type being set to Gen 2.

```
! U1 setvar "rfid.tag.type" "gen2"
```

Supported Tag Types [Table 27](#) shows the tag types supported by different RFID printers/print engines and firmware versions. Depending on your country or on the firmware version that you are using, your printer may not support all of the tag types listed. If you specify an unsupported tag type, the printer uses the default value. If a tag type is shown as supported but does not work with your printer, you may need to upgrade the printer's firmware (see <http://www.zebra.com/firmware>).

Table 27 • Supported Tag Types and Default Values

Printer	UHF Printers											HF Printers				
	R110Xi4		R110Xi7 R170Xi7		R110PAi4			R4Mplus			RZ400/ RZ600	R110Xi7/HF		R2844-Z		
Firmware Version	V53.17.7 and later	R60.13.X	R60.15.X and later		R62.13.X	R62.15.X and later	R63.13.X	R63.15.X and later	SP9940, SP999E, SP1027E, SP1082E, and earlier	SP994P, SP999F, SP1027F, SP1082F, and later	SP1056D and earlier	SP1056E and later	R53.16.X and later	R65.13.X	R65.15.X and later	all
Tag Type																
UHF Tag Types and Options																
None (no tag type specified)	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—	—
EPC Class 0	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—	—
EPC Class 0 Plus	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—	—
EPC Class 1 64-bit	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—	—
EPC Class 1 96-bit	—	#	*	#	*	—	*	*	*	—	—	—	—	—	—	—
UCODE EPC 1.19	—	* a	*	—	*	#	*	#	*	#	*	—	—	—	—	—
Impinj Class 0 Plus	—	*	*	*	*	—	—	—	—	—	—	—	—	—	—	—
ISO 18000-06A	—	—	—	*	—	—	*	*	*	—	—	—	—	—	—	—
EPC Class 1, Generation 2 (Gen 2)	#	*	#	*	#	—	#	*	#	*	#	#	—	—	—	—
ISO 18000-06B	—	*	*	*	*	—	*	*	*	*	*	*	—	—	—	—
HF Tag Types and Options																
Auto-detect the tag type by querying the tag	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	#
Tag*It (Texas Instruments Tagit tags)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
I*code (Phillips Icode tags)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
Pico Tag (Inside Technology's)	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
ISO 15693	—	—	—	—	—	—	—	—	—	—	—	—	#	#	*	—
EPC tag	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	*
UID Tag	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Mifare UltraLight	—	—	—	—	—	—	—	—	—	—	—	—	*	*	—	—

= Default value * = Accepted value — = Not supported
a. Requires R60.13.0.13ZD or later.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ribbon.serial_number

Sets the ribbon's part number.

Commands	Details
setvar	<p>Format: ! U1 setvar "ribbon.serial_number" "value"</p> <p>Values: an alpha-numeric string between 0 and 64 characters</p> <p>Default: NA</p> <p>Example: ! U1 setvar "ribbon.serial_number" "A34567BC6789"</p>
getvar	<p>Format: ! U1 getvar "ribbon.serial_number"</p> <p>Result: "A34567BC6789"</p>

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ribbon.part_number

Sets the ribbon's part number.

Commands	Details
setvar	Format: ! U1 setvar "ribbon.part_number" "value" Values: an alpha-numeric string between 0 and 64 characters. Default: NA Example: ! U1 setvar "ribbon.part_number" "123AB987"
getvar	Format: ! U1 getvar "ribbon.part_number" Result: "123AB987"

Supported Devices

- ZD410, ZD420



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

rtc.timezone

Specifies the POSIX-compliant time zone string. This string includes the following:

- the time zone character specifier
- the offset from UTC
- daylight savings time adjustment
- when to go on and off of daylight savings time (if it pertains to the timezone).

Commands	Details
setvar	<p>Format: ! U1 setvar "rtc.timezone" "value"</p> <p>Values: www.iana.org/time-zonesThis site is updated periodically to reflect changes made by political bodies to time zone boundaries, UTC offsets, and daylight-saving rules.</p>
getvar	<p>Format: ! U1 getvar "rtc.timezone"</p>



Example: If you live in New York in the United States, in the Eastern time zone, your **setvar** string may look like:

- ! U1 setvar "rtc.timezone" "EST5EDT4,M3.2.0/02:00:00,M11.1.0/02:00:00"

The "**value**" string can be translated as follows:

EST5 (Eastern Standard Time; 5 hours off UTC), **EDT4** (Eastern Daylight Time; 4 hours off UTC), running from 2AM (/02; fully qualified: /02:00:00) from the second Sunday in March (M3.2.0/02) through 2AM (/02; fully qualified: /02:00:00) on the first Sunday in November (M11.1.0/02). **M** indicates the Month follows, followed by the two-digit month, the week (1 is the first week in which the specified weekday occurs, and 5 indicates the last week of the month with that weekday) and the weekday (0 is Sunday). The time starts with a slash, and unspecified trailing fields default to zero.

Other examples for locations in the United States:

- US Central:
! U1 setvar "rtc.timezone" "CST6CDT5,M3.2.0/02,M11.1.0/02"
- US Mountain:
! U1 setvar "rtc.timezone" "MST7MDT6,M3.2.0/02,M11.1.0/02"
- US Pacific:
! U1 setvar "rtc.timezone" "PST8PDT7,M3.2.0/02,M11.1.0/02"
- US Alaska:
! U1 setvar "rtc.timezone" "AST9ADT8,M3.2.0/02,M11.1.0/02"
- US Hawaii:
! U1 setvar "rtc.timezone" "HST10"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520

- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

sensor.cover_open

This printer setting determines if the printer media cover is open.

Commands	Details
getvar	Displays if the printer cover is open or not. Format: ! U1 getvar "sensor.cover_open" Values: "yes" = the printer cover is open "no" = the printer cover is closed

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

sensor.paper_supply

Returns current paper supply status.

Commands	Details
getvar	<p>Format: ! U1 getvar "sensor.paper_supply"</p> <p>Result: Obtains current paper supply status:</p> <p>"ok" = printer has paper. "out" = printer is out of paper.</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

sensor.peeler

Obtains current peeler sensor status:

Commands	Details
getvar	Format: ! U1 getvar "sensor.peeler" Result: "clear": the last printed item has been removed, or there are no items waiting to be removed. "not clear": last printed item has not yet been removed.

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

sensor.self_adjusting_enable

Enables the self-adjusting gap sensor.

Commands	Details
setvar	! U1 setvar "sensor.self_adjusting_enable" "value" Values: "yes" = enables the self-adjusting gap sensor and disables the traditional gap sensor "no" = disables the self-adjusting gap sensor and enables the traditional gap sensor Default: "no"
getvar	! U1 getvar "sensor.self_adjusting_enable"

Supported Devices

- ZT610, ZT620



Example: This setvar example shows the value set to "yes".

```
! U1 setvar "sensor.self_adjusting_enable" "yes"
```

The setvar value is the getvar result. In this example, the getvar result is "yes".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.device_id_string

This command retrieves the manufacturer assigned IEEE1284 Device Identification string for USB devices.

Commands	Details
getvar	This command retrieves the device ID string. Format: ! U1 getvar "usb.device.device_id_string"



Example:

```
! U1 getvar "usb.device.device_id_string"
```

Result:

```
"MANUFACTURER:Zebra Technologies ;COMMAND SET:ZPL;MODEL:ZTC ZT220-200dpi  
ZPL;CLASS:PRINTER;OPTIONS:XML;"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.device_unique_id

This command sets the USB Unique Device ID setting. The identifier that makes any printer unique is set by the "usb.device.serial_string" command which is reported to the USB driver.

By default "usb.device.serial_string" reports the printer's serial number. If "usb.device_unique_id" is set to "off" the printer will report the usb.device.serial_string parameter as its product family (e.g. ZT230, etc).

When subsequent printers of the same model, with "usb.device_unique_id" parameter to "off", are connected via USB, the host computer will not treat them as a new Plug and Play events, nor require new driver installations.

Commands	Details
setvar	This command sets the current USB Unique Device Id setting. Format: ! U1 setvar "usb.device.device_unique_id" "value" Values: "off" "on" Default: "on"
getvar	This command returns the current USB Unique Device Id setting stored in the printer. Format: ! U1 getvar "usb.device.device_unique_id"



Example:

```
! U1 setvar "usb.device.device_unique_id" "off"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.device_version

This command returns the version of the USB device being queried.

Commands	Details
getvar	This command instructs the printer to respond with the printer's USB version. Format: ! U1 getvar "usb.device.device_version"



Example:

```
! U1 getvar "usb.device.device_version"
```

Result: "1.1"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.manufacturer_string

This command retrieves the USB device manufacturer's name.

Commands	Details
getvar	This command instructs the printer to respond with the manufacturer name. Format: ! U1 getvar "usb.device.manufacturer_string"



Example:

! U1 getvar "usb.device.manufacturer_string"

Result: "Zebra Technologies"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.product_id

This command retrieves the Product Identification number that a manufacturer assigned to a particular product. This number, along with the Vendor ID, allows a USB host to distinguish between devices.

Commands	Details
getvar	This command retrieves the product ID. Format: ! U1 getvar "usb.device.product_id"



Example:

```
! U1 getvar "usb.device.product_id"
```

Result: "003D"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.product_string

This command returns the manufacturer-assigned string describing a particular USB product.

Commands	Details
getvar	This command instructs the printer to respond with the product string description. Format: ! U1 getvar "usb.device.product_string"

Supported Devices

- ZT200 Series
- QLn Series



Example: Issuing the command on a ZT210 printer:

```
! U1 getvar "usb.device.product_string"
```

Result: "ZT210"

Issuing the command on a QLn320 printer:

```
! U1 getvar "usb.device.product_string"
```

Result: "ZTC QLn320-203dpi CPCL"



Note • For firmware V68.19.0 and V72.19.0, the return value was changed to the longer name, which is the same as the USB PID. The QLnXXX is replaced by the printer model and number for each printer.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.serial_string

This command returns the manufacturer-assigned serial number for a particular USB product.

Commands	Details
getvar	This command returns the printer's serial number. Format: ! U1 getvar "usb.device.serial_string"



Example:

```
! U1 getvar "usb.device.serial_string"
```

Result: "ABC1234567890"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.device.vendor_id

This command returns the Vendor Identification number that the USB-IF organization has assigned to a manufacturer. This number, along with the Product ID, allows a USB host to distinguish between devices.

Commands	Details
getvar	This command retrieves the vendor ID of the device. Format: ! U1 getvar "usb.device.vendor_id"

**Example:**

```
! U1 getvar "usb.device.vendor_id"
```

Result: "0a5f"

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.halt

This command controls whether the printer allows communication over the USB port when the printer is in an error condition.

Commands	Details
setvar	This command controls whether the printer allows communication over the USB port when the printer is in an error condition. Format: ! U1 setvar "usb.halt" "value" Values: "yes" "no" Default: "no"
getvar	This command returns the current "usb.halt" setting stored in the printer. Format: ! U1 getvar "usb.halt"



Example:

```
! U1 setvar "usb.halt" "yes"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

usb.host.fn_field_data

This command is used to collect a user's response to a presented ^FN prompt.



Important • This command is used only in the context of the on-printer Print Station application. Altering the use of this command in the WML can make the Print Station application non-functional. It is recommended changes to portions of this portion of the menu system be done by Zebra Professional Services team.

Commands	Details
setvar	<p>Format: ! U1 setvar "usb.host.fn_field_data" "value"</p> <p>Values: the text entered by the user via a USB Human Interface Device (HID) keyboard</p> <p>Default: "NULL"</p>
getvar	<p>Format: ! U1 getvar "usb.host.fn_field_data"</p> <p>Result: One of the following:</p> <ul style="list-style-type: none"> NULL the current user response to an ^FN prompt

Supported Devices

- ZT410, ZT420



Note

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.host.fn_last_field

This command is intended for use by WML code to control the presentation of ^FN fields contained within a template file that resides on the E:/ drive and has an extension of .ZPL.

Commands	Details
getvar	Format: ! U1 getvar "usb.host.fn_last_field" Result: YES or NO

Supported Devices

- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* [on page 1239](#).
- For details on SGD command structure, see *Command Structure* [on page 629](#).

usb.host.hid_count

This command displays the number of USB Human Interface Devices (HIDs) connected to the printer. Refer to <http://www.usb.org> for further details on USB device types.

Commands	Details
getvar	<p>Format: ! U1 getvar "usb.host.hid_count"</p> <p>Example: When no devices are attached: ! U1 getvar "usb.host.hid_count"</p> <p>Result: "0"</p>

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.host.keyboard_input

This command enables/disables USB keyboard input to the printer, affecting the Print Station user menu item.

Commands	Details
setvar	Format: ! U1 setvar "usb.host.keyboard_input" Values: "on"—keyboard input is supported. "off"—keyboard input is not supported Default: "on"
getvar	Format: ! U1 getvar "usb.host.keyboard_input"

Supported Devices

- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support on page 1239*.
- For details on SGD command structure, see *Command Structure on page 629*.

usb.host.lock_out

This command enables/disables the USB host port.

Commands	Details
setvar	<p>Format: ! U1 setvar "usb.host.lock_out" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "on"—the USB host port is enabled. "off"—the USB host port is disabled <p>Default: "on"</p>
getvar	<p>Format: ! U1 getvar "usb.host.lock_out"</p>

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* [on page 1239](#).
- For details on SGD command structure, see *Command Structure* [on page 629](#).

usb.host.mass_storage_count

This command displays the number of USB mass storage devices connected to the printer. Only the first USB mass storage device found will be mounted and accessible.

Commands	Details
getvar	Format: ! U1 getvar "usb.host.mass_storage_count"

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420




Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.host.read_list

This command scans the mounted usb mass storage device for non-user-restricted files and displays the files in a list.

Commands	Details
setvar	<p>Format: ! U1 setvar "usb.host.read_list" "value"</p> <p>Values:</p> <p>"fill_store"—The printer creates a list of all of the top-level files that are readable on a connected mass storage device. (.ZPL and .XML files)</p> <p>"store"—The printer copies the current file (the file listed on the display) or all eligible files if SELECT ALL is displayed from the USB mass storage device to the printer's E: drive.</p> <p> Important • Store does an exact byte-for-byte copy of the file being stored. ZPL files that are transferred to the printer using the "store" command are NOT prepared to be used with a recall format command (^XF). See XREF Character Substitution (in Mirror) for the modifications necessary to prepare a ZPL file for use with ^XF. If the ZPL file contains a ^DF, the appropriate way to place it on the printer's memory is to use the "print" command, below.</p> <p>"fill_print"—The printer analyzes the content of the USB mass storage device and creates a list of files that may be printed. (.ZPL files only)</p> <p>"print"—The printer prints the current file (the file listed on the display) or all eligible files if SELECT ALL is displayed.</p> <p>"clear" -</p>
getvar	<p>Format: ! U1 getvar "usb.host.read_list"</p> <p>Result: the current file in the list or NONE</p>

Supported Devices

- ZT410, ZT420



Example:

```
! U1 getvar "usb.host.read_list"
```

Result:

One of the following:

- The current file in the list.
- **NONE** if there are no files on the USB mass storage device.



Note •

- For printer support, see *SGD Command Support on page 1239*.
- For details on SGD command structure, see *Command Structure on page 629*.

usb.host.read_list_print_delay

This command specifies a number of milliseconds for the printer to wait before processing the next file when “SELECT ALL” is chosen on the USB PRINT FILES user menu.

Commands	Details
setvar	Format: ! U1 setvar "usb.host.read_list_print_delay" Values: 0 to 65535 Default: "0"
getvar	Format: ! U1 getvar "usb.host.read_list_print_delay"

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.host.template_list

This command is used by WML to support selecting .ZPL template files resident on the E:/ drive.

Commands	Details
setvar	<p>Format: ! U1 setvar "usb.host.template_list" "value"</p> <p>"fill"—The printer analyzes the contents of its E:/ drive and creates a list of the template files with a .ZPL extension.</p> <p>"up" - moves to the previous file in the list</p> <p>"down" - moves to the next file in the list</p> <p>Default: "on"</p>
getvar	<p>Format: ! U1 getvar "usb.host.template_list"</p> <p>Result:</p> <p>One of the following:</p> <p>UNINITIALIZED</p> <p>IN PROGRESS</p> <p>NONE (if no .ZPL files reside on the E:/ drive)</p> <p>the current .ZPL file</p>

Supported Devices

- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support on page 1239*.
- For details on SGD command structure, see *Command Structure on page 629*.

usb.host.template_print_amount

This command is used by WML to control the number of template-type labels to print.

Commands	Details
setvar	Format: ! U1 setvar "usb.host.template_print_amount" "value" Values: 1 to 99999 "up" - moves to the previous file in the list "down" - moves to the next file in the list Default: "1" which will change based on the contents of the selected template file
getvar	Format: ! U1 getvar "usb.host.template_print_amount" Result: the current value

Supported Devices

- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support on page 1239*.
- For details on SGD command structure, see *Command Structure on page 629*.

usb.host.write_list

This command scans the E: flash drive for non-user-restricted files and displays the files in a list.

Commands	Details
setvar	<p>Format: ! U1 setvar "usb.host.write_list" "value"</p> <p>"fill_store"—The printer analyzes the contents of its E: drive and creates a list of files that may be copied to a USB mass storage device connected to the printer.</p> <p>"store"—The printer copies the current file (the file listed on the display) or all eligible files if SELECT ALL is displayed to the USB mass storage device.</p> <p>"up"</p> <p>"down"</p> <p>Default: "on"</p>
getvar	<p>Format: ! U1 getvar "usb.host.write_list"</p> <p>Result:</p> <p>One of the following:</p> <ul style="list-style-type: none"> • The current file in the list. • NONE if there are no files on the printer's E: drive. • READONLY if the USB mass storage device is read-only.

Supported Devices

- ZT400 Series



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.appl_path

This command specifies the path to the location on a USB device from which Mirror files are retrieved. If no path is specified, then the path is **zebra/appl**.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.appl_path" "path" Values: a valid path up to 255 characters Default: "zebra/appl"
getvar	Format: ! U1 getvar "usb.mirror.appl_path"

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* [on page 1239](#).
- For details on SGD command structure, see *Command Structure* [on page 629](#).

usb.mirror.auto

This command determines if mirroring happens automatically when a USB device is inserted in the printer. To use this function, the setting for `usb.mirror.enable` must be "on".

Commands	Details
setvar	<p>Format: ! U1 setvar "usb.mirror.auto" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "on"—mirroring occurs automatically when the USB device is inserted and <code>usb.mirror.enable</code> is on. "off"—mirroring does not occur automatically when the USB device is inserted. "prompt"—the printer gives you the option to start or abort a mirroring process. <p>Default: "on"</p>
getvar	<p>Format: ! U1 getvar "usb.mirror.auto"</p>

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.enable

This command enables or disables the ability to perform mirroring of a USB device.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.enable" "value" Values: "on"—mirroring is enabled "off"—mirroring is disabled Default: "on"
getvar	Format: ! U1 getvar "usb.mirror.enable"

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* [on page 1239](#).
- For details on SGD command structure, see *Command Structure* [on page 629](#).

usb.mirror.enabled

Enables or disables the ability to perform mirroring using a USB device memory stick.

Setvar

To set the command:

```
! U1 setvar "usb.mirror.enabled" "value"
```

Values:

- **on** — mirroring is enabled
- **off** — mirroring is disabled

Default:

on

Getvar

To have the printer return the current setting value:

```
! U1 getvar "usb.mirror.enabled"
```

Related SGDs

- usb.mirror.enable

Supported Printers

- ZD400, ZD410, ZD420
- ZD620
- ZQ510, ZQ520
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

usb.mirror.error_retry

This command specifies the number of times that the USB mirror operation will be repeated if the process fails.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.error_retry" "value" Values: 0 to 65535 Default: "0"
getvar	Format: ! U1 getvar "usb.mirror.error_retry"

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.feedback.auto

This command determines if a feedback file is written to the USB device connected to the printer after mirroring.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.feedback.auto" "value" "on"—a feedback file is written to the USB device connected to the printer. "off"—a feedback file is not written to the USB device connected to the printer. Default: "off"
getvar	Format: ! U1 getvar "usb.mirror.feedback.auto"

Supported Devices

- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see *SGD Command Support on page 1239*.
- For details on SGD command structure, see *Command Structure on page 629*.

usb.mirror.feedback.odometer

This command instructs the printer to set or retrieve the `usb.mirror.feedback.odometer` value.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.feedback.odometer" "value" Values: 0 to 65535 Default: "0" Example: This example sets the counter to 0, which resets the counter. ! U1 setvar "usb.mirror.feedback.odometer" "0"
getvar	Format: ! U1 getvar "usb.mirror.feedback.odometer"

Supported Devices

- ZT400 Series
- ZQ500 Series



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.feedback.path

This command specifies where the feedback file is stored on the USB drive connected to the printer.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.feedback.path" "value" Values: a valid path up to 255 characters NOTE: The path must exist on the USB drive before the printer can write files to it. Default: "zebra/feedback"
getvar	Format: ! U1 getvar "usb.mirror.feedback.path"

Supported Devices

- ZT400 Series
- ZQ500 Series



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.fetch

This command immediately initiates a USB mirroring operation. To use this function, the setting for `usb.mirror.enable` must be "on".

Commands	Details
do	Format: ! U1 do "usb.mirror.fetch"

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.last_error

This command returns the last USB mirroring error string. If there are no errors, the result is "No Error".

Commands	Details
getvar	Format: ! U1 getvar "usb.mirror.last_error"

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.last_time

This command returns the date and time of the last USB mirroring operation. The date and time reported are from the printer's clock.

Commands	Details
getvar	Format: ! U1 getvar "usb.mirror.last_time" Result: 02 18 2015 11:10:09 (mm dd yyyy hh:mm:ss)

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.path

This command specifies the root directory on the connected USB drive. The root directory contains the subdirectories from which files are retrieved during the mirror operation. If no path is specified, then the path is `/zebra`.

The standard subdirectories to use are:

- "`<update-root>/appl`"
- "`<update-root>/files`"
- "`<update-root>/commands`"
- "`<feedback-root>`"

See [How Mirror Works on page 1447](#) for a comprehensive overview of mirroring.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.appl_path" "path" Values: a valid path up to 255 characters Default: "zebra"
getvar	Format: ! U1 getvar "usb.mirror.path"

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1239](#).
- For details on SGD command structure, see [Command Structure on page 629](#).

usb.mirror.reset_delay

This command specifies a number of seconds for the printer to wait after it loads the last of the files in the /commands directory during mirroring.

Commands	Details
setvar	Format: ! U1 setvar "usb.mirror.reset_delay" Values: 0 to 900 Default: "5"
getvar	Format: ! U1 getvar "usb.mirror.reset_delay"

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

usb.mirror.success

This command returns the last USB mirroring event status string.

Commands	Details
getvar	Format: ! U1 getvar "usb.mirror.success" Values: yes (indicates that the mirroring operation was successful) no (indicates that the mirroring operation was not successful)

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* [on page 1239](#).
- For details on SGD command structure, see *Command Structure* [on page 629](#).

usb.mirror.success_time

This command returns the date and time of the last successful USB mirroring operation. The date and time reported are from the printer's clock.

Commands	Details
getvar	Format: ! U1 getvar "usb.mirror.success_time.fm" Result: 02 18 2015 11:10:09 (mm dd yyyy hh:mm:ss)

Supported Devices

- ZT410, ZT420
- ZQ510, ZQ520



Note •

- For printer support, see *SGD Command Support* on page 1239.
- For details on SGD command structure, see *Command Structure* on page 629.

zbi.control.add_breakpoint

This command instructs the printer to set a ZBI program break point. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command instructs the printer to set a ZBI program break point.</p> <p>Format: ! U1 setvar "zbi.control.add_breakpoint" "value"</p> <p>Values: Any line number of the program currently being debugged.</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows setting the breakpoint at line "30".
! U1 setvar "zbi.control.add_breakpoint" "30"

zbi.control.break

This command breaks the execution of the ZBI 2.0 program that is currently running. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command breaks the execution of the ZBI program that is currently running. Format: ! U1 setvar "zbi.control.break" "" Values: ""



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "".
! U1 setvar "zbi.control.break" ""

zbi.control.clear_breakpoints

This command deletes all breakpoints in the current ZBI 2.0 program. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to delete all breakpoints. Format: ! U1 setvar "zbi.control.clear_breakpoints" "" Values: ""



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "".
 ! U1 setvar "zbi.control.clear_breakpoints" ""

zbi.control.delete_breakpoint

This command deletes a breakpoint in the current ZBI 2.0 program. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to delete the breakpoint at the line indicated by the value parameter. Format: ! U1 setvar "zbi.control.delete_breakpoint" "value" Values: you can use the same value as add_breakpoint.



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the breakpoint set to "30".
! U1 setvar "zbi.control.delete_breakpoint" "30"

zbi.control.line_number

This command gives you control and information about which line of a stopped ZBI 2.0 program is being executed. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command sets which line of the current ZBI 2.0 program should be executed. Format: ! U1 setvar "zbi.control.line_number" "value" Values: Any line number of the currently stopped ZBI program. Default: "0"
getvar	This command returns the line number that is currently being executed in the ZBI 2.0 program. Format: ! U1 getvar "zbi.control.line_number"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value parameter set to "30".

```
! U1 setvar "zbi.control.line_number" "30"
```

When the setvar value is set to "30", the getvar result is "30".

zbi.control.restart

This command restarts a ZBI 2.0 program that is currently stopped. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command restarts a ZBI 2.0 program that is currently stopped. Format: ! U1 setvar "zbi.control.restart" "value" Values: ""



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "".

```
! U1 setvar "zbi.control.restart" ""
```


zbi.control.run

This command runs the current ZBI 2.0 program that is loaded in the interpreter. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	<p>This command runs the ZBI 2.0 program that is loaded in the interpreter.</p> <p>Format: ! U1 setvar "zbi.control.run" ""</p> <p>Values: ""</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "".

```
! U1 setvar "zbi.control.run" ""
```

zbi.control.step

This command restarts the execution of the currently stopped ZBI 2.0 program for one line. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the printer to restart the execution of the currently stopped ZBI 2.0 program for one line. Format: ! U1 setvar "zbi.control.step" "" Values: "" Default: ""



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "".

```
! U1 setvar "zbi.control.step" ""
```

When the setvar value is set to "".

zbi.control.terminate

This command instructs the ZBI 2.0 program to terminate and shuts down the interpreter. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the ZBI 2.0 program to terminate and shuts down the interpreter. Format: ! U1 setvar "zbi.control.terminate" "value" Values: ""



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "".
! U1 setvar "zbi.control.terminate" ""

zbi.control.variable_name

This command sets the name of the variable that is to be read or modified through `variable_value`. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
<code>setvar</code>	This command sets the variable that is to show on the front panel. Format: <code>! U1 setvar "zbi.control.variable_name" "value"</code> Values: Any ZBI variable in the program that is currently being debugged. Default: ""
<code>getvar</code>	This command retrieves the variable value that is to show on the front panel. Format: <code>! U1 getvar "zbi.control.variable_name"</code>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This `setvar` example shows the value set to "MYVAR\$".

```
! U1 setvar "zbi.control.variable_name" "MYVAR$"
```

When the `setvar` value is set to "MYVAR\$", the `getvar` result is "MYVAR\$".

zbi.control.variable_value

This command identifies the variable name. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command sets a value to the variable referenced by a variable_name. Format: ! U1 setvar "zbi.control.variable_value" "value" Values: A string or integer that is dependent on the variable type in variable_name. Default: The current value of the variable referenced via variable_name
getvar	This command retrieves the variable name that is loaded into the variable_name. Format: ! U1 getvar "zbi.control.variable_value"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "Hello World".

```
! U1 setvar "zbi.control.variable_value" "Hello World"
```

When the setvar value is set to "Hello World", the getvar result is "Hello World".

zbi.enable

This command enables ZBI on the printer.

Setvar

To set the command:

```
! U1 setvar "zbi.enable" "value"
```

Values:

- on
- off

Default:

"on"

Getvar

To have the printer return the current setting value:

```
! U1 getvar "zbi.enable"
```

Supported Printers

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

zbi.key

This command identifies if the ZBI 2.0 option is enabled or disabled on the printer. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the status of the ZBI 2.0 option on the printer. Format: ! U1 getvar "zbi.key"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` shows the status of ZBI on the printer.

```
! U1 getvar "zbi.key"  
"ENABLED"
```

zbi.last_error

This command identifies the last error that the ZBI 2.0 interpreter encountered. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command shows the last error that the ZBI 2.0 interpreter encountered. Format: ! U1 getvar "zbi.last_error"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This example demonstrates how to make the ZBI 2.0 interpreter return the last error it encountered.

```
! U1 getvar "zbi.last_error"
```


zbi.program_list

This SGD is intended to be used on WML pages. Its purpose is to support displaying the name of each ZBI program file contained on the E: drive.



Important • A specific sequence is required to get an accurate listing of files. See the example below.

Type	Details
setvar	<p>Format: ! U1 setvar "zbi.program_list" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "fill" = initializes the device (first step) "up" = gets the previous file in the list "down" = gets the next file in the list "execute" = executes the currently specified zbi file (as determined by the getvar command) <p>Default: "none"</p> <p>Example: A specific sequence of commands is required to get an accurate listing of files.</p> <ol style="list-style-type: none"> 1. Initialize the device by issuing: ! U1 setvar "zbi.program_list" "fill" 2. To get the first file, issue: ! U1 getvar "zbi.program_list" This will return the current filename in the list of zbi files present on the E: drive If the response returned is "none" you have reached the end of the list. 3. To get the next filename in the list, issue: ! U1 setvar "zbi.program_list" "up" 4. To get the previous filename in the list, issue: ! U1 setvar "zbi.program_list" "down" 5. To execute the current zbi filename, i.e. the one returned by a getvar, issue: ! U1 setvar "zbi.program_list" "execute"
getvar	<p>Format: ! U1 getvar "zbi.program_list"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338, ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For device support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zbi.reseller_key

This command allows programs that are encrypted with this key in ZBI- Developer to run. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command allows programs that are encrypted with this key in ZBI developer to run. Format: ! U1 setvar "zbi.reseller_key" "value" Values: Any valid encryption key provided by ZBI Developer.



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example shows the value set to "abc123".
! U1 setvar "zbi.reseller_key" "abc123".

zbi.revision

This command identifies the current ZBI version. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the current ZBI version. Format: ! U1 getvar "zbi.revision"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` shows the current ZBI version.
! U1 getvar "zbi.revision"

zbi.running_program_name

This command identifies the name of the ZBI 2.0 program that is currently running. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the name of the currently running ZBI 2.0 program. Format: ! U1 getvar "zbi.running_program_name"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` command causes the printer to respond that the program `choices.bas` is currently running.

```
! U1 getvar "zbi.running_program_name"  
"CHOICES.BAS"
```

zbi.start_info.execute

This command instructs the ZBI 2.0 environment to execute the program listed in the file_name. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
setvar	This command instructs the ZBI 2.0 environment to execute the program listed in the file_name. Format: ! U1 setvar "zbi.start_info.execute"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This setvar example executes the "choices.bas" program.
! U1 setvar "zbi.start_info.execute" "choices.bas"

zbi.start_info.file_name

This command prepares a program to run when the `zbi.start_info.execute` command is used. This command does not run the program. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
<code>setvar</code>	<p>This command is used to prepare a ZBI 2.0 program to be executed using the <code>zbi.start_info.execute</code> command.</p> <p>Format: ! U1 setvar "zbi.start_info.file_name" "value"</p> <p>Values: a file name or path of a basic program</p>
<code>getvar</code>	<p>This command is used to return the file path and file name of a ZBI 2.0 program to run using the <code>zbi.start_info.execute</code> command.</p> <p>Format: ! U1 getvar "zbi.start_info.file_name"</p> <p>Default: The last program run. If nothing has been run, <code>"*:\.BAZ"</code>.</p>



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: This `setvar` example shows the value set to `"E:PROGRAM1.BAS"`.

```
! U1 setvar "zbi.start_info.file_name" "E:PROGRAM1.BAS"
```

When the `setvar` value is set to `"E:PROGRAM1.BAS"`, the `getvar` result is `"E:PROGRAM1.BAS"`.

zbi.start_info.memory_alloc

This command identifies the amount of memory currently in use in a ZBI 2.0 program. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command shows the amount of memory currently in use in bytes. Format: ! U1 getvar "zbi.start_info.memory_alloc"



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` shows the amount of memory currently in use.

```
! U1 getvar "zbi.start_info.memory_alloc"
"17203"
```

zbi.state

This command shows the current state of the ZBI 2.0 program. For printer support, see [SGD Command Support on page 1393](#).

Commands	Details
getvar	This command retrieves the current state of ZBI. Format: ! U1 getvar "zbi.state" Values: "running" = ZBI Interpreter is active and running a program "off" = ZBI Interpreter is inactive "stopped" = ZBI Interpreter is active but not executing a program



Note • For details on SGD command structure, see [Command Structure on page 573](#).



Example: In this example, the `getvar` shows that state of ZBI.

```
! U1 getvar "zbi.state"  
"running"
```


zpl.caret

This command is used to change the format command prefix for ZPL commands. The default prefix is the caret (^)

This command is equivalent to the ~CC and ^CC ZPL commands.

Commands	Details
setvar	This command sets the command prefix. Format: ! U1 setvar "zpl.caret" "value" Values: any ASCII character Default: "^"
getvar	This command retrieves the current format command prefix. Format: ! U1 getvar "zpl.caret"



Example: This setvar example changes the format prefix to a forward slash "/"
! U1 setvar "zpl.caret" "/"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.control_character

This command is used to change the control command prefix. The default prefix is the tilde (~).

This command is equivalent to the ^CT and ~CT commands.

Commands	Details
setvar	This command changes the control character. Format: ! U1 setvar "zpl.control_character" "value" Values: ASCII values for the desired character "00-FF,00-ff,up,down" See ASCII Code Chart on page 1332 . Default: "7E" (tilde)
getvar	This command returns the currently set control character. Format: ! U1 getvar "zpl.control_character"



Example: This example sets the value set to "+".

```
! U1 setvar "zpl.control_characater" "2b"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.delimiter

This command is used to change the delimiter character for ZPL commands. The default delimiter character is the comma (,).

Related Commands: ^CD and ~CD commands.

Commands	Details
setvar	This command changes the delimiter character for ZPL commands. Format: ! U1 setvar "zpl.delimiter" "value" Values: HEX values for the desired character "00-FF,00-ff,up,down" See ASCII Code Chart on page 1332 . Default: "2C" (comma)
getvar	This command returns the currently set delimiter character. Format: ! U1 getvar "zpl.delimiter"



Example: This example changes the delimiter to a semi-colon (;).

```
! U1 setvar "zpl.delimiter" "3B"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.label_length

This command defines the length of the label. This command is necessary when using continuous media (media that is not divided into separate labels by gaps, spaces, notches, slots, or holes).

This command is equivalent to the ^LL command.

Commands	Details
setvar	<p>This command sets the label length.</p> <p>Format: ! U1 setvar "zpl.label_length" "value"</p> <p>Values: 1 to 32000, (in dots) not to exceed the maximum label length. While the printer accepts any value for this parameter, the amount of memory installed determines the maximum length of the label.</p>
getvar	<p>This command returns the current label length setting.</p> <p>Format: ! U1 getvar "zpl.label_length"</p>

Comments These formulas can be used to determine the value of y:

For 6 dot/mm printheads...	Label length in inches x 152.4 (dots/inch) = y
For 8 dot/mm printheads...	Label length in inches x 203.2 (dots/inch) = y
For 12 dot/mm printheads...	Label length in inches x 304.8 (dots/inch) = y
For 24 dot/mm printheads...	Label length in inches x 609.6 (dots/inch) = y

Values for y depend on the memory size. If the entered value for y exceeds the acceptable limits, the bottom of the label is cut off. The label also shifts down from top to bottom.



Example:

```
! U1 setvar zpl.label_length" "1281"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.left_position

This command sets the label's left margin offset in dots.

Related Command: ^LS

Commands	Details
setvar	This command sets the label left margin offset in dots. Format: ! U1 setvar "zpl.left_position" "value" Values: "-9999 to 9999" Default: "0"
getvar	This command retrieves the currently set left margin offset for the label. Format: ! U1 getvar "zpl.left_position"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Example:

```
! U1 setvar "zpl.left_position" "100"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.system_error

This command returns the system error flags.

This command is equivalent to the error recording of ~HQES

Commands	Details
getvar	This command returns the state of the system error flags.. Format: ! U1 getvar "zpl.system_error" Result: 0,0,00000000,00000000 (flag, error flag, Group 2, Group 1)

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Example 1 • This example shows how to request the printer's status. To request the printer's status, type ! U1 getvar "zpl.system_error" The printer responds with data similar to this: "1,1,00000000,00000004" In this example, the Printer Status resolves to these conditions:

- The printer is in Pause (value = 1)
- The Error Flag is 0 if there are no errors (i.e. Group 2 and Group 1 are all 0s), and 1 if there are any errors.
- The cover/printhead is open (value = 4).

Table 28 • Error Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16 -9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
No Error	0	00000000	0	0	0	0	0	0	0	0
Error Present	1	00000000	X	X	X	X	X	X	X	X
Printhead Thermistor Open	1	00000000	X	X	X	X	X	2	X	X
Invalid Firmware Config.	1	00000000	X	X	X	X	X	1	X	X
Printhead Detection Error	1	00000000	X	X	X	X	X	X	8	X
Bad Printhead Element	1	00000000	X	X	X	X	X	X	4	X
Motor Over Temperature	1	00000000	X	X	X	X	X	X	2	X
Printhead Over Temperature	1	00000000	X	X	X	X	X	X	1	X
Cutter Fault	1	00000000	X	X	X	X	X	X	X	8

aq. This error flag is supported only on KR403 printers.

Table 28 • Error Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16 -9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
Head Open	1	00000000	X	X	X	X	X	X	X	4
Ribbon Out	1	00000000	X	X	X	X	X	X	X	2
Media Out	1	00000000	X	X	X	X	X	X	X	1
Clear Paper Path Failed <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	X	8 <i>aq</i>	X	X	X
Paper Feed Error <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	X	4 <i>aq</i>	X	X	X
Presenter Not Running <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	X	2 <i>aq</i>	X	X	X
Paper Jam during Retract <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	X	1 <i>aq</i>	X	X	X
Black Mark not Found <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	8 <i>aq</i>	X	X	X	X
Black Mark Calabrate Error <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	4 <i>aq</i>	X	X	X	X
Retract Function timed out <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	2 <i>aq</i>	X	X	X	X
Paused <i>aq</i>	1 <i>aq</i>	00000000	X	X	X	1 <i>aq</i>	X	X	X	X

aq. This error flag is supported only on KR403 printers.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.system_status

This command returns the errors and warnings of the system.

This command is equivalent to all data reported by the ~HQES ZPL command.

Commands	Details
getvar	This command returns the system error and warning flags. Format: ! U1 getvar "zpl.system_status" Result: 0,0,00000000,00000000,0,00000000,00000000 (flag, error flag, group 2, group 1, warning flag, group 2, group 1)

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Example 1 • This example shows how to request the printer's status.

a. To request the printer's status, type ! U1 getvar "zpl.system_status"
The printer responds with data similar to this:

"1, 1, 00000000, 00000004, 0, 00000000, 00000000"

In this example, the Printer Status resolves to these conditions:

- The printer is in Pause (value = 1)
- The Error Flag is 0 if there are no errors (i.e. Group 2 and Group 1 are all 0s), and 1 if there are any errors (non-zero).
- The cover/printhead is open (value = 4).
- The Warning Flag is 0 if there are no warnings (i.e. Group 2 and Group 1 are all 0s), and 1 if there are any errors (non-zero).

Table 29 • Error Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])							
		Nibbles16 -9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1
No Error	0	00000000	0	0	0	0	0	0	0	0
Error Present	1	00000000	X	X	X	X	X	X	X	X
Printhead Thermistor Open	1	00000000	X	X	X	X	X	2	X	X
Invalid Firmware Config.	1	00000000	X	X	X	X	X	1	X	X
Printhead Detection Error	1	00000000	X	X	X	X	X	X	8	X
Bad Printhead Element	1	00000000	X	X	X	X	X	X	4	X

ar. This error flag is supported only on KR403 printers.

Table 29 • Error Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])								
		Nibbles16 -9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1	
Motor Over Temperature	1	00000000	X	X	X	X	X	X	X	2	X
Printhead Over Temperature	1	00000000	X	X	X	X	X	X	X	1	X
Cutter Fault	1	00000000	X	X	X	X	X	X	X	X	8
Head Open	1	00000000	X	X	X	X	X	X	X	X	4
Ribbon Out	1	00000000	X	X	X	X	X	X	X	X	2
Media Out	1	00000000	X	X	X	X	X	X	X	X	1
Clear Paper Path Failed ^{ar}	1 ^{ar}	00000000	X	X	X	X	X	8 ^{ar}	X	X	X
Paper Feed Error ^{ar}	1 ^{ar}	00000000	X	X	X	X	X	4 ^{ar}	X	X	X
Presenter Not Running ^{ar}	1 ^{ar}	00000000	X	X	X	X	X	2 ^{ar}	X	X	X
Paper Jam during Retract ^{ar}	1 ^{ar}	00000000	X	X	X	X	X	1 ^{ar}	X	X	X
Black Mark not Found ^{ar}	1 ^{ar}	00000000	X	X	X	X	8 ^{ar}	X	X	X	X
Black Mark Calabrate Error ^{ar}	1 ^{ar}	00000000	X	X	X	X	4 ^{ar}	X	X	X	X
Retract Function timed out ^{ar}	1 ^{ar}	00000000	X	X	X	X	2 ^{ar}	X	X	X	X
Paused ^{ar}	1 ^{ar}	00000000	X	X	X	X	1 ^{ar}	X	X	X	X

^{ar}. This error flag is supported only on KR403 printers.

Table 30 • Warning Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])								
		Nibbles16 -9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1	
No Warning	0	00000000	0	0	0	0	0	0	0	0	0
Warning Present	1	00000000	X	X	X	X	X	X	X	X	X
Paper-near-end Sensor ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	X	X	8 ^{as}
Replace Printhead	1	00000000	X	X	X	X	X	X	X	X	4
Clean Printhead	1	00000000	X	X	X	X	X	X	X	X	2
Need to Calibrate Media	1	00000000	X	X	X	X	X	X	X	X	1
Sensor 1 (Paper before head) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	X	1 ^{as}	X
Sensor 2 (Black mark) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	X	2 ^{as}	X
Sensor 3 (Paper after head) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	X	4 ^{as}	X
Sensor 4 (loop ready) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	X	8 ^{as}	X
Sensor 5 (presenter) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	1 ^{as}	X	X
Sensor 6 (retract ready) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	2 ^{as}	X	X

^{as}. This error flag is supported only on KR403 printers.

Table 30 • Warning Flags (~HQES)

Error Flags	Flag	Group 2	Group 1 (X = Value can be any hexadecimal number [0-9, A-F])								
		Nibbles16 -9	Nibble 8	Nibble 7	Nibble 6	Nibble 5	Nibble 4	Nibble 3	Nibble 2	Nibble 1	
Sensor 7 (in retract) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	4 ^{as}	X	X
Sensor 8 (at bin) ^{as}	1 ^{as}	00000000	X	X	X	X	X	X	8 ^{as}	X	X

as. This error flag is supported only on KR403 printers.



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

zpl.zpl_mode

This command sets the ZPL mode to ZPL II or ZPL.

Commands	Details
setvar	<p>This command sets the printer ZPL mode.</p> <p>Format: ! U1 setvar "zpl.zpl_mode" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "zpl" "zpl II" <p>Default: "zpl II"</p>
getvar	<p>This command returns the current ZPL mode setting.</p> <p>Format: ! U1 getvar "zpl.zpl_mode"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Example: This setvar example sets the ZPL mode to ZPL.

```
! U1 setvar "zpl.system_status" "zpl"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.zpl_override

Enable this menu item to prevent the following ZPL commands from changing the printer's current settings:

- ^MM (print mode)
- ^MT (Direct Thermal or Thermal Transfer print method)
- ^MN (media type - non-continuous or continuous)

When this menu item is disabled, these commands override the printer's settings.

Commands	Details
setvar	<p>Sets the override status to the specified value.</p> <p>Format: ! U1 setvar "zpl.zpl_override" "value"</p> <p>Values:</p> <p>"disabled" = allows override</p> <p>"enabled" = prevents ZPL commands from overriding printer settings.</p> <p>Default: "disabled"</p>
getvar	<p>Returns the current override status.</p> <p>Format: ! U1 getvar "zpl.zpl_override"</p> <p>Values:</p> <p>"disabled"</p> <p>"enabled"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Example: This example enables `zpl.zpl_override`, which prevents ^MM, ^MT, and ^MN from making changes to the current printer settings.

```
! U1 setvar "zpl.zpl_override" "enabled"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

zpl.relative_darkness

Changes the relative darkness for ZPL labels. This command is similar to the ZPL ^MD command.



Important • This value is saved permanently on Desktop printers, but it is not saved permanently on Industrial or Mobile.

Commands	Details
setvar	Format: ! U1 setvar "zpl.relative_darkness" "value" Values: "" to "300" Default: "0"
getvar	Format: ! U1 getvar "relative_darkness"



Example: These examples show setting the printer to different darkness levels:

- If the current value shown on the configuration label is "16", using a `zpl.relative_darkness` command of "-90" decreases the value to "7.0".
- If the current value shown on the configuration label is "1", using a `zpl.relative_darkness` command of "153" increases the value to "16.3".
- If the current value shown on the configuration label is "25", using a `zpl.relative_darkness` command of "105" increases the value to "30.0", which is the maximum value allowed.

Each `zpl.relative_darkness` command is treated separately in relation to the current value as printed on the configuration label.

Supported Devices

- iMZ 220, iMZ 320
- QLn220, QLn320, QLn420
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

SGD Wired Commands

This chapter provides a high-level overview of the wired Set / Get / Do (SGD) commands. For printer support of these SGD commands, see [SGD Command Support on page 1393](#).

.15↑

SGD commands are available in printers with the following firmware versions or later:

- V54
- V66
- V68
- V72
- V73
- V74
- V75
- V76
- V78
- V79
- V60.16.2Z or later
- V60.15.xZ or later
- V50.15.xZ or later
- V61.15.xZ or later
- V56.15.xZ or later
- V53.16.x or later
- V53.15.2Z or later
- R53.16.3Z or later
- R60.15.8Z or later
- R62.15.8Z or later
- R63.15.8Z or later
- R65.15.8Z or later



Important • These are important points to note when using ZPL and SGD commands:

- SGD commands are case-sensitive.
- ZPL and SGD commands should be sent to the printer as separate files.
- Certain settings can be controlled by both ZPL and SGD. Configuration changes made in ZPL can affect configuration changes made in SGD.
- Changes made with one command type (ZPL or SGD) will affect the data returned to the host in response to both ZPL and getvar commands. The command type (ZPL or SGD) that was sent last determines the current setting.
- Some RF cards do not support all of the SGD commands.



Important • These are important points to note when using a Zebra G-Series printer:

- You can send instructions to the printer using multiple programming languages: EPL, ZPL, or SGD. EPL and ZPL commands configure the printer, print labels, and get device status information. SGD commands set and get configuration details. These three languages can be used without the need to send the printer instructions to switch from one language to another.
- EPL, ZPL, and SGD commands must be sent to the printer as separate files. They cannot be used together in one format, or set of commands. For example, if you send a series of SGD commands to the printer and they are followed by a printable format, this needs to be done using separate files.

Overview

This section describes how and why to use the Set / Get / Do (SGD) commands. It also provides an example of a typical command structure.



Note • SGD commands must be terminated by a carriage return or a space and line feed.

SGD commands are commands that allow you to configure all printers with firmware version V60.15.x, V50.15.x, V61.15.x, V56.15.x, V53.15.xZ, or later. The printer performs the specified function immediately after receiving the command. The commands are:

- **setvar**
- **getvar**
- **do**

setvar Command

Setvar commands:

- are used to configure printer settings to specific values by setting them in the printer
- must be terminated by a space character or a CR/ LF (0x0D, 0x0A)



Important • The setvar command and attributes must be specified in lower case.

getvar Command

Getvar commands:

- are used to get the current value of the printer settings
- must be terminated by a space character or CR/LF (0x0D, 0x0A)

The printer responds with the printer setting of “?” if:

- the printer setting does not exist (usually due to incorrect spelling of the printer setting)
- it has not been configured yet



Important • The printer settings and attributes must be specified in lower case.

do Command

Do commands:

- are used to instruct the printer to perform predefined actions
- must be terminated by a space character or a CR/LF (0x0D, 0x0A)

Some **Do** commands require additional settings which must be enclosed in double quotes.




Important • The values must be specified in lower case.

Command Structure

It is important to understand the structure of the command and its components. A command structure illustration is provided for each command in this guide.

➔ **Example:** This is an example of a command structure illustration:




1	Command—always preceded with an exclamation point (!) and must be specified in lower case. A space resides between the ! and U1 and between U1 and the command (setvar or getvar).
2	Attribute—always in double quotes and must be specified in lower case.
3	Chosen value—always in double quotes. Only applicable for setvar and do .

This command must be terminated by a space character or a CR/ LF (0x0D, 0x0A).

How to Send Multiple SGD Commands

For any **getvar**, **setvar**, or **do** command, if you issue the syntax without the "1" and use the END command followed by a space, multiple SGD commands are sent simultaneously.

➔ **Example:** This syntax shows how you can send multiple **getvar** commands:



1	The command portion of the string does not use the "1" after the "! U".
2	Commands issued after the first command do not require the "! U".
3	The string of commands is terminated by the word "END" with a space after the word, and by a carriage return/ line feed.

external_wired.check

This command controls whether to check for external print server during the network interface search.

Commands	Details
setvar	<p>This command instructs the printer to set the network interface search.</p> <p>Format: ! U1 setvar "external_wired.check" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "on" = turn on external wired network interface search "off" = turn off external wired network interface search <p>Default:</p> <ul style="list-style-type: none"> "on" = If wireless option board is not installed "off" = If wireless option board is installed
getvar	<p>This command retrieves the status of the network interface search.</p> <p>Format: ! U1 getvar "external_wired.check"</p>



Example: This setvar example shows the value set to "off".

```
! U1 setvar "external_wired.check" "off"
```

When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.addr

This command allows you to get or set the external wired print servers's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	This command instructs the printer to change its current external wired print server IP address upon powering the printer on. Format: ! U1 setvar "external_wired.ip.addr" "value" Values: any valid IP address Default: "0.0.0.0"
getvar *	This command instructs the printer to respond with its current external wired print server IP address. Format: ! U1 getvar "external_wired.ip.addr"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Note • The **setvar** value of this command can be affected by the **external_wired.ip.dhcp.enable** command.



Example: This **setvar** example shows the value set to "10.14.4.235".
! U1 setvar "external_wired.ip.addr" "10.14.4.235"

What the **setvar** value is set to is the **getvar** result. In this example, the **getvar** result is "10.14.4.235".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.arp_interval

This print server setting allows you to specify the ARP (Address Resolution Protocol) interval or the ARP cache time out for the external wired print server.

Commands	Details
setvar	<p>This command instructs the printer to change the ARP interval or the ARP cache time out for the external wired print server.</p> <p>Format: ! U1 setvar "external_wired.ip.arp_interval" "value"</p> <p>Values: 0 - 30</p> <p>Default: "0"</p>
getvar *	<p>This command instructs the printer to respond with the ARP interval or the ARP cache time out value for the external wired print server.</p> <p>Format: ! U1 getvar "external_wired.ip.arp_interval"</p>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "0".

```
! U1 setvar "external_wired.ip.arp_interval" "0"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.default_addr_enable

This command allows you to default the external wired print server's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	<p>This command tells the printer to use it's default address, if no address is provided through DHCP or BOOTP. If you do not assign an IP address after 2 minutes, the 10/100 Internal PS defaults to IP address 192.168.254.254.</p> <p>Format: ! U1 setvar "external_wired.ip.default_addr_enable" "value"</p> <p>Values: "on" = enabled "off" = disabled</p> <p>Default: "on"</p>
getvar *	<p>This command instructs the printer to show the status of the setting of external wired print server's default IP address feature.</p> <p>Format: ! U1 getvar "external_wired.ip.default_addr_enable"</p>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "on".

```
! U1 setvar "external_wired.ip.default_addr_enable" "on"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.dhcp.cid_all

This printer setting defines the entire client identifier (DHCP option 61) if DHCP is enabled on the external print server and "external_wired.ip.dhcp.cid_type" is set to "0", or "2". The MAC address is used if the type is set to "1".

Commands	Details
setvar	<p>This command instructs the printer to change the client identifier prefix and suffix of the external wired print server. The prefix gets cleared and the suffix contains the entire client identifier.</p> <p>Format: ! U1 setvar "external_wired.ip.dhcp.cid_all" "value"</p> <p>Values: A maximum length of 60 characters if the CID type is ASCII, or 120 characters if the CID type is hexadecimal.</p> <p>Default: ""</p>
getvar *	<p>This command instructs the printer to respond with the client identifier prefix and suffix of the external wired print server.</p> <p>Format: ! U1 getvar "external_wired.ip.dhcp.cid_all"</p>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "external_wired.ip.dhcp.cid_all" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.dhcp.cid_enable

This command determines if DHCP (option 61) on the external wired print server is turned on or off.

Commands	Details
setvar	This command instructs the printer to set the status of the client identifier of the external wired print server. Format: ! U1 setvar "external_wired.ip.dhcp.cid_enable" "value" Values: "off" = client identifier is turned off "on" = client identifier is turned on Default: "off"
getvar *	This command instructs the printer to respond with the status of the client identifier of the external wired print server. Format: ! U1 getvar "external_wired.ip.dhcp.cid_enable"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "off".

```
! U1 setvar "external_wired.ip.dhcp.cid_enable" "off"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.dhcp.cid_prefix

This printer setting defines the prefix to be prepended to the DHCP client identifier (option 61) when DHCP is enabled on the external wired print server and "external_wired.ip.dhcp.cid_type" is set to "0" or "2".

Commands	Details
setvar	This command instructs the printer to change the CID prefix of the external wired print server. Format: ! U1 setvar "external_wired.ip.dhcp.cid_prefix" "value" Values: Any text string up to 10 characters if the CID type is ASCII, or 20 characters if the CID type is hexadecimal. Default: ""
getvar *	This command instructs the printer to respond with the client identifier prefix of the external wired print server. Format: ! U1 getvar "external_wired.ip.dhcp.cid_prefix"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "PRT001".

```
! U1 setvar "external_wired.ip.dhcp.cid_prefix" "PRT001"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "PRT001".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.dhcp.cid_suffix

This printer setting defines the unique suffix to be used as the client identifier (DHCP option 61) if DHCP is enabled repeated on the external wired print server and [external_wired.ip.dhcp.cid_type on page 995](#) is set to "0" or "2", not "1".

Commands	Details
setvar	This command instructs the printer to change the client identifier suffix value. Format: ! U1 setvar "external_wired.ip.dhcp.cid_suffix" "value" Values: The maximum length of a value allowed is 60 ASCII characters when the CID type is ASCII, or 120 hexadecimal values when the CID type is hexadecimal. Default: ""
getvar *	This command instructs the printer to respond with the client identifier suffix on the external wired print server. Format: ! U1 getvar "external_wired.ip.dhcp.cid_suffix"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows setting the suffix to "printer".

```
! U1 setvar "external_wired.ip.dhcp.cid_suffix" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.dhcp.cid_type

This printer setting defines the type of client identifier (DHCP option 61) that will be sent if DHCP is enabled on the external wired print server. A value of "1" means the type of "Ethernet" and the printer's MAC address will be used. A value of "0" or "2" means the client identifier sent will be "external_wired.ip.dhcp.cid_prefix" concatenated with "external_wired.ip.dhcp.cid_suffix".

Commands	Details
setvar	<p>This command instructs the printer to enable "synthetic" Client Identifier for the external wired print server.</p> <p>Format: ! U1 setvar "external_wired.ip.dhcp.cid_type" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "0" = ASCII string "1" = wired print server's MAC address "2" = HEX value <p>Default: "1"</p>
getvar *	<p>This command instructs the printer to respond with the client identifier type for the external wired print server.</p> <p>Format: ! U1 getvar "external_wired.ip.dhcp.cid_type"</p>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "1".
! U1 setvar "external_wired.ip.dhcp.cid_type" "1"
When the setvar value is set to "1", the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.gateway

This command instructs the printer to change the external wired print server's gateway address.



Important • This setting refers to the gateway address. A set value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the external wired printer server's gateway address. Format: ! U1 setvar "external_wired.ip.gateway" "value" Values: Any valid gateway address Default: "0.0.0.0"
getvar *	This command instructs the printer to respond with the external wired printer server's gateway address. Format: ! U1 getvar "external_wired.ip.gateway"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "10.3.5.1".

```
! U1 setvar "external_wired.ip.gateway" "10.3.5.1"
```

When the setvar value is set to "10.3.5.1", the getvar result is "10.3.5.1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.netmask

This setting refers to the external wired print server's subnet mask address. This value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the external wired print servers's subnet mask. Format: ! U1 setvar "external_wired.ip.netmask" "value" Values: Any valid subnet mask. Default: "255.255.255.0"
getvar *	This command instructs the printer to respond with the external wired print server's subnet mask. Format: ! U1 getvar "external_wired.ip.netmask"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "255.255.255.0".

```
! U1 setvar "external_wired.ip.netmask" "255.255.255.0"
```

When the setvar value is set to "255.255.255.0", the getvar result is "255.255.255.0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.port

This printer setting refers to the external wired print server's port number that the TCP print service is listening on. Normal TCP communications from the host should be directed to this port.

Commands	Details
setvar	This command instructs the printer to set the external wired print server's TCP/UDP port number. Format: ! U1 setvar "external_wired.ip.port" "value" Values: 1 - 65535 (excluding any ports currently used by other services, such as 21, 23, 80, and 515). Default: "9100"
getvar *	This command instructs the printer to respond with the external wired printer server's TCP/UDP port number. Format: ! U1 getvar "external_wired.ip.port"

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "9100".

```
! U1 setvar "external_wired.ip.port" "9100"
```

When the setvar value is set to "9100", the getvar result is "9100".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.protocol

This command configures the IP addressing method used by the external wired print server.

Commands	Details
setvar	<p>This command instructs the printer to configure the IP addressing method used by the external wired print server.</p> <p>Format: ! U1 setvar "external_wired.ip.protocol" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "bootp" = uses the standard bootp addressing method to obtain an IP address and configuration "dhcp" = uses the standard dhcp addressing method to obtain an IP address and configuration for a server specified period of time "rarp" = uses the standard rarp addressing method to obtain an IP address "glean" = uses the IP address from a PING packet that is sent to its hardware address (unicast address) "permanent" = uses static values assigned through other commands "all" = tries all of the dynamic addressing methods, not permanent, to obtain an IP address <p>Default: "all"</p>
getvar *	<p>This command returns the IP addressing method used by the external print server.</p> <p>Format: ! U1 getvar "external_wired.ip.protocol"</p>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: In this example, the **setvar** result is the current programming language that the printer is using.

```
! U1 setvar "external_wired.ip.protocol" "bootp"
```

What the **setvar** value is set to is the **getvar** result. In this example, the **getvar** result is "bootp".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.timeout.enable

This network setting refers to enabling the connection timeout on the external wired 10/100 print server. For this to take effect, the print server must be reset.

Commands	Details
<code>setvar</code>	<p>This command instructs the printer to enable or disable the timeout checking on the external wired print server.</p> <p>Format:</p> <pre>! U1 setvar "external_wired.ip.timeout.enable" "value"</pre> <p>Values:</p> <p>"off" = turns off the connection checking "on" = turns on the connection checking</p> <p>Default: "on"</p>
<code>getvar *</code>	<p>This command instructs the printer to return whether the timeout checking is enabled on the external wired print server.</p> <p>Format:</p> <pre>! U1 getvar "external_wired.ip.timeout.enable"</pre>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This `setvar` example shows the value set to "on".

```
! U1 setvar "external_wired.ip.timeout.enable" "on"
```

When the `setvar` value is set to "on", the `getvar` result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.timeout.value

This network setting refers to the number of seconds before the connection times out for the external wired print server.

Commands	Details
setvar	<p>This command instructs the printer to set the time of the external wired print server, in seconds, before the connection times out.</p> <p>Format: ! U1 setvar "external_wired.ip.timeout.value" "value"</p> <p>Values: "1" through "3600"</p> <p>Default: "300"</p>
getvar *	<p>This command instructs the printer to respond with the time of the external wired print server, in seconds, before the connection times out.</p> <p>Format: ! U1 getvar "external_wired.ip.timeout.value"</p>

* On SEH print server models PS102-Z or the PS105-Z, only the getvar command is supported.



Example: This setvar example shows the value set to "300".
! U1 setvar "external_wired.ip.timeout.value" "300"
When the setvar value is set to "300", the getvar result is "300".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.v6.addr

This command retrieves the IPv6 address of the SEH wired print server. This command is only supported on SEH print server models PS105-Z and PS102-Z with firmware version V60.16.5Z or V53.16.5Z and later.

Commands	Details
getvar	This command retrieves the IPv6 address of the SEH wired print server. Format: ! U1 getvar "external_wired.ip.v6.addr" Values: 8 group of four hexadecimal digits with a colon delimiter character set = A-F or 0-9 (39-character maximum)

Supported Devices

- SEH print server model PS105-Z with firmware version V60.16.5Z or V53.16.5Z and later.
- SEH print server model PS102-Z with firmware version V60.16.5Z or V53.16.5Z and later.



Example: In this example, the `getvar` returns the IPv6 address of the wired print server.
! U1 getvar "external_wired.ip.v6.addr"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.v6.gateway

This command retrieves the IPv6 gateway of the SEH wired print server.

Commands	Details
getvar	<p>This command retrieves the IPv6 gateway of the SEH wired print server.</p> <p>Format: ! U1 getvar "external_wired.ip.v6.gateway"</p> <p>Values: 8 group of four hexadecimal digits with a colon delimiter character set = A-F or 0-9 (39-character maximum)</p>

Supported Devices

- SEH print server model PS105-Z with firmware version V60.16.5Z or V53.16.5Z and later.
- SEH print server model PS102-Z with firmware version V60.16.5Z or V53.16.5Z and later.



Example: In this example, the `getvar` returns the IPv6 gateway of the wired print server.

```
! U1 getvar "external_wired.ip.v6.gateway"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.ip.v6.prefix_length

This command retrieves the IPv6 address prefix length of the SEH wired print server.

Commands	Details
getvar	This command retrieves the IPv6 address prefix length of the SEH wired print server. Format: ! U1 getvar "external_wired.ip.v6.prefix_length" Values: character set = 0-9 (3-character maximum)

Supported Devices

- SEH print server model PS105-Z with firmware version V60.16.5Z or V53.16.5Z and later.
- SEH print server model PS102-Z with firmware version V60.16.5Z or V53.16.5Z and later.



Example: In this example, the `getvar` returns the IPv6 address prefix length of the wired print server.

```
! U1 getvar "external_wired.ip.v6.prefix_length"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.mac_addr

This command retrieves the MAC address of the external wired print server.

Commands	Details
getvar	This command instructs the printer to respond with the MAC address of the external wired print server. Format: ! U1 getvar "external_wired.mac_addr"



Example: In this example, the `getvar` result is the MAC address of the external wired print server.
! U1 getvar "external_wired.mac_addr"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

external_wired.mac_raw

This command specifies the RAW MAC address of the external print server. The raw mac address is the mac address without the colons (":").

Commands	Details
getvar	This command retrieves the RAW MAC address of the external print server. Format: ! U1 getvar "external_wired.mac_raw"



Example: In this example, the `getvar` retrieves the RAW MAC address of the external print server.

```
! U1 getvar "external_wired.mac_raw"
```

```
"00074d2408ff"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.8021x.password

Sets the password to be used for authentication with the wired network.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.password" "value"
```

Values:

The value is a string of up to 32 ASCII characters.

Related SGDs

- internal_wired.8021x.security
- internal_wired.8021x.username

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.8021x.peap.validate_server_certificate

When using PEAP, this command determines if the printer requires the server certificate to be signed by a CA in Zebra's CA chain of trust.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.peap.validate_server_certificate"  
"value"
```

Values:

- on
- off

Default:

"on"

Getvar

To have the printer return the current setting value:

```
! U1 getvar "internal_wired.8021x.peap.validate_server_certificate"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.8021x.peap.anonymous_identity

Sets the phase 1 ID name when authenticating with the wired network.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.peap.anonymous_identity" "value"
```

Values:

The value is a string of up to 32 ASCII characters.

Default:

""

Getvar

To confirm the command is set:

```
! U1 getvar "internal_wired.8021x.peap.anonymous_identity"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.8021x.private_key_password

Sets the private key password for encryption in the certificate file.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.private_key_password" "value"
```

Values:

The value is a string of up to 32 ASCII characters.

Default:

""

Getvar

To have the printer return the current setting value:

```
! U1 getvar "internal_wired.8021x.private_key_password"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.8021x.security

Returns the security type used for the wired network.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.security" "none"
```

Values:

- none
- peap
- eap-tls
- eap-ttls

Default:

"none"

Getvar

To have the printer return the current setting value:

```
! U1 getvar "internal_wired.8021x.security"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.8021x.ttls_tunnel

Sets the TTLS tunnel protocol to use in the authentication process.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.ttls_tunnel" "value"
```

Values:

- pap
- chap
- mschap
- mschapv2

Default:

```
"mschapv2"
```

Getvar

To have the printer return the current setting value:

```
! U1 getvar "internal_wired.8021x.ttls_tunnel"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.8021x.username

Sets the user name to use for authentication with the wired network.

Setvar

To set the command:

```
! U1 setvar "internal_wired.8021x.username" "value"
```

Values:

The value is a string of up to 32 ASCII characters.

Default:

""

Getvar

To have the printer return the current setting value:

```
! U1 getvar "internal_wired.8021x.username"
```

The value is a string of up to 32 ASCII characters.

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.activity_led

Controls whether the Ethernet activity LED will blink or be solid when there is link.

Commands	Details
setvar	Format: ! U1 setvar "internal_wired.activity_led" "value" Values: "blink" = the LED will blink "solid" = the LED will be solid Default: "blink"
getvar	Format: ! U1 getvar "internal_wired.activity_led"

Supported Devices

- QLn220, QLn420, QLn320
- ZR628, ZR638



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.auto_switchover

This command instructs the printer to switch from wireless to the internal wired print server when an Ethernet cable is plugged into the printer and the printer detects an active data link.

Commands	Details
setvar	This command configures switches between the wireless and wired interfaces. Format: ! U1 setvar "internal_wired.auto_switchover" "value" Values: "on" = switchover enabled "off" = switchover disabled Default: "off"
getvar	This command retrieves the current automatic switchover value. Format: ! U1 getvar "internal_wired.auto_switchover"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Important • For this command to work, be sure:

- you are using a ZM400/ZM600 or RZ400/RZ600 printer with both the internal 10/100 wired print server and wireless option board installed
- the value for this command is set to "on" (switchover enabled)
- the printer is currently communicating to the network through a wireless connection
- a Ethernet cable is plugged into the ZM400/ZM600 or RZ400/RZ600 printer and the printer recognizes a data link connection

When the above conditions exist and an active Ethernet cable is plugged into an internal wired print server, the printer will detect the wired data link and automatically switch to the wired interface. The printer will automatically switch back to the wireless interface when the Ethernet cable is disconnected.



Example: This setvar example shows the value set to "off".

```
! U1 setvar "internal_wired.auto_switchover" "off"
```

When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.enable

Enables or disables the wired network interface.

IMPORTANT: A network or printer reset is required for this setting to take effect.

Setvar

To set the command:

```
! U1 setvar "internal_wired.enable" "value"
```

Values:

- on
- off

Default:

"on"

Getvar

To have the printer return the current setting value:

```
! U1 getvar "internal_wired.enable"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

internal_wired.installed

Returns if the wired option is installed in the printer.

Commands	Details
getvar	Format: ! U1 getvar "internal_wired.installed" Values: "yes" = the wired print server is installed "no" = the wired print server is not installed

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.addr

This command allows you to get or set the internal wired print servers's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	This command instructs the printer to change its current internal wired print server IP address upon powering the printer on. Format: ! U1 setvar "internal_wired.ip.addr" "value" Values: any valid IP address Default: "0.0.0.0"
getvar	This command instructs the printer to respond with its current internal wired print server IP address. Format: ! U1 getvar "internal_wired.ip.addr"



Note • The `setvar` value of this command can be affected by the `internal_wired.ip.dhcp.enable` command.



Example: This `setvar` example shows the value set to "10.14.4.235".

```
! U1 setvar "internal_wired.ip.addr" "10.14.4.235"
```

What the `setvar` value is set to is the `getvar` result. In this example, the `getvar` result is "10.14.4.235".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.arp_interval

This print server setting allows you to specify the ARP (Address Resolution Protocol) interval or the ARP cache time out for the internal wired print server.

Commands	Details
setvar	This command instructs the printer to change the ARP interval or the ARP cache time out for the internal wired print server. Format: ! U1 setvar "internal_wired.ip.arp_interval" "value" Values: 0 - 30 Default: "0"
getvar	This command instructs the printer to respond with the ARP interval or the ARP cache time out value for the internal wired print server. Format: ! U1 getvar "internal_wired.ip.arp_interval"



Example: This setvar example shows the value set to "0".

```
! U1 setvar "internal_wired.ip.arp_interval" "0"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.default_addr_enable

This command allows you to default the internal wired print server's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	<p>This command tells the printer to use it's default address, if no address is provided through DHCP or BOOTP. If you do not assign an IP address after 2 minutes, the 10/100 Internal PS defaults to IP address 192.168.254.254.</p> <p>Format: ! U1 setvar "internal_wired.ip.default_addr_enable" "value"</p> <p>Values: "on" = enabled "off" = disabled</p> <p>Default: "on"</p>
getvar	<p>This command instructs the printer to show the status of the setting of internal wired print server's default IP address feature.</p> <p>Format: ! U1 getvar "internal_wired.ip.default_addr_enable"</p>



Example: This setvar example shows the value set to "on".

```
! U1 setvar "internal_wired.ip.default_addr_enable" "on"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.arp_verify

This command controls whether the internal wired print server will send an ARP response after receiving an IP address via DHCP.

Commands	Details
setvar	<p>Format: ! U1 setvar "internal_wired.ip.dhcp.arp_verify" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "off" = ARP response will not be sent. "on" = ARP response will be sent. <p>Default:</p> <ul style="list-style-type: none"> "off" for mobile Link-OS printers "on" for desktop and industrial printers
getvar	<p>Format: ! U1 getvar "internal_wired.ip.dhcp.arp_verify"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.cache_ip

This command enables or disables the IP cache on the internal wired print server.

Commands	Details
setvar	This command sets the status of the IP cache. Format: ! U1 setvar "internal_wired.ip.dhcp.cache_ip" "value" Values: "on" = enabled "off" = disabled Default: "off"
getvar	This command retrieves the status of the IP cache on the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.cache_ip"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: This setvar example shows the value set to "off".

```
! U1 setvar "internal_wired.ip.dhcp.cache_ip" "off"
```

When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.cid_all

This printer setting defines the entire client identifier (DHCP option 61) if DHCP is enabled on the internal print server and "internal_wired.ip.dhcp.cid_type" is set to "0", or "2". The MAC address is used if the type is set to "1".

Commands	Details
setvar	<p>This command instructs the printer to change the client identifier prefix and suffix of the internal wired print server. The prefix gets cleared and the suffix contains the entire client identifier.</p> <p>Format: ! U1 setvar "internal_wired.ip.dhcp.cid_all" "value"</p> <p>Values: A maximum length of 60 characters if the CID type is ASCII, or 120 characters if the CID type is hexadecimal.</p> <p>Default: ""</p>
getvar	<p>This command instructs the printer to respond with the client identifier prefix and suffix of the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.dhcp.cid_all"</p>



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "internal_wired.ip.dhcp.cid_all" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.cid_enable

This command determines if DHCP (option 61) is turned on or off of the internal wired print server.

Commands	Details
setvar	This command instructs the printer to set the status of the client identifier of the internal wired print server. Format: ! U1 setvar "internal_wired.ip.dhcp.cid_enable" "value" Values: "off" = client identifier is turned off "on" = client identifier is turned on Default: "off"
getvar	This command instructs the printer to respond with the status of the client identifier of the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.cid_enable"



Example: This setvar example shows the value set to "off".

```
! U1 setvar "internal_wired.ip.dhcp.cid_enable" "off"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.cid_prefix

This printer setting defines the prefix to be prepended to the DHCP client identifier (option 61) when DHCP is enabled on the internal wired print server and "internal_wired.ip.dhcp.cid_type" is set to "0" or "2".

Command s	Details
setvar	<p>This command instructs the printer to change the CID prefix of the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.dhcp.cid_prefix" "value"</p> <p>Values: Any text string up to 10 characters if the CID type is ASCII, or 20 characters if the CID type is hexadecimal.</p> <p>Default: ""</p>
getvar	<p>This command instructs the printer to respond with the client identifier prefix of the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.dhcp.cid_prefix"</p>



Example: This setvar example shows the value set to "PRT001".

```
! U1 setvar "internal_wired.ip.dhcp.cid_prefix" "PRT001"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "PRT001".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.cid_suffix

This printer setting defines the unique suffix to be used as the client identifier (DHCP option 61) if DHCP is enabled on the internal wired 10/100 print server and "internal_wired.ip.dhcp.cid_type" is set to "0" or "2".

Commands	Details
setvar	This command instructs the printer to change the client identifier suffix value of the internal wired 10/100 print server. Format: ! U1 setvar "internal_wired.ip.dhcp.cid_suffix" "value" Values: The maximum length of a value allowed is 60 ASCII characters when the CID type is ASCII, or 120 hexadecimal values when the CID type is hexadecimal. Default: ""
getvar	This command instructs the printer to respond with the client identifier suffix of the internal wired 10/100 print server. Format: ! U1 getvar "internal_wired.ip.dhcp.cid_suffix"



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "internal_wired.ip.dhcp.cid_suffix" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.cid_type

This printer setting defines the type of client identifier (DHCP option 61) that will be sent if DHCP is enabled on the internal wired print server. A value of "1" means the type of "Ethernet" and the printer's MAC address will be used. A value of "0" or "2" means the client identifier sent will be "internal_wired.ip.dhcp.cid_prefix" concatenated with "internal_wired.ip.dhcp.cid_suffix".

Commands	Details
setvar	<p>This command instructs the printer to enable "synthetic" Client Identifier for the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.dhcp.cid_type" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "0" = ASCII string "1" = wired print server's MAC address "2" = HEX value <p>Default: "1"</p>
getvar	<p>This command instructs the printer to respond with the client identifier type for the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.dhcp.cid_type"</p>



Example: This setvar example shows the value set to "1".

```
! U1 setvar "internal_wired.ip.dhcp.cid_type" "1"
```

 When the setvar value is set to "1", the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.lease.last_attempt

This command retrieves the last time a DHCP request was sent from the internal wired print server.

Commands	Details
getvar	This command retrieves the last time a DHCP request was sent from the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.lease.last_attempt"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: In this example, the `getvar` retrieves the last time a DHCP request was sent to the internal wired print server.

```
! U1 getvar "internal_wired.ip.dhcp.lease.last_attempt"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.lease.length

This command retrieves the original length (in seconds) of the DHCP lease on the internal wired print server.

Commands	Details
getvar	This command retrieves the original length (in seconds) of the DHCP lease on the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.lease.length"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: In this example, the `getvar` returns the original length of the DHCP lease on the internal wired print server.

```
! U1 getvar "internal_wired.ip.dhcp.lease.length"
```

```
"691200"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.lease.server

This command retrieves the address of the server that provided the DHCP lease on the internal wired print server.

Commands	Details
getvar	This command retrieves the address of the server that provided the DHCP lease on the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.lease.server"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: In this example, the `getvar` retrieves the address of the server that provided the DHCP lease on the internal wired print server.

```
! U1 getvar "internal_wired.ip.dhcp.lease.server"
```

```
"10.3.1.98"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.lease.time_left

This command retrieves the time (in seconds) left in the current DHCP lease on the internal wired print server.

Commands	Details
getvar	This command retrieves the time (in seconds) left in the current DHCP lease on the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.lease.time_left"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: In this example, the `getvar` retrieves the time left in the current DHCP lease on the wired internal print server.

```
! U1 getvar "internal_wired.ip.dhcp.lease.time_left"

"10.3.1.98"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.option12

This command specifies if the DHCP option 12 (host name) is on or off in the discovery packet that is sent from the internal wired print server.

Commands	Details
setvar	<p>This command instructs the printer to set the DHCP option 12 (host name) in the discovery packet of the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.dhcp.option12" "value"</p> <p>Values: "on" = turns on option 12 "off" = turns off option 12</p> <p>Default: "on"</p>
getvar	<p>This command retrieves the status of the DHCP option 12 (host name) in the discovery packet of the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.dhcp.option12"</p>

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: This setvar example shows the value set to "on".
! U1 setvar "internal_wired.ip.dhcp.option12" "on"
When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.option12_format

This command specifies the value which will be used for option 12 (host name) to be used in the DHCP discovery packet of the internal wired print server.

Commands	Details
setvar	<p>This command instructs the printer to set value which will be used for option 12 (host name) to be used in the DHCP discovery packet of the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.dhcp.option12_format" "value"</p> <p>Values: 0 to 109 alphanumeric characters</p> <p>Default: ""</p>
getvar	<p>This command retrieves the value which will be used for option 12 (host name) to be used in the DHCP discovery packet of the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.dhcp.option12_format"</p>

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: This setvar example shows configuring the internal_wired.ip.dhcp.option12_format to the value contained in the device.friendly_name.

It is necessary to surround the SGD entry to be used as source for the data with the < and > characters.

```
! U1 setvar "internal_wired.ip.dhcp.option12_format" "<device.friendly_name>"
```

To further explain, if the above command was issued and the value currently stored in the device.friendly_name parameter was "ShipPrinter", then the response to following command would be "ShipPrinter":

```
! U1 getvar "internal_wired.ip.dhcp.option12_value"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.option12_value

This command retrieves the actual value which will be used in the discovery packet of the internal wired print server.

Commands	Details
getvar	This command retrieves the actual value which will be used in the discovery packet of the internal wired print server. Format: ! U1 getvar "internal_wired.ip.dhcp.option12_value"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: This `setvar` example shows configuring the `internal_wired.ip.dhcp.option12_format` to the value contained in the `device.friendly_name`.

It is necessary to surround the SGD entry to be used as source for the data with the `<` and `>` characters.

```
! U1 setvar "internal_wired.ip.dhcp.option12_format" "<device.friendly_name>"
```

To further explain, if the above command was issued and the value currently stored in the `device.friendly_name` parameter was "ShipPrinter", then the response to following command would be "ShipPrinter":

```
! U1 getvar "internal_wired.ip.dhcp.option12_value"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dhcp.requests_per_session

This command retrieves the maximum amount of DHCP discover requests for a single DHCP session on the internal wired print server.

Commands	Details
setvar	<p>This command instructs the printer to set the maximum amount of DHCP discover requests for a single DHCP session on the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.dhcp.requests_per_session" "value"</p> <p>Values: 1-10 Default: "2"</p>
getvar	<p>This command retrieves the currently set maximum amount of DHCP discover requests for a single DHCP session on the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.dhcp.requests_per_session"</p>

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: This setvar example shows the value set to "2".

```
! U1 setvar "internal_wired.ip.dhcp.requests_per_session" "2"
```

When the setvar value is set to "2", the getvar result is "2".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.dns.servers

This command retrieves a space delimited list of the domain name servers from an internal wired print server.

Commands	Details
getvar	This command retrieves a list of space delimited DNS internal wired print servers. Format: ! U1 getvar "internal_wired.ip.dns.servers"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.gateway

This command instructs the printer to change the internal wired print servers gateway address.



Important • This setting refers to the gateway address. A set value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the internal wired printer servers gateway address. Format: ! U1 setvar "internal_wired.ip.gateway" "value" Values: Any valid gateway address Default: "0.0.0.0"
getvar	This command instructs the printer to respond with the internal wired printer servers gateway address. Format: ! U1 getvar "internal_wired.ip.gateway"



Example: This setvar example shows the value set to "10.3.5.1".

```
! U1 setvar "internal_wired.ip.gateway" "10.3.5.1"
```

When the setvar value is set to "10.3.5.1", the getvar result is "10.3.5.1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.netmask

This setting refers to the internal wired print server's subnet mask address. This value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the internal wired print servers subnet mask. Format: ! U1 setvar "internal_wired.ip.netmask" "value" Values: Any valid subnet mask. Default: "255.255.255.0"
getvar	This command instructs the printer to respond with internal wired print servers subnet mask. Format: ! U1 getvar "internal_wired.ip.netmask"



Example: This setvar example shows the value set to "255.255.255.0".

```
! U1 setvar "internal_wired.ip.netmask" "255.255.255.0"
```

When the setvar value is set to "255.255.255.0", the getvar result is "255.255.255.0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.port

This printer setting refers to the internal wired print servers port number that the TCP print service is listening on. Normal TCP communications from the host should be directed to this port.

Commands	Details
setvar	This command instructs the printer to set the internal wired print servers TCP/UDP port number. Format: ! U1 setvar "internal_wired.ip.port" "value" Values: 1 - 65535 (excluding any ports currently used by other services, such as 21, 23, 80, and 515). Default: "9100"
getvar	This command instructs the printer to respond with the internal wired printer servers TCP/UDP port number. Format: ! U1 getvar "internal_wired.ip.port"



Example: This setvar example shows the value set to "9100".

```
! U1 setvar "internal_wired.ip.port" "9100"
```

When the setvar value is set to "9100", the getvar result is "9100".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.port_alternate

This command sets the port number of the alternate port.



Note • Print servers supporting this command will monitor both the primary port and the alternate port for connections at the same time.

Commands	Details
setvar	This command sets the alternate port for the print server. Format: ! U1 setvar "internal_wired.ip.port_alternate" "value" Values: Any valid TCP port address. Default: "9100"
getvar	This command returns the current alternate port setting. Format: ! U1 setvar "internal_wired.ip.port_alternate" Values: The current port setting.

Supported Devices

- iMZ 220, iMZ 320
- QLn220, QLn320, QLn420
- ZD410, ZD420, ZD500
- ZQ510, ZQ520
- ZR338, ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.port_json_config

This command determines the TCP port number to listen on for JSON configuration packets.

Commands	Details
setvar	<p>This command sets the TCP port number to listen on for JSON configuration packets.</p> <p>Format: ! U1 setvar "internal_wired.ip.port_json_config" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> • 0 = disable the port • 1-65535 = Port number to listen on. <p>Note • Ports that are already in use or the standard network ports are invalid values.</p> <p>Default: "9200"</p>
getvar	<p>This command retrieves the port number.</p> <p>Format: ! U1 getvar "internal_wired.ip.port_json_config"</p>

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar,getvar



Example: This example sets the port value to listen on as 1234.

```
! U1 setvar "internal_wired.ip.port_json_config" "1234"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.protocol

This command configures the IP addressing method used by the internal wired print server.

Commands	Details
setvar	<p>This command instructs the printer to configure the IP addressing method used by the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.protocol" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "bootp" = uses the standard bootp addressing method to obtain an IP address and configuration "dhcp" = uses the standard dhcp addressing method to obtain an IP address and configuration for a server specified period of time "rarp" = uses the standard rarp addressing method to obtain an IP address "glean" = uses the IP address from a PING packet that is sent to its hardware address (unicast address) "permanent" = uses static values assigned through other commands "all" = tries all of the dynamic addressing methods, not permanent, to obtain an IP address <p>Default: "all"</p>
getvar	<p>This command returns the IP addressing method used by the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.protocol"</p>



Example: In this example, the **setvar** result is the current programming language that the printer is using.

```
! U1 setvar "internal_wired.ip.protocol" "bootp"
```

What the **setvar** value is set to is the **getvar** result. In this example, the **getvar** result is "bootp".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.timeout.enable

This network setting refers to enabling the connection timeout on the internal wired print server. For this to take effect, the print server must be reset.

Commands	Details
setvar	<p>This command instructs the printer to enable or disable the timeout checking on the internal wired print server.</p> <p>Format: ! U1 setvar "internal_wired.ip.timeout.enable" "value"</p> <p>Values: "off" = turns off the connection checking "on" = turns on the connection checking</p> <p>Default: "on"</p>
getvar	<p>This command instructs the printer to return whether the timeout checking is enabled on the internal wired print server.</p> <p>Format: ! U1 getvar "internal_wired.ip.timeout.enable"</p>



Example: This setvar example shows the value set to "on".
! U1 setvar "internal_wired.ip.timeout.enable" "on"
When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.timeout.value

This network setting refers to the number of seconds before the connection times out for the internal wired print server. For this to take effect, the print server must be reset.

Command s	Details
setvar	This command instructs the printer to set the time of the internal wired print server, in seconds, before the connection times out. Format: ! U1 setvar "internal_wired.ip.timeout.value" "value" Values: "1" through "3600" Default: "300"
getvar	This command instructs the printer to respond with the time of the internal wired print server, in seconds, before the connection times out. Format: ! U1 getvar "internal_wired.ip.timeout.value"



Example: This `setvar` example shows the value set to "300".
! U1 setvar "internal_wired.ip.timeout.value" "300"
When the `setvar` value is set to "300", the `getvar` result is "300".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.wins.addr

Sets or returns the current WINS server address. If WinsAddressing is DHCP, then this will automatically be filled by the DHCP server.

Commands	Details
setvar	<p>Format: ! U1 setvar "internal_wired.ip.wins.addr" "value"</p> <p>Values: a valid WINS IP address.</p> <p>Default: "0.0.0.0"</p>
getvar	<p>Format: ! U1 getvar "internal_wired.ip.wins.addr"</p> <p>Result: the current WINS server address</p>

Supported Devices

- 140XiIIIPlus, 170XiIIIPlus, 170XiIIIPlus, 220XiIIIPlus
- 170Xi4, 220Xi4
- GK420d, , GK420t, GK888t
- GT800 (ZPL)
- GX420d, GX420t, GX430t
- HC100
- iMZ220, iMZ320
- KR403
- LP 2824 Plus
- QLn220, QLn320, QLn420, QL420+
- S4M
- Z4MPlus, Z6MPlus
- ZD410, ZD420
- ZD500
- ZE500
- ZM400, ZM600
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.ip.wins.permanent_source

Specifies if the WINS address will be permanent or set via DHCP.

Commands	Details
setvar	<p>Format: ! U1 setvar "internal_wired.ip.wins.permanent_source" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "off" = use DHCP-assigned WINS address "on" = use currently stored WINS address <p>The WINS address can be set using the <code>interface.network.active.wins_address</code> command.</p> <p>Default: "off"</p>
getvar	<p>Format: ! U1 getvar "internal_wired.ip.wins.permanent_source"</p>

Supported Devices

- 140XiIIIPlus, 170XiIIIPlus, 170XiIIIPlus, 220XiIIIPlus
- 170Xi4, 220Xi4
- GK420d, , GK420t, GK888t
- GT800 (ZPL)
- GX420d, GX420t, GX430t
- HC100
- iMZ220, iMZ320
- KR403
- LP 2824 Plus
- QLn220, QLn320, QLn420, QL420+
- S4M
- Z4MPlus, Z6MPlus
- ZD410, ZD420
- ZD500
- ZE500
- ZM400, ZM600
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.mac_addr

This command retrieves the MAC address of the internal wired print server.

Commands	Details
getvar	This command instructs the printer to respond with the MAC address of the internal wired print server. Format: ! U1 getvar "internal_wired.mac_addr"



Example: In this example, the `getvar` result is the MAC address of the internal wired print server.
! U1 getvar "internal_wired.mac_addr"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

internal_wired.mac_raw

This command identifies the RAW MAC address of the internal wired print server. The raw mac address is the mac address without the colons (":").

Commands	Details
getvar	This command retrieves the RAW MAC address of the internal wired print server. Format: ! U1 getvar "internal_wired.mac_raw"

Supported Devices

- ZM400/ZM600
- RZ400/RZ600



Example: In this example, the `getvar` retrieves the RAW MAC address of the internal wired print server.

```
! U1 getvar "internal_wired.mac_raw"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

SGD Wireless Commands

This chapter provides a high-level overview of the wireless Set / Get / Do (SGD) commands and details on each SGD command. For printer support of these SGD commands, see [SGD Command Support on page 1393](#).



SGD commands are available in printers with the following firmware versions or later:

- V60.16.2Z or later
- V60.15.xZ or later
- V50.15.xZ or later
- V61.15.xZ or later
- V56.15.xZ or later
- V53.16.x or later
- V53.15.2Z or later
- R53.16.3Z or later
- R60.15.8Z or later
- R62.15.8Z or later
- R63.15.8Z or later
- R65.15.8Z or later



Note • The commands listed in this chapter are for use with the Wireless Print Server and Wireless Plus Print Server, when used with firmware version V60.15.x, V50.15.x, or later.



Important • These are important points to note when using ZPL and SGD commands:

- SGD commands are case-sensitive.
- ZPL and SGD commands should be sent to the printer as separate files.
- Certain settings can be controlled by both ZPL and SGD. Configuration changes made in ZPL can affect configuration changes made in SGD.
- Changes made with one command type (ZPL or SGD) will affect the data returned to the host in response to both ZPL and getvar commands. The command type (ZPL or SGD) that was sent last determines the current setting.
- Some RF cards do not support all of the SGD commands.



Important • These are important points to note when using a Zebra G-Series printer:

- You can send instructions to the printer using multiple programming languages: EPL, ZPL, or SGD. EPL and ZPL commands configure the printer, print labels, and get device status information. SGD commands set and get configuration details. These three languages can be used without the need to send the printer instructions to switch from one language to another.
- EPL, ZPL, and SGD commands must be sent to the printer as separate files. They cannot be used together in one format, or set of commands. For example, if you send a series of SGD commands to the printer and they are followed by a printable format, this needs to be done using separate files.

Overview

This section describes how and why to use the Set / Get / Do (SGD) commands. It also provides an example of a typical command structure.



Note • SGD commands must be terminated by a carriage return or a space and line feed.

SGD commands are commands that allow you to configure all printers with firmware version V60.15.x, V50.15.x, V61.15.x, V56.15.x, V53.15.xZ, or later. The printer performs the specified function immediately after receiving the command. The commands are:

- **setvar**
- **getvar**
- **do**

setvar Command

Setvar commands:

- are used to configure printer settings to specific values by setting them in the printer
- must be terminated by a space character or a CR/ LF (0x0D, 0x0A)



Important • The setvar command and attributes must be specified in lower case.

getvar Command

Getvar commands:

- are used to get the current value of the printer settings
- must be terminated by a space character or CR/LF (0x0D, 0x0A)

The printer responds with the printer setting of “?” if:

- the printer setting does not exist (usually due to incorrect spelling of the printer setting)
- it has not been configured yet



Important • The printer settings and attributes must be specified in lower case.

do Command

Do commands:

- are used to instruct the printer to perform predefined actions
- must be terminated by a space character or a CR/LF (0x0D, 0x0A)

Some **Do** commands require additional settings which must be enclosed in double quotes.




Important • The values must be specified in lower case.

Command Structure

It is important to understand the structure of the command and its components. A command structure illustration is provided for each command in this guide.

➔ **Example:** This is an example of a command structure illustration:




1	Command—always preceded with an exclamation point (!) and must be specified in lower case. A space resides between the ! and U1 and between U1 and the command (setvar or getvar).
2	Attribute—always in double quotes and must be specified in lower case.
3	Chosen value—always in double quotes. Only applicable for setvar and do .

This command must be terminated by a space character or a CR/ LF (0x0D, 0x0A).

How to Send Multiple SGD Commands

For any **getvar**, **setvar**, or **do** command, if you issue the syntax without the "1" and use the **END** command followed by a space, multiple SGD commands are sent simultaneously.

➔ **Example:** This syntax shows how you can send multiple **getvar** commands:



1	The command portion of the string does not use the "1" after the "! U".
2	Commands issued after the first command do not require the "! U".
3	The string of commands is terminated by the word "END" with a space after the word, and by a carriage return/ line feed.

bluetooth.address

This command returns the printer's Bluetooth device address.

Commands	Details
getvar	This command retrieves the printer's Bluetooth address. Format: ! U1 getvar "bluetooth.address"



Example: In this example, the `getvar` command causes the printer to return the printer's Bluetooth address.

```
! U1 getvar "bluetooth.address"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.afh_map

Sets or retrieves the default AFH (adaptive frequency hopping) channel map (Bluetooth radios 1.2 and later); 20 bytes.

Commands	Details
setvar	Selectively enables or disables individual Bluetooth channels for use when AFH mode is set to "on". Format: ! U1 setvar "bluetooth.afh_map" "value" Values: 20-byte string of hexadecimal characters Default: "7FFFFFFFFFFFFFFFFFFF"
getvar	Retrieves default AFH channel map. Format: ! U1 getvar "bluetooth.afh_map"



Example: This setvar example shows the value set to "7FFFFFFFFFFFFFFFFFFF".

```
! U1 setvar "bluetooth.afh_map" "7FFFFFFFFFFFFFFFFFFF"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "7FFFFFFFFFFFFFFFFFFF".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.afh_map_curr

This command retrieves the current AFH (adaptive frequency hopping) channel map (Bluetooth radios 1.2 and later).

Commands	Details
getvar	This command retrieves the current AFH channel map. Format: ! U1 getvar "bluetooth.afh_map_curr"



Example: In this example, the `getvar` command causes the printer to retrieve the current AFH channel map.

```
! U1 getvar "bluetooth.afh_map_curr"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.afh_mode

This command sets or retrieves AFH (adaptive frequency hopping) mode setting (Bluetooth radios 1.2 and later).

Commands	Details
setvar	This command enables and disables AFH mode. Format: ! U1 setvar "bluetooth.afh_mode" "value" Values: "on" = enables AFH mode "off" = disables AFH mode Default: "off"
getvar	This command retrieves the current setting of the AFH mode. Format: ! U1 getvar "bluetooth.afh_mode"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "bluetooth.afh_mode" "on"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.authentication

This command sets or retrieves Bluetooth authentication mode and works in combination with the `bluetooth.bluetooth_pin`.

Commands	Details
<code>setvar</code>	This command enables and disables Bluetooth authentication. Format: <code>! U1 setvar "bluetooth.authentication" "value"</code> Values: <code>"off"</code> = disables authentication (can connect to master device without PIN) <code>"setpin"</code> = enables authentication (requires PIN or passkey to connect to a master device) Default: <code>"off"</code>
<code>getvar</code>	This command retrieves the current Bluetooth authentication mode. Format: <code>! U1 getvar "bluetooth.authentication"</code>



Example: This `setvar` example shows the value set to `"setpin"`.

```
! U1 setvar "bluetooth.authentication" "setpin"
```

What the `setvar` value is set to is the `getvar` result. In this example, the `getvar` result is `"setpin"`.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.bluetooth_pin

This command is used to connect to the printer only when the command `bluetooth.authentication` is set to `"setpin"`.

Commands	Details
<code>setvar</code>	This command sets the Bluetooth pin value. Format: <code>! U1 setvar "bluetooth.bluetooth_pin" "value"</code> Values: Any text string up to 10 characters Default: ""
<code>getvar</code>	This command retrieves the current Bluetooth pin. Format: <code>! U1 getvar "bluetooth.bluetooth_pin"</code>



Example: This `setvar` example shows the value set to `"1234567890"`.

```
! U1 setvar "bluetooth.bluetooth_pin" "1234567890"
```

What the `setvar` value is set to is the `getvar` result. In this example, the `getvar` result is `"1234567890"`.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.clear_bonding_cache

Deletes all information related to previous Bluetooth pairing events from the printer.

Commands	Details
do	Format: ! U1 do "bluetooth.clear_bonding_cache" Values: NA Default: NA

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.date

This command shows the release date of the Bluetooth module.

`getvar`

Commands	Details
<code>getvar</code>	This command shows the release date of the Bluetooth module. Format: <code>! U1 getvar "bluetooth.date"</code>



Example: In this example, the `getvar` command returns the release date of the Bluetooth module.

`! U1 getvar "bluetooth.date"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.discoverable

This command enables or disables the Bluetooth discoverable mode.

Commands	Details
setvar	This command enables or disables the Bluetooth discoverable mode. Format: ! U1 setvar "bluetooth.discoverable" "value" Values: "on" = enables Bluetooth discoverable mode "off" = disables Bluetooth discoverable mode Default: "on"
getvar	This command retrieves the current Bluetooth discoverable mode. Format: ! U1 getvar "bluetooth.discoverable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "bluetooth.discoverable" "on"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.enable

This command enables or disables the Bluetooth radio.

Commands	Details
setvar	This command enables or disables the Bluetooth radio. Format: ! U1 setvar "bluetooth.enable" Values: "on" = enables the Bluetooth radio "off" = disables the Bluetooth radio Default: "on"
getvar	This command retrieves the current status of the Bluetooth radio. Format: ! U1 getvar "bluetooth.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "bluetooth.enable" "on"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.enable_reconnect

Enables the Bluetooth reconnect feature required by iOS devices.

Commands	Details
setvar	Format: ! U1 setvar "bluetooth.enable_reconnect" "value" Values: "off" = disables the command "ios_only" = enables the command to work with iOS devices only
getvar	Format: ! U1 getvar "bluetooth.enable_reconnect"

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZQ510™, ZQ520™
- ZR338™, ZR628™, ZR638™



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.friendly_name

This command sets the friendly name, which is used during service discovery. For changes to take effect, you must power cycle the printer or issue the `device.reset` command. If `bluetooth.friendly_name` is not set by you, it will default to the printer serial number.

Commands	Details
setvar	This command sets the Bluetooth discoverable mode. Format: ! U1 setvar "bluetooth.friendly_name" "value" Values: Any text string up to 17 characters
getvar	This command retrieves the current Bluetooth discoverable mode. Format: ! U1 getvar "bluetooth.friendly_name"



Example: This `setvar` example shows the value set to "1234567".

```
! U1 setvar "bluetooth.friendly_name" "1234567"
```

What the `setvar` value is set to is the `getvar` result. In this example, the `getvar` result is "1234567".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.json_config_channel_enable

Enables or disables the Bluetooth JSON configuration channel. Changes to this command setting only take effect when the printer is reset or power cycled.



Note • The JSON config channel will stop being advertised when there is no connection to the JSON channel and there is no connection on the main SPP channel.



Important • All Bluetooth devices must first make an SPP connection before being able to make the JSON channel connection to a printer.

setvar	<p>Format: ! U1 setvar "bluetooth.json_config_channel_enable" "value"</p> <p>Values: "on" - the channel is advertised and available for use only when the main serial port protocol (SPP) channel is connected. "off" - the channel is not advertised or available for use.</p> <p>Default: "on"</p> <p>Example: ! U1 setvar "bluetooth.json_config_channel_enable" "off"</p>
getvar	<p>Format: ! U1 getvar "bluetooth.json_config_channel_enable"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.le.controller_mode

For printers that support both Bluetooth Classic and Bluetooth Low-Energy mode, this command controls the mode of operation.

Commands	Details
setvar	Format: ! U1 setvar "bluetooth.le.controller_mode" "value" Values: "both" = the Bluetooth radio operates in both low energy and classic mode "le" = the Bluetooth radio operates in low energy mode "classic" = the Bluetooth radio operates in the classic mode Default: "both"
getvar	Format: ! U1 getvar "bluetooth.le.controller_mode"

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.le.minimum_security

Determines the minimum device-level security settings the printer will use to connect for Bluetooth Low-Energy (LE) connections.

Commands	Details
setvar	<p>Format: ! U1 setvar "bluetooth.le.minimum_security" "value"</p> <p>Values: "none" = security is not required unless the particular Bluetooth LE service or characteristic being accessed requires security.</p> <p>For all other choices, all services will require pairing and apply some form of security. "unauth_key_signing" = (un)authenticated pairing and signing keys are required "auth_key_signing" = authenticated pairing and signing keys are required. "unauth_key_encrypt" = (un)authenticated pairing and encryption are required. "auth_key_encrypt" = authenticated pairing and encryption are required.</p> <p>Default: "none" - if the printer has a Bluetooth LE radio. If the printer does not have a Bluetooth LE radio installed, there is no default value.</p>
getvar	<p>Format: ! U1 getvar "bluetooth.le.minimum_security"</p> <p>If the printer does not have a Bluetooth LE radio installed, the printer will return an empty string.</p>

Supported Devices

- ZQ510, ZQ520



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.local_name

This command retrieves the local name that is provided during service discovery.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the local name that is provided during service discovery. Format: <code>! U1 getvar "bluetooth.local_name"</code>



Example: In this example, the `getvar` command returns the local name that is provided during service discovery.

`! U1 getvar "bluetooth.local_name"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.minimum_security_mode

This printer setting parameter sets the Bluetooth Minimum Security mode. Minimum Security Mode provides for three levels of security, depending on the printer radio version and printer firmware: "1", "2", and "3".



Important • This feature is available in printers with Bluetooth® radio version 2.0 or higher.

Commands	Details
setvar	Sets the Bluetooth Minimum Security mode Format: ! U1 setvar "bluetooth.minimum_security_mode" "value" Values: "1" = Security mode 1 - the printer will: <ul style="list-style-type: none"> • be discoverable • not require a PIN to connect to "2" = the printer will: <ul style="list-style-type: none"> • switch to bluetooth.authentication = "setpin" (Connecting device must provide the printer's bluetooth.bluetooth_pin), • switch to Bluetooth.encryption = "on", and • use existing Bluetooth.discoverable setting "3" = Link Level Enforced Security - the printer will: <ul style="list-style-type: none"> • switch to bluetooth.authentication = "setpin" (Connecting device must provide the printer's bluetooth.bluetooth_pin) • switch to bluetooth.encryption = "on" • switch to bluetooth.discoverable = "off" • only connect to devices which use Link Level Enforced Security Default: "1"
getvar	Retrieves the current Bluetooth Minimum Security Mode. Format: ! U1 getvar "bluetooth.minimum_security_mode"

Supported Devices

- EZ320™
- Link-OS printers with firmware Vxx.19.7Z and later.



Example: This setvar example shows the value set to "2".
 ! U1 setvar "bluetooth.minimum_security_mode" "2"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.radio_auto_baud

This command retrieves the Bluetooth radio data rate.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves Bluetooth radio data rate. Format: <code>! U1 getvar "bluetooth.radio_auto_baud"</code>



Example: In this example, the `getvar` retrieves the short Bluetooth address.

`! U1 getvar "bluetooth.radio_auto_baud"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.radio_version

This command returns the version of the currently installed Bluetooth radio.

`getvar`

Commands	Details
<code>getvar</code>	This command returns the version of the currently installed Bluetooth radio. Format: ! U1 <code>getvar "bluetooth.radio_version"</code>



Example: In this example, the `getvar` command returns the currently installed Bluetooth radio.

! U1 `getvar "bluetooth.radio_version"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.short_address

This command shortens the Bluetooth address by removing the colons (":").

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the shortened Bluetooth address. Format: <code>! U1 getvar "bluetooth.short_address"</code>



Example: In this example, the `getvar` retrieves the short Bluetooth address.

`! U1 getvar "bluetooth.short_address"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

bluetooth.version

This command returns the Bluetooth library version number.

`getvar`

Commands	Details
<code>getvar</code>	This command returns the Bluetooth library version number. Format: ! U1 getvar "bluetooth.version"



Example: In this example, the `getvar` command returns the Bluetooth library version number.

`! U1 getvar "bluetooth.version"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

card.mac_addr

This command retrieves the MAC address of the wireless radio card.

getvar

Commands	Details
getvar	This command instructs the printer to respond with the MAC address. Format: ! U1 getvar "card.mac_addr"



Example: In this example, the `getvar` result is the MAC address for the wireless radio card.

```
! U1 getvar "card.mac_addr"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

card.inserted

This command indicates whether the wireless radio card is or is not inserted.

`getvar`

Commands	Details
<code>getvar</code>	This command instructs the printer to respond with the wireless radio card status. It's inserted or it's not inserted. Format: <code>! U1 getvar "card.inserted"</code>



Example: In this example, the `getvar` result is "Inserted".

```
! U1 getvar "card.inserted"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.active_network

This command displays if the printer is actively connected to wireless, external wired, or internal wired.

getvar

Commands	Details
getvar	This command instructs the printer to respond with what the printer is currently connected to internal wired, wireless, external wired, or unknown. Table 31 provides details on the potential return values. Format: ! U1 getvar "ip.active_network"



Example: In this example, the `getvar` will return the current active network the printer is connected to.

```
! U1 getvar "ip.active_network"
```

Table 31 • Printer Responses

Return Values	Details
"internal wired"	This is the return value when an internal wired device is detected.
"wireless"	This is the return value when a wireless device is detected.
"external wired"	This is the return value when an external wired device is detected.
"unknown"	This is the return value: <ul style="list-style-type: none"> • if the printer has not established a network connection on any of the devices • if you don't have any of the network devices plugged in • if the printer is still trying to establish a connection (i.e. on wireless it is going through the association process).



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.addr

This command allows you to get or set the printer's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	This command instructs the printer to change its current IP address upon powering the printer on. Format: ! U1 setvar "ip.addr" "value" Values: any valid IP address Default: "0.0.0.0"
getvar	This command instructs the printer to respond with its current IP address. Format: ! U1 getvar "ip.addr"



Note • The **setvar** value of this command can be affected by the **ip.dhcp.enable** command.



Example: This **setvar** example shows the value set to "10.14.4.235".

```
! U1 setvar "ip.addr" "10.14.4.235"
```

What the **setvar** value is set to is the **getvar** result. In this example, the **getvar** result is "10.14.4.235".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.arp_interval

This printer setting allows you to specify the ARP (Address Resolution Protocol) interval or the ARP cache time out.

Commands	Details
setvar	This command instructs the printer to change the ARP interval or the ARP cache time out. Format: ! U1 setvar "ip.arp_interval" "value" Values: 0 - 30 Default: "0"
getvar	This command instructs the printer to respond with the ARP interval or the ARP cache time out value in seconds. Format: ! U1 getvar "ip.arp_interval"



Example: This setvar example shows the value set to "0".

```
! U1 setvar "ip.arp_interval" "0"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.bootp.enable

This printer setting turns BOOTP on or off. BOOTP is a method for acquiring an IP address, netmask, and gateway automatically on printer power-up. It requires a BOOTP server on the local network.



Note • If you are using static IP addressing, the IP protocol must be set to permanent.

Commands	Details
setvar	This command instructs the printer to turn BOOTP on or off. Format: ! U1 setvar "ip.bootp.enable" "value" Values: "off" = printer does not use BOOTP to get the IP address "on" = printer uses BOOTP to get the IP address Default: "on"
getvar	This command instructs the printer to respond with the current BOOTP setting. Format: ! U1 getvar "ip.bootp.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.bootp.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.arp_verify

This command configures the print server to send out an ARP request during the DHCP address negotiation. This is used to verify if the IP address received from the DHCP server is in use.

- If an ARP reply is received, a DHCP DECLINE message is sent to the DHCP server telling it that the received address cannot be used and then the normal DHCP procedure is restarted.
- If no ARP reply is received the DHCP address is used.

Commands	Details
setvar	This command instructs the printer to turn on ARP verify. Format: ! U1 setvar "ip.dhcp.arp_verify" "value" Values: "on" "off" Default: "off"
getvar	This command returns whether the printer will send the ARP request during the DHCP negotiation. Format: ! U1 getvar "ip.dhcp.arp_verify"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.dhcp.arp_verify" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.auto_provision_enable

This command prepares the printer to receive Weblink settings from the DHCP server. These settings are used to allow the printer to connect to on-premise or web-based servers.

If DHCP receives option 43 in the format of "**10642 <auto provision code> < auto provision settings>**" and the Client is not already configured, the client will use the configuration to connect to the server.

Using this feature requires configuring your DHCP server to send option 43 information during address assignment. The feature allows the printer to obtain the settings used to control Cloud Connect weblink connections or Mirror events as part of receiving a DHCP assigned IP address. This requires that DHCP option 60 is not empty and that `ip.dhcp.auto_provision_enable` is set to "on".

The package of Cloud Connect/weblink information sent from the DHCP server in the Option 43 response can include the:

- Server address
- Authentication server name
- User name and password for proxy logins

The package of Mirror information sent from the DHCP server in the Option 43 packet can include the:

- Server address
- Mirror path
- Mirror feedback path
- Mirror appl path
- Mirror mode

Commands	Details
setvar	This command enables or disables the DHCP auto provision feature of the printer. Format: ! U1 setvar "ip.dhcp.auto_provision_enable" "value" Values: "on" = enabled "off" = disabled Default: "off"
getvar	This command retrieves the current value of on or off for the DHCP auto provision feature. Format: ! U1 getvar "ip.dhcp.auto_provision_enable"

Supported Devices

- iMZ™ series
- QLn™ series
- ZT200™ series
- ZT400™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cache_ip

This command enables or disables the IP caching.

Commands	Details
setvar	<p>This command sets the status of the IP cache.</p> <p>Format: ! U1 setvar "ip.dhcp.cache_ip" "value"</p> <p>Values: "on" = enabled "off" = disabled</p> <p>Default: "off"</p>
getvar	<p>This command retrieves the status of the IP cache.</p> <p>Format: ! U1 getvar "ip.dhcp.cache_ip"</p>



Example: This setvar example shows the value set to "off".

```
! U1 setvar "ip.dhcp.cache_ip" "off"
```

When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cid_all

This printer setting defines the entire client identifier (DHCP option 61) if the DHCP is enabled and "ip.dhcp.cid_type" is set to "0", or "2". The MAC address is used if the type is set to "1".

Commands	Details
setvar	This command instructs the printer to change the CID prefix and suffix. Format: ! U1 setvar "ip.dhcp.cid_all" "value" Values: A maximum length of 60 characters if the CID type is ASCII, or 120 characters if the CID type is hexadecimal. Default: ""
getvar	This command instructs the printer to respond with the client identifier prefix and suffix. Format: ! U1 getvar "ip.dhcp.cid_all"



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "ip.dhcp.cid_all" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cid_enable

This command determines if DHCP (option 61) is turned on or off.

Commands	Details
setvar	This command instructs the printer to set the status of the client identifier. Format: ! U1 setvar "ip.dhcp.cid_enable" "value" Values: "off" = client identifier is turned off "on" = client identifier is turned on Default: "off"
getvar	This command instructs the printer to respond with the status of the client identifier. Format: ! U1 getvar "ip.dhcp.cid_enable"



Example: This setvar example shows the value set to "off".

```
! U1 setvar "ip.dhcp.cid_enable" "off"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cid_prefix

This printer setting defines the prefix to be prepended to the DHCP client identifier (option 61) when DHCP is enabled and "ip.dhcp.cid_type" is set to "0" or "2".

Commands	Details
setvar	This command instructs the printer to change the CID prefix. Format: ! U1 setvar "ip.dhcp.cid_prefix" "value" Values: Any text string up to 10 characters if the CID type is ASCII, or 20 characters if the CID type is hexadecimal. Default: ""
getvar	This command instructs the printer to respond with the client identifier prefix. Format: ! U1 getvar "ip.dhcp.cid_prefix"



Example: This setvar example sets the value to "ZEB".

```
! U1 setvar "ip.dhcp.cid_prefix" "ZEB"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "ZEB".

The next time the printer sends a DHCP request, if ip.dhcp.cid_type is "0", the client identifier sent will be prefixed with the string "ZEB". For example, if ip.dhcp.cid_value is "PRT001", the actual client identifier sent will be "ZEBPRT001"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cid_suffix

This printer setting defines the unique suffix to be used as the client identifier (DHCP option 61) if DHCP is enabled and "ip.dhcp.cid_type" is set to "0" or "2".

Commands	Details
setvar	This command instructs the printer to change the CID value. Format: ! U1 setvar "ip.dhcp.cid_suffix" "value" Values: The maximum length of a value allowed is 60 ASCII characters when the CID type is ASCII, or 120 hexadecimal values when the CID type is hexadecimal. Default: ""
getvar	This command instructs the printer to respond with the client identifier suffix. Format: ! U1 getvar "ip.dhcp.cid_suffix"



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "ip.dhcp.cid_suffix" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cid_type

This printer setting defines the type of client identifier (DHCP option 61) that will be sent if DHCP is enabled. A value of "1" means the type of "Ethernet" and the printer's MAC address will be used. A value of "0" or "2" means the client identifier sent will be "ip.dhcp.cid_prefix" concatenated with "ip.dhcp.cid_suffix".

Commands	Details
setvar	This command instructs the printer to set the Client Identifier type. Format: ! U1 setvar "ip.dhcp.cid_type" "value" Values: "0" = ASCII string "1" = wireless radio card's MAC address "2" = HEX value Default: "1"
getvar	This command instructs the printer to respond with the client identifier type. Format: ! U1 getvar "ip.dhcp.cid_type"



Example: This setvar example shows the value set to "1".

```
! U1 setvar "ip.dhcp.cid_type" "1"
```

When the setvar value is set to "1", the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.cid_value

This parameter defines the unique value to be used as the client identifier (option 61) if DHCP is enabled and "ip.dhcp.cid_type" is "1".



Note • This parameter is only applicable if [ip.dhcp.cid_enable](#) is set to "on".

Commands	Details
setvar	<p>This command instructs the printer to change the CID value.</p> <p>Format: ! U1 setvar "ip.dhcp.cid_value" "value"</p> <p>Values: Any text string up to 20 characters in length.</p> <p>Default: If ip.dhcp.cid_type is set to:</p> <ul style="list-style-type: none"> "0" — the default is the printer's friendly name (see device.friendly_name on page 647). "1" — the default is the printer's MAC address.
getvar	<p>This command instructs the printer to respond with the client identifier value.</p> <p>Format: ! U1 getvar "ip.dhcp.cid_value"</p>



Example: This setvar example changes the cid value to "PRT001".

```
! U1 setvar "ip.dhcp.cid_value" "PRT001"
```

The next time the printer sends a DHCP request, if [ip.dhcp.cid_type](#) is "0", the client identifier sent will be [ip.dhcp.cid_prefix](#) plus "PRT001". For example, if [ip.dhcp.cid_prefix](#) is "ZEB", the actual client identifier sent will be "ZEBPRT001"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.enable

This printer setting turns DHCP on or off. DHCP is a method for acquiring an IP address, netmask, and gateway automatically on printer power-up. It requires a DHCP server on the local network.



Note • If you are using static IP addressing, the IP protocol must be set to permanent.

Commands	Details
setvar	This command instructs the printer to turn DHCP on or off. Format: ! U1 setvar "ip.dhcp.enable" "value" Values: "off" = printer does not use DHCP to get the IP address "on" = printer uses DHCP to get the IP address Default: "on"
getvar	This command instructs the printer to respond with the DHCP status. Format: ! U1 getvar "ip.dhcp.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.dhcp.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.lease.last_attempt

This command retrieves the time from the DHCP server of when the last DHCP request was sent.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the last time a DHCP request was sent. Format: <code>! U1 getvar "ip.dhcp.lease.last_attempt"</code>



Example: In this example, the `getvar` retrieves the last time a DHCP request was sent to the wireless print server.

`! U1 getvar "ip.dhcp.lease.last_attempt"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.lease.server

This command retrieves the address of the server that provided the DHCP lease on the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the address of the server that provided the DHCP lease on the wireless print server. Format: ! U1 <code>getvar "ip.dhcp.lease.server"</code>



Example: In this example, the `getvar` retrieves the server that provided the DHCP lease on the wireless print server.

```
! U1 getvar "ip.dhcp.lease.server"
```

```
"10.3.5.1"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.lease.time_left

This command retrieves the time left in the current DHCP lease on the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the time left in the current DHCP lease on the wireless print server. Format: ! U1 <code>getvar "ip.dhcp.lease.time_left"</code>



Example: In this example, the `getvar` retrieves the time left in the current DHCP lease on the wireless print server.

```
! U1 getvar "ip.dhcp.lease.time_left"
```

```
"1192518"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.ntp.enable

This command controls whether or not the printer retrieves the address of a Network Time Protocol (NTP) server during DHCP address assignment.

Commands	Details
setvar	Format: ! U1 setvar "ip.dhcp.ntp.enable" "value" Values: "off" = does not request the NTP server address "on" = requests the NTP server address Default: "off"
getvar	Format: ! U1 getvar "ip.dhcp.ntp.enable"

Supported Devices

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.ntp.received_servers

Returns the list of Network Time Protocol (NTP) server IP Addresses received via DHCP.

Commands	Details
getvar	<p>Format: ! U1 getvar "ip.dhcp.ntp.received_servers"</p> <p>Values: A comma-separated list of IP address. The maximum number of servers listed will be three (3).</p> <p>Default: ""</p> <p>Example: "10.4.3.24,172.30.16.52"</p>

Supported Devices

- QLn220, QLn320, QLn420
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.option12

This command specifies if the DHCP option 12 (host name) is on or off in the discovery packet that is sent from the wireless print server.

Commands	Details
setvar	<p>This command instructs the printer to set the DHCP option 12 (host name) in the discovery packet that is sent from the wireless print server.</p> <p>Format: ! U1 setvar "ip.dhcp.option12" "value"</p> <p>Values:</p> <ul style="list-style-type: none">"on" = turns on option 12"off" = turns off option 12 <p>Default: "on"</p>
getvar	<p>This command retrieves the status of the DHCP option 12 (host name) in the discovery packet that is sent from the wireless print server.</p> <p>Format: ! U1 getvar "ip.dhcp.option12"</p>



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.dhcp.option12" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.option12_format

This command specifies the value which will be used for option 12 (host name) to be used in the DHCP discovery packet of the wireless print server.

Commands	Details
setvar	<p>This command instructs the printer to set the value which will be used for option 12 (host name) to be used in the DHCP discovery packet of the wireless print server.</p> <p>Format: ! U1 setvar "ip.dhcp.option12_format" "value"</p> <p>Values: string</p> <p>Default: ""</p>
getvar	<p>This command retrieves the value which will be used for option 12 (host name) to be used in the DHCP discovery packet of the wireless print server.</p> <p>Format: ! U1 getvar "ip.dhcp.option12_format"</p>



Example: This setvar example shows configuring the ip.dhcp.option12_format to the value contained in the device.friendly_name.

It is necessary to surround the SGD entry to be used as source for the data with the < and > characters.

```
! U1 setvar "ip.dhcp.option12_format" "<device.friendly_name>"
```

To further explain, if the above command was issued and the value currently stored in the device.friendly_name parameter was "ShipPrinter", then the response to following command would be "ShipPrinter":

```
! U1 getvar "ip.dhcp.option12_value"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.option12_value

This command retrieves the actual value which will be used in the discovery packet of the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the actual value which will be used in the discovery packet of the wireless print server. Format: <code>! U1 getvar "ip.dhcp.option12_value"</code>



Example: This `setvar` example shows configuring the `ip.dhcp.option12_format` to the value contained in the `device.friendly_name`.

It is necessary to surround the SGD entry to be used as source for the data with the `<` and `>` characters.

```
! U1 setvar "ip.dhcp.option12_format" "<device.friendly_name>"
```

To further explain, if the above command was issued and the value currently stored in the `device.friendly_name` parameter was "ShipPrinter", then the response to following command would be "ShipPrinter":

```
! U1 getvar "ip.dhcp.option12_value"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.request_timeout

This command retrieves the maximum amount of time (in seconds) for a DHCP discovery requests on the wireless print server.

Commands	Details
setvar	<p>This command instructs the printer to set the amount of time (in seconds) to wait before timing out a DHCP discovery request.</p> <p>Format: ! U1 setvar "ip.dhcp.request_timeout" "value"</p> <p>Values: "2" through "30"</p> <p>Default: "2"</p>
getvar	<p>This command retrieves the currently set the amount of time (in seconds) to wait before timing out a DHCP discovery request.</p> <p>Format: ! U1 getvar "ip.dhcp.request_timeout"</p>



Example: This setvar example shows the value set to "2".

```
! U1 setvar "ip.dhcp.request_timeout" "2"
```

When the setvar value is set to "2", the getvar result is "2".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.requests_per_session

This command retrieves the maximum amount of DHCP discovery requests for a single DHCP session on the wireless print server.

Commands	Details
setvar	This command instructs the printer to set the maximum amount of DHCP discovery requests for a single DHCP session on the wireless print server. Format: ! U1 setvar "ip.dhcp.requests_per_session" "value" Values: "1" through "10" Default: "2"
getvar	This command retrieves the currently set maximum amount of DHCP discovery requests for a single DHCP session on the wireless print server. Format: ! U1 getvar "ip.dhcp.requests_per_session"



Example: This setvar example shows the value set to "2".

```
! U1 setvar "ip.dhcp.requests_per_session" "2"
```

When the setvar value is set to "2", the getvar result is "2".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.session_interval

This command configures the time interval (in seconds) before a new DHCP session is started on the wireless print server.

Commands	Details
setvar	This command instructs the printer to set the DHCP session time out value (in seconds). Format: ! U1 setvar "ip.dhcp.session_interval" "value" Values: "0" through "60" Default: "10"
getvar	This command retrieves the current DHCP session time out value (in seconds). Format: ! U1 getvar "ip.dhcp.session_interval"



Example: This setvar example shows the value set to "10".

```
! U1 setvar "ip.dhcp.session_interval" "10"
```

When the setvar value is set to "10", the getvar result is "10".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.user_class_id

This command sets or retrieves the current DHCP class ID setting.

Commands	Details
setvar	Format: ! U1 setvar "ip.dhcp.user_class_id" "value" Values: any class ID string, Default: ""
getvar	Format: ! U1 getvar "ip.dhcp.user_class_id" Result: the current DHCP class ID setting.

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- QLn420, ZD410
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dhcp.vendor_class_id

This command configures the DHCP vendor class ID setting.

Commands	Details
setvar	<p>This command sets the DHCP vendor class ID setting.</p> <p>Format: ! U1 setvar "ip.dhcp.vendor_class_id" "value"</p> <p>Values: Max string length of 64.</p> <p>This command builds a string using the following values: (device.company_name) (device.product_name)-(head.resolution.in_dpi) (device.pnp_option)</p> <p>Default: <i>The default varies by printer.</i></p>
getvar	<p>This command retrieves the current DHCP vendor class ID setting.</p> <p>Format: ! U1 getvar "ip.dhcp.vendor_class_id"</p>



Example: For a Zebra ZT230 printer set at 203dpi, the result would be:
Zebra Technologies ZTC ZT230-2003dpi ZPL

Supported Devices

- iMz™ series
- QLn™ series
- ZT200™ series
- ZD500R™ series
- ZT400™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dns.domain

This command identifies the network domain of the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the network domain of the wireless print server. Format: <code>! U1 getvar "ip.dns.domain"</code>



Example: In this example, the `getvar` retrieves the network domain of the wireless print server.

`! U1 getvar "ip.dns.domain"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.dns.servers

This command retrieves a space delimited list of the domain name servers from a wireless print server.

getvar

Commands	Details
getvar	This command retrieves a list of space delimited DNS wireless print servers. Format: ! U1 getvar "ip.dns.servers"



Example: In this example, the `getvar` retrieves a list of space delimited DNS wireless print servers.
! U1 getvar "ip.dns.servers"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.ftp.enable

This printer setting refers to the FTP protocol setting. This command tells the printer to turn FTP on or off.

Commands	Details
setvar	This command instructs the printer to turn FTP on or off. Format: ! U1 setvar "ip.ftp.enable" "value" Values: "off" = disables FTP "on" = enables FTP Default: "on"
getvar	This command instructs the printer to respond with the FTP status. Format: ! U1 getvar "ip.ftp.enable"



Example: This setvar example shows the FTP status set to "on".

```
! U1 setvar "ip.ftp.enable" "on"
```

When the setvar value is set to "on", the getvar result is that the FTP status is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.ftp.execute_file

This command setting controls the printers' ability to process or not process commands received via the FTP protocol using the printers ZPL engine.

Commands	Details
setvar	<p>This command instructs the printer to turn FTP processing ability on or off.</p> <p>Format: ! U1 setvar "ip.ftp.execute_file" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "off" = disables the printer's ability to process FTP commands "on" = enables the printer's ability to process FTP commands <p>Default: "on"</p>
getvar	<p>This command instructs the printer to respond with the FTP processing ability status.</p> <p>Format: ! U1 getvar "ip.ftp.execute_file"</p>



Example: This setvar example shows the FTP processing ability set to "on".

```
! U1 setvar "ip.ftp.execute_file" "on"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.ftp.request_password

This command controls whether the ftp client will prompt the user to enter a password at the beginning of an ftp session.

Commands	Details
setvar	This command instructs the printer to turn on or off the ftp session password request. Format: ! U1 setvar "ip.ftp.request_password" "value" Values: "no" "yes" Default: "no"
getvar	This command returns whether the ftp client is set to prompt the user for a password at the start of an ftp session. Format: ! U1 getvar "ip.ftp.request_password"



Example: This setvar example shows the value set to "yes".
! U1 setvar "ip.ftp.request_password" "yes"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.gateway

This command instructs the printer to change the gateway address.



Important • This setting refers to the gateway address. A set value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the gateway address. Format: ! U1 setvar "ip.gateway" "value" Values: Any valid gateway address Default: "0.0.0.0"
getvar	This command instructs the printer to respond with the gateway address. Format: ! U1 getvar "ip.gateway"



Example: This setvar example shows the value set to "10.3.5.1".

```
! U1 setvar "ip.gateway" "10.3.5.1"
```

When the setvar value is set to "10.3.5.1", the getvar result is "10.3.5.1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.admin_name

This command sets the name to be used for authentication on the print server web pages.

Commands	Details
setvar	This command instructs the printer to set the admin user name to the specified value. Format: ! U1 setvar "ip.http.admin_name" "value" Values: a string with a maximum of 25 characters Default: "admin"
getvar	This command instructs the printer to respond with the admin user name. Format: ! U1 getvar "ip.http.admin_name" Result: A user name



Example: This setvar example shows the value set to "useradmin101".
! U1 setvar "ip.http.admin_name" "useradmin101"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.admin_password

This command sets the password to be used for authentication on the print server web pages.

Commands	Details
setvar	This command instructs the printer to set print server web page password. Format: ! U1 setvar "ip.http.admin_password" "value" Values: a string, maximum 25 characters Default: 1234
getvar	This command instructs the printer to respond with the print server web page password. Format: ! U1 getvar "ip.http.admin_password"



Example: This setvar example shows the value set to "P@ssword101".
! U1 setvar "ip.http.admin_password" "P@ssword101"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.custom_link_name

This command creates a custom link below the FAQ link on the print server settings page. Use [ip.http.custom_link_url on page 1113](#) to define the URL for your link name.

Commands	Details
setvar	This command instructs the printer to set the custom link name. Format: ! U1 setvar "ip.http.custom_link_name" "value" Values: Any string, maximum of 25 characters Default: ""
getvar	This command instructs the printer to respond with the custom link name. Format: ! U1 getvar "ip.http.custom_link_name"



Example: This setvar example shows the value set to "Click Here for Info".
! U1 setvar "ip.http.custom_link_name" "Click Here for Info"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.custom_link_url

This command creates a custom link on the printer web page for the printer's URL. Use [ip.http.custom_link_name on page 1112](#) to define the text that will display for your link.

Commands	Details
setvar	This command instructs the printer to change the custom URL. Format: ! U1 setvar "ip.http.custom_link_url" "value" Values: A string of 64 characters or less Default: ""
getvar	This command instructs the printer to respond with the custom URL. Format: ! U1 getvar "ip.http.custom_link_url"



Example:

```
! U1 setvar "ip.http.custom_link_url" "http://www.zebra.com/sdk"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.enable

This printer setting refers to the HTTP protocol/web server setting.

Commands	Details
setvar	This command instructs the printer to change HTTP to on or off. Format: ! U1 setvar "ip.http.enable" "value" Values: "off" = disables HTTP protocol "on" = enables HTTP protocol Default: "on"
getvar	This command instructs the printer to respond with the HTTP status. Format: ! U1 getvar "ip.http.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.http.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.faq_url

This command sets the FAQ URL displayed on the printer web pages.

Commands	Details
setvar	This command instructs the printer to change the FAQ URL. Format: ! U1 setvar "ip.http.faq_url" "value" Values: A string of 64 characters or less. Default: ""
getvar	This command instructs the printer to respond with the current FAQ URL. Format: ! U1 getvar "ip.http.faq_url"



Example:

```
! U1 setvar "ip.http.faq_url" "http://www.yoursite.com/faq"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.http.port

This command sets the port number at which the printer web pages will be served.

Commands	Details
setvar	This command instructs the printer to change the port setting for the printer web pages. Format: ! U1 setvar "ip.http.port" "value" Values: "0" to "65535" Default: "80"
getvar	This command instructs the printer to respond with the current port setting for the printer web pages. Format: ! U1 getvar "ip.http.port"



Example: This setvar example shows the value set to "8080".
! U1 setvar "ip.http.enable" "8080"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.lpd.enable

This printer setting refers to the LPD (Line Printer Daemon) protocol setting.



Important • LPD communications from the host should be directed to port 515.

Commands	Details
setvar	This command instructs the printer to turn LPD on or off. Format: ! U1 setvar "ip.lpd.enable" "value" Values: "off" = disables LPD protocol "on" = enables LPD protocol Default: "on"
getvar	This command instructs the printer to respond with the LPD status. Format: ! U1 getvar "ip.lpd.enable"



Example: This `setvar` example shows the value set to "on".

```
! U1 setvar "ip.lpd.enable" "on"
```

When the `setvar` value is set to "on", the `getvar` result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mac_raw

This command specifies the RAW MAC address of the wireless print server. The raw mac address is the mac address without the colons (":").

getvar

Commands	Details
getvar	This command retrieves the RAW MAC address of the wireless print server. Format: ! U1 getvar "ip.mac_raw"



Example: In this example, the `getvar` retrieves the RAW MAC address of the wireless print server.
! U1 getvar "ip.mac_raw"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.appl_path



This command overrides the default location of the mirror application path ("appl" in "ip.mirror.path"). If the SGD is empty, the default path is used. If an error occurs retrieving application from path (i.e. path not found or application not there), the default path is NOT used. This path must be fully defined in relation to the mirror server root and is not relative to [ip.mirror.path](#).

Commands	Details
setvar	This command sets the path to the application on the mirror server. Format: ! U1 setvar "ip.mirror.appl_path" "values" Values: A valid application path (location) Default: ""
getvar	This command retrieves the path to the application on the mirror server. Format: ! U1 getvar "ip.mirror.appl_path"



Example: If the default value is used, the application would be copied from "ip.mirror.path"\appl
If you send ! U1 setvar "ip.mirror.appl_path" "program\current" and "ip.mirror.path" has the value "c:\mirror", then the application would be copied from c:\mirror\program\current.

Supported Devices

- iMz™ series
- QLn™ series
- ZT200™ series
- ZD500R™ series
- ZT400™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.auto



This command enables the ability to automatically perform a mirror update (fetch) command on power up.

Commands	Details
setvar	This command instructs the printer to perform a mirror update (fetch) command when the printer is turned on using the interval that is set for "ip.mirror.freq" or "ip.mirror.freq_hours". Format: ! U1 setvar "ip.mirror.auto" "values" Values: "on" = turns on the auto mirroring feature "off" = turns off the auto mirroring feature Default: "off"
getvar	This command will report whether the printer will perform a mirror update (fetch) automatically on power up. Format: ! U1 getvar "ip.mirror.auto"



Example: This setvar example shows the value set to "off".

```
! U1 setvar "ip.mirror.auto" "off"
```

When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.error_retry



This command identifies how many times mirroring is retried when an error occurs.

Commands	Details
setvar	<p>This command instructs the printer to set the required times that mirroring retries when an error occurs.</p> <p>Format: ! U1 setvar "ip.mirror.error_retry" "value"</p> <p>Values: numeric values (0 - 65535)</p> <p>Default: "0"</p>
getvar	<p>This command retrieves the number of times the printer retries mirroring when an error occurs.</p> <p>Format: ! U1 getvar "ip.mirror.error_retry"</p>



Example: This setvar example shows the value set to "0".

```
! U1 setvar "ip.mirror.error_retry" "0"
```

When the setvar value is set to "0", the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.feedback.auto



This command identifies if a feedback file is pushed to the mirroring server by the printer when a mirroring update (fetch) is complete.

Commands	Details
setvar	This command instructs the printer to set the mirror feedback feature to on or off. Format: ! U1 setvar "ip.mirror.feedback.auto" "value" Values: "on" = turns on mirror feedback "off" = turns off mirror feedback Default: "off"
getvar	This command retrieves the mirror feedback setting that the printer is currently using. Format: ! U1 getvar "ip.mirror.feedback.auto"



Example: This setvar example shows the value set to "off".
 ! U1 setvar "ip.mirror.feedback.auto" "off"
When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.feedback.freq



This command specifies the time interval (in minutes) between performing feedback file uploads.

Commands	Details
setvar	<p>This command instructs the printer to set the number of minutes to wait between feedback file uploads.</p> <p>Format: ! U1 setvar "ip.mirror.feedback.freq" "value"</p> <p>Values: numeric value (0 - 65535)</p> <p>Default: "0"</p>
getvar	<p>This command retrieves the number of minutes set to wait between feedback file uploads.</p> <p>Format: ! U1 getvar "ip.mirror.feedback.freq"</p>



Example: This setvar example shows the value set to "0".

```
! U1 setvar "ip.mirror.feedback.freq" "0"
```

When the setvar value is set to "0", the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.feedback.odometer



This command instructs the printer to set the mirror feedback odometer.

Commands	Details
setvar	This command instructs the printer to set the odometer counter. Format: ! U1 setvar "ip.mirror.feedback.odometer" "values" Values: numeric value between 0 and 4294967295 Default: "0"
getvar	This command retrieves the mirror feedback odometer. Format: ! U1 getvar "ip.mirror.feedback.odometer"



Example: This setvar example shows the value set to "0".

```
! U1 setvar "ip.mirror.feedback.odometer" "0"
```

When the setvar value is set to "0", the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.feedback.path



This command identifies where the feedback file is stored on the mirroring server.

Commands	Details
setvar	<p>This command instructs the printer to set the path on the mirroring server that stores the feedback file.</p> <p>Format: ! U1 setvar "ip.mirror.feedback.path" "value"</p> <p>Values: alphanumeric text (1 to 50 characters)</p> <p>Default: "Zebra/feedback"</p>
getvar	<p>This command retrieves the path on the mirroring sever that the printer is currently using to store the feedback file.</p> <p>Format: ! U1 getvar "ip.mirror.feedback.path"</p>



Example: This setvar example shows the value set to "Zebra/feedback".

```
! U1 setvar "ip.mirror.feedback.path" "Zebra/feedback"
```

When the setvar value is set to "Zebra/feedback", the getvar result is "Zebra/feedback".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.fetch



This command forces a mirroring update sequence.
setvar;do

Commands	Details
setvar	This command forces a mirroring update sequence. Format: ! U1 setvar "ip.mirror.fetch" ""
do	This command forces a mirroring update sequence. Format: ! U1 do "ip.mirror.fetch" ""



Example: This setvar example forces a mirroring update sequence.
! U1 setvar "ip.mirror.fetch" ""




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.freq



This command defines the frequency of mirroring updates (in minutes).

Commands	Details
setvar	<p>This command instructs the printer to set the mirror frequency.</p> <p>Format: ! U1 setvar "ip.mirror.freq" "value"</p> <p>Values: "0" through "65535" (minutes)</p> <p>Default: "0" (disables this feature)</p> <p> Important • When the "ip.mirror.freq" is set to a low value (other than zero) the printer will spend a lot of time performing the mirroring process.</p>
getvar	<p>This command retrieves the number of minutes to wait before performing another mirror update.</p> <p>Format: ! U1 getvar "ip.mirror.freq"</p>



Example: This setvar example shows the value set to "1000".

```
! U1 setvar "ip.mirror.freq" "1000"
```

When the setvar value is set to "1000", the getvar result is "1000" and mirroring will be attempted every 1000 minutes.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.freq_hours



This command defines the frequency of mirroring updates (in hours).

Commands	Details
setvar	This command instructs the printer to set the frequency of mirroring updates (in hours). Format: ! U1 setvar "ip.mirror.freq_hours" "values" Values: "0" through "100" Default: "0" (disables this feature)
getvar	This command retrieves the frequency of mirroring updates (in hours) that the printer is currently using. Format: ! U1 getvar "ip.mirror.freq_hours"



Example: This setvar example shows the value set to "8".

```
! U1 setvar "ip.mirror.freq_hours" "8"
```

When the setvar value is set to "8", the getvar result is "8" and mirroring will be attempted every 8 hours.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.interface

Determines the interface over which Mirror will operate.

Commands	Details
setvar	<p>Format: ! U1 setvar "ip.mirror.interface" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "both" = internal or external wired and WLAN "wired" = internal or external wired "wireless" = WLAN <p>Default: "both"</p>
getvar	<p>Format: ! U1 getvar "ip.mirror.interface"</p>

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.last_error



This command retrieves the last error encountered during a mirroring operation.

getvar

Commands	Details
getvar	This command retrieves the error code of the last mirroring update (fetch). Format: ! U1 getvar "ip.mirror.last_error"



Example: In this example, the `getvar` retrieves the error code of the last mirroring update.

```
! U1 getvar "ip.mirror.last_error"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.last_time



This command retrieves the timestamp, in seconds, of the last time the system attempted a mirror update (fetch).

getvar

Commands	Details
getvar	This command retrieves the timestamp, in seconds, of the last time the system attempted a mirror update (fetch). Format: ! U1 getvar "ip.mirror.last_time"



Example: In this example, the `getvar` retrieves the timestamp, in seconds, of the last time the system attempted a mirror update.

```
! U1 getvar "ip.mirror.last_time"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.mode



This command sets the protocol used to perform mirror tasks.

Commands	Details
setvar	This command sets the protocol for mirror tasks. Format: ! U1 setvar "ip.mirror.mode" "values" Values: <ul style="list-style-type: none">• ftp - FTP protocol will be used to perform mirror tasks• sftp - SFTP protocol will be used to perform mirror tasks Default: "ftp"
getvar	This command retrieves the path to the application on the mirror server. Format: ! U1 getvar "ip.mirror.mode"

Supported Devices

- iMz™ series
- QLn™ series
- ZT200™ series
- ZD500R™ series
- ZT400™ series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.password



This command specifies the user password on the mirroring server assigned for mirroring updates (fetch).

Commands	Details
setvar	This command instructs the printer to use a specific password for mirroring updates (fetch). Format: ! U1 setvar "ip.mirror.password" "value" Values: alphanumeric text string (1 to 20 characters) Default: "password"
getvar	This command retrieves the user password the printer is currently using for mirroring updates (fetch). Format: ! U1 getvar "ip.mirror.password"



Example: This setvar example shows the value set to "password".

```
! U1 setvar "ip.mirror.password" "password"
```

When the setvar value is set to "password", the getvar result is "*". For security purposes, the printer does not return password information.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.path



This command identifies the base path on the FTP server where the mirror directory resides.

Commands	Details
setvar	This command sets the base path on the FTP server where the mirror directory resides. Format: ! U1 setvar "ip.mirror.path" "value" Values: alphanumeric text string (1 to 50 characters) Default: "zebra"
getvar	This command retrieves the base path of the FTP server where the mirror directory resides. Format: ! U1 getvar "ip.mirror.path"



Example: This setvar example shows the value set to "zebra".

```
! U1 setvar "ip.mirror.path" "zebra"
```

When the setvar value is set to "zebra", the getvar result is "zebra".




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.reset_delay



This command specifies the number of seconds between when the printer receives the last byte of the last file from the /commands directory and when the printer resets during a mirror event.

Commands	Details
setvar	<p>This command sets the number of seconds between when the printer receives the last byte of the last file from the /commands directory and when the printer resets during a mirror event.</p> <p>Format: ! U1 setvar "ip.mirror.reset_delay" "value"</p> <p>Values: 0 - 900 (seconds)</p> <p>Default: "5"</p> <p> The default setting for the ip.mirror.reset_delay command is 5 seconds; in some cases it may be necessary to use a longer delay to allow for full processing of longer or more complex files.</p>
getvar	<p>This command retrieves the number of seconds between when the printer receives the last byte of the last file from the /commands directory and when the printer resets during a mirror event.</p> <p>Format: ! U1 getvar "ip.mirror.reset_delay"</p>



Example: This setvar example shows the value set to "10".
! U1 setvar "ip.mirror.reset_delay" "10"
When the setvar value is set to "10", the getvar result is "10".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.server



This command identifies the IP address of the mirroring server.

Commands	Details
setvar	This command sets the IP address of the mirroring server. Format: ! U1 setvar "ip.mirror.server" "value" Values: a valid IP address Default: "127.0.0.1"
getvar	This command retrieves the IP address of the mirroring server. Format: ! U1 getvar "ip.mirror.server"



Example: This setvar example shows the value set to "10.3.1.1".

```
! U1 setvar "ip.mirror.server" "10.3.1.1"
```

When the setvar value is set to "10.3.1.1", the getvar result is "10.3.1.1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.success



This command reports the success or failure of the last mirroring update (fetch).

getvar

Commands	Details
getvar	<p>This command retrieves the success or failure of the last mirroring update (fetch).</p> <p>Format: ! U1 getvar "ip.mirror.success"</p> <p>Values: "yes" = successful "no" = unsuccessful</p>



Example: In this example, the `getvar` retrieves the success or failure of the last mirroring update (fetch).

```
! U1 getvar "ip.mirror.success"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.success_time



This command provides the timestamp, in seconds, of the last time the system successfully completed a mirror update (fetch).

getvar

Commands	Details
getvar	This command retrieves the timestamp, in seconds, of the last time the system successfully completed a mirror update (fetch). Format: ! U1 getvar "ip.mirror.success_time"



Example: In this example, the `getvar` retrieves the timestamp of the last time the system successfully completed a mirror update.

```
! U1 getvar "ip.mirror.success_time"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.username



This command specifies the user name on the mirroring server assigned for mirroring updates (fetch).

Commands	Details
setvar	This command instructs the printer to use a specific user name for mirroring updates (fetch). Format: ! U1 setvar "ip.mirror.username" "value" Values: alphanumeric text string (1 to 20 characters) Default: "user"
getvar	This command retrieves the user name the printer is currently using for mirroring updates (fetch). Format: ! U1 getvar "ip.mirror.username"



Example: This setvar example shows the value set to "user".

```
! U1 setvar "ip.mirror.username" "user"
```

When the setvar value is set to "user", the getvar result is "user".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.mirror.version



This command retrieves the mirror code build date.

getvar

Commands	Details
getvar	This command retrieves the mirror code build date. Format: ! U1 getvar "ip.mirror.version"



Example: In this example, the `getvar` retrieves the mirror code build date.

`! U1 getvar "ip.mirror.version"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.netmask

This setting refers to the subnet mask address. This value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the subnet mask. Format: ! U1 setvar "ip.netmask" "value" Values: Any valid subnet mask. Default: "255.255.255.0"
getvar	This command instructs the printer to respond with subnet mask. Format: ! U1 getvar "ip.netmask"



Example: This setvar example shows the value set to "255.255.255.0".

```
! U1 setvar "ip.netmask" "255.255.255.0"
```

When the setvar value is set to "255.255.255.0", the getvar result is "255.255.255.0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.ntp.enable

Enables or disables the Network Time Protocol (NTP) feature.

Commands	Details
setvar	Format: ! U1 setvar "ip.ntp.enable" "value" Values: "on" = enabled "off" = disabled Default: "off"
getvar	Format: ! U1 getvar "ip.ntp.enable"

Supported Devices

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

ip.ntp.log

Retrieves the Network Time Protocol (NTP) status and error log. If NTP is not running this will return "File Not Found" for the error log.

Commands	Details
getvar	Format: ! U1 getvar "ip.ntp.log" Default: "File Not Found"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.ntp.servers

Sets the list of NTP (Network Time Protocol) servers which the printer will use to set the time.

Commands	Details
setvar	Format: ! U1 setvar "ip.ntp.servers" "value" Values: A comma delimited string of server name(s) or ip address(es), with a length of 0-1024 characters. Default: "" Example: ! U1 setvar "ip.ntp.servers" "0.us.pool.ntp.org,10.3.17.124"
getvar	Format: ! U1 getvar "ip.ntp.servers" Result: A comma delimited string of server name(s) or ip address(es).

Supported Devices

- QLn220,QLn320, QLn420
- ZQ510, ZQ520
- ZR638, ZR628
- ZT210, ZT220, ZT230



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.pop3.enable

This printer setting determines if the printer queries a POP3 mailbox for mail.

Commands	Details
setvar	This command instructs the printer to turn POP3 on or off. Format: ! U1 setvar "ip.pop3.enable" "value" Values: "off" = disables POP3 "on" = enables POP3 Default: "on"
getvar	This command instructs the printer to respond with the POP3 status. Format: ! U1 getvar "ip.pop3.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.pop3.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.pop3.password

This printer setting refers to the POP3 mailbox password. This only applies if "ip.pop3.enable" is set to on.

Commands	Details
setvar	This command instructs the printer to change the POP3 password. Format: ! U1 setvar "ip.pop3.password" "value" Values: A maximum of 20 alphanumeric characters Default: " "
getvar	This command instructs the printer to respond with the POP3 password. Format: ! U1 getvar "ip.pop3.password" For protection a single "*" prints.



Example: This setvar example shows the value set to "password".

```
! U1 setvar "ip.pop3.password" "password"
```

When the setvar value is set to "password", the getvar result is "*".




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.pop3.poll

This printer setting refers to how frequent (in seconds) the printer queries a POP3 mailbox for new mail. This only applies if the "ip.pop3.enable" is set to on.

Commands	Details
setvar	<p>This command instructs the printer to change the POP3 poll interval. A value of "0" causes the printer to only query the POP3 mailbox one time, on printer power up, or following a network reset.</p> <p>Format: ! U1 setvar "ip.pop3.poll" "value"</p> <p>Values: "0" through "65535"</p> <p>Default: "0"</p> <p> Note • A poll value of less than thirty seconds is not recommended. The printer is unresponsive for several seconds when polling for email depending on data transfer time from the server to the printer.</p>
getvar	<p>This command instructs the printer to respond with the POP3 poll frequency (in seconds).</p> <p>Format: ! U1 getvar "ip.pop3.poll"</p>



Example: This setvar example shows the value set to "0".

```
! U1 setvar "ip.pop3.poll" "0"
```

When the setvar value is set to "0", the getvar result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.pop3.server_addr

This printer setting refers to the POP3 server IP address that the printer contacts when checking for new mail. This only applies if "ip.pop3.enable" is set to on.

Commands	Details
setvar	This command instructs the printer to change the POP3 server address. Format: ! U1 setvar "ip.pop3.server_addr" "value" Values: Any valid POP3 server address Default: "0.0.0.0"
getvar	This command instructs the printer to respond with the POP3 server address. Format: ! U1 getvar "ip.pop3.server_addr"



Example: This setvar example shows the value set to "10.3.5.10".

```
! U1 setvar "ip.pop3.server_addr" "10.3.5.10"
```

When the setvar value is set to "10.3.5.10", the getvar result is "10.3.5.10".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.pop3.username

This printer setting refers to the POP3 user name. This only applies if the "ip.pop3.enable" is set to on.

Commands	Details
setvar	This command instructs the printer to change the POP3 user name. Format: ! U1 setvar "ip.pop3.username" "value" Values: A maximum of 20 alphanumeric characters Default: " "
getvar	This command instructs the printer to respond with the POP3 user name. Format: ! U1 getvar "ip.pop3.username"



Example: This setvar example shows the value set to "user".

```
! U1 setvar "ip.pop3.username" "user"
```

When the setvar value is set to "user", the getvar result is "user".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.port

This printer setting refers to the port number that the TCP print service is listening on. Normal TCP communications from the host should be directed to this port.

Commands	Details
setvar	This command instructs the printer to set the TCP/UDP port number. Format: ! U1 setvar "ip.port" "value" Values: 1 - 65535 (excluding any ports currently used by other services, such as 21, 23, 80, and 515). Default: "9100"
getvar	This command instructs the printer to respond with the TCP/UDP port number. Format: ! U1 getvar "ip.port"



Example: This setvar example shows the value set to "9100".

```
! U1 setvar "ip.port" "9100"
```

When the setvar value is set to "9100", the getvar result is "9100".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.port_alternate

This command sets the port number of the alternate port.



Note • Print servers supporting this command will monitor both the primary port and the alternate port for connections at the same time.

Commands	Details
setvar	This command sets the alternate port for the print server. Format: ! U1 setvar "ip.port_alternate" "value" Values: Any valid TCP port address. Default: "9100"
getvar	This command returns the current alternate port setting. Format: ! U1 getvar "ip.port_alternate" Values: The current port setting.



Example: This setvar example shows the value set to "6101".

```
U1 setvar "ip.port_alternate" "6101"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.port_json_config

This printer setting refers to the port number that the TCP print service is listening on for JSON configuration packets. JSON TCP communications from the host should be directed to this port.

Commands	Details
setvar	This command instructs the printer to set the JSON TCP port number. Format: ! U1 setvar "ip.port_json_config" "value" Values: 0 = Disable the port 1 - 65535 (excluding any ports currently used by other services, such as 21, 23, 80, and 515). Default: "9200"
getvar	This command instructs the printer to respond with the JSON TCP port number. Format: ! U1 getvar "ip.port_json_config"



Example: This setvar example shows the value set to "9200".

```
! U1 setvar "ip.port_json_config" "9200"
```

When the setvar value is set to "9200", the getvar result is "9200".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.port_single_conn

This command configures the port number for the single connection IP port. The single-connection IP port allows only one connection at a time.

See "ip.port_single_conn_idle_timeout" for additional information.

Commands	Details
setvar	<p>Format: ! U1 setvar "ip.port_single_conn" "value"</p> <p>Values: A number between 1 and 65535. This number specifies the port.</p> <p>Default: "9300"</p>
getvar	<p>Format: ! U1 getvar "ip.port_single_conn"</p> <p>Result: A port number between 1 and 65535.</p>

Supported Devices

- iMZ220, iM320
- QLn320, QLn220
- ZD410, ZD420
- ZD500, ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.port_single_conn_idle_timeout

Sets the amount of time that must elapse with no activity for the single-connection IP port to be considered in the idle state.

When the port is idle and a new connection is requested, the currently open connection will be closed and a new connection will be opened. If the port is not in the idle state, the current connection will be maintained and the connection request will be refused with an error response.

Commands	Details
setvar	Format: ! U1 setvar "ip.port_single_conn_idle_timeout" "value" Values: A number between 1 and 65535. The value is in seconds. If the value is 0, the port will be considered to be in the idle state. Default: "180"
getvar	Format: ! U1 getvar "ip.port_single_conn_idle_timeout" Result: A number between 1 and 65535. The value is in seconds. If the value is 0, the port will be considered to be in the idle state.

Supported Devices

- iMZ220, iM320
- QLn320, QLn220
- ZD410, ZD420
- ZD500, ZQ510, ZQ520
- ZR638, ZR628
- ZT230, ZT220, ZT210
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.primary_network

This command allows you to set the primary network to either wired or wireless.

Commands	Details
setvar	<p>This command instructs the printer to set the primary network device.</p> <p>Format: ! U1 setvar "ip.primary_network" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> 1 = wired 2 = wireless <p>Default: "1"</p>
getvar	<p>This command instructs the printer to respond with the name of the current primary network device.</p> <p>Format: ! U1 getvar "ip.primary_network"</p>



Example: This setvar example shows the value set to "1".

```
! U1 setvar "ip.primary_network" "1"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.smtp.domain

This printer setting refers to the domain name used by the printer in sending email with respect to the SMTP server.

Commands	Details
setvar	This command instructs the printer to change the SMTP domain name. Format: ! U1 setvar "ip.smtp.domain" "value" Values: A maximum of 24 alphanumeric characters Default: "ZBRPrintServer"
getvar	This command instructs the printer to return the SMTP domain name. Format: ! U1 getvar "ip.smtp.domain"



Example: This setvar example shows the value set to "ZBRPrintServer.com".

```
! U1 setvar "ip.smtp.domain" "ZBRPrintServer.com"
```

When the setvar value is set to "ZBRPrintServer.com", the getvar result is "ZBRPrintServer.com".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.smtp.enable

This printer setting refers to the SMTP protocol.

Commands	Details
setvar	This command instructs the printer to turn SMTP on or off. Format: ! U1 setvar "ip.smtp.enable" "value" Values: "off" = disables SMTP "on" = enables SMTP Default: "on"
getvar	This command instructs the printer to return the SMTP status. Format: ! U1 getvar "ip.smtp.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.smtp.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.smtp.server_addr

This printer setting refers to the IP address of the SMTP server used for sending email.

Commands	Details
setvar	This command instructs the printer to change the SMTP server address. Format: ! U1 setvar "ip.smtp.server_addr" "value" Values: Any valid IP address. Default: 0.0.0.0
getvar	This command instructs the printer to respond with the current SMTP server address. Format: ! U1 getvar "ip.smtp.server_addr"



Example: This setvar example shows the value set to 10.10.10.10.

```
! U1 setvar "ip.smtp.server_addr" "10.10.10.10"
```

When the setvar value is set to "10.10.10.10", the getvar result is "10.10.10.10".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.snmp.get_community_name

This printer setting is used when making SNMP queries. The SNMP client must supply the get community name that matches the printer's get community name in order to query any SNMP data.

Commands	Details
setvar	<p>This command instructs the printer to set the SNMP get community name string.</p> <p>Format:</p> <pre>! U1 setvar "ip.snmp.get_community_name" "value"</pre> <p>Values: A maximum of 19 alphanumeric characters.</p> <p>Default: "public"</p>
getvar	<p>This command instructs the printer to get the SNMP get community name string.</p> <p>Format: ! U1 getvar "ip.snmp.get_community_name"</p> <p>For protection a single "*" prints.</p>



Example: This setvar example shows the value set to "public".

```
! U1 setvar "ip.snmp.get_community_name" "public"
```

When the setvar value is set to "public", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.snmp.set_community_name

This printer setting is used when changing SNMP data remotely. To alter any SNMP data, the SNMP client must supply the set community name that matches the printer's set community name.

Commands	Details
setvar	This command instructs the printer to set the SNMP set community name string. Format: ! U1 setvar "ip.snmp.set_community_name" "value" Values: A maximum of 19 alphanumeric characters Default: "public"
getvar	This command instructs the printer to return the printer's SNMP set community name string. Format: ! U1 getvar "ip.snmp.set_community_name" For protection a single "*" returns.



Example: This setvar example shows the value set to "public".

```
! U1 setvar "ip.snmp.set_community_name" "public"
```

When the setvar value is set to "public", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.snmp.trap_community_name

This command sets the SNMP Trap Community name of the print server.

Commands	Details
setvar	This command instructs the printer to set the SNMP trap community name. Format: ! U1 setvar "ip.snmp.get_community_name" "value" Values: A maximum of 20 alphanumeric characters. Default: "public"
getvar	This command instructs the printer to get the SNMP trap community name. Format: ! U1 getvar "ip.snmp.trap_community_name"



Example:

```
! U1 setvar "ip.snmp.trap_community_name" "public"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.snmp.enable

This printer setting refers to the SNMP protocol.

Commands	Details
setvar	This command instructs the printer to enable or disable the SNMP protocol. Format: ! U1 setvar "ip.snmp.enable" "value" Values: "on" = enable the SNMP protocol "off" = disable the SNMP protocol Default: "on"
getvar	This command instructs the printer to respond with the SNMP status. Format: ! U1 getvar "ip.snmp.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.snmp.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.tcp.enable

This printer setting refers to the TCP socket protocol.

Commands	Details
setvar	This command instructs the printer to turn the TCP on or off. Format: ! U1 setvar "ip.tcp.enable" "value" Values: "off" = disables TCP protocol "on" = enables TCP protocol Default: "on"
getvar	This command instructs the printer to respond with the TCP status. Format: ! U1 getvar "ip.tcp.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.tcp.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.telnet.enable

This printer setting refers to the TELNET (port 23) protocol.

Commands	Details
setvar	This command instructs the printer to turn TELNET on or off. Format: ! U1 setvar "ip.telnet.enable" "value" Values: "off" = disables telnet protocol "on" = enables telnet protocol Default: "on"
getvar	This command instructs the printer to respond with the TELNET status. Format: ! U1 getvar "ip.telnet.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.telnet.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.tcp.nagle_algorithm

Enables or disables the use of the Nagle algorithm on TCP connections.

Commands	Details
setvar	<p>Format: ! U1 setvar "ip.tcp.nagle_algorithm" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "enabled" = allows the use of the Nagle algorithm "disabled" = disables use of the Nagle algorithm <p>Default: "enabled"</p>
getvar	<p>Format: ! U1 getvar "ip.tcp.nagle_algorithm"</p>

Supported Devices

- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR628, ZR638
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

ip.udp.enable

This printer setting refers to the UDP socket protocol.

Commands	Details
setvar	This command instructs the printer to turn UDP on or off. Format: ! U1 setvar "ip.udp.enable" "value" Values: "off" = disables UDP protocol "on" = enables UDP protocol Default: "off"
getvar	This command instructs the printer to respond with the UDP status. Format: ! U1 getvar "ip.udp.enable"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "ip.udp.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.cloud_connect.enable

Enables the CloudConnect menu feature.

Setvar

To set the command:

```
! U1 setvar "weblink.cloud_connect.enable" "value"
```

Values:

- true — CloudConnect menu is enabled
- false — CloudConnect menu is disabled

Default:

```
"true"
```

Getvar

To have the printer return the current setting value:

```
! U1 getvar "weblink.cloud_connect.enable"
```

Supported Printers

- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- QLn220, QLn320, QLn420
- ZQ510, ZQ520
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

weblink.enable

This command indicates if one or more of the weblink connections are active.

If there is more than one connection under the weblink branch (for example, **weblink.ip.conn1**) and if any of the **.location** values are set, then this SGD will be set to **"on"**. If all connections are disabled (all connection **.location** values set to **""**), then this value will be set to **"off"**.

^JUF, **^JUS**, **^JUN**, **^JUA**, and **device.restore_defaults** do not have any affect on this setting.

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type getvar

Commands	Details
getvar	This command indicates if one or more of the weblink connections are active. Format: ! U1 getvar "weblink.enable" Result: <ul style="list-style-type: none">• "yes" if any of the .location values are set• "off" if all connections are disabled



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].authentication.add

This command allows the user to add a single server/username/password triplet into the list of authentication entries.

When the printer attempts to connect to the server (url specified in `weblink.ip.conn[1|2].location`) the server may require HTTP authentication (e.g. digest, basic, DNS, etc.). There may be multiple authentication requests along the route to the destination (e.g. a local server first requires HTTP authentication as well as on the remote server).

For each HTTP authentication request received while attempting to connect, the printer will enumerate the authentication entries and attempt to satisfy the request with the username/password pair provided for the respective server. The server name in the entry is what determines which username/password pair should be used for which authentication request. Both DNS names and IP addresses are acceptable. The server, username, and password are separated by a single space (not a tab or other white space character). The server name is the only required field. If no username is supplied, but a password is, there must be two spaces between the server and the password fields. If there is a username but no password, or simply just the servername, no space is required at the end of the entry.

If the command is changed when the connection is enabled (`weblink.enable` is set to "on"), it will not take effect until the connection is disabled, and then re-enabled.



Important • This setting only be changed when `weblink.enable` is set to "off".

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar

Commands	Details
setvar	<p>This command adds a single server/username/password triplet to the list of authentication entries.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.authentication.add" "servername[username][password]" • ! U1 setvar "weblink.ip.conn2.authentication.add" "servername[username][password]" <p>Values: servername [username][password] has a maximum length of 2048 characters</p> <p>Default: NA</p>



Example 1 • In this example, a username and a password is supplied:
! U1 setvar "weblink.ip.conn1.authentication.add" "my.server.lan
johndoe password"

Example 2 • In this example, no password is supplied
! U1 setvar "weblink.ip.conn1.authentication.add" "my.server.lan
johndoe"

Example 3 • In this example, no username is supplied (note the double space)
! U1 setvar "weblink.ip.conn1.authentication.add"
"my.server.lan password"

Example 4 • In this example, no username or password is supplied
! U1 setvar "weblink.ip.conn1.authentication.add" "my.server.lan"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].authentication.entries

This command lists the server names added to the authentication entries list.

Only the server names will be shown. The username and passwords will not be shown. The server names are separated by a `\r\n` so that each shows up on its own line.

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type getvar

Commands	Details
getvar	<p>This command lists the server names for the specified connection.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.authentication.entries" • ! U1 getvar "weblink.ip.conn2.authentication.entries"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].authentication.remove

This command allows the user to remove a single server/username/password triplet from the list of authentication entries.

To remove an entry only the server name is supplied. If an invalid entry is supplied no action is taken. If the SGD is changed when the connection is enabled (`weblink.ip.conn[1|2].enable`), it will not take effect until the connection is disabled, and then re-enabled. It is therefore recommended that this setting only be changed when `weblink.ip.conn[1|2].enable` is set to "off".

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type `setvar`

Commands	Details
<code>setvar</code>	<p>This command removes a single server/username/password triplet from the list of authentication entries.</p> <p>Format:</p> <ul style="list-style-type: none"> • <code>! U1 setvar "weblink.ip.conn1.authentication.remove" "servername"</code> • <code>! U1 setvar "weblink.ip.conn2.authentication.remove" "servername"</code> <p>Values: servername has a maximum length of string is 2048 characters.</p> <p>Default: NA</p>



Example: In this example, a username and a password is supplied

```
! U1 setvar "weblink.ip.conn1.authentication.remove" "my.server.lan"
```

weblink.ip.conn[1|2].location

This command assigns the URL of the server for this connection. The URL must follow the URL rules for the HTTP[S] protocol outlined in RFC2396 (<http://www.ietf.org/rfc/rfc2396.txt>).

The setting will not take effect until the printer is reset. Changing this setting will set weblink.printer_reset_required to "yes".

^JUF, ^JUS, ^JUN, ^JUA, and device.restore_defaults do not have any affect on this setting.

Supported Devices

- iMz™ series
- QLn™ series
- ZT200™ series
- ZD500R™ series

Type setvar, getvar

Commands	Details
setvar	<p>This command sets the server URL for the specified connection.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.location" "value" • ! U1 setvar "weblink.ip.conn2.location" "value" <p>Values: any HTTPS URL up to 2048 characters</p> <p>Default: ""</p>
getvar	<p>This command returns the server URL currently assigned to the connection.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.location" • ! U1 getvar "weblink.ip.conn2.location"



Example:

```
! U1 setvar "weblink.ip.conn2.location"
"http://my.linkos.server.com:8080/link/os"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].num_connections

This command reports the number of established connections on conn1 and conn2. Once the connection is established, this number will be incremented. When a channel is closed or the connection times out, the number is decremented..

Supported Devices

- iMz™ series
- QLn™ series
- ZT200™ series
- ZD500R™ series

Type getvar

Commands	Details
getvar	This command retrieves the number of active connections on conn1 and conn2. Format: <ul style="list-style-type: none">• ! U1 getvar "weblink.ip.conn1.num_connections"• ! U1 getvar "weblink.ip.conn2.num_connections"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].maximum_simultaneous_connections

This command indicates the maximum number of simultaneous connections that can be initiated by the printer.

Via the main connection (the original connection initiated by the printer to the remote server), the remote server can request that additional connections from the printer be initiated (e.g. a connection that supports only JSON SGDs, one that behaves similar to the RAW TCP port).

The server is free to request as many as it thinks it needs, but the printer will prevent more than N number of connections, where N is the value of this command.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, getvar

Commands	Details
setvar	<p>This command sets the maximum number of connections.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.maximum_simultaneous_connections" "value" • ! U1 setvar "weblink.ip.conn2.maximum_simultaneous_connections" "value" <p>Values: Any integer from 1-100</p> <p>Default: "10"</p>
getvar	<p>This command retrieves the maximum set number of connections.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.maximum_simultaneous_connections" • ! U1 getvar "weblink.ip.conn2.maximum_simultaneous_connections"



Example: This example sets the conn1 maximum connections to 3.

```
! U1 setvar "weblink.ip.conn1.maximum_simultaneous_connections" "3"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].proxy

This command assigns the URL of the proxy for the connection.

The proxy server protocol, port, domain, username, and password are all encoded into the URL via the format outlined in RFC2396 (<http://www.ietf.org/rfc/rfc2396.txt>).

The username and password must avoid the invalid characters listed in RFC2396 (e.g. ':', '@', '/', etc). If an invalid character must be used it needs to be escaped using '%' as described in RFC2396.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, getvar, do

Commands	Details
setvar	<p>This command assigns the URL of the connection proxy.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.proxy" "url" • ! U1 setvar "weblink.ip.conn2.proxy" "url" <p>Values:</p> <ul style="list-style-type: none"> • Any valid URL up to 2048 characters • Expected URL format: [http https]://[user:pass@]domain[:port]/[path] • The URL will need to be built according to the server/proxy environment the printer is running within. <p>Default: ""</p> <ul style="list-style-type: none"> • The user:pass, port, and path are all optional. • The default scheme must be either HTTPS or HTTP. The default is HTTP. • The default port is 1080. • The default is to omit the username and password.
getvar	<p>This command retrieves the URL of the connection proxy.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.proxy" • ! U1 getvar "weblink.ip.conn2.proxy"
do	<p>This command assigns the URL of the connection proxy.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 do "weblink.ip.conn1.proxy" "url" • ! U1 do "weblink.ip.conn2.proxy" "url" <p>Values:</p> <ul style="list-style-type: none"> • Any valid URL up to 2048 characters • Expected URL format: [scheme://][user:pass@]domain[:port]/[path] • The URL will need to be built according to the server/proxy environment the printer is running within. <p>Default: ""</p> <ul style="list-style-type: none"> • The scheme, user:pass, port, and path are all optional. • The default scheme is http. • The default port is 1080. • The default is to omit the username and password.



Example: Examples of how to connect to various proxy servers:
`http://username:password@mydomain.com:3128/`
`http://mydomain.com/`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].retry_interval

This command sets the number of seconds between attempts to connect to the server URL provided in `weblink.ip.conn1.location`. If an attempt is unsuccessful or the connection is lost, the printer will wait '`retry_interval`' seconds before attempting to connect again.

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, getvar, do

Commands	Details
setvar	This command sets the number of seconds to wait before attempting to reconnect to the server. Format: <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.retry_interval" "value" • ! U1 setvar "weblink.ip.conn2.retry_interval" "value" Values: 1 - 600 Default: "10"
getvar	This command returns the number of seconds to wait between connection attempts. Format: <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.retry_interval" • ! U1 getvar "weblink.ip.conn2.retry_interval"
do	This command sets the number of seconds to wait before attempting to reconnect to the server. Format: <ul style="list-style-type: none"> • ! U1 do "weblink.ip.conn1.retry_interval" "value" • ! U1 do "weblink.ip.conn2.retry_interval" "value" Values: 1 - 600 Default: "10"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].test.location

This command holds the URL for testing a connection to the internet. This is meant to assist users in debugging their printer's connection to remote servers when there are issues with the main weblink connection (conn1 or conn2).

The URL must follow the URL rules for the HTTP[S] protocol outlined in RFC2396 (<http://www.ietf.org/rfc/rfc2396.txt>).

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, getvar, do

Commands	Details
setvar	This command sets the URL to hold for testing a connection. Format: <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.test.location" "url" • ! U1 setvar "weblink.ip.conn2.test.location" "url" Values: Any HTTPS URL up to 2048 characters Default: "http://www.zebra.com/apps/linktest"
getvar	This command retrieves the printer's test connection URL. Format: <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.test.location" • ! U1 getvar "weblink.ip.conn2.test.location"
do	This command sets the URL to hold for testing a connection. Format: <ul style="list-style-type: none"> • ! U1 do "weblink.ip.conn1.test.location" "url" • ! U1 do "weblink.ip.conn2.test.location" "url" Values: Any HTTPS URL up to 2048 characters Default: "http://www.zebra.com/apps/linktest"



Example: The test connection can assist the user in several ways/scenarios:

1. If the `test.test_on` value is set to "failure", any time the main weblink (`conn[1|2].location`) connection fails to connect then the `test.location` URL will be used. In this situation, an attempt will be made to contact the remote URL in `test.location`, using authentication and proxy configuration that is specified by the main connection.
2. If the `test.test_on` value is set to "interval" an attempt will be made to contact the remote URL in `test.location` every `test.retry_interval` seconds, using authentication and proxy configuration that is specified by the main connection.
3. If the `test.test_on` value is set to "both", then scenario 1 and 2 will both occur. This is useful for users who will use an HTTP connection to move through their firewall - and thereafter frequently refresh the connection to indicate to their firewall that there is still activity for the purpose of keeping the connection alive.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].test.retry_interval

This command determines how often, in seconds, a connection to the test.location URL should be attempted. This setting is only applicable when the `test.test_on` SGD is set to "interval" or "both".

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type `setevar`, `getvar`, `do`

Commands	Details
<code>setvar</code>	<p>This command sets the interval for how often a connection to the test.location URL should be attempted.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.test.retry_interval" "value" • ! U1 setvar "weblink.ip.conn2.test.retry_interval" "value" <p>Values: 0-1800 (in seconds, providing 0 second - 30 minute interval)</p> <p>Default: "900"</p>
<code>getvar</code>	<p>This command retrieves the retry interval.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.test.retry_interval" • ! U1 getvar "weblink.ip.conn2.test.retry_interval"
<code>do</code>	<p>This command sets the interval for how often a connection to the test.location URL should be attempted.</p> <p>Format:</p> <ul style="list-style-type: none"> • ! U1 do "weblink.ip.conn1.test.retry_interval" "value" • ! U1 do "weblink.ip.conn2.test.retry_interval" "value" <p>Values: 0-1800</p> <p>Default: "900"</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.ip.conn[1|2].retry_interval_random_max

Specifies the maximum random wait time in seconds for weblink connection retries.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Setvar

To set the command:

```
! U1 setvar "weblink.ip.conn[1|2].retry_interval_random_max" "value"
```

Values:

- 0-600

Default:

"120"

Examples:

```
! U1 setvar "weblink.ip.conn[1].retry_interval_random_max" "120"  
! U1 setvar "weblink.ip.conn[2].retry_interval_random_max" "60"
```

Getvar

To have the printer return the current setting value:

```
! U1 getvar "weblink.ip.conn[1|2].retry_interval_random_max"
```

Related SGDs

- weblink.ip.conn[1|2].retry_interval

Supported Printers

- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500R
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZQ610, ZQ620, ZQ630
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230

- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

weblink.ip.conn[1|2].test.test_on

This command determines when the test connection should be attempted. This assists in debugging the printer's connection to remote servers when there are issues with the main weblink connection (conn1 or conn2).

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, getvar, do

Commands	Details
setvar	This command indicate when the test connection should be attempted. Format: <ul style="list-style-type: none"> • ! U1 setvar "weblink.ip.conn1.test.test_on" "value" • ! U1 setvar "weblink.ip.conn2.test.test_on" "value" Values: off, failure, interval, both Default: "failure"
getvar	This command retrieves the test connection setting. Format: <ul style="list-style-type: none"> • ! U1 getvar "weblink.ip.conn1.test.test_on" • ! U1 getvar "weblink.ip.conn2.test.test_on"
do	This command sets when the test connection should be attempted. Format: <ul style="list-style-type: none"> • ! U1 do "weblink.ip.conn1.test.test_on" "value" • ! U1 do "weblink.ip.conn2.test.test_on" "value" Values: off, failure, interval, both Default: "failure"



Example: The test connection can assist the user is several ways/scenarios:

1. If the `test.test_on` value is set to "failure", any time the main weblink (`conn[1|2].location`) connection fails to connect then the `test.location` URL will be used. An attempt will be made to contact the remote URL in `test.location`, using authentication and proxy configuration that is specified by the main connection.
2. If the `test.test_on` value is set to "interval" an attempt will be made to contact the remote URL in `test.location` every `test.retry_interval` seconds, using authentication and proxy configuration that is specified by the main connection.
3. If the `test.test_on` value is set to "both", then scenario 1 and 2 will both occur. This is useful for users who will use an HTTP connection to move through their firewall - and thereafter frequently refresh the connection to indicate to their firewall that there is still activity for the purpose of keeping the connection alive.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.logging.clear

This command clears the weblink log. Setting this value to anything will clear it, including an empty string.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, do

Commands	Details
setvar	This command clears the weblink log entires. Format: ! U1 setvar "weblink.logging.clear" "value" Values: Any string value, including an empty string. Default: NA
do	This command clears the weblink log entires. Format: ! U1 do "weblink.logging.clear" "value" Values: Any string value, including an empty string. Default: NA



Example: This example clears the weblink log entries with an empty string value.

```
! U1 setvar "weblink.logging.clear" ""
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.logging.entries

This command returns the N number of entries in the weblink log, where N has a maximum value that is set by `weblink.logging.max_entries`.

The weblink log is a collection of events related to connecting to a remote Link-OS™ server. The log entries range anywhere from general status to errors that prevented a successful connection. The log contains entries from all connections and are labeled so that it is clear which log entries are for which connection. Each log entry also contains a timestamp for when it was logged by the system. The newest events will appear at the bottom of the list.

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type getvar

Commands	Details
getvar	This command returns a lists of entries in the weblink log. Format: ! U1 getvar "weblink.logging.entries" Values: NA Default: ""



Example: This example shows the result from `weblink.logging.entries`:

```
[01-04-2013 08:40:45.655] [conn1.1] HTTP/1.1 404 Not Found
[01-04-2013 08:40:45.659] [conn1.1] Received HTTP code 404 from proxy after
CONNECT
[01-04-2013 08:40:45.660] [conn1.1] Closing connection
[01-04-2013 08:40:45.662] [conn1.1] Failed to connect (SP = 0, CU = 0, UW = 0, AC
= 0, PC = 0)
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.logging.max_entries

This command specifies the maximum number of individual log entries that will be stored in the `weblink.logging.entries` command.



Important • Changes to this command are immediate and may result in some log entries being lost. If there are N log entries currently in the log, the user sets the `max_entries` to M, where M is less than N, the oldest (N-M) log entries will be removed.

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type `setvar`, `getvar`, `do`

Commands	Details
<code>setvar</code>	This command sets the maximum number of log entires that will be stored. Format: ! U1 setvar "weblink.logging.max_entries" "value" Values: 0 - 10000 Note • Setting the value to 0 disables logging. Default: "0"
<code>getvar</code>	This command returns the setting for the maximum number of log entries that will be stored. Format: ! U1 getvar "weblink.logging.max_entries"
<code>do</code>	This command sets the maximum number of log entires that will be stored. Format: ! U1 do "weblink.logging.max_entries" "value" Values: 0 - 10000 Note • Setting the value to 0 disables logging. Default: "0"



Example 1 • In this example, `weblink.logging.max_entries` is set to 3:
[01-04-2013 08:40:45.659] [conn1.1] Received HTTP code 404 from proxy after CONNECT
[01-04-2013 08:40:45.660] [conn1.1] Closing connection
[01-04-2013 08:40:45.662] [conn1.1] Failed to connect (SP = 0, CU = 0, UW = 0, AC = 0, PC = 0)

Example 2 • In this example, `weblink.logging.max_entries` is set to 2:
`weblink.logging.entries` becomes:
[01-04-2013 08:40:45.660] [conn1.1] Closing connection
[01-04-2013 08:40:45.662] [conn1.1] Failed to connect (SP = 0, CU = 0, UW = 0, AC = 0, PC = 0)



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.printer_reset_required

This command retrieves a "yes" or "no" value indicating whether any of the weblink settings have been modified.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any effect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type getvar

Commands	Details
getvar	This command retrieves whether any of the weblink settings are modified. Format: ! U1 getvar "weblink.printer_reset_required" Values: "yes" or "no" Default: "no"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.restore_defaults

This command defaults, and saves, the weblink branch settings. Any value, including an empty string, will default the weblink branch settings.



Note • The entire weblink branch of settings will be defaulted and the settings are saved; however, the weblink connections will not use the new settings until the printer is restarted (e.g. the `weblink.printer_reset_required` SGD will be "yes" after a default).

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar, do

Commands	Details
setvar	This command defaults the weblink branch settings. Format: ! U1 setvar "weblink.restore_defaults" "value" Values: Any value, including an empty string, will default the branch Default: NA
do	This command defaults the weblink branch settings. Format: ! U1 do "weblink.restore_defaults" "value" Values: Any value, including an empty string, will default the branch Default: NA



Example: These all default the branch:

```
! U1 setvar "weblink.restore_defaults" ""
! U1 setvar "weblink.restore_defaults" "foo"
! U1 do "weblink.restore_defaults" ""
! U1 do "weblink.restore_defaults" "foo"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.zebra_connector.authentication.add

This command allows the user to add a single server/username/password triplet into the list of authentication entries.

When the printer attempts to connect to the Zebra Printer Connector, the local server may require HTTP authentication (e.g. digest, basic, DNS, etc.). There may be multiple authentication requests along the route to the destination (e.g. a local server first requires HTTP authentication as well as on the remote server).

For each HTTP authentication request received while attempting to connect, the printer will enumerate the authentication entries and attempt to satisfy the request with the username/password pair provided for the respective server. The server name in the entry is what determines which username/password pair should be used for which authentication request. Both DNS names and IP addresses are acceptable. The server, username, and password are separated by a single space (not a tab or other white space character). The server name is the only required field. If no username is supplied, but a password is, there must be two spaces between the server and the password fields. If there is a username but no password, or simply just the servername, no space is required at the end of the entry.

If the command is changed while the Visibility Agent is enabled, it will not take effect until the connection is disabled, and then re-enabled.



Important • This setting only be changed when `weblink.zebra_connector.enable` is set to "off".

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Commands	Details
setvar	<p>Format: ! U1 setvar "weblink.zebra_connector.authentication.add" "server username password"</p> <p>Values:</p> <ul style="list-style-type: none"> "server" = an IP address or a DNS name "username" = user name on this server "password" = password for this username on this server <p>Default: ""</p> <p>Result: ! U1 setvar "weblink.zebra_connector.authentication.add" "10.3.5.70 jsmith LedZepR0cks!"</p>

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.zebra_connector.authentication.entries

This command lists the server names added to the authentication entries list.

Only the server names will be shown. The username and passwords will not be shown. The server names are separated by a `\r\n` so that each shows up on its own line.

`^JUF`, `^JUS`, `^JUN`, `^JUA`, and `device.restore_defaults` do not have any affect on this setting.

Commands	Details
getvar	<p>Format: ! U1 getvar "weblink.zebra_connector.authentication.entries"</p> <p>Result: Returns the list of servers with authentication entries. It does not return the username or passwords for those servers.</p> <p>Default: ""</p>

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.zebra_connector.authentication.remove

Removes a single server/username/password triplet from the list of authentication entries.

To remove an entry only the server name is supplied, however the entire entry will be removed. If an invalid entry is supplied no action is taken.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Commands	Details
setvar	<p>Format: ! U1 setvar "weblink.zebra_connector.authentication.remove" "server"</p> <p>Values: "server" = an IP address or a DNS name of the server to remove</p> <p>Default: NA</p> <p>Example: ! U1 setvar "weblink.zebra_connector.authentication.remove" "10.3.5.70"</p>

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.zebra_connector.enable

Enables the Visibility Agent feature.

Commands	Details
setvar	Format: ! U1 setvar "weblink.zebra_connector.enable" "value" Values: "on" = enables Visibility Agent "off" = disables Visibility Agent Default: "on" Example: ! U1 setvar "weblink.zebra_connector.enable" "enable"
getvar	Format: ! U1 getvar "weblink.zebra_connector.enable" Result: "on" or "off"

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328, ZR338
- ZR628
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.zebra_connector.proxy

This command assigns the URL for the proxy used to connect to the Zebra connector.

The proxy server protocol, port, domain, username, and password are all encoded into the URL via the format outlined in RFC2396 (<http://www.ietf.org/rfc/rfc2396.txt>).

The username and password must avoid the invalid characters listed in RFC2396 (e.g. ':', '@', '/', etc). If an invalid character must be used it needs to be escaped using '%' as described in RFC2396.

^JUF, ^JUS, ^JUN, ^JUA, and `device.restore_defaults` do not have any affect on this setting.

Commands	Details
setvar	<p>Format: ! U1 setvar "weblink.zebra_connector.proxy" "url"</p> <p>Values:</p> <ul style="list-style-type: none"> Any valid URL up to 2048 characters Expected URL format: [http https]://[user:pass@]domain[:port]/[path] <p>The URL will need to be built according to the server/proxy environment the printer is running where</p> <ul style="list-style-type: none"> "user" = username "password" = password "host" = either the hostname or IP address "port" = port number "other" = anything else needed in the path <p>Default: ""</p> <ul style="list-style-type: none"> The user:pass, port, and path are all optional. The default scheme must be either HTTPS or HTTP. The default is HTTP. The default port is 1080. The default is to omit the username and password. <p>Example: ! U1 setvar "weblink.zebra_connector.proxy" "https://user:pass@my.internal.proxy:7840/init"</p>
getvar	<p>Format: ! U1 getvar "weblink.zebra_connector.proxy"</p> <p>Result: "https://user:pass@my.internal.proxy:7840/init"</p>

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

weblink.zebra_connector.version

Displays the current version of the Zebra Connector.

Commands	Details
getvar	Format: ! U1 getvar "weblink.zebra_connector.version" Values: A version number in the form of xx.yy. Default: "" Example: "0.04"

Supported Devices

- iMZ220, iMZ230
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZR318, ZR328, ZR338
- ZR628
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11ac.80mhz_enable

Enables the 80MHz wide channel support for the 802.11AC radio.

Commands	Details
setvar	! U1 setvar "wlan.11ac.80mhz_enable" "value" Values: "on" = enables the 80MHz wide channel support "off" = disables the 80MHz wide channel support Default: "on"
getvar	! U1 getvar "wlan.11ac.80mhz_enable"

Supported Devices

- ZD410, ZD420
- ZD620
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11d.enable

Allows the client to automatically configure themselves to their local regulatory domain.

Setvar

To set the command:

```
! U1 setvar "wlan.11d.enable" "value"
```

Values:

- off
- on

Default:

"off"

Getvar

To have the printer return the current setting value:

```
! U1 getvar "wlan.11d.enable"
```

Supported Printers

- iMZ220, iMZ320
- QLn220, QLn320, QLn420
- ZD410, ZD420
- ZD500R, ZD510, ZD511
- ZD620
- ZQ310, ZQ320
- ZQ510, ZQ520
- ZQ610, ZQ620, ZQ630
- ZR318, ZR328
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [SGD Command Support on page 1393](#).
- For details on command structure, see [Command Structure on page 573](#).

wlan.11n.20mhz_only

This command forces 20 MHz operation only in printers with 802.11n radios.

Commands	Details
setvar	This command forces 20 MHz operation only in printers with 802.11n radios. Format: ! U1 setvar "wlan.11n.20mhz_only" "value" Values: "on" "off" Default: "off"
getvar	This command returns the current setting for 20 MHz operation only. Format: ! U1 getvar "wlan.11n.20mhz_only"



Example:

```
U1 setvar "wlan.11n.20mhz_only" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11n.aggregation

This command enable or disables Aggregation MAC Service Data Unit (A-MSDU) in 802.11n radio communications.

Commands	Details
setvar	This command enables or disables A-MSDU in 802.11n radio communications. Format: ! U1 setvar "wlan.11n.aggregation" "value" Values: "on" "off" Default: "off"
getvar	This command returns the current setting for A-MSDU. Format: ! U1 getvar "wlan.11n.aggregation"



Example:

```
U1 setvar "wlan.11n.aggregation" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11n.greenfield

This command will enable or disable greenfield mode in 802.11n radio communications.

Commands	Details
setvar	This command enables/disables greenfield mode. Format: ! U1 setvar "wlan.11n.greenfield" "value" Values: "on" "off" Default: "off"
getvar	This command returns the current setting for greenfield mode. Format: ! U1 getvar "wlan.11n.greenfield"



Example:

```
U1 setvar "wlan.11n.greenfield" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11n.rifs

This command enable/disables Reduced Interframe Space (RIFS) in 802.11n radio communications.

Commands	Details
setvar	This command enable/disables RIFS in 802.11n. Format: ! U1 setvar "wlan.11n.rifs" "value" Values: "on" "off" Default: "off"
getvar	This command returns the current setting for RIFS. Format: ! U1 getvar "wlan.11n.rifs"



Example:

```
U1 setvar "wlan.11n.rifs" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11n.short_gi_40mhz

This command enables/disables short Guard Interval in 40 mhz mode.

Commands	Details
setvar	This command enables/disables short Guard Interval in 40 mhz mode. Format: ! U1 setvar "wlan.11n.short_gi_40mhz" "value" Values: "on" "off" Default: "off"
getvar	This command returns the current setting for short Guard Interval 40mhz operation. Format: ! U1 getvar "wlan.11n.short_gi_40mhz"



Example:

```
U1 setvar "wlan.11n.short_gi_40mhz" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.11n.short_gi_20mhz

This command enables/disables short Guard Interval (GI) in 20 mhz mode.

Commands	Details
setvar	This command enables/disables short Guard Interval in 20 mhz mode. Format: ! U1 setvar "wlan.11n.short_gi_20mhz" "value" Values: "on" "off" Default: "off"
getvar	This command returns the current setting for short Guard Interval 20mhz operation. Format: ! U1 getvar "wlan.11n.short_gi_20mhz"



Example:

```
U1 setvar "wlan.11n.short_gi_20mhz" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.8021x.enable

Enables or disables the 802.1x security protocol, with the option to set it to WPA security protocol.

Setvar

To set the command:

```
! U1 setvar "wlan.8021x.enable" "value"
```

Values:

- **off** — 802.1x security protocol is disabled.
- **on** — 802.1x security protocol is enabled.
- **wpa** — 802.1x security protocol is enabled and uses WPA.

Default:

off

Getvar

To have the printer return the current setting value:

```
! U1 getvar "wlan.8021x.enable"
```

Supported Printers

- QLn220, QLn320, QLn420
- ZD400, ZD410, ZD420
- ZD500R
- ZD620
- ZT210, ZT220, ZT230
- ZT410, ZT420
- ZT510
- ZT610, ZT620

Notes

- For specific product support, see [xref on page xxx](#).
- For details on command structure, see [xref on page yyy](#).

wlan.8021x.validate_peap_server_certificate

This command determines if the printer will validate the PEAP server certificate.

Commands	Details
setvar	Description Format: ! U1 setvar "wlan.8021x.validate_peap_server_certificate" "value" Values: "on" "off" Default: "on"
getvar	This command returns the current setting. Format: ! U1 getvar "wlan.8021x.validate_peap_server_certificate"



Example:

```
! U1 setvar "wlan.8021x.validate_peap_server_certificate"
```



Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.active_channels

This command returns list of current active channels defined by [wlan.allowed_band on page 1214](#) and [wlan.user_channel_list on page 1300](#).

Supported Devices ZT200 Series

Type getvar

Commands	Details
getvar	<p>This command returns the list of current active channels.</p> <p>Format: ! U1 getvar "wlan.active_channels"</p> <p>Result: One or more of the following channels: 1,2,3,4,5,6,7,8,9,10,11,36,40,44,48,52,56,60,64,100,104,108, 112,116,132,136,140,149,153,157,161,165,all</p>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.adhoc_last_channel

Reports the last channel used for WiFi ad hoc communication.

Commands	Details
getvar	Format: ! U1 getvar "wlan.adhoc_last_channel" Values: a numeric value between 1-11 Default: "1"

Supported Devices

- iMZ 220, iMZ320
- QLn220, QLn320, QLn420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.authenticated

Returns the authentication state of the wireless interface.

Commands	Details
getvar	Format: ! U1 getvar "wlan.authenticated" Values: "yes" = the printer wlan connection has been authenticated "no" = the printer wlan connection has not been authenticated

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.authentication_error

Reports the last error that occurred during the WLAN authentication process.

Commands	Details
getvar	Format: ! U1 getvar "wlan.authentication_error" Values: "none" = the authentication was successful. "timed out" = the authentication did not succeed in the allotted time.

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.available

Determines if a WLAN radio has been installed in the printer.

Commands	Details
getvar	<p>Format: ! U1 getvar "wlan.available"</p> <p>Values:</p> <ul style="list-style-type: none"> "yes" = a WLAN radio is installed "no" = a WLAN radio is installed

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.allowed_band

This command provides a method to restrict the 802.11n radio to either the 2.4 GHz or 5 GHz band.

Use this option when it is beneficial to have the radio use only one frequency band. Setting the 802.11n radio to one band will reduce roaming and radio association times since the radio will not scan as many channels.

Commands	Details
setvar	This command restricts the 802.11n radio to either the 2.4 GHz or 5 GHz band. Format: ! U1 setvar "wlan.allowed_band" "value" Values: "2.4, 5, all" Default: "all" Note • If both bands are desired, use "all"
getvar	This command returns the current setting for allowed bands. Format: ! U1 getvar "wlan.allowed_band"



Example: This example sets the allowed band to only the 2.4 GHz band.

```
U1 setvar "wlan.allowed_band" "2.4"
```

Related Commands:

- [wlan.active_channels](#) on page 1209
- [wlan.user_channel_list](#) on page 1300

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

wlan.adhocautomode

This printer setting refers to enabling or disabling the adhoc auto mode.

Commands	Details
setvar	This command instructs the printer to set the adhoc auto mode. Format: ! U1 setvar "wlan.adhocautomode" "value" Values: "on" = adhoc auto mode enabled "off" = adhoc auto mode disabled Default: "off"
getvar	This command instructs the printer to respond with the adhoc auto mode status. Format: ! U1 getvar "wlan.adhocautomode"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.adhocautomode" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.adhocchannel

This printer setting refers to specifying the wireless channel for adhoc channel.

Commands	Details
setvar	This command instructs the printer to set the wireless channel for adhoc channel mode. Format: ! U1 setvar "wlan.adhocchannel" "value" Values: Decimal value between 1 and 16 inclusive Default: "1"
getvar	This command instructs the printer to respond with the wireless channel for adhoc channel mode. Format: ! U1 getvar "wlan.adhocchannel"



Example: This setvar example shows the value set to "1".

```
! U1 setvar "wlan.adhocchannel" "1"
```

When the setvar value is set to "1", the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.associated

This command refers to if the printer is or is not associated with an access point (AP).

`getvar`

Commands	Details
<code>getvar</code>	This command instructs the printer to respond with yes or no, which identifies if it is associated with the AP. Format: <code>! U1 getvar "wlan.associated"</code>



Example: In this example, the `getvar` result is "yes".

```
! U1 getvar "wlan.associated"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.auth_type

This parameter selects the authentication service to be used between the printer and the Access Point. Open System and Shared Key are the two types of authentication services.

Commands	Details
setvar	This command instructs the printer to set the authentication type to the specified value. Format: ! U1 setvar "wlan.auth_type" "value" Values: "open" "shared" Default: "open"
getvar	This command instructs the printer to retrieve the current authentication type. Format: ! U1 getvar "wlan.auth_type"



Example 1 • This example instructs the printer to set the authentication type to Shared Key.

```
! U1 setvar "wlan.auth_type" "shared"
```

The authentication type will be set to Shared Key after power cycle.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.bssid

This command returns the MAC address of the access point (AP) with which the printer is associated.

getvar

Commands	Details
getvar	This command retrieves the MAC address of the access point (AP). Format: ! U1 getvar "wlan.bssid"



Example: In this example, the `getvar` result is the MAC address of the access point.

! U1 getvar "wlan.bssid"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.channel

This command retrieves the current WI-FI channel the printer is using.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the current WI-FI channel the printer is using. Format: <code>! U1 getvar "wlan.channel"</code>



Example: In this example, the `getvar` retrieves the current WI-FI channel the printer is using.

`! U1 getvar "wlan.channel"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.channel_mask

This command specifies the wireless channel masks for enabling and disabling various channels. This controls which b/g radio channels can be used by the radio for network connections.

The value for this command is a bit field where a 0 disables a channel and a 1 enables the channel. Starting from the right, bit 0 is for channel 1, bit 1 for channel 2, etc. This can be used to limit the channels scanned for networks, which may slightly improve connection and roaming speed. It also used to ensure compliance with the regulatory domains of your location.

Commonly Used Channel Mask Settings

Region	Channels	Channel Mask
United States, Canada, Latin America	1 - 11	0x7FF
Europe, Middle East, Africa, other	1 - 13	0x1FFF
Japan	1 - 14	0x3FFF



Note • This command is not supported by all radios. Ensure the channel masks are set in accordance with the regulatory domains of your country.

Commands	Details
setvar	This command instructs the printer to set the wireless channel mask value. Format: ! U1 setvar "wlan.channel_mask" "value" Values: "0x0000" to "0xFFFF" (4 hexadecimal digits preceded by "0x") Default: "0x7FF"
getvar	This command instructs the printer to respond with the wireless channel mask value. Format: ! U1 getvar "wlan.channel_mask"



Example 1 • This setvar example shows the value set to "0x7FF" for common North American channels.

```
! U1 setvar "wlan.channel_mask" "0x7FF"
```



Example 2 • This setvar example sets the channel mask to use only channels 1,6,11.

```
! U1 setvar "wlan.channel_mask" "0x421"
```

Result: Only channels 1, 6, and 11 will be used by the radio.




Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.country_code

This command defines the regulatory country for which the radio is currently configured.

Commands	Format and Details
setvar	<p>Sets the country code for which the radio is to be configured.</p> <p>Format: ! U1 setvar "wlan.country_code" "value"</p> <p> Important • The list of country codes is specific to each printer and depends on the printer model and its wireless radio configuration. The list is subject to change, addition, or deletion with any firmware update, at any time, without notice.</p> <p>To determine the country codes available on your printer, issue the ! U1 getvar "wlan" command to return all commands related to WLAN settings. Locate the wlan.country_code command in the results and view the country codes available for your printer.</p>
getvar	<p>Retrieves the country code for which the radio is currently configured.</p> <p>! U1 getvar "wlan.country_code"</p>



Example: In this example, the **setvar** sets the country code to USA/Canada.
! U1 setvar "wlan.country_code" "usa/canada"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZT210, ZT220, ZT230, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.current_tx_rate

This command retrieves the transmission rate of the wireless print server.

getvar

Commands	Details
getvar	This command instructs the printer to retrieve the current transmit rate of the wireless print server. Format: ! U1 getvar "wlan.current_tx_rate"



Example: In this example, the `getvar` retrieves the transmission rate of the wireless print server.
! U1 getvar "wlan.current_tx_rate"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.enable

This parameter can be used to enable or disable printer's Wireless LAN functionality.

Commands	Details
setvar	Format: ! U1 setvar "wlan.enable" "value" Values: "on" = Wireless LAN functionality is enabled "off" = Wireless LAN functionality is disabled Default: "off"
getvar	Format: ! U1 getvar "wlan.enable"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.encryption_index

This parameter refers to the WEP (Wired Equivalent Privacy) encryption key index. It determines which one of the four encryption keys is to be used by the client (printer).

Commands	Details
setvar	<p>This command instructs the printer to set the encryption key index the specified value.</p> <p>Format: ! U1 setvar "wlan.encryption_index" "value"</p> <p>Values: "1" "2" "3" "4"</p> <p>Default: "1"</p>
getvar	<p>This command instructs the printer to retrieve the current encryption key setting.</p> <p>Format: ! U1 getvar "wlan.encryption_index"</p>



Example: In this example, the `setvar` command instructs the printer to set the encryption key index to 1.

```
! U1 setvar "encryption_index" "1"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.encryption_key[1|2|3|4]1

These parameters refer to the first, second, third, and fourth indexed WEP encryption keys. The WEP encryption keys are hexadecimal strings that are either 10 or 26 characters long depending on the encryption method (40-bit or 128 bit). The keys should match the wireless network WEP encryption keys.

Commands	Details
setvar	This command instructs the printer to set the encryption key value. Format: ! U1 setvar "wlan.encryption_key[1 2 3 4]" "value" Values: 10 hexadecimal characters for 40-bit encryption and 26 hexadecimal characters for 128-bit encryption. Default: All zeroes (10 or 26, depending on encryption setting)
getvar	This command instructs the printer respond with the encryption key value. Format: ! U1 getvar "wlan.encryption_key1"

➔ **Example 1** • In these examples, the `getvar` results assume that the printer is using 40-bit encryption with the default settings.

```
! U1 getvar "wlan.encryption_key1"
! U1 getvar "wlan.encryption_key2"
! U1 getvar "wlan.encryption_key3"
! U1 getvar "wlan.encryption_key4"
```

Results for each key: "0000000000"

➔ **Example 2** • In these examples, the `setvar` command instructs the printer to set the encryption key value. This example assumes that the printer is using 40-bit encryption.

```
! U1 setvar "wlan.encryption_key1" "A1B2C3D4F5"
! U1 setvar "wlan.encryption_key2" "G1H2J3K4L5"
! U1 setvar "wlan.encryption_key3" "M1N2P3Q4R5"
! U1 setvar "wlan.encryption_key4" "S1T2V3W4X5"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.encryption_mode

This parameter refers to WEP (Wired Equivalent Privacy) encryption. This parameter enables and disables the printer's WEP encryption. When using WEP encryption make sure that the encryption key matches the wireless network WEP encryption key.

Commands	Details
setvar	<p>This command instructs the printer to turn the LEAP mode "on" or "off".</p> <p>Format: ! U1 setvar "wlan.encryption_mode" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "off" "40-bit" "128-bit" <p>Default: "off"</p>
getvar	<p>This command returns the type of encryption that is currently being used by the printer.</p> <p>Format: ! U1 getvar "wlan.encryption_mode"</p>

➔ **Example 1** • This example instructs the printer to set encryption to 40-bit.
! U1 setvar "wlan.encryption_mode" "40-bit"

➔ **Example 2** • This example instructs the printer to turn encryption off.
! U1 setvar "wlan.encryption_mode" "off"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.essid

This printer setting refers to the printer's stored ESSID. Setting the ESSID to "" will set the printer in a "broadcast" mode.

Commands	Details
setvar	This command instructs the printer to change the ESSID. Format: ! U1 setvar "wlan.essid" "value" Values: 32 character alphanumeric string Default: "125"
getvar	This command instructs the printer to respond with the stored ESSID value. Format: ! U1 getvar "wlan.essid"



Example: This setvar example shows the value set to "125".

```
! U1 setvar "wlan.essid" "125"
```

When the setvar value is set to "125", the getvar result is "125".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.firmware_version

This command refers to the firmware version of the wireless radio card.

`getvar`

Commands	Details
<code>getvar</code>	This command instructs the printer to respond with the current version of the wireless radio card firmware. Format: <code>! U1 getvar "wlan.firmware_version"</code>



Example: In this example, the `getvar` result is the version of Symbol 4137 card (for example, "F3.91-69").

```
! U1 getvar "wlan.firmware_version"
```



Note •


- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.addr

This command allows you to get or set the wireless print servers's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	<p>This command instructs the printer to change its current wireless print server IP address upon powering the printer on.</p> <p>Format: ! U1 setvar "wlan.ip.addr" "value"</p> <p>Values: any valid IP address</p> <p>Default: "0.0.0.0"</p> <p> Note • The setvar value of this command can be affected by the wlan.ip.dhcp.enable command.</p>
getvar	<p>This command instructs the printer to respond with its current wireless print server IP address.</p> <p>Format: ! U1 getvar "wlan.ip.addr"</p>



Example: This setvar example shows the value set to "10.14.4.235".

```
! U1 setvar "wlan.ip.addr" "10.14.4.235"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "10.14.4.235".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.arp_interval

This print server setting allows you to specify the ARP (Address Resolution Protocol) interval or the ARP cache time out for the wireless print server.

Commands	Details
setvar	This command instructs the printer to respond with the ARP interval or the ARP cache time out value for the wireless print server. Format: ! U1 setvar "wlan.ip.arp_interval" "value" Values: 0 to 30 seconds Default: "0"
getvar	This command instructs the printer to respond with the ARP interval or the ARP cache time out value (in seconds) for the wireless print server. Format: ! U1 getvar "wlan.ip.arp_interval"



Example: This **setvar** example shows the value set to "0".

```
! U1 setvar "wlan.ip.arp_interval" "0"
```

What the **setvar** value is set to is the **getvar** result. In this example, the **getvar** result is "0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.default_addr_enable

This command allows you to default the wireless print server's IP address.



Important • For a set IP address to take affect, the IP protocol must be set to permanent and the print server must be reset.

Commands	Details
setvar	<p>This command tells the printer to use it's default address, if no address is provided through DHCP or BOOTP. If you do not assign an IP address after 2 minutes, the 10/100 Internal PS defaults to IP address 192.168.254.254.</p> <p>Format: ! U1 setvar "wlan.ip.default_addr_enable" "value"</p> <p>Values: "on" = enabled "off" = disabled</p> <p>Default: "on"</p>
getvar	<p>This command instructs the printer to show the status of the setting of the wireless print server's default IP address feature.</p> <p>Format: ! U1 getvar "wlan.ip.default_addr_enable"</p>



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.ip.default_addr_enable" "on"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.arp_verify

Specifies whether an ARP broadcast will be sent out to verify that the IP address received from the DHCP server is not already in use.

Commands	Details
setvar	Format: ! U1 setvar "wlan.ip.dhcp.arp_verify" "value" Values: "on" = an ARP broadcast will be sent out "off" = and ARP broadcast will not be sent out Default: "on" = for Desktop and Industrial printers "off" = for Mobile printers
getvar	Format: ! U1 getvar "wlan.ip.dhcp.arp_verify"

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.cache_ip

This command enables or disables the IP cache of the wireless print server.

Commands	Details
setvar	This command sets the status of the IP cache. Format: ! U1 setvar "ip.dhcp.cache_ip" "value" Values: "on" = enabled "off" = disabled Default: "off"
getvar	This command retrieves the status of the IP cache. Format: ! U1 getvar "wlan.ip.dhcp.cache_ip"



Example: This setvar example shows the value set to "off".
 ! U1 setvar "wlan.ip.dhcp.cache_ip" "off"
When the setvar value is set to "off", the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.cid_all

This printer setting defines the entire client identifier (DHCP option 61) if DHCP is enabled on the wireless print server and "wlan.ip.dhcp.cid_type" is set to "0", or "2". The MAC address is used if the type is set to "1".

Commands	Details
setvar	<p>This command instructs the printer to change the client identifier prefix and suffix of the wireless print server. The prefix gets cleared and the suffix contains the entire client identifier.</p> <p>Format: ! U1 setvar "wlan.ip.dhcp.cid_all" "value"</p> <p>Values: A maximum length of 60 characters if the CID type is ASCII, or 120 characters if the CID type is hexadecimal.</p> <p>Default: ""</p>
getvar	<p>This command instructs the printer to respond with the client identifier prefix and suffix of the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.dhcp.cid_all"</p>



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "wlan.ip.dhcp.cid_all" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.cid_enable

This command determines if DHCP (option 61) is turned on or off of the wireless print server.

Commands	Details
setvar	This command instructs the printer to set the status of the client identifier of the wireless print server. Format: ! U1 setvar "wlan.ip.dhcp.cid_enable" "value" Values: "off" = client identifier is turned off "on" = client identifier is turned on Default: "off"
getvar	This command instructs the printer to respond with the status of the client identifier of the wireless print server. Format: ! U1 getvar "wlan.ip.dhcp.cid_enable"



Example: This setvar example shows the value set to "off".

```
! U1 setvar "wlan.ip.dhcp.cid_enable" "off"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "off".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.cid_prefix

This printer setting defines the prefix to be prepended to the DHCP client identifier (option 61) when DHCP is enabled on the wireless print server and "wlan.ip.dhcp.cid_type" is set to "0" or "2".

Commands	Details
setvar	<p>This command instructs the printer to change the CID prefix of the wireless print server.</p> <p>Format: ! U1 setvar "wlan.ip.dhcp.cid_prefix" "value"</p> <p>Values: Any text string up to 10 characters if the CID type is ASCII, or 20 characters if the CID type is hexadecimal.</p> <p>Default: ""</p>
getvar	<p>This command instructs the printer to respond with the client identifier prefix of the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.dhcp.cid_prefix"</p>



Example: This setvar example shows the value set to "PRT001".

```
! U1 setvar "wlan.ip.dhcp.cid_prefix" "PRT001"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "PRT001".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.cid_suffix

This printer setting defines the unique suffix to be used as the client identifier (DHCP option 61) if DHCP is enabled on the wireless print server and "wlan.ip.dhcp.cid_type" is set to "0" or "2".

Commands	Details
setvar	This command instructs the printer to change the client identifier suffix value on the wireless print server. Format: ! U1 setvar "wlan.ip.dhcp.cid_suffix" "value" Values: The maximum length of a value allowed is 60 ASCII characters when the CID type is ASCII, or 120 hexadecimal values when the CID type is hexadecimal. Default: ""
getvar	This command instructs the printer to respond with the client identifier suffix on the wireless print server. Format: ! U1 getvar "wlan.ip.dhcp.cid_suffix"



Example: This setvar example shows the value set to "printer".

```
! U1 setvar "wlan.ip.dhcp.cid_suffix" "printer"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "printer".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.cid_type

This printer setting defines the type of client identifier (DHCP option 61) that will be sent if DHCP is enabled on the wireless print server. A value of "1" means the type of "Ethernet" and the printer's MAC address will be used. A value of "0" or "2" means the client identifier sent will be "wlan.ip.dhcp.cid_prefix" concatenated with "wlan.ip.dhcp.cid_suffix".

Commands	Details
setvar	<p>This command instructs the printer to enable "synthetic" client identifier for the wireless print server.</p> <p>Format: ! U1 setvar "wlan.ip.dhcp.cid_type" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "0" = ASCII string "1" = wireless radio card's MAC address "2" = HEX value <p>Default: "1"</p>
getvar	<p>This command instructs the printer to respond with the client identifier type for the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.dhcp.cid_type"</p>



Example: This setvar example shows the value set to "1".

```
! U1 setvar "wlan.ip.dhcp.cid_type" "1"
```

What the setvar value is set to is the getvar result. In this example, the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.lease.last_attempt

This command retrieves the last time a DHCP request was sent from the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the last time a DHCP request was sent from the wireless print server. Format: <code>! U1 getvar "wlan.ip.dhcp.lease.last_attempt"</code>



Example: In this example, the `getvar` retrieves the last time a DHCP request was sent from the wireless print server.

`! U1 getvar "wlan.ip.dhcp.lease.last_attempt"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.lease.length

This command retrieves the original length (in seconds) of the DHCP lease on the wireless print server.

getvar

Commands	Details
getvar	This command retrieves the original length (in seconds) of the DHCP lease on the wireless print server. Format: ! U1 getvar "wlan.ip.dhcp.lease.length"



Example: This command retrieves the original length of the DHCP lease on the wireless print server.

! U1 getvar "wlan.ip.dhcp.lease.length"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.lease.server

This command retrieves the address of the print server that provided the DHCP lease on the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the address of the print server that provided the DHCP lease on the wireless print server. Format: <code>! U1 getvar "wlan.ip.dhcp.lease.server"</code>



Example: In this example, the `getvar` retrieves the server that provided the DHCP lease on the wireless print server.

```
! U1 getvar "wlan.ip.dhcp.lease.server"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.lease.time_left

This command retrieves the time (in seconds) left in the current DHCP lease on the wireless print server.

getvar

Commands	Details
getvar	This command retrieves the time (in seconds) left in the current DHCP lease on the wireless print server. Format: ! U1 getvar "wlan.ip.dhcp.lease.time_left"



Example: In this example, the `getvar` retrieves the time left in the current DHCP lease on the wireless print server.

```
! U1 getvar "wlan.ip.dhcp.lease.time_left"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.option12

This command specifies if the DHCP option 12 (host name) is on or off in the discovery packet that is sent from the wireless print server.

Commands	Details
setvar	<p>This command instructs the printer to set the DHCP option 12 (host name) is on or off in the discovery packet that is sent from the wireless print server.</p> <p>Format: ! U1 setvar "wlan.ip.dhcp.option12" "value"</p> <p>Values:</p> <ul style="list-style-type: none">"on" = turns on option 12"off" = turns off option 12 <p>Default: "on"</p>
getvar	<p>This command retrieves the status of the DHCP option 12 (host name) is on or off in the discovery packet that is sent from the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.dhcp.option12"</p>



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.ip.dhcp.option12" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.option12_format

This command specifies the format of the option 12 value to be used in the discovery packet of the wireless print server.

Commands	Details
setvar	This command instructs the printer to set the format of option 12 value to be used in the discovery packet of the wireless print server. Format: ! U1 setvar "wlan.ip.dhcp.option12_format" "value" Values: string Default: ""
getvar	This command retrieves the format of option 12 value to be used in the discovery packet of the wireless print server. Format: ! U1 getvar "wlan.ip.dhcp.option12_format"



Example: This setvar example shows configuring the wlan.ip.dhcp.option12_format to the value contained in the device.friendly_name.

It is necessary to surround the SGD entry to be used as source for the data with the < and > characters.

```
! U1 setvar "wlan.ip.dhcp.option12_format" "<device.friendly_name>"
```

To further explain, if the above command was issued and the value currently stored in the device.friendly_name parameter was "ShipPrinter", then the response to following command would be "ShipPrinter":

```
! U1 getvar "wlan.ip.dhcp.option12_value"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.option12_value

This command retrieves the actual value which will be used in the discovery packet of the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves the actual value which will be used in the discovery packet of the wireless print server. Format: <code>! U1 getvar "wlan.ip.dhcp.option12_value"</code>



Example: This `setvar` example shows configuring the `wlan.ip.dhcp.option12_format` to the value contained in the `device.friendly_name`.

It is necessary to surround the SGD entry to be used as source for the data with the `<` and `>` characters.

```
! U1 setvar "wlan.ip.dhcp.option12_format" "<device.friendly_name>"
```

To further explain, if the above command was issued and the value currently stored in the `device.friendly_name` parameter was "ShipPrinter", then the response to following command would be "ShipPrinter":

```
! U1 getvar "wlan.ip.dhcp.option12_value"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.request_timeout

This command sets the maximum time (in seconds) to wait for a response to a DHCP discovery request on the wireless print server.

Commands	Details
setvar	<p>This command instructs the printer to set the maximum time (in seconds) to wait for a response to a DHCP discovery request on the wireless print server.</p> <p>Format: ! U1 setvar "wlan.ip.dhcp.request_timeout" "value"</p> <p>Values: "2" through "30"</p> <p>Default: "2"</p>
getvar	<p>This command retrieves the maximum time (in seconds) to wait for a response to a DHCP discovery request on the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.dhcp.request_timeout"</p>



Example: This setvar example shows the value set to "2".

```
! U1 setvar "wlan.ip.dhcp.request_timeout" "2"
```

When the setvar value is set to "2", the getvar result is "2".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.requests_per_session

This command retrieves the maximum amount of DHCP discover requests for a single DHCP session on the wireless print server.

Commands	Details
setvar	This command instructs the printer to set the maximum amount of DHCP discover requests for a single DHCP session on the wireless print server. Format: ! U1 setvar "wlan.ip.dhcp.requests_per_session" "value" Values: "1" through "10" Default: "2"
getvar	This command retrieves the currently set maximum amount of DHCP discover requests for a single DHCP session on the wireless print server. Format: ! U1 getvar "wlan.ip.dhcp.requests_per_session"



Example: This setvar example shows the value set to "2".
! U1 setvar "wlan.ip.dhcp.requests_per_session" "2"
When the setvar value is set to "2", the getvar result is "2".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dhcp.session_interval

This command retrieves how long it will take for a DHCP session to time out before a new DHCP session begins on the wireless print server.

Commands	Details
setvar	This command instructs the printer to set the DHCP session time out. Format: ! U1 setvar "wlan.ip.dhcp.session_interval" "value" Values: "0" through "60" Default: "10"
getvar	This command retrieves the current DHCP session time out. Format: ! U1 getvar "wlan.ip.dhcp.session_interval"



Example: This setvar example shows the value set to "10".

```
! U1 setvar "wlan.ip.dhcp.session_interval" "10"
```

When the setvar value is set to "10", the getvar result is "10".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.dns.servers

This command retrieves a space delimited list of the domain name servers from a wlan print server.

`getvar`

Commands	Details
<code>getvar</code>	This command retrieves a list of space delimited DNS wlan print servers. Format: ! U1 <code>getvar "wlan.ip.dns.servers"</code>



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.gateway

This command instructs the printer to change the wireless print server's gateway address.



Note • This setting refers to the gateway address. A set value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the wireless printer server's gateway address. Format: ! U1 setvar "wlan.ip.gateway" "value" Values: Any valid gateway address Default: "0.0.0.0"
getvar	This command instructs the printer to respond with the wireless printer server's gateway address. Format: ! U1 getvar "wlan.ip.gateway"



Example: This setvar example shows the value set to "10.3.5.1".

```
! U1 setvar "wlan.ip.gateway" "10.3.5.1"
```

When the setvar value is set to "10.3.5.1", the getvar result is "10.3.5.1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.netmask

This setting refers to the wireless print server's subnet mask address. This value is ignored if the IP protocol is not set to permanent.

Commands	Details
setvar	This command instructs the printer to change the wireless print servers's subnet mask. Format: ! U1 setvar "wlan.ip.netmask" "value" Values: Any valid subnet mask. Default: "255.255.255.0"
getvar	This command instructs the printer to respond with wireless print server's subnet mask. Format: ! U1 getvar "wlan.ip.netmask"



Example: This setvar example shows the value set to "255.255.255.0".

```
! U1 setvar "wlan.ip.netmask" "255.255.255.0"
```

When the setvar value is set to "255.255.255.0", the getvar result is "255.255.255.0".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.port

This printer setting refers to the wireless print server's port number that the TCP print service is listening on. Normal TCP communications from the host should be directed to this port.

Commands	Details
setvar	This command instructs the printer to set the wireless print server's TCP/UDP port number. Format: ! U1 setvar "wlan.ip.port" "value" Values: 1 - 65535 (excluding any ports currently used by other services, such as 21, 23, 80, and 515). Default: "9100"
getvar	This command instructs the printer to respond with the wireless printer server's TCP/UDP port number. Format: ! U1 getvar "wlan.ip.port"



Example: This `setvar` example shows the value set to "9100".

```
! U1 setvar "wlan.ip.port" "9100"
```

When the `setvar` value is set to "9100", the `getvar` result is "9100".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.port_alternate

This command sets the port number of the alternate wlan port.



Note • Print servers supporting this command will monitor both the primary port and the alternate port for connections at the same time.

Commands	Details
setvar	This command sets the alternate wlan port for the print server. Format: ! U1 setvar "wlan.ip.port_alternate" "value" Values: Any valid TCP port address. Default: 9100
getvar	This command returns the current alternate wlan port setting. Format: ! U1 getvar "wlan.ip.port_alternate" Values: The current port setting.



Example 1 • This setvar example shows the value set to "6101".
`U1 setvar "wlan.ip.port_alternate" "6101"`



Example 2 • This setvar example sets the channel mask to use only channels 1,6,11.
`! U1 setvar "wlan.channel_mask" "0x421"`
Result: Only channels 1, 6, and 11 will be used by the radio.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

Supported Devices ZT200 Series

wlan.ip.port_json_config

This command determines the TCP port number to listen on for JSON configuration packets.

Supported Devices

- iMZ 220™, iMZ 320™
- QLn220™, QLn320™, QLn420™
- ZT210™, ZT220™, ZT230™

Type setvar; getvar

Commands	Details
setvar	This command determines the TCP port number on which to listen for JSON configuration packets. Format: ! U1 setvar "wlan.ip.port_json_config" "value" Values: Any valid port number except ports already in use or the standard network ports. <ul style="list-style-type: none"> • 0 = disable the port • 1-65535 = port number to listen on. Default: "9200"
getvar	This command retrieves the TCP port number which is listening for JSON configuration packets. Format: ! U1 getvar "wlan.ip.port_json_config"



Example: In this example, the `getvar` command causes the printer to get the TCP port number which is listening for JSON configuration packets.

```
! U1 getvar "wlan.ip.port_json_config"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.protocol

This command configures the IP addressing method used by the wireless print server.

Commands	Details
setvar	<p>This command instructs the printer to configure the IP addressing method used by the wireless print server.</p> <p>Format: ! U1 setvar "wlan.ip.protocol" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "bootp" = uses the standard bootp addressing method to obtain an IP address and configuration "dhcp" = uses the standard dhcp addressing method to obtain an IP address and configuration for a server specified period of time "rarp" = uses the standard rarp addressing method to obtain an IP address "glean only" = uses the IP address from a PING packet that is sent to its hardware address (unicast address) "permanent" = uses static values assigned through other commands "all" = tries all of the dynamic addressing methods, not permanent, to obtain an IP address <p>Default: "all"</p>
getvar	<p>This command returns the value of the currently selected IP protocol used by the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.protocol"</p>



Example: In this example, the **setvar** result is the current programming language that the printer is using.

```
! U1 setvar "wlan.ip.protocol" "bootp"
```

What the **setvar** value is set to is the **getvar** result. In this example, the **getvar** result is "bootp".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.timeout.enable

This network setting refers to enabling the connection timeout on the wireless print server. For this to take effect, the print server must be reset.

Commands	Details
setvar	<p>This command instructs the printer to enable or disable the timeout checking on the wireless print server.</p> <p>Format: ! U1 setvar "wlan.ip.timeout.enable" "value"</p> <p>Values: "off" = turns off the connection checking "on" = turns on the connection checking</p> <p>Default: "on"</p>
getvar	<p>This command instructs the printer to return whether the timeout checking is enabled on the wireless print server.</p> <p>Format: ! U1 getvar "wlan.ip.timeout.enable"</p>



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.ip.timeout.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.timeout.value

This network setting refers to the number of seconds before the connection times out for the wireless print server. For this to take effect, the print server must be reset.

Commands	Details
setvar	This command instructs the printer to set the the time value of the wireless print server, in seconds, before the connection times out. Format: ! U1 setvar "wlan.ip.timeout.value" "value" Values: "1" through "3600" Default: "300"
getvar	This command instructs the printer to respond with the time, in seconds, before the connection times out. Format: ! U1 getvar "wlan.ip.timeout.value"



Example: This setvar example shows the value set to "300".

```
! U1 setvar "wlan.ip.timeout.value" "300"
```

When the setvar value is set to "300", the getvar result is "300".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.wins.addr

Specifies the WINS server address. If WINS Addressing is done via DHCP, then this value will automatically be filled by the DHCP server.

Commands	Details
setvar	Format: ! U1 setvar "wlan.ip.wins.addr" "value" Values: a valid IP address Default: "0.0.0.0"
getvar	Format: ! U1 getvar "wlan.ip.wins.addr"

**Note •**

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.ip.wins.permanent_source

Specifies if the source of the WINS address is DHCP or if it is set manually.

Commands	Details
setvar	Format: ! U1 setvar "wlan.ip.wins.permanent_source" "value" Values: "off": Use DHCP assigned WINS address "on": Use manually set WINS address (set via wlan.ip.wins.addr) Default: "off"
getvar	Format: ! U1 getvar "wlan.ip.wins.permanent_source"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.keep_alive.enable

This setting controls the printers ability to send a LSAP (link service access point) packet to the access point on an user controllable interval. This feature is included to accommodate access points that require a regular confirmation that wireless clients are still active.

Commands	Details
setvar	<p>This command instructs the printer to send a LSAP (link service access point) packet to the access point on an user controllable interval.</p> <p>Format: ! U1 setvar "wlan.keep_alive.enable" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "on" = turns on keep_alive "off" = turns off keep_alive <p>Default: "on"</p>
getvar	<p>This command instructs the printer to respond with the wlan.keep_alive.enable setting.</p> <p>Format: ! U1 getvar "wlan.keep_alive.enable"</p>



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.keep_alive.enable" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.keep_alive.timeout

This printer setting manages the interval at which the LSAP (link service access point) packet is sent.

Commands	Details
setvar	This command instructs the printer to configure the frequency at which the printer sends the <code>wlan.keep_alive</code> packet. Format: ! U1 setvar "wlan.keep_alive.timeout" "value" Values: 5 to 300 seconds Default: "15"
getvar	This command instructs the printer to respond with the <code>wlan.keep_alive.timeout</code> interval value. Format: ! U1 getvar "wlan.keep_alive.timeout"



Example: This setvar example shows the value set to "15".

```
! U1 setvar "wlan.keep_alive.timeout" "15"
```

When the setvar value is set to "15", the getvar result is "15".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.kerberos.kdc

This printer setting refers to the Kerberos Key Distribution Center (KDC). The KDC is a trusted server which maintains a database with account information for all security principals (users) for a particular site or administrative domain (realm).

Commands	Details
setvar	This command instructs the printer to change the Kerberos KDC. Format: ! U1 setvar "wlan.kerberos.kdc" "value" Values: 0-32 ASCII characters Default: "krbtgt"
getvar	This command instructs the printer to respond with the current Kerberos KDC. Format: ! U1 getvar "wlan.kerberos.kdc"



Example: This setvar example shows the value set to "krbtgt".

```
! U1 setvar "wlan.kerberos.kdc" "krbtgt"
```

When the setvar value is set to "krbtgt", the getvar result is "krbtgt".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.kerberos.mode

This printer setting refers to the Kerberos network authentication protocol. Kerberos provides secure mutual authentication for a wireless client through a Symbol Access Point, based on user information stored on a Kerberos KDC (Key Distribution Center) server.

Commands	Details
setvar	This command instructs the printer to turn Kerberos mode "on" or "off". Format: ! U1 setvar "wlan.kerberos.mode" "values" Values: "off" = disables Kerberos mode "on" = enables Kerberos mode Default: "off"
getvar	This command instructs the printer to respond with the current Kerberos mode. Format: ! U1 getvar "wlan.kerberos.mode"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.kerberos.mode" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.kerberos.password

This printer setting refers to the Kerberos password. The password must correspond to a user profile established on the Kerberos KDC server in use.

Commands	Details
setvar	This command instructs the printer to set the Kerberos password. Format: ! U1 setvar "wlan.kerberos.password" "value" Values: 0-32 alphanumeric characters Default: "password"
getvar	This command instructs the printer to respond with the current Kerberos password. Format: ! U1 getvar "wlan.kerberos.password" For protection a single "*" prints.



Example: This setvar example shows the value set to "password".

```
! U1 setvar "wlan.kerberos.password" "password"
```

When the setvar value is set to "password", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.kerberos.realm

This printer setting refers to the Kerberos realm, an administrative domain with its own Kerberos server (KDC).



Important • If you are using a Windows 2000 Server the realm must be all upper-case. For details, see [Example 2](#) below.

Commands	Details
setvar	This command instructs the printer to change the Kerberos realm. Format: ! U1 setvar "wlan.kerberos.realm" "value" Values: 0-64 alphanumeric characters Default: "kerberos"
getvar	This command instructs the printer to respond with the current Kerberos realm. Format: ! U1 getvar "wlan.kerberos.realm"



Example 1 • This setvar example shows the value set to "zebra".

```
! U1 setvar "wlan.kerberos.realm" "zebra"
```

When the setvar value is set to "zebra", the getvar result is "zebra".



Example 2 • This setvar example shows the value set to "ZEBRA" on a Windows 2000 server.

```
! U1 setvar "wlan.kerberos.realm" "ZEBRA"
```

When the setvar value is set to "ZEBRA", the getvar result is "ZEBRA".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.kerberos.username

This printer setting refers to the Kerberos user name. The user name must correspond to a user profile established on the Kerberos KDC server in use.

Commands	Details
setvar	This command instructs the printer to change the Kerberos user name. Format: ! U1 setvar "wlan.kerberos.username" "value" Values: 0-32 alphanumeric characters Default: "user"
getvar	This command instructs the printer to respond with the current Kerberos user name. Format: ! U1 getvar "wlan.kerberos.username"



Example: This setvar example shows the value set to "user".

```
! U1 setvar "wlan.kerberos.username" "user"
```

When the setvar value is set to "user", the getvar result is "user".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.leap_mode

This printer setting refers to Cisco LEAP (Lightweight Extensible Authentication Protocol). LEAP provides secure mutual authentication for a wireless client through a Cisco Aironet Access Point, based on user information stored on a backend RADIUS (Remote Authentication in Dial-Up User Service) /AAA (Authentication, Authorization, and Accounting) server.



Note •

1. This command is only supported on printers using firmware Vxx.18.xx or earlier.
2. This command is not supported on units with a Frequency Hopping Spread Spectrum (FHSS) radio.

Commands	Details
setvar	This command instructs the printer to turn the LEAP mode "on" or "off". Format: ! U1 setvar "wlan.leap_mode" "values" Values: "off" = disables LEAP mode "on" = enables LEAP mode Default: "off"
getvar	This command instructs the printer to respond with the LEAP mode. Format: ! U1 getvar "wlan.leap_mode"



Example: This setvar example shows the value set to "on".

```
! U1 setvar "wlan.leap_mode" "on"
```

When the setvar value is set to "on", the getvar result is "on".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.leap_password

This printer setting refers to the LEAP password. The password must correspond to a user profile established on the RADIUS/AAA server in use.



Note • This parameter is not supported on units with a Frequency Hopping Spread Spectrum (FHSS) radio.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.leap_username

This printer setting refers to the LEAP user name. The user name must correspond to a user profile established on the RADIUS/AAA server in use.



Note • This parameter is not supported on units with a Frequency Hopping Spread Spectrum (FHSS) radio.

Commands	Details
setvar	This command instructs the printer to change the LEAP user name. Format: ! U1 setvar "wlan.leap_username" "values" Values: 0-32 alphanumeric ASCII characters. Default: "user"
getvar	This command instructs the printer to respond with the LEAP user name. Format: ! U1 getvar "wlan.leap_username"



Example: This setvar example shows the value set to "user".

```
! U1 setvar "wlan.leap_username" "user"
```

When the setvar value is set to "user", the getvar result is "user".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.mac_addr

This command retrieves the MAC address of the wireless print server.

`getvar`

Commands	Details
<code>getvar</code>	This command instructs the printer to respond with the MAC address of the wireless print server. Format: <code>! U1 getvar "wlan.mac_addr"</code>



Example: In this example, the `getvar` result is the MAC address for the wireless print server.

`! U1 getvar "wlan.mac_addr"`



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.mac_raw

This command specifies the RAW MAC address of the wireless print server. The raw mac address is the mac address without the colons (":").

getvar

Commands	Details
getvar	This command retrieves the RAW MAC address of the wireless print server. Format: ! U1 getvar "wlan.mac_raw"



Example: In this example, the `getvar` retrieves the RAW MAC address of the wireless print server.

```
! U1 getvar "wlan.mac_raw"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.operating_mode

This printer setting refers to the network operating mode. Infrastructure mode means that the printer will try to associate with an access point. Ad hoc mode means that the printer will try to associate with a device other than an access point and join a standalone network.

To use "ad hoc" mode configure the printer as follows:

- Set the ESSID to the new network's ESSID.
- Turn off the DHCP and assign an IP Address to the printer.
- Set the subnet mask on the printer to the new network's subnet mask.
- Change the operating mode on the printer to "ad hoc".

Commands	Details
setvar	This command instructs the printer to set the network operating mode. Format: ! U1 setvar "wlan.operating_mode" "value" Values: "adhoc" = printer will try to associate with a network device "infrastructure" = printer will try to associate with an access point Format: "infrastructure"
getvar	This command instructs the printer to respond with the network-mode value. Format: ! U1 getvar "wlan.operating_mode"



Example: This setvar example shows the value set to "infrastructure".

```
! U1 setvar "wlan.operating_mode" "infrastructure"
```

When the setvar value is set to "infrastructure", the getvar result is "infrastructure".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.password

This printer setting refers to the generic password that is used by the wireless securities that need a password.



Important • Kerberos has its own password field

Commands	Details
setvar	This command instructs the printer to set a generic password for the wireless securities that need a password. Format: ! U1 setvar "wlan.password" "value" Values: A maximum of 32 alphanumeric characters. Default: "password"
getvar	This command instructs the printer to respond with a generic password for wireless securities. Format: ! U1 getvar "wlan.password" For protection a single "*" prints.



Example: This setvar example shows the value set to "password".

```
! U1 setvar "wlan.password" "password"
```

When the setvar value is set to "password", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.permitted_channels

This command returns the list of permitted channels.

Related Commands:

- [wlan.active_channels](#) on page 1209
- [wlan.allowed_band](#) on page 1214

Supported Devices ZT200 Series

Type `getvar`

Commands	Details
<code>getvar</code>	<p>This command returns the list of permitted channels within the defined country or region.</p> <p>Format: ! U1 <code>getvar "wlan.permitted_channels"</code></p> <p>Result: One or more of the following channels: 1,2,3,4,5,6,7,8,9,10,11,36,40,44,48,52,56,60,64,100,104,108,112,116,132,136,140</p>



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

wlan.poor_signal_threshold

Sets or returns the poor signal threshold value. The poor signal threshold is a percentage of the signal strength.

Commands	Details
setvar	Format: ! U1 setvar "wlan.poor_signal_threshold" "value" Values: 0-100 Default: "0"
getvar	Format: ! U1 getvar "wlan.poor_signal_threshold"

Supported Devices

- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.preamble

This printer setting selects the radio preamble length to be used.

Commands	Details
setvar	This command instructs the printer to set the preamble length. Format: ! U1 setvar "wlan.preamble" "value" Values: "long" = enables long preamble "short" = enables short preamble Default: "long"
getvar	This command instructs the printer to respond with the current preamble length. Format: ! U1 getvar "wlan.preamble"



Example: This setvar example shows the value set to "long".

```
! U1 setvar "wlan.preamble" "long"
```

When the setvar value is set to "long", the getvar result is "long".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.private_key_password

This printer setting allows the setting of the optional private key password.

Commands	Details
setvar	This command instructs the printer to set the private key password. Format: ! U1 setvar "wlan.private_key_password" "value" Values: A maximum of 32 alphanumeric characters Default: ""
getvar	This command instructs the printer to respond with the value of the private key password. Format: ! U1 getvar "wlan.private_key_password" For protection a single "*" prints.



Example: This setvar example shows the value set to "password".

```
! U1 setvar "wlan.private_key_password" "password"
```

When the setvar value is set to "password", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.region_code

This command defines the regulatory country for which the radio is currently configured.

Commands	Details
setvar	This command sets the region code for which the radio is to be configured. ! U1 setvar "wlan.region_code" "value" Values: <ul style="list-style-type: none">• not available• usa/canada• japan• rest of world
getvar	This command retrieves the region code for which the radio is currently configured. ! U1 getvar "wlan.country_code"

**Note •**

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

wlan.roam.interchannel_delay

This command sets how long of a delay before scanning the next channel when roaming.

Commands	Details
setvar	This command sets how long of a delay before scanning the next channel when roaming. The values are in milliseconds. Format: ! U1 setvar "wlan.roam.interchannel_delay" "value" Values: 0 to 30000 Default: "400"
getvar	This command retrieves the current set delay time before scanning the next channel when roaming. Format: ! U1 getvar "wlan.roam.interchannel_delay"



Example: This setvar example shows the value set to "400".

```
! U1 setvar "wlan.roam.interchannel_delay" "400"
```

The getvar result returns the current setvar value. In this example, the getvar result is "400".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.roam.interval

This printer setting refers to specifying the wireless roam interval.

Commands	Details
setvar	This command instructs the printer to set the wireless roam interval. Format: ! U1 setvar "wlan.roam.interval" "value" Values: Decimal values between 5 and 255 inclusive Default: "20"
getvar	This command instructs the printer to respond with the specified roam interval. Format: ! U1 getvar "wlan.roam.interval"



Example: This setvar example shows the value set to "20".

```
! U1 setvar "wlan.roam.interval" "20"
```

When the setvar value is set to "20", the getvar result is "20".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.roam.max_chan_scan_time

This command sets how long the radio waits on a channel looking for probe responses.

Commands	Details
setvar	This command sets how long the radio waits on a channel looking for probe responses. The values are in milliseconds. Format: ! U1 setvar "wlan.roam.max_chan_scan_time" "value" Values: 10 to 500 Default: "100"
getvar	This command retrieves the current setting for how long the radio waits on a channel looking for probe responses. Format: ! U1 getvar "wlan.roam.max_chan_scan_time"



Example: This setvar example shows the value set to "100".

```
! U1 setvar "wlan.roam.max_chan_scan_time" "100"
```

The getvar result returns the current setvar value. In this example, the getvar result is "100".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.roam.max_fail

This command determines the number of consecutive tx packet failures, at which point the radio should start its roaming algorithm.

Commands	Details
setvar	This command sets the max_fail threshold value. Format: ! U1 setvar "wlan.roam.max_fail" "value" Values: 2 to 75 inclusive Default: 10
getvar	This command returns the number for the max_fail threshold. Format: ! U1 getvar "wlan.roam.max_fail"



Example: In this example, the setvar sets the max_fail threshold value to 30 packets.

```
! U1 setvar "wlan.roam.max_fail" "30"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.roam.rssi

This command allows you to specify the absolute value of the negative dBm for the RSSI threshold, which is the point at which the radio will start the roaming algorithm.

Commands	Details
setvar	This command sets the RSSI threshold value. Format: ! U1 setvar "wlan.roam.rssi" "value" Values: 60 to 125 Default: 74
getvar	This command retrieves the absolute value of the negative dBm for the RSSI threshold. Format: ! U1 getvar "wlan.roam.rssi"



Example: In this example, the setvar sets the RSSI threshold value to -80 dBm.

```
! U1 setvar "wlan.roam.rssi" "80"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.roam.signal

This printer setting refers to specifying the wireless roam signal.

Commands	Details
setvar	This command instructs the printer to set the wireless roam signal. Format: ! U1 setvar "wlan.roam.signal" "value" Values: Decimal values between 1 and 75 inclusive. Default: "50"
getvar	This command instructs the printer to respond with the specified wireless roam signal. Format: ! U1 getvar "wlan.roam.signal"



Example: This `setvar` example shows the value set to "50".

```
! U1 setvar "wlan.roam.signal" "50"
```

When the `setvar` value is set to "50", the `getvar` result is "50".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.rts_cts_enabled

Enables the RTS/CTS HT protection frames when configuring a WLAN connection, preventing interference with other nearby 802.11 signals. If the protection frames are not enabled, the WLAN radio will use CTS-to-self.

Commands	Details
setvar	Format: ! U1 setvar "wlan.rts_cts_enabled" "value" Values: on, off Default: off
getvar	Format: ! U1 getvar "wlan.rts_cts_enabled" Values: on, off



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.security

This printer setting allows you to specify both the wireless encryption type and authentication type in one command.



Note • The supporting parameters that are required vary based on the security type that you select. See [Supporting SGD Commands for Different Security Types on page 1288](#) for instructions for each security type.

When using certificate files, Zebra printers support:

- using Privacy Enhanced Mail (PEM) formatted certificate files.
- using the client certificate and private key as two files, each downloaded separately.
- using exportable PAC files for EAP-FAST.

These certificate files can only be sent using ZPL, not SGD. The ZPL command to use when sending these certificate files is the `~DY` command.

Configuring the printer for WPA also allows the printer to be used in WPA2 environments.



Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.

Commands	Details
setvar	<p>This command instructs the printer to set the wireless security value.</p> <p>Format: <code>! U1 setvar "wlan.security" "value"</code></p> <p>Values:</p> <ul style="list-style-type: none"> "1" = No wireless security or "none" "2" = WEP 40-bit or "wep 40-bit" "3" = WEP 128-bit or "wep 128-bit" "4" = EAP-TLS or "eap-tls" "5" = EAP-TTLS or "eap-ttls" "6" = EAP-FAST or "eap-fast" "7" = PEAP or "peap" "8" = LEAP or "leap" "9" = WPA PSK or "wpa psk" (Key rotation for WPA2 PSK is supported in firmware versions V53.15.8Z , V60.15.8Z, and later.) "10" = WPA EAP-TLS or "wpa eap-tls" "11" = WPA EAP-TTLS or "wpa eap-ttls" "12" = WPA EAP-FAST or "wpa eap-fast" "13" = WPA PEAP or "wpa peap" "14" = WPA LEAP or "wpa leap" "15" = Kerberos or "kerberos" <p>Default: "1"</p>
getvar	<p>This command instructs the printer to return the name and not the type. If an invalid security mode is entered the printer returns Invalid Mode.</p> <p>Format: <code>! U1 getvar "wlan.security" "value"</code></p>



Example: This `setvar` example shows the value set to "1".

```
! U1 setvar "wlan.security" "1"
```

When the `setvar` value is set to "1", the `getvar` result is "none".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

Supporting SGD Commands for Different Security Types

The supporting SGD commands required for `wlan.security` vary based on the security type that you select. You must send the additional commands for your printer to be able to work on your wireless network. Follow the example and format for your specific security type in this section, substituting your own wireless network data.

Security Type 1: No Wireless Security Active

Additional parameters that need to be set: none



Example: This example turns off all wireless securities controlled under this command, but it does not reset the printer's wireless settings to their defaults.

```
! U1 setvar "wlan.security" "1"
```

Security Type 2: WEP 40-Bit

Additional parameters that need to be set and the SGD commands to use:

- WEP encryption index (see [wlan.wep.index on page 1305](#))
- WEP authentication type (see [wlan.wep.auth_type on page 1304](#))
- WEP key type (see [wlan.wep.key_format on page 1311](#))
- the actual values of any WEP encryption keys to be used (see [wlan.wep.key1 on page 1306](#), [wlan.wep.key2 on page 1307](#), [wlan.wep.key3 on page 1308](#), or [wlan.wep.key4 on page 1309](#))



Example: This example configures the printer for WEP 40-bit encryption using index key 1, open authentication, and a hexadecimal WEP key with a value of "A1B2C3D4F5."

```
! U1 setvar "wlan.security" "2"  
! U1 setvar "wlan.wep.index" "1"  
! U1 setvar "wlan.wep.auth_type" "open"  
! U1 setvar "wlan.wep.key_format" "hex"  
! U1 setvar "wlan.wep.key1" "A1B2C3D4F5"
```

Security Type 3: WEP 128-Bit

Additional parameters that need to be set and the SGD commands to use:

- WEP encryption index (see [wlan.wep.index on page 1305](#))

- WEP authentication type (see [wlan.wep.auth_type](#) on page 1304)
- WEP key type (see [wlan.wep.key_format](#) on page 1311)
- the actual values of any WEP encryption keys to be used (see [wlan.wep.key1](#) on page 1306, [wlan.wep.key2](#) on page 1307, [wlan.wep.key3](#) on page 1308, or [wlan.wep.key4](#) on page 1309)



Example: This example configures the printer for WEP 128-bit encryption using index key 2, open authentication, and four hexadecimal WEP keys.

```
! U1 setvar "wlan.security" "3"  
! U1 setvar "wlan.wep.index" "2"  
! U1 setvar "wlan.wep.auth_type" "open"  
! U1 setvar "wlan.wep.key_format" "hex"  
! U1 setvar "wlan.wep.key1" "001122334455667788"  
! U1 setvar "wlan.wep.key2" "112233445566778899"  
! U1 setvar "wlan.wep.key3" "223344556677889900"  
! U1 setvar "wlan.wep.key4" "334455667788990011"
```

Security Type 4: EAP-TLS

Additional parameters that need to be set and the SGD commands to use:

- optional private key password (see [wlan.private_key_password](#) on page 1278)



Example: This example configures the printer for EAP-TLS authentication with an optional private key password with a value of "private."

```
! U1 setvar "wlan.security" "4"  
! U1 setvar "wlan.private_key_password" "private"
```

Security Type 5: EAP-TTLS

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username](#) on page 1301)
- password (see [wlan.password](#) on page 1274)



Example: This example configures the printer for EAP-TTLS authentication, including a user ID with a value of "user" and a password with a value of "password."

```
! U1 setvar "wlan.security" "5"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"
```

Security Type 6: EAP-FAST

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))
- optional private key password (see [wlan.private_key_password on page 1278](#))



Example: This example configures the printer for EAP-FAST authentication, including a user ID of “user,” a password of “password,” and an optional private key of “private.”

```
! U1 setvar "wlan.security" "6"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"  
! U1 setvar "wlan.private_key_password" "private"
```

Security Type 7: PEAP

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))



Example: This example configures the printer for PEAP authentication, including a user ID with a value of “user” and a password with a value of “password.”

```
! U1 setvar "wlan.security" "7"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"
```

Security Type 8: LEAP

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))



Example: This example configures the printer for LEAP authentication, including a user ID with a value of “user” and a password with a value of “password.”

```
! U1 setvar "wlan.security" "8"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"
```

Security Type 9: WPA PSK



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments. Key rotation for WPA2 PSK is supported in firmware version 60.15.8Z and later and in firmware version 53.15.8Z and later.

Additional parameters that need to be set and the SGD commands to use:

- Pre-Shared Key (PSK) value (see [wlan.wpa.psk on page 1310](#))



Example: This example configures the printer for WPA PSK authentication with a PSK value of all zeroes (64 hexadecimal digits).

```
! U1 setvar "wlan.security" "9"  
! U1 setvar "wlan.wpa.psk" "00000000..."
```

Security Type 10: WPA EAP-TLS



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Additional parameters that need to be set and the SGD commands to use:

- optional private key password (see [wlan.private_key_password on page 1278](#))



Example: This example configures the printer for WPA EAP-TLS authentication with an optional private key password with a value of "private."

```
! U1 setvar "wlan.security" "10"  
! U1 setvar "wlan.private_key_password" "private"
```

Security Type 11: WPA EAP-TTLS



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))



Example: This example configures the printer for WPA EAP-TTLS authentication, including a user ID with a value of “user” and a password with a value of “password.”

```
! U1 setvar "wlan.security" "11"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"
```

Security Type 12: WPA EAP-FAST



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))
- optional private key password (see [wlan.private_key_password on page 1278](#))



Example: This example configures the printer for WPA EAP-FAST authentication, including a user ID of “user,” a password of “password,” and an optional private key of “private.”

```
! U1 setvar "wlan.security" "12"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"  
! U1 setvar "wlan.private_key_password" "private"
```

Security Type 13: WPA PEAP



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))



Example: This example configures the printer for WPA PEAP authentication, including a user ID with a value of “user” and a password with a value of “password.”

```
! U1 setvar "wlan.security" "13"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"
```

Security Type 14: WPA LEAP



Note • Configuring the printer for WPA also allows the printer to be used in WPA2 environments.

Additional parameters that need to be set and the SGD commands to use:

- user ID (see [wlan.username on page 1301](#))
- password (see [wlan.password on page 1274](#))



Example: This example configures the printer for WPA LEAP authentication, including a user ID with a value of “user” and a password with a value of “password.”

```
! U1 setvar "wlan.security" "14"  
! U1 setvar "wlan.username" "user"  
! U1 setvar "wlan.password" "password"
```

Security Type 15: Kerberos

Additional parameters that need to be set and the SGD commands to use:

- Kerberos user ID (see [wlan.kerberos.username on page 1267](#))
- Kerberos password (see [wlan.kerberos.password on page 1265](#))
- realm (see [wlan.kerberos.realm on page 1266](#))
- Key Distribution Center (KDC) (see [wlan.kerberos.kdc on page 1263](#))



Example: This example configures the printer for Kerberos encryption, including a Kerberos user ID with a value of “user,” a Kerberos password with a value of “password,” a realm of “zebra,” and a KDC of “krbtgt.”

```
! U1 setvar "wlan.security" "15"  
! U1 setvar "wlan.kerberos.username" "user"  
! U1 setvar "wlan.kerberos.password" "password"  
! U1 setvar "wlan.kerberos.realm" "zebra"  
! U1 setvar "wlan.kerberos.kdc" "krbtgt"
```

wlan.signal_noise

This command returns the signal noise on the wireless network. Values above 40% represent a very significant noise, and radio communication is not reliable.

getvar

Commands	Details
getvar	This command instructs the printer to return the current signal noise on the wireless network. Format: ! U1 getvar "wlan.signal_noise"



Example: In this example, the getvar result is the current signal_noise value.

```
! U1 getvar "wlan.signal_noise"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.signal_quality

This command instructs the printer to return the current signal quality of the wireless network. Values below 40% represent a very poor signal quality, and radio communication is not reliable.

getvar

Commands	Details
getvar	This command instructs the printer to return the current signal quality of the wireless network. Format: ! U1 getvar "wlan.signal_quality"



Example: In this example, the getvar result is the current signal_quality value.

```
! U1 getvar "wlan.signal_quality"
```



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.signal_strength

This command returns the signal strength of the connection to the access point as a percentage value between zero (not connected) and 100 (strongest signal). Values below 40% represent a very poor signal and radio communication is not reliable.

getvar

Commands	Details
getvar	This command instructs the printer to respond with the current signal strength. Format: ! U1 getvar "wlan.signal_strength"



Example: In this example, the getvar result is "93".
! U1 getvar "wlan.signal_strength"



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.station_name

This printer setting refers to the station name.

Commands	Details
setvar	This command instructs the printer to set the station name. Format: ! U1 setvar "wlan.station_name" "value" Values: A maximum of 32 alphanumeric characters Default: "ZEBRA"
getvar	This command instructs the printer to respond with the station name value. Format: ! U1 getvar "wlan.station_name"



Example: This setvar example shows the value set to "ZEBRA".

```
! U1 setvar "wlan.station_name" "ZEBRA"
```

When the setvar value is set to "ZEBRA", the getvar result is "ZEBRA".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.tx_power

This printer setting refers to specifying the wireless transmit power.

Commands	Details
setvar	This command instructs the printer to set the wireless transmit power. Format: ! U1 setvar "wlan.tx_power" "value" Values: Decimal values of 1, 5, 20, 30, 50, 100 Default: "100"
getvar	This command instructs the printer to respond with the wireless transmit power. Format: ! U1 getvar "wlan.tx_power"



Example: This setvar example shows the value set to "100".

```
! U1 setvar "wlan.tx_power" "100"
```

When the setvar value is set to "100", the getvar result is "100".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.tx_rate

This printer setting refers to specifying the wireless transmit rate.

Commands	Details
setvar	This command instructs the printer to set the wireless transmit rate. Format: ! U1 setvar "wlan.tx_rate" "value" Values: 1, 2, 5.5, 11, all Default: "all"
getvar	This command instructs the printer to respond with the wireless transmit rate. Format: ! U1 getvar "wlan.tx_rate"



Example: This setvar example shows the value set to "all".

```
! U1 setvar "wlan.tx_rate" "all"
```

When the setvar value is set to "all", the getvar result is "all".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.user_channel_list

This command sets the list of available channels.

Related Commands:

- [wlan.active_channels](#) on page 1209
- [wlan.allowed_band](#) on page 1214
- [wlan.permitted_channels](#) on page 1275

Commands	Details
setvar	This command sets the list of available channels. Format: ! U1 setvar "wlan.user_channel_list" "value" Values: One or more of the following: 1,2,3,4,5,6,7,8,9,10,11,36,40,44,48,52,56,60,64,100,104,108, 112,116,132,136,140,149,153,157,161,165,all Default: "all"
getvar	This command retrieves the currently set list of available channels. Format: ! U1 getvar wlan.user_channel_list"



Example: This example sets the available channel list to channels 1-9.
! U1 setvar "wlan.user_channel_list" "1,2,3,4,5,6,7,8,9"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support](#) on page 1393.
- For details on SGD command structure, see [Command Structure](#) on page 573.

wlan.username

This printer setting refers to the generic user name that is used by the wireless securities that need a user name.



Important • Kerberos has its own user name field.

Commands	Details
setvar	This command instructs the printer to set a generic user name for wireless securities that need a user name. Format: ! U1 setvar "wlan.username" "value" Values: A maximum of 32 alphanumeric characters Default: "user"
getvar	This command instructs the printer to respond with a generic user name for the wireless securities that need a user name. Format: ! U1 getvar "wlan.username"



Example: This setvar example shows the value set to "user".

```
! U1 setvar "wlan.username" "user"
```

When the setvar value is set to "user", the getvar result is "user".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.waveagent.enable

This command enables/disables the internal agent for support of Veriwave's WaveDeploy system. WaveDeploy is a software product used for performing network site surveys.

Commands	Details
setvar	This command enables or disables internal agent support for waveagent. Format: ! U1 setvar "wlan.waveagent.enable" "value" Values: "off" "on" Default: "off"
getvar	This command instructs the printer to respond with the current waveagent support status. Format: ! U1 getvar "wlan.waveagent.enable"



Example:

```
! U1 setvar "wlan.waveagent.enable" "on"
```

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.waveagent.udp_port

This command specifies the UDP port number used by WaveAgent.

Commands	Details
setvar	This command specifies the port to be used by WaveAgent. Format: ! U1 setvar "wlan.waveagent.udp_port" "value" Values: "1" to "64000" Default: "18100"
getvar	This command instructs the printer to respond with the current port setting for WaveAgent. Format: ! U1 getvar "wlan.waveagent.udp_port"



Example: This setvar example shows the value set to "on".
! U1 setvar "wlan.waveagent.udp_port" "21000"

Supported Devices ZT200 Series



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.auth_type

For the WEP security type, this printer setting selects the authentication type to be used between the printer and the access point. The authentication types are open system and shared key.

Commands	Details
setvar	This command instructs the printer to set the WEP authentication type. Format: ! U1 setvar "wlan.wep.auth_type" "value" Values: "open" = enables the open authentication type "shared" = enables the shared authentication type Default: "open"
getvar	This command instructs the printer to retrieve the current WEP authentication type. Format: ! U1 getvar "wlan.wep.auth_type"



Example: This setvar example shows the value set to "open".

```
! U1 setvar "wlan.wep.auth_type" "open"
```

When the setvar value is set to "open", the getvar result is "open".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.index

This printer setting refers to the WEP (Wired Equivalent Privacy) encryption key index. This printer setting determines which one of the four encryption keys is to be used by the client (printer).

Commands	Details
setvar	<p>This command instructs the printer to set the encryption key index.</p> <p>Format: ! U1 setvar "wlan.wep.index" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> "1" = enables encryption key 1 "2" = enables encryption key 2 "3" = enables encryption key 3 "4" = enables encryption key 4 <p>Default: "1"</p>
getvar	<p>This command instructs the printer to respond with the encryption key index.</p> <p>Format: ! U1 getvar "wlan.wep.index"</p>



Example: This setvar example shows the value set to "1".

```
! U1 setvar "wlan.wep.index" "1"
```

When the setvar value is set to "1", the getvar result is "1".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.key1

This printer setting refers to the first indexed WEP encryption key. The WEP encryption key is a hexadecimal or string value. This key should match the wireless network WEP encryption key 1.

Commands	Details
setvar	This command instructs the printer to set the encryption key. Format: ! U1 setvar "wlan.wep.key1" "value" Values: 10 hexadecimal characters for 40-bit encryption 26 hexadecimal characters for 128-bit encryption Default: All zeros
getvar	This command instructs the printer to respond with the encryption key. Format: ! U1 getvar "wlan.wep.key1" For protection a single "*" prints.



Example: This setvar example shows the value set to "A1B2C3D4F5".
 ! U1 setvar "wlan.wep.key1" "A1B2C3D4F5"
When the setvar value is set to "A1B2C3D4F5", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.key2

This printer setting refers to the second indexed WEP encryption key. The WEP encryption key is a hexadecimal string value. This key should match the wireless network WEP encryption key 2.

Commands	Details
setvar	<p>This command instructs the printer to set the encryption key.</p> <p>Format: ! U1 setvar "wlan.wep.key2" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> 10 hexadecimal characters for 40-bit encryption 26 hexadecimal characters for 128-bit encryption <p>Default: All zeros</p>
getvar	<p>This command instructs the printer respond with the encryption key.</p> <p>Format: ! U1 getvar "wlan.wep.key2"</p> <p>For protection a single "*" prints.</p>



Example: This setvar example shows the value set to "A1B2C3D4F5".
! U1 setvar "wlan.wep.key2" "A1B2C3D4F5"
When the setvar value is set to "A1B2C3D4F5", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.key3

This printer setting refers to the third indexed WEP encryption key. The WEP encryption key is a hexadecimal string value. This key should match the wireless network WEP encryption key 3.

Commands	Details
setvar	This command instructs the printer to set the encryption key. Format: ! U1 setvar "wlan.wep.key3" "value" Values: 10 hexadecimal characters for 40-bit encryption 26 hexadecimal characters for 128-bit encryption Default: All zeros
getvar	This command instructs the printer to respond with the encryption key. Format: ! U1 getvar "wlan.wep.key3" For protection a single "*" prints.



Example: This setvar example shows the value set to "A1B2C3D4F5".
! U1 setvar "wlan.wep.key3" "A1B2C3D4F5"
When the setvar value is set to "A1B2C3D4F5", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.key4

This printer setting refers to the fourth indexed WEP encryption key. The WEP encryption key is a hexadecimal string value. This key should match the wireless network WEP encryption key 4.

Commands	Details
setvar	<p>This command instructs the printer to set the encryption key.</p> <p>Format: ! U1 setvar "wlan.wep.key4" "value"</p> <p>Values:</p> <ul style="list-style-type: none"> 10 hexadecimal characters for 40-bit encryption 26 hexadecimal characters for 128-bit encryption <p>Default: All zeros</p>
getvar	<p>This command instructs the printer respond with the encryption key.</p> <p>Format: ! U1 getvar "wlan.wep.key4"</p> <p>For protection a single "*" prints.</p>



Example: This setvar example shows the value set to "A1B2C3D4F5".
! U1 setvar "wlan.wep.key4" "A1B2C3D4F5"
When the setvar value is set to "A1B2C3D4F5", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wpa.psk

This printer setting specifies the pre-shared key (PSK) value to use when the WPA authentication is set to PSK.

Commands	Details
setvar	This command instructs the printer to set the pre-shared key. Format: ! U1 setvar "wlan.wpa.psk" "value" Values: 64 hexadecimal digits Default: 64 zeros (00000000...)
getvar	This command instructs the printer to respond with the pre-shared key. Format: ! U1 getvar "wlan.wpa.psk" For protection a single "*" prints.



Example: This setvar example shows the value set to "00000000...".

```
! U1 setvar "wlan.wpa.psk" "00000000..."
```

When the setvar value is set to "00000000...", the getvar result is "*".



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wep.key_format

This printer setting specifies the format for the WEP key.



Important • This printer setting should proceed any of the `wep.key` settings if you select a non-default value.

Commands	Details
<code>setvar</code>	<p>This command instructs the printer to set the WEP key format.</p> <p>Format: <code>! U1 setvar "wlan.wep.key_format" "value"</code></p> <p>Values:</p> <ul style="list-style-type: none"> <code>"ascii"</code> = WEP key is set by ASCII string <code>"hex"</code> = WEP key is a Hex string <p>Default: <code>"hex"</code></p>
<code>getvar</code>	<p>This command instructs the printer to respond with the WEP key format.</p> <p>Format: <code>! U1 getvar "wep.key_format"</code></p>



Example: This `setvar` example shows the value set to `"ascii"`.

```
! U1 setvar "wlan.wep.key_format" "ascii"
```

When the `setvar` value is set to `"ascii"`, the `getvar` result is `"ascii"`.



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).



Notes • _____

wlan.wpa.timecheck

Allows the user to disable the certificate timestamp check that is performed during a WPA TLS handshake.

Commands	Details
setvar	! U1 setvar "wlan.wpa.timecheck" "value" Values: "yes" = the timecheck during the handshake will be performed "no" = the timecheck during the handshake will not be performed Default: "yes"
getvar	! U1 getvar "wlan.wpa.timecheck"

Supported Devices

- ZD400, ZD410, ZD420
- ZD500, ZD620
- iMZ 220, iMZ 320
- QLn220, QLn320, QLn420
- ZQ510, ZQ520
- ZT210, ZT220, ZT230
- ZT4004, ZT4006
- ZT510
- ZT610, ZT620



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

wlan.wpa.wpa_version

Returns the currently active WPA version.

Commands	Details
getvar	Format: ! U1 getvar "wlan.wpa.wpa_version" Values: "WPA": WPA being used. "WPA2": WPA2 being used. "": Reported if wireless LAN is not connected or WPA is not enabled.

Supported Devices

- iMZ220, iMZ320
- QLn220, QLn320
- ZD410, ZD420
- ZD500
- ZQ510, ZQ520
- ZR338
- ZR628, ZR638
- ZT210, ZT220, ZT230
- ZT410, ZT420



Note •

- For printer support, see [SGD Command Support on page 1393](#).
- For details on SGD command structure, see [Command Structure on page 573](#).

Zebra Code Pages

This section provides you with a visual of the different Zebra Code pages.

Contents

Zebra Code Page 850 — Latin Character Set.....	1317
Zebra Code Page 1250 — Central and Eastern European Latin Character Set.....	1320
Zebra Code Page 1252— Latin Character Set.....	1322
Zebra Code Page 1253 — Modern Greek Character Set	1324
Zebra Code Page 1254 — Turkish Character Set.....	1326
Zebra Code Page 1255 — Hebrew Character Set.....	1328

Zebra Code Page 850 — Latin Character Set

This is the Zebra Code Page 850:



Note • For hex 5C, a cent sign prints for all printer resident fonts. A backslash prints for downloaded fonts.

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC
	20	32	0	30	48	@	40	64	P	50	80	'	60	96	p	70	112	Ç	80	128
!	21	33	1	31	49	A	41	65	Q	51	81	a	61	97	q	71	113	ü	81	129
"	22	34	2	32	50	B	42	66	R	52	82	b	62	98	r	72	114	é	82	130
#	23	35	3	33	51	C	43	67	S	53	83	c	63	99	s	73	115	â	83	131
\$	24	36	4	34	52	D	44	68	T	54	84	d	64	100	t	74	116	ã	84	132
%	25	37	5	35	53	E	45	69	U	55	85	e	65	101	u	75	117	à	85	133
&	26	38	6	36	54	F	46	70	V	56	86	f	66	102	v	76	118	á	86	134
'	27	39	7	37	55	G	47	71	W	57	87	g	67	103	w	77	119	ç	87	135
(28	40	8	38	56	H	48	72	X	58	88	h	68	104	x	78	120	ê	88	136
)	29	41	9	39	57	I	49	73	Y	59	89	i	69	105	y	79	121	ë	89	137
*	2a	42	:	3a	58	J	4a	74	Z	5a	90	j	6a	106	z	7a	122	è	8a	138
+	2b	43	;	3b	59	K	4b	75	[5b	91	k	6b	107	{	7b	123	ï	8b	139
,	2c	44	<	3c	60	L	4c	76	ç	5c	92	l	6c	108		7c	124	î	8c	140
-	2d	45	=	3d	61	M	4d	77]	5d	93	m	6d	109	}	7d	125	ì	8d	141
.	2e	46	>	3e	62	N	4e	78	^	5e	94	n	6e	110	~	7e	126	Ä	8e	142
/	2f	47	?	3f	63	O	4f	79	_	5f	95	o	6f	111	␣	7f	127	Å	8f	143

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC
É	90	144	á	a0	160	⋮	b0	176	└	c0	192	ð	d0	208	Ó	e0	224	-	f0	240
æ	91	145	í	a1	161	⊞	b1	177	┘	c1	193	Ð	d1	209	β	e1	225	±	f1	241
Æ	92	146	ó	a2	162	⊞	b2	178	┘	c2	194	È	d2	210	Ò	e2	226	=	f2	242
ô	93	147	ú	a3	163		b3	179	┘	c3	195	Ë	d3	211	Ó	e3	227	¾	f3	243
ö	94	148	ñ	a4	164	┘	b4	180	—	c4	196	È	d4	212	õ	e4	228	¶	f4	244
ò	95	149	Ñ	a5	165	Á	b5	181	+	c5	197	ı	d5	213	Õ	e5	229	§	f5	245
û	96	150	ª	a6	166	Â	b6	182	ã	c6	198	í	d6	214	μ	e6	230	÷	f6	246
ù	97	151	º	a7	167	À	b7	183	Ä	c7	199	ï	d7	215	þ	e7	231	¸	f7	247
ÿ	98	152	¿	a8	168	©	b8	184	└	c8	200	İ	d8	216	þ	e8	232	°	f8	248
Ö	99	153	®	a9	169	≡	b9	185	┘	c9	201	┘	d9	217	Ú	e9	233	”	f9	249
Ü	9a	154	¬	aa	170		ba	186	┘	ca	202	┘	da	218	Û	ea	234	•	fa	250
ø	9b	155	½	ab	171	┘	bb	187	┘	cb	203	■	db	219	Ù	eb	235	¹	fb	251
£	9c	156	¼	ac	172	┘	bc	188	┘	cc	204	■	dc	220	Ý	ec	236	³	fc	252
Ø	9d	157	ı	ad	173	©	bd	189	=	cd	205		dd	221	Ý	ed	237	²	fd	253
×	9e	158	«	ae	174	¥	be	190	≡	ce	206	ı	de	222	˘	ee	238	■	fe	254
f	9f	159	»	af	175	┘	bf	191	œ	cf	207	■	df	223	˙	ef	239		ff	255

Zebra Code Page 1250 — Central and Eastern European Latin Character Set

This is the Zebra Code Page 1250 that supports scalable/downloaded TTF fonts:



Note • Font 0 (zero) was used to display this chart.

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC
	20	32	0	30	48	@	40	64	P	50	80	'	60	96	p	70	112	€	80	128
!	21	33	1	31	49	A	41	65	Q	51	81	a	61	97	q	71	113		81	129
"	22	34	2	32	50	B	42	66	R	52	82	b	62	98	r	72	114	,	82	130
#	23	35	3	33	51	C	43	67	S	53	83	c	63	99	s	73	115		83	131
\$	24	36	4	34	52	D	44	68	T	54	84	d	64	100	t	74	116	,	84	132
%	25	37	5	35	53	E	45	69	U	55	85	e	65	101	u	75	117	...	85	133
&	26	38	6	36	54	F	46	70	V	56	86	f	66	102	v	76	118	†	86	134
'	27	39	7	37	55	G	47	71	W	57	87	g	67	103	w	77	119	‡	87	135
(28	40	8	38	56	H	48	72	X	58	88	h	68	104	x	78	120		88	136
)	29	41	9	39	57	I	49	73	Y	59	89	i	69	105	y	79	121	‰	89	137
*	2a	42	:	3a	58	J	4a	74	Z	5a	90	j	6a	106	z	7a	122	Š	8a	138
+	2b	43	;	3b	59	K	4b	75	[5b	91	k	6b	107	{	7b	123	◀	8b	139
,	2c	44	<	3c	60	L	4c	76	\	5c	92	l	6c	108		7c	124	Š	8c	140
-	2d	45	=	3d	61	M	4d	77]	5d	93	m	6d	109	}	7d	125	Ť	8d	141
.	2e	46	>	3e	62	N	4e	78	^	5e	94	n	6e	110	~	7e	126	Ž	8e	142
/	2f	47	?	3f	63	O	4f	79	_	5f	95	o	6f	111		7f	127	Ž	8f	143

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC
	90	144		a0	160	°	b0	176	Ř	c0	192	Đ	d0	208	í	e0	224	đ	f0	240
‘	91	145	ˇ	a1	161	±	b1	177	Á	c1	193	Ń	d1	209	á	e1	225	ń	f1	241
’	92	146	ˇ	a2	162	ˆ	b2	178	Ā	c2	194	Ň	d2	210	â	e2	226	ň	f2	242
“	93	147	Ł	a3	163	†	b3	179	Ǻ	c3	195	Ó	d3	211	ǻ	e3	227	ó	f3	243
”	94	148	Ǫ	a4	164	˙	b4	180	ǻ	c4	196	Ö	d4	212	ǻ	e4	228	ô	f4	244
•	95	149	Ą	a5	165	μ	b5	181	Ĺ	c5	197	Ő	d5	213	í	e5	229	ő	f5	245
—	96	150	ı	a6	166	¶	b6	182	Č	c6	198	Ö	d6	214	ć	e6	230	ö	f6	246
—	97	151	§	a7	167	˙	b7	183	Ç	c7	199	×	d7	215	ç	e7	231	÷	f7	247
	98	152	”	a8	168	˙	b8	184	Č	c8	200	Ř	d8	216	č	e8	232	ř	f8	248
™	99	153	©	a9	169	ą	b9	185	É	c9	201	Ů	d9	217	é	e9	233	ů	f9	249
š	9a	154	§	aa	170	ş	ba	186	Ę	ca	202	Ú	da	218	ę	ea	234	ú	fa	250
›	9b	155	«	ab	171	»	bb	187	Ě	cb	203	Ů	db	219	ě	eb	235	ů	fb	251
ś	9c	156	¬	ac	172	Ĺ	bc	188	Ě	cc	204	Ů	dc	220	ě	ec	236	ů	fc	252
ř	9d	157	-	ad	173	”	bd	189	Í	cd	205	Ý	dd	221	í	ed	237	ý	fd	253
ž	9e	158	®	ae	174	ı	be	190	Ī	ce	206	Ť	de	222	î	ee	238	ı	fe	254
ž	9f	159	Ž	af	175	ž	bf	191	Ď	cf	207	ß	df	223	d'	ef	239	˙	ff	255

Zebra Code Page 1252— Latin Character Set

This is the Zebra Code Page 1252:

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC			
	20	32	0	30	48	@	40	64	P	50	80	`	60	96	p	70	112	€	80	128			
!	21	33	1	31	49	A	41	65	Q	51	81	a	61	97	q	71	113		81	129			
"	22	34	2	32	50	B	42	66	R	52	82	b	62	98	r	72	114	,	82	130			
#	23	35	3	33	51	C	43	67	S	53	83	c	63	99	s	73	115	f	83	131			
\$	24	36	4	34	52	D	44	68	T	54	84	d	64	100	t	74	116	„	84	132			
%	25	37	5	35	53	E	45	69	U	55	85	e	65	101	u	75	117	...	85	133			
&	26	38	6	36	54	F	46	70	V	56	86	f	66	102	v	76	118	†	86	134			
'	27	39	7	37	55	G	47	71	W	57	87	g	67	103	w	77	119	‡	87	135			
(28	40	8	38	56	H	48	72	X	58	88	h	68	104	x	78	120	^	88	136			
)	29	41	9	39	57	I	49	73	Y	59	89	i	69	105	y	79	121	‰	89	137			
*	2a	42	:	3a	58	J	4a	74	Z	5a	90	j	6a	106	z	7a	122	Š	8a	138			
+	2b	43	;	3b	59	K	4b	75	[5b	91	k	6b	107	{	7b	123	<	8b	139			
,	2c	44	<	3c	60	L	4c	76	\	5c	92	l	6c	108		7c	124	Œ	8c	140			
-	2d	45	=	3d	61	M	4d	77]	5d	93	m	6d	109	}	7d	125		8d	141			
.	2e	46	>	3e	62	N	4e	78	^	5e	94	n	6e	110	~	7e	126	Ž	8e	142			
/	2f	47	?	3f	63	O	4f	79	_	5f	95	o	6f	111		7f	127		8f	143			

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC
	90	144		a0	160	°	b0	176	À	c0	192	Ð	d0	208	à	e0	224	ö	f0	240
‘	91	145	í	a1	161	±	b1	177	Á	c1	193	Ñ	d1	209	á	e1	225	ñ	f1	241
’	92	146	ç	a2	162	²	b2	178	Â	c2	194	Ò	d2	210	â	e2	226	ò	f2	242
“	93	147	£	a3	163	³	b3	179	Ã	c3	195	Ó	d3	211	ã	e3	227	ó	f3	243
”	94	148	¤	a4	164	´	b4	180	Ä	c4	196	Ô	d4	212	ä	e4	228	ô	f4	244
•	95	149	¥	a5	165	µ	b5	181	Å	c5	197	Õ	d5	213	å	e5	229	õ	f5	245
—	96	150		a6	166	¶	b6	182	Æ	c6	198	Ö	d6	214	æ	e6	230	ö	f6	246
—	97	151	§	a7	167	·	b7	183	Ç	c7	199	×	d7	215	ç	e7	231	÷	f7	247
~	98	152	¨	a8	168	¸	b8	184	È	c8	200	Ø	d8	216	è	e8	232	ø	f8	248
™	99	153	©	a9	169	¹	b9	185	É	c9	201	Ù	d9	217	é	e9	233	ù	f9	249
š	9a	154	à	aa	170	º	ba	186	Ê	ca	202	Ú	da	218	ê	ea	234	ú	fa	250
›	9b	155	«	ab	171	»	bb	187	Ë	cb	203	Û	db	219	ë	eb	235	û	fb	251
œ	9c	156	¬	ac	172	¼	bc	188	Ì	cc	204	Ü	dc	220	ì	ec	236	ü	fc	252
	9d	157	-	ad	173	½	bd	189	Í	cd	205	Ý	dd	221	í	ed	237	ý	fd	253
ž	9e	158	®	ae	174	¾	be	190	Î	ce	206	Þ	de	222	î	ee	238	þ	fe	254
ÿ	9f	159	¯	af	175	¿	bf	191	Ï	cf	207	ß	df	223	ï	ef	239	ÿ	ff	255

Zebra Code Page 1253 — Modern Greek Character Set

This is the Zebra Code Page 1253:

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC			
0	0		1	1		20	32		0	30	48	@	40	64	P	50	80	'	60	96	p	70	112
2	2		3	3		!	21	33	1	31	49	A	41	65	Q	51	81	a	61	97	q	71	113
4	4		5	5		"	22	34	2	32	50	B	42	66	R	52	82	b	62	98	r	72	114
6	6		7	7		#	23	35	3	33	51	C	43	67	S	53	83	c	63	99	s	73	115
8	8		9	9		\$	24	36	4	34	52	D	44	68	T	54	84	d	64	100	t	74	116
a	10		b	11		%	25	37	5	35	53	E	45	69	U	55	85	e	65	101	u	75	117
c	12		d	13		&	26	38	6	36	54	F	46	70	V	56	86	f	66	102	v	76	118
e	14		f	15		'	27	39	7	37	55	G	47	71	W	57	87	g	67	103	w	77	119
10	16		11	17		(28	40	8	38	56	H	48	72	X	58	88	h	68	104	x	78	120
12	18		13	19)	29	41	9	39	57	I	49	73	Y	59	89	i	69	105	y	79	121
14	20		15	21		*	2a	42	:	3a	58	J	4a	74	Z	5a	90	j	6a	106	z	7a	122
16	22		17	23		+	2b	43	;	3b	59	K	4b	75	[5b	91	k	6b	107	{	7b	123
18	24		19	25		,	2c	44	<	3c	60	L	4c	76	\	5c	92	l	6c	108		7c	124
1a	26		1b	27		-	2d	45	=	3d	61	M	4d	77]	5d	93	m	6d	109	}	7d	125
1c	28		1d	29		.	2e	46	>	3e	62	N	4e	78	^	5e	94	n	6e	110	~	7e	126
1e	30		1f	31		/	2f	47	?	3f	63	O	4f	79	_	5f	95	o	6f	111		7f	127

CHRHEXDEC	CHRHEXDEC	CHRHEXDEC	CHRHEXDEC	CHRHEXDEC	CHRHEXDEC	CHRHEXDEC	CHRHEXDEC
€ 80 128	90 144	€ 160	° 176	Τ 192	Π 208	Û 224	π 240
81 129	91 145	€ 161	± 177	Α 193	Ρ 209	α 225	ρ 241
, 82 130	92 146	Α 162	² 178	Β 194	d2 210	β 226	ς 242
f 83 131	93 147	£ 163	³ 179	Γ 195	Σ 211	γ 227	σ 243
” 84 132	94 148	α 164	´ 180	Δ 196	Τ 212	δ 228	τ 244
... 85 133	95 149	¥ 165	μ 181	Ε 197	Υ 213	ε 229	υ 245
† 86 134	96 150	166	¶ 182	Ζ 198	Φ 214	ζ 230	φ 246
‡ 87 135	97 151	§ 167	· 183	Η 199	Χ 215	η 231	χ 247
88 136	98 152	” 168	Ε 184	Θ 200	Ψ 216	θ 232	ψ 248
‰ 89 137	™ 99 153	© 169	Η 185	Ι 201	Ω 217	ι 233	ω 249
8a 138	9a 154	€ 170	Ι 186	Κ 202	Ι 218	κ 234	ι 250
‘ 8b 139	’ 9b 155	“ 171	” 187	Λ 203	Υ 219	λ 235	υ 251
8c 140	9c 156	¬ 172	Ο 188	Μ 204	ά 220	μ 236	ό 252
8d 141	9d 157	• 173	½ 189	Ν 205	έ 221	ν 237	ύ 253
8e 142	9e 158	® 174	Υ 190	Ξ 206	ή 222	ξ 238	ώ 254
8f 143	9f 159	— 175	Ω 191	Ο 207	Ι 223	ο 239	ff 255

Zebra Code Page 1254 — Turkish Character Set

This is the Zebra Code Page 1254:

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC			
0	0		1	1		20	32		0	30	48	@	40	64	P	50	80	'	60	96	p	70	112
2	2		3	3		!	21	33	1	31	49	A	41	65	Q	51	81	a	61	97	q	71	113
4	4		5	5		"	22	34	2	32	50	B	42	66	R	52	82	b	62	98	r	72	114
6	6		7	7		#	23	35	3	33	51	C	43	67	S	53	83	c	63	99	s	73	115
8	8		9	9		\$	24	36	4	34	52	D	44	68	T	54	84	d	64	100	t	74	116
a	10		b	11		%	25	37	5	35	53	E	45	69	U	55	85	e	65	101	u	75	117
c	12		d	13		&	26	38	6	36	54	F	46	70	V	56	86	f	66	102	v	76	118
e	14		f	15		'	27	39	7	37	55	G	47	71	W	57	87	g	67	103	w	77	119
10	16		11	17		(28	40	8	38	56	H	48	72	X	58	88	h	68	104	x	78	120
12	18		13	19)	29	41	9	39	57	I	49	73	Y	59	89	i	69	105	y	79	121
14	20		15	21		*	2a	42	:	3a	58	J	4a	74	Z	5a	90	j	6a	106	z	7a	122
16	22		17	23		+	2b	43	;	3b	59	K	4b	75	[5b	91	k	6b	107	{	7b	123
18	24		19	25		,	2c	44	<	3c	60	L	4c	76	\	5c	92	l	6c	108		7c	124
1a	26		1b	27		-	2d	45	=	3d	61	M	4d	77]	5d	93	m	6d	109	}	7d	125
1c	28		1d	29		.	2e	46	>	3e	62	N	4e	78	^	5e	94	n	6e	110	~	7e	126
1e	30		1f	31		/	2f	47	?	3f	63	O	4f	79	_	5f	95	o	6f	111		7f	127

CHRHEXDEC		CHRHEXDEC		CHRHEXDEC		CHRHEXDEC		CHRHEXDEC		CHRHEXDEC		CHRHEXDEC		CHRHEXDEC									
€	80	128		90	144		a0	160	°	b0	176	À	c0	192	Ĝ	d0	208	à	e0	224	ğ	f0	240
	81	129	'	91	145	ı	a1	161	±	b1	177	Á	c1	193	Ŋ	d1	209	á	e1	225	ñ	f1	241
,	82	130	'	92	146	Ċ	a2	162	²	b2	178	Â	c2	194	Ō	d2	210	â	e2	226	ó	f2	242
/	83	131	"	93	147	£	a3	163	³	b3	179	Ã	c3	195	Ó	d3	211	ã	e3	227	ô	f3	243
„	84	132	”	94	148	¤	a4	164	´	b4	180	Ä	c4	196	Ö	d4	212	ä	e4	228	õ	f4	244
...	85	133	•	95	149	¥	a5	165	µ	b5	181	Å	c5	197	Ø	d5	213	å	e5	229	ö	f5	245
†	86	134	—	96	150		a6	166	¶	b6	182	Æ	c6	198	Ŏ	d6	214	æ	e6	230	ő	f6	246
‡	87	135	—	97	151	§	a7	167	·	b7	183	Ç	c7	199	×	d7	215	ç	e7	231	÷	f7	247
^	88	136	~	98	152	"	a8	168	¸	b8	184	È	c8	200	Ø	d8	216	è	e8	232	ø	f8	248
‰	89	137	™	99	153	©	a9	169	¹	b9	185	É	c9	201	Ù	d9	217	é	e9	233	ù	f9	249
Š	8a	138	š	9a	154	ª	aa	170	º	ba	186	Ê	ca	202	Ú	da	218	ê	ea	234	ú	fa	250
‘	8b	139	’	9b	155	«	ab	171	»	bb	187	Ë	cb	203	Û	db	219	ë	eb	235	û	fb	251
Œ	8c	140	œ	9c	156	¬	ac	172	¼	bc	188	Ì	cc	204	Ü	dc	220	ì	ec	236	ü	fc	252
	8d	141		9d	157	•	ad	173	½	bd	189	Í	cd	205	İ	dd	221	í	ed	237	ı	fd	253
	8e	142		9e	158	®	ae	174	¾	be	190	Î	ce	206	Ş	de	222	î	ee	238	ş	fe	254
	8f	143	ÿ	9f	159		af	175	¿	bf	191	Ï	cf	207	ß	df	223	ï	ef	239	ÿ	ff	255

Zebra Code Page 1255 — Hebrew Character Set

This is the Zebra Code Page 1255:

CHR	HEXDEC	CHR	HEXDEC	CHR	HEXDEC	CHR	HEXDEC	CHR	HEXDEC	CHR	HEXDEC	CHR	HEXDEC	CHR	HEXDEC
0	0	1	1	20	32	0	30 48	@	40 64	P	50 80	'	60 96	p	70 112
2	2	3	3	!	21 33	1	31 49	A	41 65	Q	51 81	a	61 97	q	71 113
4	4	5	5	"	22 34	2	32 50	B	42 66	R	52 82	b	62 98	r	72 114
6	6	7	7	#	23 35	3	33 51	C	43 67	S	53 83	c	63 99	s	73 115
8	8	9	9	\$	24 36	4	34 52	D	44 68	T	54 84	d	64 100	t	74 116
a	10	b	11	%	25 37	5	35 53	E	45 69	U	55 85	e	65 101	u	75 117
c	12	d	13	&	26 38	6	36 54	F	46 70	V	56 86	f	66 102	v	76 118
e	14	f	15	'	27 39	7	37 55	G	47 71	W	57 87	g	67 103	w	77 119
10	16	11	17	(28 40	8	38 56	H	48 72	X	58 88	h	68 104	x	78 120
12	18	13	19)	29 41	9	39 57	I	49 73	Y	59 89	i	69 105	y	79 121
14	20	15	21	*	2a 42	:	3a 58	J	4a 74	Z	5a 90	j	6a 106	z	7a 122
16	22	17	23	+	2b 43	;	3b 59	K	4b 75	[5b 91	k	6b 107	{	7b 123
18	24	19	25	,	2c 44	<	3c 60	L	4c 76	\	5c 92	l	6c 108		7c 124
1a	26	1b	27	-	2d 45	=	3d 61	M	4d 77]	5d 93	m	6d 109	}	7d 125
1c	28	1d	29	.	2e 46	>	3e 62	N	4e 78	^	5e 94	n	6e 110	~	7e 126
1e	30	1f	31	/	2f 47	?	3f 63	O	4f 79	_	5f 95	o	6f 111		7f 127

CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC	CHR	HEX	DEC			
€	80	128		90	144		a0	160	°	b0	176	.	c0	192		d0	208	κ	e0	224	ן	f0	240
	81	129	'	91	145	ı	a1	161	±	b1	177	..	c1	193		d1	209	ך	e1	225	ו	f1	241
,	82	130	'	92	146	ץ	a2	162	²	b2	178	..	c2	194		d2	210	ל	e2	226	י	f2	242
f	83	131	"	93	147	£	a3	163	³	b3	179	..	c3	195	:	d3	211	ג	e3	227	ף	f3	243
”	84	132	”	94	148	ן	a4	164		b4	180	.	c4	196	ן	d4	212	ה	e4	228	צ	f4	244
...	85	133	·	95	149	¥	a5	165	μ	b5	181	..	c5	197	ן	d5	213	ו	e5	229	ץ	f5	245
†	86	134	—	96	150		a6	166	¶	b6	182	..	c6	198	”	d6	214	י	e6	230	ץ	f6	246
‡	87	135	—	97	151	§	a7	167	·	b7	183	.	c7	199	'	d7	215	ן	e7	231	פ	f7	247
^	88	136	~	98	152	”	a8	168	.	b8	184	.	c8	200	”	d8	216	ו	e8	232	ך	f8	248
0/0	89	137	™	99	153	©	a9	169	1	b9	185		c9	201		d9	217	'	e9	233	י	f9	249
	8a	138		9a	154	×	aa	170	÷	ba	186		ca	202		da	218	ך	ea	234	ן	fa	250
‘	8b	139	’	9b	155	“	ab	171	”	bb	187	..	cb	203		db	219	ן	eb	235		fb	251
	8c	140		9c	156	⌒	ac	172	¼	bc	188	.	cc	204		dc	220	ן	ec	236		fc	252
	8d	141		9d	157	·	ad	173	½	bd	189	.	cd	205		dd	221	ו	ed	237		fd	253
	8e	142		9e	158	®	ae	174	¾	be	190	.	ce	206		de	222	ן	ee	238		fe	254
	8f	143		9f	159		af	175	ı	bf	191	.	cf	207		df	223	ן	ef	239		ff	255

ASCII

This section shows the American Standard Code for Information Interchange (ASCII) code used by Zebra printers.

ASCII Code Chart

Shaded areas in [Table 32](#) indicate characters not recommended for command prefix, format prefix, or delimiter characters.

Table 32 • ASCII Code Chart

HEX	Character	HEX	Character	HEX	Character	HEX	Character
00	NUL	20	Space	40	@	60	'
01	SOH	21	!	41	A	61	a
02	STX	22	"	42	B	62	b
03	ETX	23	#	43	C	63	c
04	EOT	24	\$	44	D	64	d
05	ENQ	25	%	45	E	65	e
06	ACK	26	&	46	F	66	f
07	BEL	27	'	47	G	67	g
08	BS	28	(48	H	68	h
09	HT	29)	49	I	69	i
0A	LF	2A	*	4A	J	6A	j
0B	VT	2B	+	4B	K	6B	k
0C	FF	2C	,	4C	L	6C	l
0D	CR	2D	-	4D	M	6D	m
0E	SO	2E	.	4E	N	6E	n
0F	SI	2F	/	4F	O	6F	o
10	DLE	30	0	50	P	70	p
11	DC1	31	1	51	Q	71	q
12	DC2	32	2	52	R	72	r
13	DC3	33	3	53	S	73	s
14	DC4	34	4	54	T	74	t
15	NAK	35	5	55	U	75	u
16	SYN	36	6	56	V	76	v
17	ETB	37	7	57	W	77	w
18	CAN	38	8	58	X	78	x
19	EM	39	9	59	Y	79	y
1A	SUB	3A	:	5A	Z	7A	z
1B	ESC	3B	;	5B	[7B	{
1C	FS	3C	<	5C	\	7C	
1D	GS	3D	=	5D]	7D	}

Table 32 • ASCII Code Chart

HEX	Character	HEX	Character	HEX	Character	HEX	Character
1E	RS	3E	>	5E	^	7E	~
1F	US	3F	?	5F	_	7F	DEL

Fonts and Bar Codes

This section provides information about different fonts (type faces) and bar codes that can be used with the printer.

Contents

- Standard Printer Fonts 1336
- Proportional and Fixed Spacing 1338
- Scalable Versus Bitmapped Fonts..... 1339
 - Scalable Fonts 1339
 - Bitmapped Fonts..... 1339
- Font Matrices 1341
- Bar Codes..... 1343
 - Basic Format for Bar Codes..... 1343
 - Bar Code Field Instructions..... 1344
 - Bar Code Command Groups 1345

Standard Printer Fonts

Most Zebra printers come standard with 15 bitmapped fonts and one scalable font, see [Figure 3](#). Additional downloadable bitmapped and scalable fonts are also available. Character size and density (how dark it appears) depend on the density of the printhead and the media used.

Figure 3 • Examples of the Standard Printer Fonts

FONT A -- ABCDwxyz 12345
FONT B -- ABCDXYZ 12345 UPPER CASE ONLY
FONT D -- ABCDwxyz 12345
FONT E -- (OCR-B) ABCDwxyz 12345
FONT F -- ABCDwxyz 12345
FONT G -- ABYz 12
FONT H -- (OCR-A) UPPER CASE ONLY
zero — **FONT O** -- (Scaleable) ABCDwxyz 12345
FONT GS -- © © ™ ® Accessed with the ^GS command.
FONT P -- ABCDwxyz 12345
FONT Q -- ABCDwxyz 12345
FONT R -- ABCDwxyz 12345
FONT S -- ABCDwxyz 12345
FONT T -- ABCDwxyz 12345
FONT U -- ABCDwxyz 12345
FONT V -- ABCDwxyz 12345

To use one of these fonts, you must either use the change alphanumeric default font command (^CF) or specify an alphanumeric field command (^A).

The standard Zebra character set is Code 850 for character values greater than 20 HEX. There are six HEX character values below 20 HEX that are also recognized. [Figure 4](#) shows how these character values are printed.



Note • Unidentified characters should default to a space.


Figure 4 • Recognized HEX Values below 20 HEX

A HEX	1a	will print a	0 (numeric)
A HEX	1b	will print a	$\frac{1}{3}$
A HEX	1c	will print a	$\frac{2}{3}$
A HEX	1d	will print a	U
A HEX	1e	will print a	ij
A HEX	1f	will print a	\

Proportional and Fixed Spacing

Proportional spacing is different than fixed spacing. In Table 33, the intercharacter gap (ICG), the space between characters, is constant for fonts A through H, which means that the spacing between all characters is the same. For example, the spacing between the letters MW is the same as between the letters IE.

Figure 5 is an example of fixed space fonts:



The baseline is the imaginary line on which the bottom (base) of all characters (except any descenders) rest. The area between the baseline and the bottom of the matrix is used for any character “descenders.” Baseline numbers define where the baseline is located in relationship to the top of the matrix. For example, the baseline for font “E” is 23 dots down from the top of the matrix.

Table 33 • Intercharacter Gap and Baseline Parameters

Font	H x W (in dots)	Type	Intercharacter Gap (in dots)	Baseline (in dots)
A	9 x 5	U-L-D	1	7
B	11 x 7	U	2	11
C,D	18 x 10	U-L-D	2	14
E	28 x 15	OCR-B	5	23
F	26 x 13	U-L-D	3	21
G	60 x 40	U-L-D	8	48
H	21 x 13	OCR-A	6	21
GS	24 x 24	SYMBOL	PROPORTIONAL	3 x HEIGHT/4
0	DEFAULT: 15 x 12		PROPORTIONAL	3 x HEIGHT/4

Scalable Versus Bitmapped Fonts

For scalable fonts, setting the height and width equally produces characters that appear the most balanced. Balanced characters are pleasing to the eye because actual height and width are approximately equal to each other. This is achieved through the use of a smooth-scaling algorithm in the printer.

For bitmapped fonts, this balancing is built into the font. In actuality, the height of a bitmap font is slightly larger than the width. Bitmap fonts are always at the maximum size of the character's cell.

Scalable Fonts

All dot parameters used in the commands to create scalable fonts are translated into a point size because scalable fonts are measured in point sizes, not dots. To determine how many dots to enter to obtain a particular point size, use the following formula. The actual point size will be an approximate value.

$$\text{Dots} = \frac{(\text{Point size}) \times (\text{Dots per inch of Printer})}{72}$$

- For printers using a 6 dot/mm printhead the "dots per inch of printer" value is 152.4
- For printers using a 8 dot/mm printhead the "dots per inch of printer" value is 203.2
- For printers using a 12 dot/mm printhead the "dots per inch of printer" value is 304.8
- For printers using a 24 dot/mm printhead the "dots per inch of printer" value is 609.6

The actual height and width of the character in dots will vary, depending on the font style and the particular character. Therefore, some characters will be smaller and some will be larger than the actual dot size requested. The baselines for all scalable fonts are calculated against the dot size of the cell. The baseline is 3/4 down from the top of the cell. For example, if the size of the cell is 80 dots, the baseline will be 60 dots (3/4) down from the top of the cell.

For more information concerning fonts and related commands, see [~DB on page 147](#) and [~DS on page 156](#).

Bitmapped Fonts

Internal bitmapped fonts can be magnified from 1 to 10 times their normal (default) size. The magnification factor is in whole numbers. Therefore, if the normal size of a bitmapped font is 9 dots high and 5 dots wide, a magnification factor of 3 would produce a character of 27 dots high and 15 dots wide. Height and width can be magnified independently.

Magnification Factor

The font commands contain parameters for entering the height and width of printed characters. The values are always entered in dots. When entering these values for bitmapped fonts, use the following formula:

$$\text{Base Height} \times \text{Magnification Factor} = \text{Height Parameter Value}$$

The same principle applies when calculating width.

Example:

Base height = 9 dots
 Base width = 5 dots

To magnify a bitmapped character with the above specifics 3 times its size:

Height parameter = 27 [9 x 3]

Width parameter = 15 [5 x 3]

Changing Bitmapped Font Size

Alphanumeric field command (^A) parameters h and w control the magnification and, therefore, the ultimate size of the font. The parameter is specified in dots, but ZPL II actually uses an integer multiplier times the original height/width of the font. For example, if you specify

^AD, 54

you get characters three times their normal size (54 dots high), but if you specify

^AD, 52

you receive the same result, not characters 52 dots high.

Defining only the height or width of a bitmapped font forces the magnification to be proportional to the parameter defined. If neither is defined, the ^CF height and width are used. For example, if the height is twice the standard height, the width will be twice the standard width.



Example: If a ^CF command, with height and width parameters defined, is used to set the first font, any ^A commands (to select a different font) that follow must have the height and width parameter filled in.

If this is not done, the newly selected font will be magnified using values for the ^CF height and width parameters. This is an example of what happens:.

ZPL II CODE	GENERATED LABEL
<pre> ^XA^LL1800 ^FO50,50^CFD,26,10^FDZEBRA...^FS ^FO50,100^FD"Bar Code, Bar None"^FS ^FO50,200^AA^FDZEBRA...^FS ^FO50,250^FD"Bar Code, Bar None"^FS ^XZ </pre>	

Font Matrices

Type Key U = Uppercase, L = Lowercase, D = Descenders

Table 34 • 6 dot/mm Printhead

Font	Matrix	Type	Character Size			
	HxW (in dots)		HxW (in in.)	Char./in.	HxW (in mm)	Char. /mm
A	9 x 5	U-L-D	0.059 x 0.039	25.4	1.50 x 0.99	1.01
B	11 x 7	U	0.072 x 0.059	16.9	1.82 x 1.50	0.066
C, D	18 x 10	U-L-D	0.118 x 0.079	12.7	2.99 x 2.00	0.05
E	21 x 10	OCR-B	0.138 x 0.085	11.7	3.50 x 2.16	0.46
F	26 x 13	U-L-D	0.170 x 0.105	9.53	4.32 x 2.67	0.37
G	60 x 40	U-L-D	0.394 x 0.315	3.18	10.0 x 8.00	0.125
H	17 x 11	OCR-A	0.111 x 0.098	10.2	2.81 x 2.48	0.40
GS	24 x 24	SYMBOL	0.157 x 0.157	6.35	3.98 x 3.98	0.251
0	Default: 15 x 12					

Table 35 • 8 dot/mm (203 dpi) Printhead

Font	Matrix	Type	Character Size			
	HxW (in dots)		HxW (in in.)	Char./in.	HxW (in mm)	Char. /mm
A	9 X 5	U-L-D	0.044 x 0.030	33.3	1.12 x 0.76	1.31
B	11 X 7	U	0.054 x 0.044	22.7	1.37 x 1.12	0.89
C, D	18 X 10	U-L-D	0.089 x 0.059	16.9	2.26 x 1.12	0.66
E	28 x 15	OCR-B	0.138 x 0.098	10.2	3.50 x 2.49	0.40
F	26 x 13	U-L-D	0.128 x 0.079	12.7	3.25 x 2.00	0.50
G	60 x 40	U-L-D	0.295 x 0.197	4.2	7.49 x 5.00	0.167
H	21 x 13	OCR-A	0.103 x 0.093	10.8	2.61 x 2.36	0.423
GS	24 x 24	SYMBOL	0.118 x 0.118	8.5	2.99 x 2.99	0.334
P	20 x 18	U-L-D	0.098 x 0.089	N/A	2.50 x 2.25	N/A
Q	28 x 24	U-L-D	0.138 x 0.118	N/A	3.50 x 3.00	N/A
R	35 x 31	U-L-D	0.172 x 0.153	N/A	4.38 x 3.88	N/A
S	40 x 35	U-L-D	0.197 x 0.172	N/A	5.00 x 4.38	N/A
T	48 x 42	U-L-D	0.236 x 0.207	N/A	6.00 x 5.25	N/A
U	59 x 53	U-L-D	0.290 x 0.261	N/A	7.38 x 6.63	N/A
V	80 x 71	U-L-D	0.394 x 0.349	N/A	10.00 x 8.88	N/A
0	Default: 15 x 12	U-L-D	Scalable		Scalable	

Table 36 • 12 dot/mm (300 dpi) Printhead

Font	Matrix	Type	Character Size			
	HxW (in dots)		HxW (in in.)	Char./in.	HxW (in mm)	Char. /mm
A	9 X 5	U-L-D	0.030 x 0.020	50.8	0.75 x 0.50	2.02
B	11 X 7	U	0.036 x 0.030	33.8	0.91 x 0.75	1.32
C, D	18 X 10	U-L-D	0.059 x 0.040	25.4	1.50 x 1.00	1.00
E	42 x 20	OCR-B	0.138 x 0.085	23.4	1.75 x 1.08	0.92
F	26 x 13	U-L-D	0.085 x 0.053	19.06	2.16 x 1.34	0.74
G	60 x 40	U-L-D	0.197 x 0.158	6.36	5.00 x 4.00	0.25
H	34 x 22	OCR-A	0.111 x 0.098	10.20	2.81 x 2.48	0.40
GS	24 x 24	SYMBOL	0.079 x 0.079	12.70	1.99 x 1.99	0.52
P	20 x 18	U-L-D	0.067 x 0.060	N/A	1.69 x 1.52	N/A
Q	28 x 24	U-L-D	0.093 x 0.080	N/A	2.37 x 2.03	N/A
R	35 x 31	U-L-D	0.117 x 0.103	N/A	2.96 x 2.62	N/A
S	40 x 35	U-L-D	0.133 x 0.177	N/A	3.39 x 2.96	N/A
T	48 x 42	U-L-D	0.160 x 0.140	N/A	4.06 x 3.56	N/A
U	59 x 53	U-L-D	0.197 x 0.177	N/A	5.00 x 4.49	N/A
V	80 x 71	U-L-D	0.267 x 0.237	N/A	6.77 x 6.01	N/A
0	Default: 15 x 12	U-L-D	Scalable		Scalable	

Table 37 • 24 dot/mm (600 dpi) Printhead

Font	Matrix	Type	Character Size			
	HxW (in dots)		HxW (in in.)	Char./in.	HxW (in mm)	Char. /mm
A	9 X 5	U-L-D	0.015 x 0.010	100.00	0.38 x 0.25	4.00
B	11 X 7	U	0.018 x 0.015	66.66	0.46 x 0.38	2.60
C, D	18 X 10	U-L-D	0.030 x 0.020	50.00	0.77 x 0.51	2.0
E	42 x 20	OCR-B	0.137 x 0.087	11.54	3.47 x 2.20	0.45
F	26 x 13	U-L-D	0.043 x 0.027	37.5	1.10 x 0.68	1.50
G	60 x 40	U-L-D	0.100 x 0.080	12.50	2.54 x 2.04	0.50
H	34 x 22	OCR-A	0.100 x 0.093	10.71	2.54 x 2.37	0.42
GS	24 x 24	SYMBOL	0.040 x 0.040	25.00	1.02 x 1.02	1.00
P	20 x 18	U-L-D	0.067 x 0.060	N/A	1.69 x 1.52	N/A
Q	28 x 24	U-L-D	0.093 x 0.080	N/A	2.37 x 2.03	N/A
R	35 x 31	U-L-D	0.117 x 0.103	N/A	2.96 x 2.62	N/A
S	40 x 35	U-L-D	0.133 x 0.117	N/A	3.39 x 2.96	N/A
T	48 x 42	U-L-D	0.160 x 0.140	N/A	4.06 x 3.56	N/A
U	59 x 53	U-L-D	0.197 x 0.177	N/A	5.00 x 4.49	N/A
V	80 x 71	U-L-D	0.267 x 0.237	N/A	6.77 x 6.01	N/A
0	Default: 15 x 12	U-L-D	Scalable		Scalable	

Bar Codes

Every bar code contains data made up of a sequence of light spaces and dark bars that represent letters, numbers, or other graphic characters. The usable characters differ among the various kinds of bar codes. Each bar code section in the *ZPL Commands on page 31* provides a table of applicable characters. Start and stop characters and check digits are used by many, but not all, bar codes. These will be indicated in the specific bar code explanations.

Zebra printers can print the following kinds of bar codes:

<p>Bar code modulus “X” dimensions</p> <ul style="list-style-type: none"> • Picket fence (non-rotated) orientation: <ul style="list-style-type: none"> • 203 dpi = 0.0049 in. mil to 0.049 in. • 300 dpi = 0.0033 in. mil to 0.033 in. • Ladder (rotated) orientation: <ul style="list-style-type: none"> • 203 dpi = 0.0049 in. mil to 0.049 in. • 300 dpi = 0.0039 in. mil to 0.039 in. 	<p>Linear bar codes</p> <ul style="list-style-type: none"> • Codabar • Code 11 • Code 39 • Code 93 • Code 128 with subsets A/B C and UCC Case Codes • ISBT-128 • UPC-A • UPC-E • EAN-8 • EAN-13 • UPC and EAN 2 or 5 digit extensions • Planet Code • Plessey • Postnet • Standard 2 of 5 • Industrial 2 of 5 • Interleaved 2 of 5 • LOGMARS • MSI • GS1 DataBar Omnidirectional
<p>Two-dimensional bar codes</p> <ul style="list-style-type: none"> • Aztec • Code 49 • Maxi Code • TLC39 • PDF-417 • QR Code • Codablock • DataMatrix • Micro-PDF417 	
<p>Bar code ratios</p> <ul style="list-style-type: none"> • 2:1 • 7:3 • 5:2 • 3:1 	

Basic Format for Bar Codes

The basic format for bar codes is quiet zone, start character, data, check digit, stop character, and quiet zone. Not all bar codes require each of these elements.

Every bar code requires a quiet zone. A quiet zone (sometimes called a “clear area”) is an area adjacent to the machine-readable symbols that ensure proper reading (decoding) of the symbols. No printing is permissible within this area. Preprinted characters, borders, and background color are acceptable if they are invisible to the reading device; these are used in some applications but restrict the type of reading device that can be used. The size of the quiet zone depends on the size of bar widths (usually 10 times the width of the narrow bar).

Figure 6 • Quiet Zone in a Bar Code



Bar Code Field Instructions

To create a bar code, a bar code field command must be contained in the label format. [Table 38](#) shows the bar code field commands. The number in brackets denotes the print ratio. Each command produces a unique bar code.



Important • (*) for Fixed Printing Ratio means that the ratio between the width of the bars in the code is a fixed standard and cannot be changed.

As another reference to the bar code field commands ratio, see [Table 12 on page 126](#).

Table 38 • Bar Code Field Commands

ZPL Command	Command Description	Ratio
^B0	Aztec Bar Code Parameters	[Fixed]
^B1	Code 11 (USD-8)	[2.0 - 3.0]
^B2	Interleaved 2 of 5	[2.0 - 3.0]
^B3	Code 39 (USD-3 and 3 of 9)	[2.0 - 3.0]
^B4	Code 49 (*)	[Fixed]
^B5	Planet Code Bar Code	[Fixed]
^B7	PDF417 (*)	[Fixed]
^B8	EAN-8 (*)	[Fixed]
^B9	UPC-E	[Fixed]
^BA	Code 93 (USS-93)(*)	[Fixed]
^BB	CODABLOCK A, E, F (*)	[Fixed]
^BC	Code 128 (USD-6) (*)	[Fixed]
^BD	UPS MaxiCode (*)	[Fixed]
^BE	EAN-13	[Fixed]
^BF	Micro-PDF417	[Fixed]
^BI	Industrial 2 of 5	[2.0 - 3.0]

Table 38 • Bar Code Field Commands (Continued)

ZPL Command	Command Description	Ratio
^BJ	Standard 2 of 5	[2.0 - 3.0]
^BK	ANSI Codabar (USD-4 and 2 of 7)	[2.0 - 3.0]
^BL	LOGMARS	[2.0 - 3.0]
^BM	MSI	[2.0 - 3.0]
^BO	Aztec Bar Code Parameters	[Fixed]
^BP	Plessey	[2.0 - 3.0]
^BQ	QR Code (*)	[Fixed]
^BR	GS1 Databar (formerly RSS)	[Fixed]
^BS	UPC/EAN Extensions (*)	[Fixed]
^BU	UPC-A (*)	[Fixed]
^BX	Data Matrix (*)	[Fixed]
^BZ	PostNet (*), USPS Intelligent Mail, and Planet bar codes	[Fixed]

Additionally, each bar code field command can be issued with a definition parameter string. The parameter string defines field rotation, height, and interpretation line status for all bar codes. For some bar codes, the parameter string also sets a check digit, start character, and/or stop character. Use the definition parameter string to command the printer to print bar codes of appropriate heights and densities that conform to the specifications of the application.

The use of the parameter string is optional because all parameters have default values. If the default values for all of the bar code parameters suit the application, then only the bar code command needs to be entered.

Parameters in bar code field commands are “position specific.” If a value (other than the default value) is manually entered for one parameter the ZPL II delimiter character (a comma) must be used to mark the position of the preceding parameters in the string.

To change just the third parameter, enter two commas and then the value for the third parameter. The default values will be automatically used for the first and second parameters.

Bar Code Command Groups

Bar code commands are organized into four groups. Each group represents a type of bar code. [Table 39](#) through [Table 42](#) identify the groups and the bar codes they contain:

Table 39 • Numeric Only Bar Codes

ZPL Command	Command Description
^B0	Aztec Bar Code Parameters
^B1	Code 11
^B5	Planet Code Bar Code
^BI	Industrial 2 of 5
^BJ	Standard 2 of 5
^BK	ANSI Codabar (or NW-7)

Table 39 • (Continued) Numeric Only Bar Codes

ZPL Command	Command Description
^BM	MSI
^BO	Aztec Bar Code Parameters
^BP	Plessey
^BZ	PostNet (*), USPS Intelligent Mail, and Planet bar codes

Table 40 • Retail Labeling Bar Codes

ZPL Command	Command Description
^B0	Aztec Bar Code Parameters
^B8	EAN-8
^B9	UPC-E
^BE	EAN-13
^BO	Aztec Bar Code Parameters
^BS	UPC/EAN extensions
^BU	UPC-A

Table 41 • Alphanumeric Bar Codes

ZPL Command	Command Description
^B0	Aztec Bar Code Parameters
^B3	Code 39
^BA	Code 93
^BC	Code 128
^BL	LOGMARS
^BO	Aztec Bar Code Parameters

Table 42 • Two-Dimensional Bar Codes

ZPL Command	Command Description
^B0	Aztec Bar Code Parameters
^B4	Code 49
^B7	PDF417
^BB	CODABLOCK
^BD	UPS MaxiCode
^BF	MicroPDF417
^BQ	QR Code

Table 42 • Two-Dimensional Bar Codes (Continued)

^BO	Aztec Bar Code Parameters
^BR	GS1 Databar (formerly RSS)
^BT	TLC39
^BX	Data Matrix

Mod 10 and Mod 43 Check Digits

This section provides information about Mod 10 and Mod 43 check digits.

Mod 10 Check Digit

The calculations for determining the Mod 10 Check Digit character are as follows:

Contents

Mod 10 Check Digit	1349
Mod 43 Check Digit	1350

1. Start at the first position and add the value of every other position together.
 $0 + 2 + 4 + 6 + 8 + 0 = 20$
2. The result of Step 1 is multiplied by 3.
 $20 \times 3 = 60$
3. Start at the second position and add the value of every other position together.
 $1 + 3 + 5 + 7 + 9 = 25$
4. The results of steps 2 and 3 are added together.
 $60 + 25 = 85$
5. The check character (12th character) is the smallest number which, when added to the result in step 4, produces a multiple of 10.
 $85 + X = 90$ (next higher multiple of 10)
 $X = 5$ Check Character

This bar code illustrates the above example. The digit on the right (5) is the check digit.



Mod 43 Check Digit

The calculations for determining the Mod 43 check Digit character are as follows:

Each character in the Code 39 character set has a specific value, as follows:

0=0	B=11	M=22	X=33
1=1	C=12	N=23	Y=34
2=2	D=13	O=24	Z=35
3=3	E=14	P=25	- =36
4=4	F=15	Q=26	. = 37
5=5	G=16	R=27	Space=38
6=6	H=17	S=28	\$=39
7=7	I=18	T=29	/=40
8=8	J=19	U=30	+ =41
9=9	K=20	V=31	%=42
A=10	L=21	W=32	



Example: Data string 2345ABCDE/

1. Add the sum of all the character values in the data string. Using the chart above, the sum of the character values is as follows:
 $1 + 2 + 3 + 4 + 5 + 10 + 11 + 12 + 13 + 14 + 40 = 115$
2. Divide the total by 43. Keep track of the remainder.
 $115 / 43 = 2$ Remainder is 29
3. The “check digit” is the character that corresponds to the value of the remainder.
 Remainder = 29
 29 is the value for the letter T.
 T is the check digit.

Below is a bar code that illustrates the example. The character on the right, T, is the check digit.



^F0125,100^B3N,Y,150,Y,N^FD12345ABCDE/^FS



Notes • _____

Error Detection Protocol

This section explains the Zebra protocol that has been supplanted in TCP/IP based applications because of the error detection compatibility inherent in the TCP/IP protocol.

Contents

Introduction.....	1355
-------------------	------

- What is a Protocol?..... 1355
- How Protocols Work..... 1355
- Request Packet Formats from the Host Computer 1356
 - Header Block Fields..... 1356
 - Data Block Fields..... 1356
- Response From the Zebra Printer..... 1358
 - Zebra Packet Response..... 1358
 - Header Block Fields..... 1358
 - Data Block Fields..... 1359
 - Disguising Control Code Characters..... 1359
- Error Detection Protocol Application 1360
- Error Conditions and System Faults..... 1361
- How the Zebra Printer Processes a Request Packet 1361
- How the Zebra Printer Responds to Host Status 1362

Introduction

There are many instances when it is vitally important that the information sent to the Zebra printer is received completely Error-Free. ZPL II supports an error detection protocol called Zebra Packet Response Protocol to meet this need.



Note • This protocol only works when using serial interface. It does not function when using parallel interface.

What is a Protocol?

A protocol is a precisely defined set of rules. In the case of data communications, a Protocol defines how data is transmitted, received, and acknowledged between two devices.

The sole purpose of the Packet Response Protocol is to ensure that the information sent from a Host computer to the Zebra printer is received accurately. Remember, the protocol cannot insure the accuracy of the data that is actually sent from the Host computer. The commands and data needed to make a label (ZPL II Format) are encapsulated within the information sent from the Host computer.

How Protocols Work

The basic unit of data transfer in the Packet Response Protocol is called a “Transaction.” A Transaction is a two-way communication procedure that consists of information being sent from the Host computer to the Zebra printer, and the printer sending back a response to the Host computer. This response is an indication that the Zebra printer has either accepted or rejected the information sent from the Host computer.

Information is sent in the form of “Packets.” Packets sent from the Host computer are called Request Packets.

When a Request Packet is received, the Zebra printer analyzes the information in the Packet. If the Request Packet is accepted, the Zebra printer will send a positive response back to the Host computer. The Host computer can then send the next Request Packet. If the information is rejected, the Zebra printer will send a negative response back to the Host computer. The Host computer then sends the same Request Packet again.

The Zebra Packet Response Protocol can be used in both single-printer applications, where there is only one Zebra printer connected to the Host computer, and multi-drop systems in which several Zebra printers are connected to the same Host computer.

Request Packet Formats from the Host Computer

The first part of each data transfer Transaction is the sending of a Request Packet by the Host computer. The Request Packet contains a fixed length “Header” block and a variable length “Data” block. Each Packet sent from the Host computer to the Zebra printer must always use the following format.

The Request Packet Header Block is comprised of five fixed-length fields. The Request Packet Data Block is comprised of four fixed-length fields and one variable-length field. These fields are defined as follows.

Header Block					Data Block				
SOH	DST. Z-ID	SRC. Z-ID	TYPE	SEQ. #	STX	FORMAT	EXT	CRC	EOT
1	3	3	1	1	1	≤1024	1	2	1

Header Block Fields

- **SOH** (start of header character)
The Zebra printer interprets this character as the beginning of a new Request Packet. The ASCII Control Code character SOH (01H) is used as the Start of Header Character.
- **DST. Z-ID** (destination Zebra-ID)
This is the three-digit ASCII I.D. number used to identify which Zebra printer is to receive the Request Packet. The Zebra printer compares this number to the Network ID number assigned to it during Printer Configuration. The Zebra printer will act on the Request Packet only if these numbers match.
- **SRC. Z-ID** (source Zebra-ID)
This is a three-digit ASCII number used to identify the Host computer. This number is determined by the user.
- **TYPE** (packet type)
This field is used to define the type of Request Packet being sent by the Host. Only two characters are valid in this field:
 - ‘P’ indicates a Print Request Packet
 - ‘I’ indicates an Initialize Request Packet
 Most of the Packets sent by the Host to the Zebra printer will be of the ‘P’ variety, requesting a label to be printed.
The ‘I’ character tells the Zebra printer to initialize the packet sequence numbering. It is required in the first packet of a new printing session, after starting up the Host computer or the Zebra printer.
- **SEQ. #** (the sequence number of the request packet)
This block contains a single digit number used to denote the current Transaction Number. The Host computer must increment this number by “1” for each new Request/Response Transaction pair, i.e. 0, 1, 2, ..., 9. The numbers repeat after every 10 Transactions.

Data Block Fields

- **STX** (Start of Text)
The Zebra printer interprets this character as the beginning of the variable-length Data Format portion of the Request Packet. The ASCII Control Code character STX (02H) is used as the Start of Text Character.

- **DATA FORMAT** (Label Information)
A variable-length portion of the Request Packet that contains the complete or partial ZPL II label format, or partial data string (such as a downloaded graphic).
This field can contain from 0 to 1024 characters. If the Format of a label is longer than 1024 characters, the Data Format fields from consecutive packets will be concatenated together in the printer's Receive Data Buffer as if they were sent as one long direct transmission.
Special consideration has been given to the possible requirement to include ASCII Control Characters (values less than 20H) in the Data Format portion of a Request Packet. Characters such as EOT (04H), STX (02H), SOH (01H), and ETX (03H), are part of the Error Detection Protocol and could interrupt normal communication procedures if received at the wrong time.
- **ETX** (End of Text)
The Zebra printer interprets this character as the end of the variable length Data Format portion of the Request Packet. The ASCII Control Code character ETX (03H) is used as the End of Text Character.
- **CRC** (Cyclic Redundancy Check)
The CRC is a 2 character field. A Cyclic Redundancy Check is a type of error checking used to maintain the validity and integrity of the information transmitted between the Host computer and the Zebra printer. This Protocol uses the 16-bit CCITT method of producing a CRC.
The CRC is a two-byte value derived from the contents of the packet between, but not including, the SOH character and the CRC code itself. The Zebra printer will calculate a CRC of the Request Packet received and compare the value with the CRC Value in this field. The CRC of the Request Packet must match the CRC calculated by the Zebra printer in order for the Request Packet to be valid.
- **EOT** (End of Transmission)
The Zebra printer interprets this character as the end of the Request Packet. The ASCII Control Code character EOT (04H) is used as the End of Transmission Character.

Response From the Zebra Printer

When the Zebra printer receives the EOT character, it will begin acting on the Request Packet received. The printer will compare certain characters and numeric values within the received Request Packet and send a response back to the Host computer.

Zebra Packet Response

The Packet Response protocol provides the highest degree of error checking and is well suited to the Host-Multiple Printer application. The Response Packet from the Zebra printer will always use the following format.

The Request Packet Header Block is comprised of five fixed-length fields. The Request Packet Data Block is comprised of four fixed-length fields and one variable-length field. These fields are defined as follows.

Header Block					Data Block				
SOH	DST. Z-ID	SRC. Z-ID	TYPE	SEQ. #	STX	FORMAT	EXT	CRC	EOT
1	3	3	1	1	1	≤1024	1	2	1

Header Block Fields

- **SOH** (Start of Header Character)
The Zebra printer sends this character as the beginning of a new Response Packet. The ASCII Control Code character SOH (01H) is used as the Start of Header Character.
- **DST. Z-ID** (Destination Zebra-ID)
This is the same three-digit ASCII number used to identify the Host Computer that was contained in the SRC. Z-ID field of the Request Packet that initiated this Response Packet. The Host compares this number to its known value to insure it is the proper destination.
- **SRC. Z-ID** (Source Zebra-ID)
This is the three character ASCII Network I.D. of the Zebra printer that is sending the Response Packet.
- **TYPE** (Packet Type)
This block is used to define the type of Response Packet being sent to the Host. Only three characters are valid in this field.
 - 'A' This is a Positive Acknowledgment to the Host computer. It indicates that the Request Packet was received without a CRC error. The Host computer may send the next Request Packet.
 - 'N' This is the Negative Acknowledgment to the Host computer. It indicates that an error was detected in the packet sent from the Host computer. The Host computer must retransmit the same Request Packet again.
 - 'S' This character indicates that the Response Packet contains the Zebra Printer Status requested by a ~HS (Host Status) command received from the Host.
- **SEQ. #** (Used to denote the current message sequence number)
This number is identical to the message sequence number in the Request Packet. It denotes the message sequence number to which the Response Packet is replying.

Data Block Fields

- **STX** (Start of Text)
The Zebra printer sends this character as the beginning of the variable length Data Format portion of the Response Packet. The ASCII Control Code character STX (02H) is used as the Start of Text Character.
- **DATA FORMAT** (Label Information)
The 'variable length' portion of the Response Packet. If the Packet Type field in the Response Header contains an 'A' or an 'N', no data will appear in this field. If the Packet Type field contains an 'S', this field will contain the Printer Status Message.
- **ETX** (End of Text)
The Zebra printer sends this character as the end of the variable length Data Format portion of the Request Packet. The ASCII Control Code character ETX (03H) is used as the End of Text Character.
- **CRC** (Cyclic Redundancy Check)
This is the CRC of the Response Packet as calculated by the Zebra printer. This Cyclic Redundancy Check maintains the validity and integrity of the information transmitted between the Zebra printer and the Host computer.
This CRC is a two Byte value derived from the contents of the packet between, but not including, the SOH character and the CRC code itself. The Host computer will calculate a CRC of the received Response Packet and compare it to the CRC value in this field. The CRC of the Response Packet must match the CRC calculated by the Host computer in order for the Response Packet to be valid.
- **EOT** (End of Transmission)
The Zebra printer sends this character as the end of the Response Packet. The ASCII Control Code character EOT (04H) is used as the End of Transmission Character.

Disguising Control Code Characters

There may be occasions when ASCII Control Codes (00H - 19H) must be included as part of the Data Format block of a Request Packet. To eliminate any problems, these characters must be disguised so that the communication protocol does not act on them.

This procedure must be used to disguise each Control Code.

- A SUB (1AH) character must precede each Control Code placed in the Data Format block.
- The value of 40H must be added to the Hex value of the Control Code.
- The ASCII Character corresponding to the total value produced in step 2 must be entered in the Data Format right after the SUB character.

The Zebra printer automatically converts the modified control character back to its correct value by discarding the SUB (1AH) character and subtracting 40H from the next character.



Example: To include a DLE (10H) character in the Data Format block:

1. Enter a SUB (1AH) character into the Data Format.
2. Add 40H to the DLE value of 10H for a resulting value of 50H.
3. Enter the ASCII character "P" (50H) in the Data Format after the SUB character.



Note • This technique is counted as two characters of the 1024 allowed in the Data Format block.

Rules for Transactions

- Every Transaction is independent of every other Transaction and can only be initiated by the Host computer.
- A valid Response Packet must be received by the Host computer to complete a Transaction before the next Request Packet is sent.
- If an error is encountered during a Transaction, the entire Transaction (i.e., Request Packet and Response Packet) must be repeated.
- The Zebra printer does not provide for system time-outs and has no responsibility for insuring that its Response Packets are received by the Host computer.
- The Host computer must provide time-outs for all of the Transactions and insure that communication continues.
- If any part of a Transaction is lost or received incorrectly, it is the responsibility of the Host computer to retry the whole Transaction.

Error Detection Protocol Application

The following are the basic requirements for setting up the Zebra printer to use the Error Detection Protocol.

Activating the Protocol Protocol is a front panel selection, or can be done with the ZPL command `^SC`.

Setting Up Communications Insure that the Host computer and the Zebra printer are characterized with the same communication parameters; i.e., Parity, Baud Rate, etc. The communications must be set up for 8 data bits.

Setting the Printer ID Number The Protocol uses the printer's Network ID number to insure communication with the proper unit. The Network ID is programmed into the printer by sending the printer a `^NI` (Network ID Number) command or done through the front panel.

If there is only one printer connected to the Host computer, the Network ID number should be set to all zeros (default).

If there is more than one printer, such as in a broadcast or multi-drop environment, each printer should be assigned its own unique ID number. Printers in this environment, with an ID of all zeros, will receive ALL label formats regardless of the actual printer ID number in the DST. Z-ID block of the Request Packet.

Error Conditions and System Faults

Restarting a Transmission If a break in communication occurs, the Host must restart the transmission of the current label format with an Initialization Request Packet. The Zebra printer will not respond to Request Packets sent out of sequence. However, the Zebra printer will respond to an Initialization Request Packet and restart its internal counting with the sequence number of the Request Packet.

CRC Error Conditions and Responses A CRC error condition can be detected when the printer receives a Request Packet or when the Host computer receives a Response Packet. The following list defines these errors and how the Host computer should respond to them.

Error	Response
The CRC calculated by the Zebra printer does not match the one received as part of the Request Packet.	The Zebra printer will return a Negative Acknowledgment Response Packet. The Host computer should retry the same Transaction with the same Sequence Number.
The CRC calculated by the Host computer does not match the one received as part of the Response Packet.	The Host computer should retry the same Transaction with the same Sequence Number.

Time-Out Error Conditions and Responses

There are certain conditions at the Zebra printer that might cause the Host computer to time-out while processing a Transaction. The following list illustrates these conditions and how the Host computer should respond to them.

Error	Response
A Request Packet from the Host computer is not received by the Zebra printer.	The Host computer times out and resends the Request Packet of the same Transaction with the same Sequence Number.
A Request Packet from the Host computer is partially received by the Zebra printer.	The Host computer times out and resends the Request Packet of the same Transaction with the same Sequence Number.
A Response Packet from the Zebra printer is not received by the Host computer.	The Host computer times out and resends the Request Packet of the same Transaction with the same Sequence Number.
A Response Packet from the Zebra printer is partially received by the Host computer.	The Host computer times out and resends the Request Packet of the same Transaction with the same Sequence Number.

How the Zebra Printer Processes a Request Packet

The following describes the steps taken at the Zebra printer to process a Request Packet.

1. The Zebra printer looks for a SOH (Start of Header) character. As soon as it finds one, it places the SOH and all the data after it into its Receive Data Buffer. This process continues until the printer receives an EOT (End of Transmission) character.



Note • If a second SOH is received before an EOT is detected, the contents of the Receive Buffer will be discarded. All of the data after the second SOH will be placed in the Receive Data Buffer.

2. After detecting the EOT, the printer checks for the following:
 - * The DST. Z-ID matches the printer's Network I.D.



Note • If the Network ID at the printer is all zeros, the printer will accept all Request Packets regardless of the DST. Z-ID received. If a Request Packet is received with the DST. Z-ID all zeros, it is accepted by all printers regardless of their Network ID setting.

- *The Data Format begins with STX and ends with ETX.
- *The Sequence Number has not been used before.

If the check is satisfactory, proceed to Step 3 on the following page.

If any part of the check is unsatisfactory, the printer discards the data in its Receive Data Buffer and waits for another SOH. No response is sent to the computer.

Exceptions

It is possible that the printer will send a response to the host that the host does not receive. Therefore, the host will send the same request packet to the printer again. If this happens, the printer will not use the data if it already used it before. However, the printer will send a response back to the host.

The printer calculates the CRC and compares it with the one received in the Request Packet. If the CRC is valid, the printer sends a Positive Response Packet to the Host computer. It then transfers the 'Variable Length' data from the Receive Buffer to its memory for processing. If the CRC does not match, and the printer is set up to return a Negative Response Packet, the following will take place:

1. The printer assumes that the DST. Z-ID, SRC. Z-ID, and Sequence Number are correct and that the error was in the variable data.
2. The same DST. Z-ID, printers SRC. Z-ID, and Sequence Number will be returned back to the host in the Negative Response Packet.
3. If the assumption in (a) is incorrect, the Host computer can time-out and retransmit the original Request Packet.

How the Zebra Printer Responds to Host Status

If a **~HS** (Host Status) command is received by the Zebra printer, the printer will send back an acknowledgment for the receipt of the packet. It then sends an additional packet that includes the Host Status information in the Variable Length portion of the packet.



Notes • _____

ZB64 Encoding and Compression

This section describes the Base 64 MIME (ZB64) encoding and compression. This is the same type of MIME encoding that is used in e-mail.

For more information on ZB64 Encoding and Compression, contact your Reseller or Zebra Representative.

Contents

Introduction to B64 and Z64 1366
B64 and Z64 Encoding 1367

Introduction to B64 and Z64

The first encoding, known as B64, encodes the data using the MIME Base64 scheme. Base64 is used to encode e-mail attachments and is specifically designed to address communications path limitations, such as control characters and 7-bit data links. It encodes the data using only the printable ASCII characters:

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z
a b c d e f g h i j k l m n o p q r s t u v w x y z
0 1 2 3 4 5 6 7 8 9 + / =

With the use of ZPL, this has the added benefit of avoiding the caret (^) and tilde (~) characters. Base64 encodes six bits to the byte, for an expansion of 33 percent over the un-encoded data. This is much better than the 100 percent expansion given by the existing ASCII hexadecimal encoding.

The second encoding, known as Z64, first compresses the data using the LZ77 algorithm to reduce its size. (This algorithm is used by the PKWARE® compression program PKZIP™ and is integral to the PNG graphics format.) The compressed data is then encoded using the MIME Base64 scheme as described above.

A CRC is calculated across the Base64-encoded data. If the CRC-check fails or the download is aborted, the object can be invalidated by the printer.

The robust encodings can be piggybacked on the existing download commands with full backward compatibility. This is done by prefacing the new encodings with a header that uniquely identifies them. The download routines in the printer firmware can key-off the header to determine whether the data is in the old ASCII hexadecimal encoding or one of the new encodings. This allows existing downloadable objects to be used in their present format, while new objects can be created using the same download commands with the new encodings for increased integrity and reduced download times.

For easy reference, B64 and Z64 are referred to as ZB64. In any reference to the ZB64 encoding, assume that both Base64-only (B64) and LZ77/Base64 (Z64) encodings are accepted.



Example: The following is an example of an existing download command using the new encoding:

```
~DTARIAL,59494,:Z64:H4sICMB8+DMAC0FSSUFML1RURgDsmnd8VEW7x5+Z0edsyibZNNJhlyWhbEJI
wYSwJJDGNkmwghJIgJYEEhQIPsggKAjEaiIiVaSoIJYNBAkIGGxUBVUUCGU0JQSC0WFnPvbE+SF18+9
H+8f973X+3Jm93umzzNznvnNSSFGRJ6ARAVZvXK7XDaxLyTiR5B7ontuZPQ824I5RKIa6ew+aba8+pU1
rVDZiciv
```

[multiple lines deleted]

```
/O6DU5wZ7ie2+g4xzDPwCpwm3nqW2GAPcdc1xF4fIP66jHjncmKvKzh/ZUNCx19/QQx2HXHYB4m/PkQc
dCdx2G7OYt+mszkMh4iZxoiFvkh89BFipo87kwD/Bf/d0cycAAEA:a1b2
```

The parameters are identical to the existing ~DT command:

Table 43 •

Parameter	Details
<code>o = font name</code>	<p>Values: any valid TrueType name, up to 8 characters</p> <p>Default: if a name is not specified, UNKNOWN is used</p> <p>In this example, Arial is the specified font.</p>
<code>s = font size</code>	<p>Values: the number of memory bytes required to hold the Zebra-downloadable format of the font</p> <p>Default: if an incorrect value or no value is entered, the command is ignored</p> <p>In this example, 59494 is the size.</p> <p>To maintain compatibility with the existing ASCII hexadecimal encoding, this field must contain the size of the un-enclosed and uncompressed object — the number of bytes that are finally placed into the printer’s memory, not the number of bytes downloaded.</p>
<code>data = data string</code>	<p>Values: a string of ASCII hexadecimal values (two hexadecimal digits/byte). The total number of two-digit values must match parameter <code>s</code>.</p> <p>Default: if no data is entered, the command is ignored</p> <p>Everything following the size field is data. The new encoding imposes a header with a unique signature. The new encoding must start with the characters <code>:B64:</code> (data encoded in Base-64 only) or <code>:Z64:</code> (data compressed with LZ77, then encoded in Base-64) followed by the encoded data.</p> <p>After the data is presented, another colon (<code>:</code>) and four hexadecimal digits comprise the CRC. The Base64 standard allows new-line characters (carriage returns and line feeds) to be inserted into the encoded data for clarity. These characters are ignored by the printer.</p>

When downloading graphics, the colon is used in the current ASCII hexadecimal encoding indicate “repeat the previous dot row.” Since this shorthand is invalid for the first character of data (no previous dot row has been downloaded), it is safe for the printer to detect the leading colon character as the lead-in for the new encodings.

B64 and Z64 Encoding

These download encodings, B64 and Z64, are created as drop-in replacements for the existing ASCII hexadecimal encoding.

B64 encoding do the following:

- Encode the compressed data using the MIME Base64 algorithm.
- Calculate a CRC across the encoded data.
- Add a unique header to differentiate the new format from the existing ASCII hex encoding.

Z64 encoding do the following:

- Compress the data using the LZ77 algorithm.

- Encode the compressed data using the MIME Base64 algorithm.
- Calculate a CRC across the encoded data.
- Add a unique header to differentiate the new format from the existing ASCII hexadecimal encoding.

The data field have this format:

:id:encoded_data:crc

Table 44 •

Parameter	Details
:id	the identifying string B64 or Z64
:iencoded_data	data to download, compressed with LZ77 (if the id parameter is set to Z64) and encoded with Base64.
:crc	four hexadecimal digits representing the CRC calculated over the :encoded_data field.

The printer calculates a CRC across the received data bytes and compare this to the CRC in the header. A CRC mismatch is treated as an aborted download.

The B64 and Z64 encodings can be used in place of the ASCII hexadecimal encoding in any download command. The commands are:

- ~DB – Download Bitmap Font
- ~DE – Download Encoding
- ~DG – Download Graphic
- ~DL – Download Unicode Bitmap Font
- ~DS – Download Scalable Font
- ~DT – Download TrueType Font
- ~DU – Download Unbounded TrueType Font
- ^GF – Graphic Field (with compression type set to “ASCII hex”)

The ~DB (Download Bitmap Font) command can use the new encodings in place of the ASCII hexadecimal encoding in data sub-fields. Each character is encoded individually. However, for small amounts of data, the identifying B64 or Z64 header and trailing CRC may negate any gains made by using the new format.

For backward compatibility, the ^HG (Host Graphic) command uses the ASCII hexadecimal encoding. It does not use the new encodings.

Field Interactions

This section provides you with examples that show how commands interact with various justification parameters. The examples are in charts for these orientations:

Normal Orientation	1370
Rotated Orientation	1371
Bottom Up Orientation.....	1372
Inverted Orientation.....	1373

These charts are designed so that you can identify the location of the field origin and interactions between the rotation, formatting and justification commands.

Normal Orientation

Table 45 shows you the various normal orientation outputs:

Table 45 • Normal Orientation Examples

	^FPH	^FPV	^FPR
^FO Left Justified	┌ABCDE	┌A B C D E	EDCBA┌
^FT Left Justified	┌ABCDE	┌A B C D E	EDCBA┌
^FO Right Justified	ABCDE┌	A┌ B C D E	EDCBA
^FT Right Justified	ABCDE┌	A┌ B C D E	EDCBA

Rotated Orientation

Table 46 shows you the various rotated orientation outputs:

Table 46 • Rotated Orientation Examples

	^FPH	^FPV	^FPR
^FO Left Justified	┌ ABCDE	A B C D └ E	EDCBA ┌
^FT Left Justified	┌ ABCDE	┌ A B C D E	EDCBA ┌
^FO Right Justified	┌ ABCDE	┌ A B C D E	EDCBA ┌
^FT Right Justified	ABCDE └	A B C D E	EDCBA ┌

Bottom Up Orientation

Table 47 shows you the various bottom up orientation outputs:

Table 47 • Bottom Orientation Examples

	^FPH	^FPV	^FPR
^FO Left Justified	ABCDE	A B C D E	EDCBA
^FT Left Justified	ABCDE	A B C D E	EDCBA
^FO Right Justified	ABCDE	A B C D E	EDCBA
^FT Right Justified	ABCDE	A B C D E	EDCBA

Inverted Orientation

Table 48 shows you the various inverted orientation outputs:

Table 48 • Inverted Orientation Examples

	^FPH	^FPV	^FPR
^FO Left Justified	ABCDE+	A B C D E+	EDCBA+
^FT Left Justified	ABCDE+	A B C D E+	EDCBA+
^FO Right Justified	ABCDE+	A B C D E+	EDCBA+
^FT Right Justified	ABCDE+	A B C D E+	EDCBA+



Notes • _____

Real Time Clock

This appendix contains the information needed to install, program, and operate the Real Time Clock (RTC) option. This hardware option is available as either a factory-installed or field-installable option in specific printer products manufactured and sold by Zebra Technologies Corporation.

The Real Time Clock option is currently available for following printers, and requires that the firmware version shown is installed on that printer.

Contents

Control Panel Programming	1376
Real Time Clock Parameters	1376
RTC Date	1377
RTC Time	1378
RTC General Information	1378
First Day of the Week Affects Calendar Week	1380
Time and Date Precision	1381
ZPL II Samples	1383

Supported Zebra Printer and Print Engine Models	Requires this Firmware Version or Later
105SL printers that meet any one of the following criteria: <ul style="list-style-type: none">• if the printer was manufactured after April 2006• if the RTC Date and the RTC Time fields are printed on the configuration label• if the RTC Date and the RTC Time appear on the LCD display	60.13.0.13Z
DA402 & T402 printers	32.8.4
LP2844-Z, TPL2844-Z, and TPL3844-Z printers	45.10.x

Supported Zebra Printer and Print Engine Models		Requires this Firmware Version or Later
PAX Series print engines	170PAX2 print engines	29.9.x or 31.9.x
	110PAX3 print engines using Standard Font	34.10.x
	110PAX3 print engines using TT Font	49.10.x
	116PAX3 print engines using TT Font	35.10.x
	170PAX3 print engines using Standard Font	37.10.x
	170PAX3 print engines using TT Font	38.10.x
	110PAX4 and 170PAX4 print engines	60.13.0.12
S4M printers (field-installable kit)		50.13.x
S600 printers		27.10.3
Xi Series printers	90XII, 140XII, 170XII & 220XII printers	18.9.x
	90XIII, 96XIII, 140XIII, 170XIII, and 220XIII printers	33.10.0
	90XIIIPlus, 96XIIIPlus, 140XIIIPlus, 170XIIIPlus, and 220XIIIPlus printers	60.13.0.12
Z4Mplus and Z6Mplus printers		60.13.0.12
ZM400/ZM600/RZ400/RZ600 printers		53.15.xZ

Control Panel Programming

New parameters for the Real Time Clock have been added to the Control Panel Configuration. These parameters are located immediately following the **FORMAT CONVERT** prompt. Refer to the printer/print engine *User Guide* for complete configuration information.

- X.9.x firmware added the parameters to XII printers and 170PAX/170PAX2 print engines.
- X.10.x firmware added the parameters to XIII printers and PAX3 print engines.
- X.13.x firmware added the parameters to XIIIPlus printers, PAX4 print engines.
- X.13.0.13Z firmware added the parameters to 105SL printers.

Real Time Clock Parameters

The parameters listed on the following pages are added to the Control Panel Configuration prompts only when both the Real Time Clock hardware option and the appropriate version of firmware are installed:

- X.9.x or later firmware installed in the XII series printers or the 170PAX/170PAX2 series print engines.
- X.10.x or later firmware installed in the XIII series printers or the PAX3 series print engines.
- X.13.0.13Z or later firmware installed in the 105SL printers
- X.13.x or later firmware installed in the XIIIPlus series printers, the PAX4 series print engines, or the S4M printers.

The RTC ZPL II commands apply to all printers/print engines with the Real Time Clock hardware option and proper firmware.

Idle Display

Selects the printer/print engine Idle Display format and the method of displaying the time/date information. This parameter also affects the Configuration Label printout and the **RTC DATE** and **RTC TIME** formats.

Selections

- FW VERSION
- MM/DD/YY 24HR
- MM/DD/YY 12HR
- DD/MM/YY 24HR
- DD/MM/YY 12HR

If FW VERSION is selected, the format on the Configuration Label and on the RTC DATE and RTC TIME parameters is MM/DD/YY 24HR.

RTC Date

Allows entry of the RTC date in the format selected by the **IDLE DISPLAY** parameter.



Note • The RTC parameters are password-protected. Refer to your printer's user guide for specific instructions on accessing and modifying printer parameters.

Printer Model	Action
<i>PAX</i> Series print engines, <i>Xi</i> Series printers, and 105 <i>SL</i> printers	<ol style="list-style-type: none"> 1. Use the LEFT oval key to select the position to be adjusted 2. Then, use the RIGHT oval key to select the correct value for that position.
<i>Z4Mplus</i> and <i>Z6Mplus</i> printers	<ol style="list-style-type: none"> 1. Press SELECT to select the parameter. 2. Use the MINUS (-) key to select the position to be adjusted 3. Then, use the PLUS (+) key to select the correct value for that position. 4. Press SELECT to accept any changes and deselect the parameter.
S4M printer	<ol style="list-style-type: none"> 1. Press ENTER. The printer displays the current RTC date. 2. Modify the values as follows: <ul style="list-style-type: none"> • Press the right arrow to move to the next digit position. • To increase the value, press the up arrow. • To decrease the value, press the down arrow. 3. Press ENTER to accept the value shown.



Note • Invalid dates, such as 2/29/1999, may be entered, but will not be saved.

RTC Time

Allows entry of the RTC time in the format selected by the **IDLE DISPLAY** parameter.



Note • The RTC parameters are password-protected. Refer to your printer's user guide for specific instructions on accessing and modifying printer parameters.

Printer Model	Action
<i>PAX</i> Series print engines, <i>Xi</i> Series printers, and 105 <i>SL</i> printers	<ol style="list-style-type: none"> 1. Use the LEFT oval key to select the position to be adjusted 2. Use the RIGHT oval key to select the correct value for that position.
<i>Z4Mplus</i> and <i>Z6Mplus</i> printers	<ol style="list-style-type: none"> 1. Press SELECT to select the parameter. 2. Use the MINUS (-) key to select the position to be adjusted. 3. Use the PLUS (+) key to select the correct value for that position. 4. Press SELECT to accept any changes and deselect the parameter.
S4M printer	<ol style="list-style-type: none"> 1. Press ENTER. The printer displays the current RTC date. 2. Modify the values as follows: <ul style="list-style-type: none"> • Press the right arrow to move to the next digit position. • To increase the value, press the up arrow. • To decrease the value, press the down arrow. 3. Press ENTER to accept the value shown.

RTC General Information

The Real Time Clock commands are only applicable if the Real Time Clock option is installed in the printer. For those printers with an LCD control panel display, additional control panel configuration parameters are also included.

The ZPL II Field Clock **^FC** command is used to specify the clock-indicator character for the primary, secondary, and third clocks. This command must be included within each label field command string whenever the date or time clock values are required within the field. No date or time clock information can be printed in a label field unless this command is included. The **^FC** command can now be combined with the **^SN** command in V60.13.0.10 and later.

A clock-indicator can be any printable character except the ZPL II Format Prefix, Control Prefix, or Delimiter characters. The default value for the primary clock-indicator is the percent sign **%**. The secondary and third clock-indicators have no defaults and must be specified in order for that clock to be used.

The Field Data **^FD** command has been expanded to recognize the clock-indicators and associated command characters, and to replace them during the printing process with the corresponding time or date parameter. For example, if the primary clock-indicator is the percent sign **%**, then during printing, the character sequence **%H** in the **^FD** statement would be replaced by the 2-digit current hour.



Note • If the Real Time Clock is not installed, or the **^FC** command has not preceded the **^FD** statement, no replacement would occur. In this case, the characters **%H** would print as text on the label.

The name of the day of the week, the name of the month, and the AM or PM designation can also be inserted in place of a specific clock-indicator/command character sequence. See [Table 49](#) for the list of command characters and their functions.

Table 49 • Command Characters

Command Character	Function
%a	is replaced by the abbreviated weekday name
%A	is replaced by the weekday name
%b	is replaced by the abbreviated month name
%B	is replaced by the month name
%d	is replaced by the day of the month number, 01 to 31
%H	is replaced by the hour of the day (military), 00 to 23
%I	is replaced by the hour of the day (civilian), 01 to 12
%j	is replaced by the day of the year, 001 to 366
%m	is replaced by the month number, 01 to 12
%M	is replaced by the minute, 00 to 59
%p	is replaced by the AM or PM designation
%S	is replaced by the seconds, 00 to 59
%U	is replaced by the week# of the year, 00 to 53, Sunday is 1st day*
%W	is replaced by the week# of the year, 00 to 53, Monday is 1st day**
%w	is replaced by the day# of the week, 00 (Sunday) to 06 (Saturday)
%y	is replaced by the 2 digits of the year, 00 to 99
%Y	is replaced by the full 4 digit year number—where% is the specified clock-indicator character

*. %U establishes Sunday as the first day of the year.

**.%W establishes Monday as the first day of the year.

The Set Offset **^SO** command permits the printing of specific times and dates relative to the primary clock. The secondary (or third) clock is enabled when secondary (or third) offsets are entered using this command. The secondary (or third) clock time and date are determined by adding the offsets to the current clock reading.

One **^SO** command is required to set the secondary offset; an additional **^SO** command is required for a third offset. The offsets remain until changed or until the printer is either powered down or reset.



Note • Only dates from January 1, 1998 to December 31, 2097 are supported. Setting the offsets to values that result in dates outside this range is not recommended and may have unexpected results.

The Set Mode/Language (see **^SL** on page 313) command is used to select the language the days of the week and the months are printed in. This command also sets the printing mode, which can be **S** for START TIME, **T** for TIME NOW, or a Numeric Value for the time accuracy. In START TIME mode, the time printed on the label is the time that is read from the Real Time Clock when the label formatting begins (when the **^XA** command is received by the printer). In TIME NOW mode, the time printed on the label is the time that is read from the Real Time Clock when the label is placed in the queue to be printed. In Numeric Value mode, a time accuracy tolerance can be specified.

First Day of the Week Affects Calendar Week

The `%U` and `%W` commands set the first day of the week. The week numbering starts at the beginning of the year with Week 01 representing the **first full week** of the year. Any day(s) before that established first day of the week are part of the Week 00. The following examples show how setting different days as the first day of the week affect the calendar week.



Important • The `%U` and `%W` commands determine the numbering for all weeks in the year.



Example: January, 2005 with Week 00

Set Sunday as the first day of the week using the `%U` command. In this example, notice that Saturday, January 1st is Week 00 and Sunday, January 2nd begins Week 01.

	Sun	Mon	Tue	Wed	Thu	Fri	Sat	
							1	← Week 00
First Day of the Week →	2	3	4	5	6	7	8	← Week 01
	9	10	11	12	13	14	15	
	16	17	18	19	20	21	22	
	23	24	25	26	27	28	29	
	30	31						



Example: January, 2005 with Week 00

Set Monday as the first day of the week using the `%W` command. In this example, notice that Saturday, January 1st **and** Sunday, January 2nd are Week 00 and Monday, January 3rd begins Week 01.

	Mon	Tue	Wed	Thu	Fri	Sat	Sun	
						1	2	← Week 00
First Day of the Week →	3	4	5	6	7	8	9	← Week 01
	10	11	12	13	14	15	16	
	17	18	19	20	21	22	23	
	24	25	26	27	28	29	30	
	31							

→ **Example: January, 2006 without Week 00**

Set Sunday as the first day of the week using the %U command. Since 2006 begins on a Sunday, there is no Week 00 in this example.

Sun	Mon	Tue	Wed	Thu	Fri	Sat
No Week 00						
1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31				

First Day of the Week → (points to Sun column)

← Week 01 (points to row 1-7)

→ **Example: January, 2006 with Week 00**

Set Monday as the first day of the week using the %W command. In this example, Saturday, January 1st is Week 00 and Sunday, January 2nd begins Week 01.

Mon	Tue	Wed	Thu	Fri	Sat	Sun
						1
2	3	4	5	6	7	8
9	10	11	12	13	14	15
16	17	18	19	20	21	22
23	24	25	26	27	28	29
30	31					

First Day of the Week → (points to Mon column)

← Week 00 (points to row 1)

← Week 01 (points to row 2-8)

Time and Date Precision

As of V60.13.0.1 firmware, the ^CO command is now ignored. While the S4M printer has a lower firmware version number (V50.x), its firmware was recently released and follows the rule to ignore the ^CO command.

The time and date placed in a label field is determined at the time the label bitmap is created by the printer (start time mode). If a batch of labels is formatted, the date and time will be the same for all labels in the batch. If the printer is paused during the printing process and remains in that state for a period of time, when printing resumes, the time and date will still be the same as when the batch was first started.

If more precise time and date stamps are required on versions prior to V60, follow the process below. For versions after V60, use the Numeric Value mode as shown in [^SL on page 313](#).

Cycle the printer/print engine power Off (O) and On (I) to clear the memory before performing the steps below.

Table 50.

1. Print a Memory Usage Label (^XA^WD*:*.*^XZ) and note the following value:
Available RAM (in BYTES) (A) _____
2. Print a Configuration Label and note these values:
Printer "Print Width" (in DOTS) (B) _____
(NOT the Label Width)
Label Length (in DOTS) (C) _____
3. Determine the desired maximum number of queued labels with the same Time and Date value. (D) _____



Note • Increasing the number of queued labels will improve throughput performance, but Real Time Clock values will be less accurate. Two is usually a good compromise.

Table 51.

4. Substitute the values for B through D from the previous page into the following formula:
The "label queue" memory required (in BYTES)
 $(B \times C \times D)/8 =$ (E) _____
5. Substitute the values for A and E into the following formula:
The ^CO command memory required (in KBYTES)
 $(A-E)/1024-5=$ (F) _____



Note • If the value of (F) is less than zero, then no ^CO command is needed. If the value of (F) is greater than zero, use the integer portion in the ^CO command.



Example:

Table 52.

Available RAM (A) = 71478 BYTES
 Print Width (B) = 832 DOTS
 Label Length (C) = 1000 DOTS
 Max Labels Queued (D) = 2
 Then —
 The label queue memory required (E) =
 $(B \times C \times D)/8 = 208000$ BYTES
 And —
 The ^CO command memory required (F) =

This command string will cause 489 KBYTES to be set aside as Font Memory and make it unavailable as label format memory. The memory remaining will only allow two labels to be formatted at one time, and the time and date will be more precise for those two labels.



Note • For the 170PAX2 print engine, you must disable the Reprint Function for the Time Now Mode to function properly.

ZPL II Samples

The ZPL II scripts shown on this page establish the initial settings for the date and time clock. The script below then references these settings to provide the output shown in [Figure 7 on page 1384](#).

Setting the date and time for the Real Time Clock only needs to be done once. The date and time are maintained by an on-board battery when the printer is reset or the printer is turned Off (O).

To set the date and time to April 23, 2005 at 2:30pm, the following command string should be sent to the printer:

```
^XA
  ^ST04,23,2005,02,30,0,P^FS
^XZ
```

To initialize the Real Time Clock and set up two offset values (offset #2 set to 3 months and 1 hour in the future, offset #3 set to 1 year in the past), the following command sequence should be sent to the printer:

```
^XA
  ^SL
  ^S02,3,0,0,1,0,0^FS
  ^S03,0,0,-1,0,0,0^FS
^XZ
```

The above ZPL II scripts initialize the RTC date and time and must be sent to a printer to provide proper date and time parameters for the ZPL II script below.

The following ZPL II script illustrates the various methods of printing the date and time initialized in the script above within separate fields on continuous media. [Figure 7 on page 1384](#) illustrates the printout of this script on a label.

For the below example, the **^FC** command delimiters are:

```
% Primary clock indicator
{ Secondary clock indicator
# Third clock indicator
^XA
  ^LL175
  ^F010,025^AD^FC%,{,#^FD1: Mil: %H:%M:%S Civ: %I:%M:%S %p^FS
  ^F010,050^AD^FC%,{,#^FD2: Mil: {H:{M:{S Civ: {I:{M:{S {p^FS
  ^F010,075^AD^FC%,{,#^FD3: Mil: #H:#M:#S Civ: #I:#M:#S #p^FS
  ^F010,100^AD^FC%,{,#^FD1: On %A, %B %d
  , %Y (%a, %m/%d/%y, %d %b %Y).^FS
  ^F010,125^AD^FC%,{,#^FD2: On {A, {B {d, {Y (
  {a, {m/{d/{y, {d {b {Y).^FS
  ^F010,150^AD^FC%,{,#^FD3: On #A, #B #d, #Y (
  #a, #m/#d/#y, #d #b #Y).^FS
^XZ
```

Figure 7 • Printed Result of the Above ZPL II Script

```
1: Mil: 14:30:00 Civ: 02:30:00 PM
2: Mil: 15:30:00 Civ: 03:30:00 PM
3: Mil: 14:30:00 Civ: 02:30:00 PM
1: On Wed, April 23, 2005 (Fri, 04/23/05, 23 Apr 2005)
2: On Saturday, July 23, 2005 (Sat, 07/23/05, 23 Jul 2005)
3: On Friday, April 23, 2004 (Fri, 04/23/04, 23 Apr 2004)
```


The following are examples of the time stamp using the **^SL1** and **^SL5** at 2 ips and 10 ips for the Enhanced Real Time Clock (V60.13.0.10 and later).



Note • They show the variation of time due to print speed and label complexity.

```
^XA
  ^SL1^FS
  ^F0187,184^A0N,101,121^FC%^FD%H:%M:%S^FS
  ^PQ10
^XZ
```


Figure 8 • Example of ^SL1, 2 ips and 10 ips




1	Label 1	4	Label 4	7	Label 7	10	Label 10
2	Label 2	5	Label 5	8	Label 8		
3	Label 3	6	Label 6	9	Label 9		

```

^XA
  ^SL5^FS
  ^F0187,184^A0N,101,121^FC%^FD%H:%M:%S^FS
  ^PQ10
^XZ
  
```

Figure 9 • Example of ^SL5, 2 ips and 10 ips



1	Label 1	6	Label 6
2	Label 2	7	Label 7
3	Label 3	8	Label 8
4	Label 4	9	Label 9
5	Label 5	10	Label 10



Notes • _____

ZBI Character Set

This section provides you with the set of characters that are supported on the front panel of the following Zebra printers with ZBI 2.0: *XiIIIPlus*, 105SL, Z4M/Z6M, ZM400/ZM600, RZ400/RZ600, PAX4 and S4M when V60.16.0Z or V53.16.0Z, or later firmware are loaded. These characters can be used in ZBI programs to display content on the LCD.

Character Set

These are the supported characters for these Zebra printers:

- *XiIIIPlus*
- 105SL
- Z4M/Z6M
- PAX4
- S4M:

Char. code

	0	0	0	0	0	0	0	1	1	1	1	1	1
	0	0	0	1	1	1	1	0	0	1	1	1	1
	0	1	1	0	0	1	1	1	1	0	0	1	1
	0	0	1	0	1	0	1	0	1	0	1	0	1
xxxx0000			0	@	P	`	F		-	9	≡	α	∅
xxxx0001		!	1	A	Q	a	q	。	ア	チ	△	ä	∅
xxxx0010		"	2	B	R	b	r	「	イ	ツ	×	β	θ
xxxx0011		#	3	C	S	c	s	」	ウ	テ	ε	ε	∞
xxxx0100		\$	4	D	T	d	t	、	エ	ト	†	μ	Ω
xxxx0101		%	5	E	U	e	u	・	オ	ナ	1	ö	Ü
xxxx0110		&	6	F	V	f	v	ヲ	カ	ニ	ヨ	ρ	Σ
xxxx0111		'	7	G	W	g	w	ア	キ	ヌ	ラ	q	π
xxxx1000		<	8	H	X	h	x	イ	ク	ネ	リ	∫	∞
xxxx1001)	9	I	Y	i	y	ウ	ツ	ル	”	∪	
xxxx1010		*	:	J	Z	j	z	エ	コ	ハ	レ	i	〒
xxxx1011		+	;	K	[k	[オ	サ	ヒ	ロ	*	〒
xxxx1100		,	<	L	¥	l	l	カ	シ	フ	フ	φ	円
xxxx1101		-	=	M]	m]	ユ	ズ	ハ	ン	も	÷
xxxx1110		.	>	N	^	n	^	ヨ	セ	ホ	”	ñ	
xxxx1111		/	?	O	_	o	_	ッ	ッ	マ	”	ö	■

These are the supported characters for these Zebra printers:

- ZM400/ZM600
- RZ400/RZ600
- Xi4
- RXi4

space 0020	" 0022	% 0025	& 0026	(0028) 0029	+ 002B	- 002D	. 002E	/ 002F
0 0030	1 0031	2 0032	3 0033	4 0034	6 0035	7 0037	8 0038	9 0039	: 003A
> 003E	? 003F	A 0041	B 0042	C 0043	D 0044	E 0045	F 0046	G 0047	H 0048
I 0049	J 004A	K 004B	L 004C	M 004D	N 004E	O 004F	P 0050	Q 0051	R 0052
S 0053	T 0054	U 0055	V 0056	W 0057	X 0058	Y 0059	Z 005A	_ 005F	

SGD Command Support

This appendix provides you with details identifying which SGD commands can be used with different printers and firmware versions.

Printer and Firmware Compatibility

This section provides supported printer models and minimum firmware versions for all SGD commands. In order to set and get configurations, the SGD commands can be used through the Ethernet, serial, parallel, and USB interfaces.



Note • The printer responds with the printer setting of "?" if the printer setting:

- does not exist
- has not been configured yet

If you have ...	Then...
<ul style="list-style-type: none">• 105SL• PAX4• S4M• Xi4• XiIIIPlus <ul style="list-style-type: none">• Z4MPlus/Z6MPlus• ZM400/ZM600• ZT200 Series• ZE500 Series	Go to Table 53, Table Top and Print Engine SGD Firmware Compatibility on page 1394 .
<ul style="list-style-type: none">• ZD500R• HC100• KR403• LP2824 Plus• TLP2824 Plus <ul style="list-style-type: none">• G-Series• GT800• GC420d• GC420t• GK800• GK888	Go to Table 54, Desktop and Kiosk SGD Firmware Compatibility on page 1405 .
<ul style="list-style-type: none">• R110PAX4• R110Xi (UHF)• R110Xi HF• R170Xi <ul style="list-style-type: none">• R4Mplus• RXi4• RZ400/RZ600	Go to Table 55, RFID Printer SGD Firmware Compatibility on page 1426 .

Standard Table Top Printers and Print Engines



Important • All the firmware versions noted in [Table 53](#) refer to the minimum firmware version required. For Desktop and Kiosk printers see [Table 54](#). For RFID printer support, see [Table 55](#).

Table 53 • Table Top and Print Engine SGD Firmware Compatibility

SGD Commands	ZE500 Series	ZT200 Series	XiiiPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
appl.bootblock	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
appl.name	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
appl.option_board_version	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
bluetooth.address	—	V72.18.2Z	—	—	—	—
bluetooth.afh_map	—	V72.18.2Z	—	—	—	—
bluetooth.afh_map_curr	—	V72.18.2Z	—	—	—	—
bluetooth.afh_mode	—	V72.18.2Z	—	—	—	—
bluetooth.authentication	—	V72.18.2Z	—	—	—	—
bluetooth.bluetooth_pin	—	V72.18.2Z	—	—	—	—
bluetooth.date	—	V72.18.2Z	—	—	—	—
bluetooth.discoverable	—	V72.18.2Z	—	—	—	—
bluetooth.enable	—	V72.18.2Z	—	—	—	—
bluetooth.friendly_name	—	V72.18.2Z	—	—	—	—
bluetooth.local_name	—	V72.18.2Z	—	—	—	—
bluetooth.radio_auto_baud	—	V72.18.2Z	—	—	—	—
bluetooth.radio_version	—	V72.18.2Z	—	—	—	—
bluetooth.short_address	—	V72.18.2Z	—	—	—	—
bluetooth.version	—	V72.18.2Z	—	—	—	—
card.inserted	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
card.mac_addr	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
CISDFCRC16	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
comm.baud	V53.17.2Z	V72.18.2Z	V60.15.0	V50.15.0	V53.15.5Z	V53.17.2Z
comm.halt	—	V72.18.2Z	—	—	—	—
comm.parity	V53.17.2Z	V72.18.2Z	V60.15.1	V50.15.0	V53.15.5Z	V53.17.2Z
comm.pnp_option	V53.17.2Z	V72.18.2Z	V60.15.0	V50.15.0	V53.15.5Z	V53.17.2Z
comm.stop_bits	V53.17.2Z	V72.18.2Z	V60.15.2	V50.15.0	V53.15.5Z	V53.17.2Z
comm.type	—	V72.18.2Z	—	—	—	—
cutter.clean_cutter	—	V72.18.2Z	—	—	—	—
device.command_override.active	—	—	—	—	—	—
device.command_override.clear	—	—	—	—	—	—
device.command_override.list	—	—	—	—	—	—
device.cutter_installed	—	—	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
device.download_connection_timeout	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.epl_legacy_mode	—	V72.18.2Z	—	—	—	—
device.friendly_name	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.frontpanel.feedenabled	—	V72.18.2Z	—	—	—	—
device.frontpanel.key_press	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
device.frontpanel.line1	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
device.frontpanel.line2	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
device.frontpanel.xml	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
device.host_identification	—	V72.18.2Z	—	—	—	—
device.host_status	—	V72.18.2Z	—	—	—	—
device.jobs_print	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.languages	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
device.ltu_installed	—	V72.18.2Z	—	—	—	—
device.orientation	—	V72.18.2Z	—	—	—	—
device.pause	—	V72.18.2Z	—	—	—	—
device.pnp_option	—	V72.18.2Z	—	—	—	—
device.position.accuracy	—	V72.19.6Z	—	—	—	—
device.position.altitude	—	V72.19.6Z	—	—	—	—
device.position.latitude	—	V72.19.6Z	—	—	—	—
device.position.longitude	—	V72.19.6Z	—	—	—	—
device.print_reprogram_2key	—	V72.18.2Z	—	—	—	—
device.reset	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.restore_defaults	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.super_host_status	—	V72.18.2Z	—	—	—	—
device.unique_id	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
device.unpause	—	V72.18.2Z	—	—	—	—
device.uptime	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.user_p1	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.user_p2	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
device.xml.enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.8Z	V53.15.8Z	V53.17.1Z
display.backlight	—	V72.18.2Z	—	—	—	—
display.backlight_on_time	—	V72.18.2Z	—	—	—	—
display.language	—	V72.18.2Z	—	—	—	—
display.load_card	—	V72.18.2Z	—	—	—	—
display.text	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
external_wired.check	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
external_wired.ip.addr	V53.17.16Z	V72.18.2Z	V60.15.8Z	**V53.15.5Z	**V53.15.5Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
external_wired.ip.arp_interval	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.default_addr_enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.dhcp.cid_all	V53.17.16Z	V72.18.2Z	V60.15.8Z	**V53.15.5Z	**V53.15.5Z	V53.17.1Z
external_wired.ip.dhcp.cid_enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	**V53.15.5Z	**V53.15.5Z	V53.17.1Z
external_wired.ip.dhcp.cid_prefix	V53.17.16Z	V72.18.2Z	V60.15.8Z	**V53.15.5Z	**V53.15.5Z	V53.17.1Z
external_wired.ip.dhcp.cid_suffix	V53.17.16Z	V72.18.2Z	V60.15.8Z	**V53.15.5Z	**V53.15.5Z	V53.17.1Z
external_wired.ip.dhcp.cid_type	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	**V53.15.5Z	V53.17.1Z
external_wired.ip.gateway	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.netmask	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.port	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.protocol	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.timeout.enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.timeout.value	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.ip.v6.addr	V53.17.16Z	V72.18.2Z	V60.16.5Z	v53.16.5Z	v53.16.5Z	V53.17.1Z
external_wired.ip.v6.gateway	V53.17.16Z	V72.18.2Z	V60.16.5Z	v53.16.5Z	v53.16.5Z	V53.17.1Z
external_wired.ip.v6.prefix_length	V53.17.16Z	V72.18.2Z	V60.16.5Z	v53.16.5Z	v53.16.5Z	V53.17.1Z
external_wired.mac_addr	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
external_wired.mac_raw	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ezpl.head_close_action	—	V72.18.2Z	—	—	—	—
ezpl.label_length_max	—	V72.18.2Z	—	—	—	—
ezpl.label_sensor	—	V72.18.2Z	—	—	—	—
ezpl.manual_calibration	—	V72.18.2Z	—	—	—	—
ezpl.media_type	—	V72.18.2Z	—	—	—	—
ezpl.power_up_action	—	V72.18.2Z	—	—	—	—
ezpl.print_method	—	V72.18.2Z	—	—	—	—
ezpl.print_width	—	V72.18.2Z	—	—	—	—
ezpl.reprint_mode	—	V72.18.2Z	—	—	—	—
ezpl.take_label	—	V72.18.2Z	—	—	—	—
ezpl.tear_off	—	V72.18.2Z	—	—	—	—
file.delete	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
file.dir	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
file.dir_format	—	V72.18.2Z	—	—	—	—
file.run	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
file.type	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
formats.cancel_all	—	V72.18.2Z	—	—	—	—
head.latch	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
input.capture	—	V72.18.2Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XiiiPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
interface.network.active.arp_interval	—	V72.18.2Z	—	—	—	—
interface.network.active.cable_type	—	V72.18.2Z	—	—	—	—
interface.network.active.dhcp_received_host_name	—	V72.18.2Z	—	—	—	—
interface.network.active.gateway	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
interface.network.active.ip_addr	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
interface.network.active.mac_addr	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
interface.network.active.mac_raw	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
interface.network.active.netmask	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
interface.network.active.protocol	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
interface.network.active.protocol_error	—	V72.18.2Z	—	—	—	—
interface.network.active.rx_errors	—	V72.18.2Z	—	—	—	—
interface.network.active.rx_packets	—	V72.18.2Z	—	—	—	—
interface.network.active.server_address	—	V72.18.2Z	—	—	—	—
interface.network.active.speed	—	V72.18.2Z	—	—	—	—
interface.network.active.tx_errors	—	V72.18.2Z	—	—	—	—
interface.network.active.tx_packets	—	V72.18.2Z	—	—	—	—
interface.network.active.wins_addr	—	V72.18.2Z	—	—	—	—
internal_wired.auto_switchover	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.addr	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.arp_interval	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.default_addr_enable	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.dhcp.cache_ip	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.cid_all	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.dhcp.cid_enable	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.dhcp.cid_prefix	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.dhcp.cid_suffix	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.dhcp.cid_type	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.dhcp.lease.last_attempt	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.lease.length	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.lease.server	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.lease.time_left	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.option12	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.option12_format	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.option12_value	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.dhcp.requests_per_session	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
internal_wired.ip.gateway	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.netmask	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XiiiPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
internal_wired.ip.port	V53.17.16Z	V72.18.2Z	—	—	V53.15.5Z	V53.17.1Z
internal_wired.ip.port_alternate	—	V72.18.2Z	—	—	—	—
internal_wired.ip.protocol	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.timeout.enable	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.ip.timeout.value	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.mac_addr	V53.17.16Z	V72.18.2Z	—	—	* V53.15.5Z	V53.17.1Z
internal_wired.mac_raw	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.active_network	V53.17.16Z	V72.18.2Z	V60.15.8Z	—	V53.15.5Z	V53.17.1Z
ip.addr	V53.17.16Z	V72.18.2Z	V60.15.2Z	—	V53.15.5Z	V53.17.1Z
ip.arp_interval	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.bootp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V53.15.5Z V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.arp_verify	—	V72.18.2Z	—	—	—	—
ip.dhcp.auto_provision_enable	—	V72.19.6Z	—	—	—	—
ip.dhcp.cache_ip	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.cid_all	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.cid_enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.cid_prefix	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.cid_suffix	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.cid_type	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V53.15.5Z V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.dhcp.lease.last_attempt	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.lease.server	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.lease.time_left	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.option12	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.option12_format	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.option12_value	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.request_timeout	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.requests_per_session	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.session_interval	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dhcp.vendor_class_id	—	V72.19.6Z	—	—	—	—
ip.dns.domain	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.dns.servers	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.ftp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.ftp.execute_file	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.ftp.request_password	—	V72.18.2Z	—	—	—	—
ip.gateway	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.
** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
ip.http.admin_name	—	V72.18.2Z	—	—	—	—
ip.http.admin_password	—	V72.18.2Z	—	—	—	—
ip.http.custom_link_name	—	V72.18.2Z	—	—	—	—
ip.http.custom_link_url	—	V72.18.2Z	—	—	—	—
ip.http.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.http.faq_url	—	V72.18.2Z	—	—	—	—
ip.http.port	—	V72.18.2Z	—	—	—	—
ip.lpd.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.mac_raw	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
ip.mirror.appl_path	—	V72.19.6Z	—	—	—	—
ip.mirror.auto	V53.17.2Z	V72.18.2Z	V60.16.4Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.error_retry	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.feedback.auto	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.feedback.freq	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.feedback.odometer	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.feedback.path	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.fetch	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.freq	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.freq_hours	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.last_error	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.last_time	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.mode	—	V72.19.6Z	—	—	—	—
ip.mirror.password	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.path	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.reset_delay	V53.17.2ZA	V72.18.2Z	V60.17.2ZA	V53.17.2ZA	V53.17.2ZA	V53.17.2ZA
ip.mirror.server	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.success	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.success_time	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.username	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.mirror.version	V53.17.2Z	V72.18.2Z	V60.17.2Z	V53.17.2Z	V53.17.2Z	V53.17.2Z
ip.netmask	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.pop3.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.pop3.password	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.pop3.poll	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.pop3.server_addr	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.pop3.username	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.port	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
ip.port_alterate	—	V72.18.2Z	—	—	—	—
ip.primary_network	—	V72.19.6Z	—	—	—	—
ip.primary_network	V53.17.16Z	V72.18.2Z	V53.15.5Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
ip.smtp.domain	V53.17.16Z	V72.18.2Z	V60.15.2Z	V53.15.5Z V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.smtp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.smtp.server_addr	V53.17.16Z	V72.18.2Z	V60.15.2Z	V53.15.5Z, V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.snmp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.snmp.get_community_name	V53.17.16Z	V72.18.2Z	V60.15.2Z	V53.15.5Z V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.snmp.set_community_name	V53.17.16Z	V72.18.2Z	V60.15.2Z	V53.15.5Z V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.snmp.trap_community_name	—	V72.18.2Z	—	—	—	—
ip.tcp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.telnet.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
ip.udp.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
media.cartridge.part_number	—	V72.18.2Z	—	—	—	—
media.cut_now	—	V72.18.2Z	—	—	—	—
media.darkness_mode	—	V72.18.2Z	—	—	—	—
media.media_low.external	—	V72.18.2Z	—	—	—	—
media.media_low.warning	V53.17.16Z	V72.18.2Z	—	—	—	V53.17.1Z
media.present.cut_amount	—	V72.18.2Z	—	—	—	—
media.present.cut_margin	—	V72.18.2Z	—	—	—	—
media.present.eject	—	V72.18.2Z	—	—	—	—
media.present.length_addition	—	V72.18.2Z	—	—	—	—
media.present.loop_length	—	V72.18.2Z	—	—	—	—
media.present.loop_length_max	—	V72.18.2Z	—	—	—	—
media.present.present_timeout	—	V72.18.2Z	—	—	—	—
media.present.present_type	—	V72.18.2Z	—	—	—	—
media.printmode	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
media.speed	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
memory.flash_free	V53.17.2Z	V72.18.2Z	V60.17.7Z	V50.15.0	V53.15.5Z	V53.17.2Z
memory.flash_size	V53.17.2Z	V72.18.2Z	V60.17.7Z	V50.15.0	V53.15.5Z	V53.17.2Z
memory.ram_free	V53.17.2Z	V72.18.2Z	V60.17.7Z	V50.15.0	V53.15.5Z	V53.17.2Z
memory.ram_size	V53.17.2Z	V72.18.2Z	V60.17.7Z	V50.15.0	V53.15.5Z	V53.17.2Z
netmanage.avalanche.available_port	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.startup_update	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.agent_addr	—	V72.18.2Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
netmanage.avalanche.available_agent	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.encryption_type	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.interval	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.interval_update	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.model_name	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.set_property	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.tcp_connection_timeout	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.text_msg.beep	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.text_msg.display	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.text_msg.print	—	V72.18.2Z	—	—	—	—
netmanage.avalanche.udp_timeout	—	V72.18.2Z	—	—	—	—
odometer.headclean	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
odometer.headnew	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
odometer.label_dot_length	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
odometer.media_marker_count1	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
odometer.media_marker_count2	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
odometer.retracts_count	—	V72.18.2Z	—	—	—	—
odometer.rfid.valid_resettable	—	—	—	—	—	—
odometer.rfid.void_resettable	—	—	—	—	—	—
odometer.total_print_length	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
parallel_port.mode	—	V72.18.2Z	—	—	—	—
parallel_port.present	—	V72.18.2Z	—	—	—	—
power.dtr_power_off	—	V72.18.2Z	—	—	—	—
print.tone	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
rfid.country_code	—	—	—	—	—	—
rfid.enable	—	—	—	—	—	—
rfid.error.response	—	—	—	—	—	—
rfid.position.program	—	—	—	—	—	—
rfid.reader_1.firmware_version	—	—	—	—	—	—
rfid.reader_1.hardware_version	—	—	—	—	—	—
rfid.reader_1.model	—	—	—	—	—	—
rfid.reader_1.power.read	—	—	—	—	—	—
rfid.reader_1.power.write	—	—	—	—	—	—
rfid.tag.read.content	—	—	—	—	—	—
rfid.tag.read.execute	—	—	—	—	—	—
rfid.tag.read.result_line1	—	—	—	—	—	—
rfid.tag.read.result_line1	—	—	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XiiiPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
rfid.tag.read.result_line1_alterate	—	—	—	—	—	—
rfid.tag.read.result_line2	—	—	—	—	—	—
rfid.tag.read.result_line2_alterate	—	—	—	—	—	—
rfid.tag.test.content	—	—	—	—	—	—
rfid.tag.test.execute	—	—	—	—	—	—
rfid.tag.test.result_line2	—	—	—	—	—	—
usb.device.device_id_string	—	V72.18.2Z	—	—	—	—
usb.device.device_unique_id	—	V72.18.2Z	—	—	—	—
usb.device.device_version	—	V72.18.2Z	—	—	—	—
usb.device.manufacturer_string	—	V72.18.2Z	—	—	—	—
usb.device.product_id	—	V72.18.2Z	—	—	—	—
usb.device.product_string	—	V72.18.2Z	—	—	—	—
usb.device.serial_string	—	V72.18.2Z	—	—	—	—
usb.device.vendor_id	—	V72.18.2Z	—	—	—	—
usb.halt	—	V72.18.2Z	—	—	—	—
weblink.ip.conn[1 2].location	—	V72.19.6Z	—	—	—	—
weblink.ip.conn[1 2].num_connections	—	V72.19.6Z	—	—	—	—
wlan.11n.20mhz_only	—	V72.18.2Z	—	—	—	—
wlan.11n.aggregation	—	V72.18.2Z	—	—	—	—
wlan.11n.greenfield	—	V72.18.2Z	—	—	—	—
wlan.11n.rifs	—	V72.18.2Z	—	—	—	—
wlan.11n.short_gi_20mhz	—	V72.18.2Z	—	—	—	—
wlan.11n.short_gi_40mhz	—	V72.18.2Z	—	—	—	—
wlan.active_channels	—	V72.18.2Z	—	—	—	—
wlan.adhocautomode	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.adhocchannel	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.allowed_band	—	V72.18.2Z	—	—	—	—
wlan.associated	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.bssid	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.channel	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.channel_mask						
wlan.channel_mask	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.current_tx_rate	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.essid	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.firmware_version	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.ip.addr	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.arp_interval	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
wlan.ip.default_addr_enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.dhcp.cache_ip	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.cid_all	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.dhcp.cid_enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.dhcp.cid_prefix	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.dhcp.cid_suffix	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.dhcp.cid_type	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.dhcp.lease.last_attempt	V53.17.2Z	V72.18.2Z	V60.15.0	V50.15.0	V53.15.5Z	V53.17.2Z
wlan.ip.dhcp.lease.length	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.lease.server	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.lease.time_left	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.option12	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.option12_format	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.option12_value	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.request_timeout	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.requests_per_session	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.dhcp.session_interval	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.ip.gateway	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.netmask	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.port	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.port_alternate	—	V72.18.2Z	—	—	—	—
wlan.ip.protocol	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.timeout.enable	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.ip.timeout.value	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.keep_alive.enable	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.keep_alive.timeout	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.kerberos.kdc	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.kerberos.password	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.kerberos.realm	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.kerberos.username	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.mac_addr	V53.17.16Z	V72.18.2Z	V60.15.8Z	V53.15.5Z	V53.15.5Z	V53.17.1Z
wlan.mac_raw	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.operating_mode	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.password	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.permitted_channels	—	V72.18.2Z	—	—	—	—
wlan.preamble	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.private_key_password	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
wlan.roam.interchannel_delay	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.roam.interval	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.roam.max_chan_scan_time	V53.17.16Z	V72.18.2Z	V60.16.4Z	V53.16.4Z	V53.16.4Z	V53.17.1Z
wlan.roam.max_fail	V53.17.11Z	V72.18.2Z	V60.17.11Z	V53.17.11Z	V53.17.11Z	V53.17.11Z
wlan.roam.rssi	V53.17.11Z	V72.18.2Z	V60.17.11Z	V53.17.11Z	V53.17.11Z	V53.17.11Z
wlan.roam.signal	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.security	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.signal_noise	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.signal_quality	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.signal_strength	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.station_name	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.tx_power	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.tx_rate	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.user_channel_list	—	V72.18.2Z	—	—	—	—
wlan.username	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.waveagent.enable	—	V72.18.2Z	—	—	—	—
wlan.waveagent.udp_port	—	V72.18.2Z	—	—	—	—
wlan.wep.auth_type	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wep.index	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wep.key_format	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wep.key1	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wep.key2	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wep.key3	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wep.key4	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
wlan.wpa.psk	V53.17.16Z	V72.18.2Z	V60.15.2Z	V50.15.2Z	V53.15.5Z	V53.17.1Z
zbi.control.add_breakpoint	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.break	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.clear_breakpoints	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.delete_breakpoint	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.line_number	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.restart	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.run	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.step	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.terminate	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.variable_name	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.control.variable_value	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
zbi.key	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 53 • Table Top and Print Engine SGD Firmware Compatibility (Continued)

SGD Commands	ZE500 Series	ZT200 Series	XIIIPlus 105SL, PAX4 Z4MPlus Z6MPlus	S4M	ZM400 ZM600	Xi4
<i>zbi.last_error</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.reseller_key</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.revision</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.running_program_name</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.start_info.execute</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.start_info.file_name</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.start_info.memory_alloc</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zbi.state</i>	V53.17.16Z	V72.18.2Z	V60.16.2Z	V53.16.2Z	V53.16.2Z	V53.17.1Z
<i>zpl.caret</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.control_character</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.delimiter</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.label_length</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.left_position</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.system_error</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.system_status</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.zpl_mode</i>	—	V72.18.2Z	—	—	—	—
<i>zpl.zpl_override</i>	—	V72.18.2Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Desktop and Kiosk Printers



Important • All the firmware versions noted in [Table 54](#) refer to the minimum firmware version required. For .RFID printer support, see [Table 55](#). For Table Top and Print Engines, see [Table 53](#).

Table 54 • Desktop and Kiosk SGD Firmware Compatibility

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
<i>appl.bootblock</i>	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.2Z
<i>appl.name</i>	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>appl.option_board_version</i>	—	V54.16.1ZC	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
bluetooth.address	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.afh_map	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.afh_map_curr	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.afh_mode	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.authentication	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.bluetooth_pin	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.date	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.discoverable	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.enable	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.friendly_name	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.local_name	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.radio_auto_baud	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.radio_version	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.short_address	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
bluetooth.version	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
card.inserted	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
<code>card.mac_addr</code>	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>CISDFCRC16</code>	—	V54.16.1ZC	—	—	—
<code>comm.baud</code>	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	—	V66.17.4Z
<code>comm.halt</code>	V74.19.6Z	—	—	—	—
<code>comm.parity</code>	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z
<code>comm.pnp_option</code>	—	V54.16.1Z	V56.17.11Z V61.17.11Z	V70.17.11Z V71.17.11Z	V66.17.4Z
<code>comm.stop_bits</code>	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z
<code>comm.type</code>	V74.19.6Z	—	V56.17.3Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>cutter.clean_cutter</code>	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>device.command_override.active</code>	—	—	—	—	—
<code>device.command_override.clear</code>	—	—	—	—	—
<code>device.command_override.list</code>	—	—	—	—	—
<code>device.cutter_installed</code>	V74.19.6Z	—	—	—	—
<code>device.download_connection_timeout</code>	V74.19.6Z	V54.16.1ZC	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>device.epl_legacy_mode</code>	V74.19.6Z	—	V56.17.9Z V61.17.9Z V61.17.9Z	V70.17.11Z V71.17.11Z	—
<code>device.friendly_name</code>	V74.19.6Z	V54.16.1ZC	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>device.frontpanel.feedenabled</code>	—	—	V61.17.11Z, V56.17.11Z,	V70.17.11Z V71.17.11Z	—
<code>device.frontpanel.key_press</code>	V74.19.6Z	—	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>device.frontpanel.line1</code>	V74.19.6Z	—	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<code>device.frontpanel.line2</code>	V74.19.6Z	—	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
device.frontpanel.xml	V74.19.6Z	—	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.host_identification	V74.19.6Z	—	—	—	—
device.host_status	V74.19.6Z	—	—	—	—
device.jobs_print	V74.19.6Z	V54.16.1ZC	V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.languages	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.ltu_installed	V74.19.6Z	—	—	—	—
device.orientation	—	—	V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.2Z
device.pause	V74.19.6Z	—	—	—	—
device.pnp_option	V74.19.6Z	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.position.accuracy	V74.19.6Z	—	—	—	—
device.position.altitude	V74.19.6Z	—	—	—	—
device.position.latitude	V74.19.6Z	—	—	—	—
device.position.longitude	V74.19.6Z	—	—	—	—
device.print_reprogram_2key	—	—	—	—	—
device.reset	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.restore_defaults	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.super_host_status	V74.19.6Z	—	—	—	—
device.unique_id	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.unpause	V74.19.6Z	—	—	—	—
device.uptime	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.user_p1	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.user_p2	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
device.xml.enable	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
display.backlight	V74.19.6Z	—	—	—	—
display.backlight_on_time	V74.19.6Z	—	—	—	—
display.language	V74.19.6Z	—	—	—	—
display.load_card	V74.19.6Z	—	—	—	—
display.text	V74.19.6Z	—	V56.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.check	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.addr	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.arp_interval	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.default_addr_enable	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.dhcp.cid_all	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>external_wired.ip.dhcp.cid_enable</i>	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>external_wired.ip.dhcp.cid_prefix</i>	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.dhcp.cid_suffix	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.dhcp.cid_type	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.gateway	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.netmask	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.port	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.protocol	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.timeout.enable	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
external_wired.ip.timeout.value	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.v6.addr	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.v6.gateway	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.ip.v6.prefix_length	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.mac_addr	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
external_wired.mac_raw	—	—	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ezpl.head_close_action	V74.19.6Z	—	—	—	—
ezpl.label_length_max	V74.19.6Z	—	—	—	—
ezpl.label_sensor	V74.19.6Z	—	—	—	—
ezpl.manual_calibration	V74.19.6Z	—	—	—	—
ezpl.media_type	V74.19.6Z	—	—	—	—
ezpl.power_up_action	V74.19.6Z	—	—	—	—
ezpl.print_method	V74.19.6Z	—	—	—	—
ezpl.print_width	V74.19.6Z	—	—	—	—
ezpl.reprint_mode	V74.19.6Z	—	—	—	—
ezpl.take_label	V74.19.6Z	—	—	—	—
ezpl.tear_off	V74.19.6Z	—	—	—	—
file.delete	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
file.dir	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
file.dir_format	V74.19.6Z	—	—	—	—
file.run	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
file.type	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
formats.cancel_all	V74.19.6Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
head.latch	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
input.capture	V74.19.6Z	—	—	—	—
interface.network.active.arp_interval	V74.19.6Z	—	—	—	—
interface.network.active.cable_type	V74.19.6Z	—	—	—	—
interface.network.active.dhcp_received_host_name	V74.19.6Z	—	—	—	—
interface.network.active.gateway	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
interface.network.active.ip_addr	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
interface.network.active.mac_addr	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
interface.network.active.mac_raw	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
interface.network.active.netmask	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
interface.network.active.protocol	V74.19.6Z	V54.16.1ZC	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
interface.network.active.protocol_error	V74.19.6Z	—	—	—	—
interface.network.active.rx_errors	V74.19.6Z	—	—	—	—
interface.network.active.rx_packets	V74.19.6Z	—	—	—	—
interface.network.active.server_address	V74.19.6Z	—	—	—	—
interface.network.active.speed	V74.19.6Z	—	—	—	—
interface.network.active.tx_errors	V74.19.6Z	—	—	—	—
interface.network.active.tx_packets	V74.19.6Z	—	—	—	—
interface.network.active.wins_addr	V74.19.6Z	—	—	—	—
internal_wired.auto_switchover	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.addr	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.arp_interval	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.default_addr_enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
internal_wired.ip.dhcp.cache_ip	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.cid_all	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.cid_enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.cid_prefix	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.cid_suffix	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.cid_type	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.lease.last_attempt	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.lease.length	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.lease.server	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.lease.time_left	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.option12	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.option12_format	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.option12_value	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.dhcp.requests_per_session	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.gateway	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.netmask	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
internal_wired.ip.port	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.port_alternate	V74.19.6Z	—	—	—	—
internal_wired.ip.protocol	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.timeout.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.ip.timeout.value	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.mac_addr	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
internal_wired.mac_raw	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.active_network	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.addr	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.arp_interval	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.bootp.enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.arp_verify	V74.19.6Z	—	—	—	—
ip.dhcp.auto_provision_enable	V74.19.6Z	—	—	—	—
ip.dhcp.cache_ip	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.cid_all	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.cid_enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.cid_prefix	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.cid_suffix	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
ip.dhcp.cid_type	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.lease.last_attempt	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.lease.server	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.lease.time_left	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.option12	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.option12_format	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.option12_value	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.request_timeout	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.requests_per_session	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.session_interval	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.dhcp.vendor_class_id	V74.19.6Z	—	—	—	—
ip.dns.domain	V74.19.6Z	V54.16.1ZC	—	—	—
ip.dns.servers	V74.19.6Z	V54.16.1ZC	—	—	—
ip.ftp.enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	—	—
ip.ftp.execute_file	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	—	—
ip.ftp.request_password	V74.19.6Z	—	—	—	—
ip.gateway	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	—	—
ip.http.admin_name	V74.19.6Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
ip.http.admin_password	V74.19.6Z	—	—	—	—
ip.http.custom_link_name	V74.19.6Z	—	—	—	—
ip.http.custom_link_url	V74.19.6Z	—	—	—	—
ip.http.enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	—	—
ip.http.faq_url	V74.19.6Z	—	—	—	—
ip.http.port	V74.19.6Z	—	—	—	—
ip.lpd.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	—	—
ip.mac_raw	—	V54.16.1ZC	—	—	—
ip.mirror.appl_path	V74.19.6Z	—	—	—	—
ip.mirror.auto	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.error_retry	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.feedback.auto	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.feedback.freq	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.feedback.odometer	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.feedback.path	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.fetch	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.freq	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.freq_hours	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.last_error	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.last_time	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.mode	V74.19.6Z	—	—	—	—
ip.mirror.password	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.path	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.reset_delay	V74.19.6Z	—	V61.17.3ZA V56.17.3ZA	V70.17.11Z V71.17.11Z	—
ip.mirror.server	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
ip.mirror.success	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.success_time	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.username	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.mirror.version	V74.19.6Z	—	V61.17.3Z V56.17.3Z	V70.17.11Z V71.17.11Z	—
ip.netmask	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.pop3.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.pop3.password	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.pop3.poll	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.pop3.server_addr	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.pop3.username	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.port	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.port_alternate	V74.19.6Z	—	—	—	—
ip.primary_network	V74.19.6Z	—	—	—	—
ip.primary_network	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.smtp.domain	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.smtp.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.smtp.server_addr	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.snmp.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
ip.snmp.get_community_name	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.snmp.set_community_name	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.snmp.trap_community_name	V74.19.6Z	—	—	—	—
ip.tcp.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.telnet.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
ip.udp.enable	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
media.cartridge.part_number	—	V54.16.5Z	—	—	—
media.cut_now	—	—	—	—	V66.17.2Z
media.darkness_mode	—	V54.16.1Z	—	—	—
media.media_low.external	—	—	—	—	V66.17.2Z
media.media_low.warning	—	—	—	—	—
media.present.cut_amount	—	—	—	—	V66.17.2Z
media.present.cut_margin	—	—	—	—	V66.17.2Z
media.present.eject	—	—	—	—	V66.17.2Z
media.present.length_addition	—	—	—	—	V66.17.2Z
media.present.loop_length	—	—	—	—	V66.17.2Z
media.present.loop_length_max	—	—	—	—	V66.17.2Z
media.present.present_timeout	—	—	—	—	V66.17.2Z
media.present.present_type	—	—	—	—	V66.17.2Z
media.printmode	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
media.speed	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
memory.flash_free	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z
memory.flash_size	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z
memory.ram_free	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
memory.ram_size	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z
netmanage.avalanche.available_port	V74.19.6Z	—	—	—	—
netmanage.avalanche.startup_update	V74.19.6Z	—	—	—	—
netmanage.avalanche.agent_addr	V74.19.6Z	—	—	—	—
netmanage.avalanche.available_agent	V74.19.6Z	—	—	—	—
netmanage.avalanche.encryption_type	V74.19.6Z	—	—	—	—
netmanage.avalanche.interval	V74.19.6Z	—	—	—	—
netmanage.avalanche.interval_update	V74.19.6Z	—	—	—	—
netmanage.avalanche.model_name	V74.19.6Z	—	—	—	—
netmanage.avalanche.set_property	V74.19.6Z	—	—	—	—
netmanage.avalanche.tcp_connection_timeout	V74.19.6Z	—	—	—	—
netmanage.avalanche.text_msg.beep	V74.19.6Z	—	—	—	—
netmanage.avalanche.text_msg.display	V74.19.6Z	—	—	—	—
netmanage.avalanche.text_msg.print	V74.19.6Z	—	—	—	—
netmanage.avalanche.udp_timeout	V74.19.6Z	—	—	—	—
odometer.headclean	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
odometer.headnew	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
odometer.label_dot_length	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
odometer.media_marker_count1	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
odometer.media_marker_count2	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
odometer.retracts_count	—	—	—	—	V66.17.2Z
odometer.rfid.valid_resetable	V74.19.6Z	—	—	—	—
odometer.rfid.void_resetable	V74.19.6Z	—	—	—	—
odometer.total_print_length	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
parallel_port.mode	—	—	—	—	—
parallel_port.present	—	—	—	—	—
power.dtr_power_off	V74.19.6Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
print.tone	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
rfid.country_code	V74.19.6Z	—	—	—	—
rfid.enable	V74.19.6Z	—	—	—	—
rfid.error.response	V74.19.6Z	—	—	—	—
rfid.position.program	V74.19.6Z	—	—	—	—
rfid.reader_1.firmware_version	V74.19.6Z	—	—	—	—
rfid.reader_1.hardware_version	V74.19.6Z	—	—	—	—
rfid.reader_1.model	V74.19.6Z	—	—	—	—
rfid.reader_1.power.read	V74.19.6Z	—	—	—	—
rfid.reader_1.power.write	V74.19.6Z	—	—	—	—
rfid.tag.read.content	V74.19.6Z	—	—	—	—
rfid.tag.read.execute	V74.19.6Z	—	—	—	—
rfid.tag.read.result_line1	V74.19.6Z	—	—	—	—
rfid.tag.read.result_line1	V74.19.6Z	—	—	—	—
rfid.tag.read.result_line1_alternate	V74.19.6Z	—	—	—	—
rfid.tag.read.result_line2	V74.19.6Z	—	—	—	—
rfid.tag.read.result_line2_alternate	V74.19.6Z	—	—	—	—
rfid.tag.test.content	V74.19.6Z	—	—	—	—
rfid.tag.test.execute	V74.19.6Z	—	—	—	—
rfid.tag.test.result_line2	V74.19.6Z	—	—	—	—
usb.device.device_id_string	V74.19.6Z	—	—	—	—
usb.device.device_unique_id	V74.19.6Z	—	—	—	—
usb.device.device_version	V74.19.6Z	—	—	—	—
usb.device.manufacturer_string	V74.19.6Z	—	—	—	—
usb.device.product_id	V74.19.6Z	—	—	—	—
usb.device.product_string	V74.19.6Z	—	—	—	—
usb.device.serial_string	V74.19.6Z	—	—	—	—
usb.device.vendor_id	V74.19.6Z	—	—	—	—
usb.halt	V74.19.6Z	—	—	—	—
weblink.ip.conn[1 2].location	V74.19.6Z	—	—	—	—
weblink.ip.conn[1 2].num_connections	V74.19.6Z	—	—	—	—
wlan.11n.20mhz_only	V74.19.6Z	—	—	—	—
wlan.11n.aggregation		—	—	—	—
wlan.11n.greenfield	V74.19.6Z	—	—	—	—
wlan.11n.rifs	V74.19.6Z	—	—	—	—
wlan.11n.short_gi_20mhz	V74.19.6Z	—	—	—	—
wlan.11n.short_gi_40mhz	V74.19.6Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
wlan.active_channels	V74.19.6Z	—	—	—	—
wlan.adhocautomode	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.adhocchannel	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.allowed_band	V74.19.6Z	—	—	—	—
wlan.associated	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.bssid	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.channel	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.channel_mask	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.current_tx_rate	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.essid	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.firmware_version	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.addr	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.arp_interval	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.default_addr_enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.cache_ip	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.cid_all	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.cid_enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
wlan.ip.dhcp.cid_prefix	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.cid_suffix	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.cid_type	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.lease.last_attempt	V74.19.6Z	V54.16.1Z	V56.15.6Z V61.15.6Z V61.17.3Z	V70.17.11Z V71.17.11Z	V66.17.4Z
wlan.ip.dhcp.lease.length	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.lease.server	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.lease.time_left	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.option12	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.option12_format	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.option12_value	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.request_timeout	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.requests_per_session	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.dhcp.session_interval	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.gateway	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.netmask	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.port	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.port_alternate	V74.19.6Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
wlan.ip.protocol	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.timeout.enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.ip.timeout.value	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.keep_alive.enable	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.keep_alive.timeout	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.kerberos.kdc	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.kerberos.password	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.kerberos.realm	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.kerberos.username	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.mac_addr	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.mac_raw	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.operating_mode	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.password	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.permitted_channels	V74.19.6Z	—	—	—	—
wlan.preamble	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.private_key_password	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.roam.interchannel_delay	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
wlan.roam.interval	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.roam.max_chan_scan_time	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.roam.max_fail	—	—	V61.17.11Z V56.17.11Z	V70.17.11Z V71.17.11Z	—
wlan.roam.rssi	—	—	V61.17.11Z V56.17.11Z	V70.17.11Z V71.17.11Z	—
wlan.roam.signal	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.security	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.signal_noise	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.signal_quality	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.signal_strength	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.station_name	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.tx_power	—	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.tx_rate	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.user_channel_list	V74.19.6Z	—	—	—	—
wlan.username	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.waveagent.enable	V74.19.6Z	—	—	—	—
wlan.waveagent.udp_port	V74.19.6Z	—	—	—	—
wlan.wep.auth_type	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
wlan.wep.index	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
<i>wlan.wep.key_format</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>wlan.wep.key1</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>wlan.wep.key2</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>wlan.wep.key3</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>wlan.wep.key4</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>wlan.wpa.psk</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.add_breakpoint</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.break</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.clear_breakpoints</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.delete_breakpoint</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.line_number</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.restart</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.run</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.step</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.terminate</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.control.variable_name</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

Table 54 • Desktop and Kiosk SGD Firmware Compatibility (Continued)

SGD Commands	ZD500R	HC100	G-Series, LP2824 Plus TLP 2824 Plus	GK800, GT800, GK888, GC420d, GC420t	KR403
<i>zbi.control.variable_value</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.key</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.last_error</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.reseller_key</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.revision</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.running_program_name</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.start_info.execute</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.start_info.file_name</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.start_info.memory_alloc</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zbi.state</i>	V74.19.6Z	V54.16.1Z	V56.16.5Z V61.16.5Z V61.17.3Z	V70.17.11Z V71.17.11Z	—
<i>zpl.caret</i>	—	—	—	—	—
<i>zpl.control_character</i>	—	—	—	—	—
<i>zpl.delimiter</i>	V74.19.6Z	—	—	—	—
<i>zpl.label_length</i>	V74.19.6Z	—	—	—	—
<i>zpl.left_position</i>	V74.19.6Z	—	—	—	—
<i>zpl.system_error</i>	V74.19.6Z	—	—	—	—
<i>zpl.system_status</i>	V74.19.6Z	—	—	—	—
<i>zpl.zpl_mode</i>	V74.19.6Z	—	—	—	—
<i>zpl.zpl_override</i>	V74.19.6Z	—	—	—	—

* On these printers with ZebraNet™ 10/100 Internal Print Server.

** On these printers with ZebraNet™ 10/100 External Print Server, firmware version 1.1.5

RFID Printers



Important • All the firmware versions noted in [Table 55](#), refer to minimum firmware version required. For non-RFID Table Top printers and Print Engines, see [Table 53](#). For non-RFID Desktop printers, see [Table 54](#).

Once an RFID Ready printer has been reconfigured as a RFID Printer, [Table 55](#) should be used. For commands not listed in [Table 55](#), refer to [Table 53](#) and [Table 54](#) and compare your firmware version to the Vxx.xx.xx firmware to which it most closely corresponds.

Table 55 • RFID Printer SGD Firmware Compatibility

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/RZ600
<i>card.inserted</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>card.mac_addr</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.addr</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.arp_interval</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.bootp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.dhcp.cid_all</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.dhcp.cid_enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.dhcp.cid_prefix</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
<i>ip.dhcp.cid_suffix</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.dhcp.cid_type</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.dhcp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.ftp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.gateway</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.http.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.lpd.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.netmask</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.pop3.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.pop3.password</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.pop3.poll</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
<i>ip.pop3.server_addr</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.pop3.username</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.port</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.primary_network</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.smtp.domain</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.smtp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.smtp.server_addr</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.snmp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.snmp.get_community_name</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.snmp.set_community_name</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.tcp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
<i>ip.telnet.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>ip.udp.enable</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>media.printmode</i>	—	—	—	—	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>odometer.rfid.valid_resetable</i>	—	—	—	—	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>odometer.rfid.void_resetable</i>	—	—	—	—	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.error.response</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.position.program</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.reader_1.antenna_port</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.reader_1.power.read</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.reader_1.power.single_power</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.reader_1.power.write</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>rfid.tag.calibrate</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
rfid.tag.data	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
rfid.tag.test	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
rfid.tag.type	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.adhocautomode	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.adhocchannel	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.associated	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.channel_mask	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.essid	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.firmware_version	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.keep_alive.enable	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
wlan.keep_alive.timeout	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
<i>wlan.kerberos.kdc</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.kerberos.password</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.kerberos.realm</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.kerberos.username</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.operating_mode</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.password</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.preamble</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.private_key_password</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.roam.interval</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.roam.signal</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.security</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
<i>wlan.signal_noise</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.signal_quality</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.signal_strength</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.station_name</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.tx_power</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.tx_rate</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.username</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wep.auth_type</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wep.index</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wep.key_format</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wep.key1</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Table 55 • RFID Printer SGD Firmware Compatibility (Continued)

SGD Commands	R110Xi (UHF) and R170Xi	R110PAX4	R4Mplus	R110Xi HF	RXi4	RZ400/ RZ600
<i>wlan.wep.key2</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wep.key3</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wep.key4</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z
<i>wlan.wpa.psk</i>	R60.15.8Z	R62.15.8Z R63.15.8Z	SP994P SP999F SP1027F SP1056E SP1082F	R65.15.8Z	V53.17.7Z	R53.16.3Z V53.17.7Z

Firmware Features

This appendix covers features added to major firmware releases.

Firmware x.17



Identifies features that are available in printers with firmware version Vx.17.x or later.

The following is an overview of the new and enhanced features available in firmware version V53.17.x, V56.17.xZ, V60.17.x, V61.17.xZ, and later.

Mirror

Mirror is a feature that gives you the ability to:

- Centrally manage and monitor the deployment of your Zebra printers
- Centrally configure and maintain your Zebra printers through remote updates
- Remotely monitor printer updates – via the “Feedback” feature
- There are several Set/Get/Do (SGD) commands that can initiate Mirror. For details see *Mirror Printer Configuration* on page 1452.

Benefits

- When using Mirror, updating the configuration and firmware on the printer is remotely managed from a centralized FTP server. Configurations can be uniformly deployed to individual printers or to groups of printers. Unique configurations can also be targeted to printers as needed. Through the “Feedback” feature, Administrators can easily log and monitor configuration updates on a printer-by-printer basis. Typical uses of Mirror include:
- Configuring printers as they are first received.
- Performing scheduled maintenance updates, sending firmware, fonts, graphics and other objects to the printer as needed.
- Changing printer configurations in order to move printers from one role to another.

- Supported printers and print servers:

Printer	Print Servers
Xi4™ -series	<ul style="list-style-type: none"> Internal, Integrated 10/100 IPV4 wired Internal Wireless Plus
ZM400™	<ul style="list-style-type: none"> Internal, Integrated 10/100 IPV4 wired Internal Wireless Plus
ZM600™	<ul style="list-style-type: none"> Internal, Integrated 10/100 IPV4 wired Internal Wireless Plus
S4M™	<ul style="list-style-type: none"> Internal Wireless Plus

Print Servers connected to the parallel port, either externally or internally, are not supported for Mirror use.

Wireless Markup Language (WML)

WML offers a text-based method of designing customized menus on the LCD front panel of selected printers. By leveraging Set-Get-Do (SGD) and Zebra Programming Language (ZPL) commands, menus that feature both display and command features can be created. The WML “card” structure makes it possible to link from one menu screen to another, creating menus that are as many levels “deep” as desired or reduced to only those options needed by the printer operator.

Firmware x.16



Identifies features that are available in printers with firmware version V60.16.x, V53.16.x, or later.

The following is an overview of the new and enhanced features available in firmware version V53.16.x and V60.16.x, and later; it is ZBI 2.0-Ready. These include:

- ZBI 2.0 can be enabled by placing a ZBI 2.0 key on the printer via the ZBI Key Manager & Downloader utility. Printers can be ordered from the factory with the ZBI 2.0 option enabled. Printers can be ZBI-Enabled in the field by purchasing and using a ZBI Key Kit. Printers can be ZBI-Enabled in the field by purchasing a key at www.zebrasoftware.com.
- Printers which have been ZBI-Enabled will not display a “Z” at the end of the firmware version string. For example, a printer which has been ZBI-Enabled will display the firmware version as “V53.16.1”, while a printer which has not been ZBI-Enabled will display the firmware version as “V53.16.1Z”
- The printer configuration label will display the ZBI status for the printer:
 - ZBI-Enabled

```

||  ENABLED..... ZBI
||  2.0..... ZBI VERSION
||  READY..... ZBI STATUS
||

```

- Not ZBI-Enabled

```

|| DISABLED..... ZBI ||
|| 2.0..... ZBI VERSION ||

```

- The printer configuration label will list which ZBI program is running.

```

|| ENABLED..... ZBI ||
|| 2.0..... ZBI VERSION ||
|| CHOICES.BAS..... ZBI STATUS ||

```

- ZBI 2.0 is backwards compatible with previous versions of ZBI. Any code which was specifically written to handle a maximum string length of 255 characters will need to be reviewed to ensure it works with unlimited string lengths.
- Other ZBI 2.0 Features:
 - List ZBI programs from the front panel
 - Start/Stop ZBI programs from the front panel
 - Button presses on front panel can be registered as events in ZBI programs.
 - Applicator port control
 - Support for longer strings, the length of the string dependent on available memory.
 - Support for NULL values in Strings and String operations
 - SNMP & Set/Get/Do (SGD) Control of ZBI
 - On-printer Debugging (via ZBI-Developer)
 - ZBI 2.0 Program Encryption
 - ZBI 2.0 programs can be made hidden and/or persistent
- New ZBI 2.0 Commands:

ACCEPT	INTTOHEX\$
ADDBREAK	READ
AUXPORT_GETPIN	REGISTEREVENTS
AUXPORT_RELEASEPIN	SERVERSOCKET
AUXPORT_SETPIN	SPLIT
AUXPORT_STEALPIN	SPLITCOUNT
CLIENTSOCKET	SUB
CLOSE ALL	TCPX
DELBREAK	TRIGGEREVENT
HANDLEEVENT	UNREGISTEREVENTS
HEXTOINT	WRITE

Firmware x.15



Identifies features that are available in printers with firmware version V60.15.x, V50.15.x, or later.

The following is an overview of the new and enhanced features available in firmware version V60.15.x, V50.15.x, or later. These include:

- Additional wireless securities
- New and updated ZPL commands (including wireless commands)
- Extended SNMP features, providing SNMP based control over commonly-needed printer settings.
- Support for Set / Get / Do (SGD) commands

Wireless Securities

Firmware V60.15.x and V50.15.x offer support for a wider range of wireless securities. These are the supported wireless securities:

- WEP-40-BIT
- WEP-128-BIT
- EAP-TLS
- EAP-TTLS
- EAP-FAST
- PEAP
- LEAP
- WPA-PSK
- WPA EAP-TLS
- WPA EAP-TTLS
- WPA EAP-FAST
- WPA PEAP
- WPA LEAP
- KERBEROS*

* Use of any given wireless security is dependent on the RF card being used.

ZPL and SGD Commands

Table 56 identifies the new commands and updates to existing commands in firmware version V60.15.x, V50.15.x, or later. The bolded items are either new commands or new enhancements to existing commands.

Table 56 • x.15 Features in Detail

Command	Details
^KC	The ^KC command is a new command with firmware version V60.15.x, V50.15.x, or later. It allows wireless print servers to have their own client identifier (CID). When the print server is active is uses the CID on the printer. When both print servers are active they have the option to use the CID on the printer, or their own CID.
~DY	Firmware version V60.15.x, V50.15.x, or later supports .NRD (non readable file) files and .PAC files (protected access credential).

Table 56 • x.15 Features in Detail

Command	Details
~WS	<p>Firmware version V60.15.x, V50.15.x, or later added these new parameters:</p> <ul style="list-style-type: none"> wireless pulse—adds a pulse to the network traffic generated by the printer. To keep the printer online, a pulse is necessary with some network configurations. wireless pulse interval—when the wireless pulse feature is enabled this sets the interval at which the wireless pulse is sent. channel mask—for commonly used channel masks. international mode—disables or enables International mode
^WX	<p>The ^WX command configures the wireless security settings for printers using the wireless print server.</p>

SNMP

Firmware V60.15.x, V50.15.x, or later feature support for an extended Management Information Base (MIB) file. The extended support now covers many of the printer settings, such as darkness, media type, and other printer specific settings. The MIB file can be downloaded from www.zebra.com for use with SNMP management systems.

Set / Get / Do Support

Printers with firmware V60.15.x and V50.15.x support a new set of commands known as Set / Get / Do (SGD) commands. These commands allow you to configure and get status on the wireless settings in the printer. For details on the supported commands, see *SGD Printer Commands* on page 571.

XML-Enabled Printing

Printers with firmware V60.15.8Z, V53.15.8Z, or later support XML-Enabled printing. For details, go to <http://www.zebra.com/xml>. This new feature does not alter the ZPL capabilities of the printer.

Firmware x.14



Identifies features that are available in printers with firmware version V60.14.x, V50.14.x, or later.

Table 57 identifies the new commands and enhancements to existing commands in firmware V60.14.x, V50.14.x, or later. The bolded items are either new commands or new enhancements to existing commands.

Table 57 • x.14 Features in Detail

Command	Details
^CI	<p>The ^CI command selects the encoding and character set. To identify the encoding, include a ^CI in the ZPL script. These encodings are now supported with the ^CI command:</p> <p>These are new variables that were added to the desired character set or a parameter of the existing ^CI command:</p> <ul style="list-style-type: none"> • Big 5 HKSCS (^CI26) with BIGHK.DAT. This supports the Hong Kong supplementary character set of the Big 5 character set and encoding. You can download the Big 5 HKSCS DAT table from www.zebra.com. • Code Page 1252 (^CI27). The ^CI27 command supports code page 1252. • GB 18030 (^CI26) with GB18030.DAT. This supports the GB 18030 character set and encoding standard. • Unicode Support. These new values were added to the ^CI command: <ul style="list-style-type: none"> 28 = Unicode (UTF-8 encoding) 29 = Unicode (UTF-16 Big-Endian encoding) 30 = Unicode (UTF-16 Little-Endian encoding)
~DY	<p>The ~DY command downloads fonts to the printer. Firmware version V60.14.x, V50.14.x, or later improves support for TrueType fonts and adds support for TrueType Extension fonts. When OpenType fonts can be downloaded as a TrueType font they are supported.</p>
^FH	<p>The ^FH command allows you to enter the hexadecimal value for any character directly into the ^FD statement. It has been updated to function with Unicode encodings.</p>
^FL	<p>The ^FL command provides the ability to link any TrueType font, including private character fonts to associated fonts, such that if the base font does not have a glyph for the required character, the printer looks to the linked fonts for the glyph. The font links are user-definable.</p>
^FO, ^FT, ^FW	<p>In firmware version earlier than V60.15.x, V50.15.x or later, the ^FO and ^FT commands were left-justified. In firmware version V60.14.x, V50.14.x, or later, a new parameter supports right- and auto-justification. Using the ^FW command allows you to set justification options.</p>
^HT	<p>Over a communication port, the ^HT command receives the complete list of the font links.</p>
^LF	<p>The ^LF command prints out a list of the linked fonts.</p>
^PA	<p>The Advanced Text Layout Options command (^PA) is new in firmware version V60.14.x, V50.14.x, or later.</p> <p>Advanced text layout, such as bidirectional text layout, character shaping, and OpenType support, can be activated with the ^PA command. The glyph displayed when the character is missing from a font (default glyph) can be changed from a space character to the default glyph of a font, which is often a square box.</p>
^SL	<p>A new parameter was added to the ^SL command to support the Japanese language in the Real Time Clock feature set.</p>
^TB	<p>The text block (^TB) command is a new command in firmware version V60.14.x, V50.14.x, or later. The ^FB command allows you to print text into a defined block type format; it does not support complex text layout. In contrast, the ^TB command supports a text block with complex text.</p>

Global Printing Solution

The Global Printing solution greatly simplifies international character label printing by supporting Unicode compatible fonts and encoding (UTF-8, UTF-16BE and UTF-16LE) directly in its printers.

These are new and enhanced features available in firmware version V60.14.x, v50,14.x, or later:

- Advanced text layout options
- Big 5 HKSCS
- GB 18030
- Unicode support (UTF-8 and UTF-16)
- Code Page 1252
- Field hexadecimal
- Field origin justification
- Font linking
- Improved font support
- Real-time clock – Japanese support
- Text block

For details on these new features, see [Table 56 on page 1438](#).

Zebra firmware V60.14.x, V50.14.x, or later continues to support locale-specific encoding formats. These formats include:

- Code Page 850
- Shift JIS
- GB
- Unified Hangul Code
- Big 5

What Is Unicode?

Unicode is a universal code page (which converts numeric codes into characters) that can be used with many computer platforms and software applications. While ASCII and other traditional code page encoding systems support 256 characters or less, Unicode can support almost 100,000 characters for all major languages. The languages include complex non-Western languages that can be difficult to print.

Unicode encoding and supporting fonts allow the printer to seamlessly output in any language. As a result, you do not have to select the language, font, code page, or configure or adjust the printer. Zebra's printer-resident capabilities provide fast label output and seamless multi-language printing.

You can create private libraries of logos and special characters and include them in labels. The ability to create custom characters is valuable for creating shipping labels for Asia, as many Asian fonts don't support characters for names, street names, and other proper nouns. Firmware V60.14.x, V50.14.x, or later offers features that support bidirectional printing or complex text layout, including:

- Arabic
- Hindi
- Thai
- Vietnamese
- Other languages

Mirror

This section provides an overview of Mirror, details on how to use it, and configuration examples.

Contents

Mirror Overview	1444
Benefits	1444
Professional Services for Mirror Configuration	1445

Requirements	1445
How Mirror Works.....	1447
Mirror Process Summary	1447
Mirror Process Details	1448
Creating ZPL Files for Use in the "<update-root>/files" Directory	1449
One Format per File	1449
Character Substitution.....	1450
Removing the ^XA and ^XZ commands	1450
Removing the ^DF command	1450
Example Files	1451
File Naming Recommendations.....	1451
Command Use Recommendations	1451
Configuration.....	1452
Mirror FTP Server Configuration.....	1452
Mirror Printer Configuration	1452
The Feedback.get File	1452
Example Feedback.get file	1454
How to Set Up and Use Mirror	1455
Scenario One.....	1455
Scenario Two	1456
Troubleshooting	1457

Mirror Overview

Mirror is a feature that gives you the ability to:

- Centrally manage and monitor the deployment of your Zebra printers
- Centrally configure and maintain your Zebra printers through remote updates
- Remotely monitor printer updates - via the "Feedback" feature

There are several Set/Get/Do (SGD) commands that are used to configure and initiate Mirror. For details see, [Mirror Printer Configuration on page 1452](#).

Benefits

When using Mirror, updating the configuration and firmware on the printer is remotely managed from a centralized FTP server. Configurations can be uniformly deployed to individual printers or to groups of printers. Unique Configurations can also be targeted to printers as needed.


Through the "Feedback" feature, Administrators can easily log and monitor configuration updates on a printer-by-printer basis.

Typical uses of Mirror include:

- configuring printers as they are first received
- performing scheduled maintenance updates, sending firmware, fonts, graphics and other objects to the printer as needed
- changing printer Configurations in order to move printers from one role to another

[Figure 10](#) provides an illustration of Mirroring.

Figure 10 • Mirror Illustration



1	Workstation — sends SGD commands to the printer to configure it for Mirror use.
2	FTP Server — Stores configuration files and responds to Mirror requests from the printer. Receives and stores “Feedback” content.
3	Access Point — wireless network infrastructure
4	Hub — wired network infrastructure
5	Zebra Printer(s) — Configured using SGD commands. Sends Mirror requests to the FTP server to receive files. Transmits “Feedback” content to the FTP server to log Mirror event transactions and resulting printer settings.

Professional Services for Mirror Configuration

Zebra offers a Professional Services group that can help with the configuring the Mirror feature. To inquire about Zebra’s Professional Services, contact your Zebra account representative.

Requirements

These are the requirements for Mirror:

- Zebra printer loaded with Mirror capable firmware and Print Server. For details, see [Table 58, Printers and Print Servers that Support Mirror on page 1446](#).
- FTP server (with UNIX-style directory listings), configured with the following directories:
 - "**<update-root>/app1**" - This directory is used for printer firmware updates. During an update operation, the printer will first check the "**<update-root>/app1**" directory for new printer firmware
 - "**<update-root>/files**" - This directory is used for printer-resident files. Files in this directory will be stored locally on the printer's file system. Files are not processed by the printer; they are only stored.

- "**<update-root>/commands**" - This directory is used for a limited number of printer executable commands. The contents of files in this directory will be sent to the printer's command interpreter for execution.
- "**<feedback-root>**" - This optional directory is used to receive Mirror feedback content from the printer. The content sent to this directory is defined by the "**feedback.get**" template file stored on the printer.
- A client account (user name and password) on the FTP server for the printer to use.
- A Terminal Emulation program, used to send SGD commands to the printer to configure Mirror.

Supported Printers and Print Server Types

These are the Zebra printers, firmware versions, and Zebra print servers that support Mirror.

Table 58 • Printers and Print Servers that Support Mirror

Printer	Firmware	Print Servers
ZT400	V75.19.7Z (or later)	<ul style="list-style-type: none"> • ZebraNet a/b/g/n Print Server • Internal Wireless Plus • Wireless Plus
ZE500	V53.17.15Z (or later)	<ul style="list-style-type: none"> • ZebraNet b/g Print Server • Internal Wireless Plus • Wireless Plus
ZT200	V72.18.2Z(or later)	<ul style="list-style-type: none"> • ZebraNet a/b/g/n Print Server • Internal Wireless Plus • Wireless Plus
105SLPlus	V53.17.15Z (or later)	<ul style="list-style-type: none"> • ZebraNet b/g Print Server • Internal Wireless Plus • Wireless Plus
Xi4™ series	V53.17.5Z (or later)	<ul style="list-style-type: none"> • Internal, Integrated 10/100 IPV4 wired • Internal Wireless Plus
XIIIPlus™ series	V60.17.5Z (or later)	<ul style="list-style-type: none"> • Internal Wireless Plus • Wireless Plus
105SL™	V60.17.5Z (or later)	<ul style="list-style-type: none"> • Internal Wireless Plus • Wireless Plus
PAX4™	V60.17.5Z (or later)	<ul style="list-style-type: none"> • Internal Wireless Plus • Wireless Plus
ZM400™	V53.17.5Z (or later)	<ul style="list-style-type: none"> • Internal 10/100 wired • Internal Wireless Plus • Wireless Plus
ZM600™	V53.17.5Z (or later)	<ul style="list-style-type: none"> • Internal 10/100 wired • Internal Wireless Plus • Wireless Plus
S4M™	V53.17.5Z (or later)	<ul style="list-style-type: none"> • Internal Wireless Plus • Wireless Plus

Table 58 • Printers and Print Servers that Support Mirror

G™ -series	V56.17.5Z V61.17.5Z (or later)	<ul style="list-style-type: none"> • Internal 10/100 wired • Internal Wireless Plus • Wireless Plus
LP 2824 Plus TLP 2824 Plus	V61.17.3Z (or later)	<ul style="list-style-type: none"> • Internal 10/100 wired • Internal Wireless Plus • Wireless Plus



Note • Print Servers connected to the parallel port, either externally or internally, are not supported for Mirror use.

How Mirror Works

Mirror utilizes a network connection and FTP communications to perform remote updates and feedback operations. At printer startup and/or at regular intervals, the printer will establish a FTP connection back to a central FTP server and check for updates. During an update operation, the printer will check for updated files in specific directories at the FTP server.

These are the specific FTP server directories that will be checked:

- "**<update-root>/appl**" - This directory is used for printer firmware updates. During an update operation, the printer will first check the "<update-root>/appl" directory for new printer firmware
- "**<update-root>/files**" - This directory is used for printer-resident files. Files in this directory will be stored locally on the printer's file system. Files are not processed by the printer; they are only stored.
- "**<update-root>/commands**" - This directory is used for a limited number of printer executable commands. The contents of files in this directory will be sent to the printer's command interpreter for execution.
- "**<feedback-root>**" - This optional directory is used to receive Mirror feedback content from the printer. The content sent to this directory is defined by the "feedback.get" template file stored on the printer.



Note • "**<update-root>**" refers to the value of the "**ip.mirror.path**" configuration parameter.

Files in the **<update-root>/files** directory should not have download headers in them. They should be in the exact format they will be in when stored on the printer's file system. Examples of download headers are: **~DY**, **~DG**, **! CISDFCRC16** or **~DF**.



Important • When the printer is in the Mirror process:

- It is unavailable for other tasks.
- The LCD will indicate that it is performing a Mirror function, showing when the printer is downloading firmware and the names of the object files as they are transferred to the printer.

Mirror Process Summary

The Mirror process follows a specific series of steps:

1. After power-up, the printer will first check the **<update-root>/appl** directory on the FTP server for new printer firmware and update the printer if necessary

2. If the printer did not find new firmware to download, it will then check in the **<update-root>\files** and **<update-root>/commands** directories for updated files - and download them as needed.
3. As a final Mirror step, the printer can perform an optional Feedback operation, transmitting a file of user-defined printer configuration information to **<feedback-root>** directory on the FTP server.
4. Finally, if any files or commands were downloaded during **Step 2:**, the printer will automatically reset itself.

Mirror Process Details

The following items are important to be aware of when configuring the FTP server to support Firmware updated via Mirror.

- Firmware files must be named using the following format: **<firmware version>.zpl**, where **<firmware version>** is the exact Firmware revision contained in the file. For example, for Firmware version "V53.17.5Z", the filename stored on the FTP server must be "V53.17.5Z.ZPL". If the file name and Firmware version do not match, the update will not succeed.
- The firmware filename stored on the FTP server is not case sensitive. This means that "V53.17.5Z.ZPL" and "v53.17.5Z.zpl" will be processed in the exact same way.
- The **/appl** directory can contain only one (1) file at a time. If there is more than 1 file in this directory, the printer will not download anything and will skip the firmware update.

During a Mirror event, the printer will use **<firmware version>** part of the filename contained in the **/appl** directory on the FTP server to check if the Firmware stored on the FTP server is different than the firmware the printer is currently using. If the **<firmware version>** part of the Firmware file name in the **/appl** directory on the FTP server does not exactly match the printer's Firmware version, the file on the FTP server will be downloaded and used to update the printer. Once the printer is updated with the new Firmware, the printer will reset and being using the new Firmware.



Note • Performing the Firmware update first is important because it is possible that the files or commands to be downloaded via Mirror will be dependent on the new firmware.

After the printer has completed the Firmware portion of an update operation, it will check the "**<update-root>/files**" directory and "**<update-root>/commands**" directory (in that order) for updated files that need to be retrieved. If a file exists on the FTP server and the server timestamp for the file does not match the printer's archived timestamp for the file, the printer will re-download the file and update its timestamp info. Files that are on the Mirror FTP server but not currently present on the printer will be sent to the printer. The supported file types are the standard files supported on ZPL printers.

If any files are downloaded during this portion of an update operation, the printer will reboot after the file downloads have completed. At this point, the update operation is complete.



Important •

- Files in the **<update-root>/files** directory should not have download headers in them. They should be in the exact format they will be in when stored on the printer's file system. Examples of download headers are: **~DY**, **~DG**, **! CISDFCRC16** or **~DF**.
- ZPL files in the **<update-root>/files** directory must use the printers internal characters for the Format Command Prefix (^), Delimiter Character (,) and Control Command Character (~). This means that the caret (^) should be replaced with a HEX 1E, the comma (,) should be replaced with a HEX 1F and the tilde (~) should be replaced with a HEX 10.

After an update operation is complete, a printer will perform a feedback operation, if configured to do so. During a feedback operation, the printer will open its feedback template file (named **feedback.get**), populate it based on its contents, and upload the resulting contents file to the FTP server, in the "<feedback-root>" directory.



Note • "<feedback-root>" refers to the value of the "**ip.mirror.feedback.path**" configuration parameter

Creating ZPL Files for Use in the "<update-root>/files" Directory

When creating ZPL formats that will be stored in the "<update-root>/files" directory it is necessary to edit the files using the following guidelines:

1. Files must contain only one format. This means that if a file contains multiple **^XA** and **^XZ** commands, those sections of the file must be split into separate formats, or combined as one format.
2. The characters used for the Format Command Prefix (^), Delimiter Character (,), and Control Command Characters (~) must be substituted for their Hexadecimal equivalents.
3. The **^XA** and **^XZ** commands must be removed from the formats.
4. The **^DF** command should be removed.

One Format per File

Files must contain only one format. This means that if a file contains multiple **^XA** and **^XZ** commands, those sections of the file must be split into separate formats, or combined as one format. For example, if a ZPL file contains both an initialization string and a format, the two sections must be either split into two files, or combined into one format.

For example, given the following formats:

```
^XA
^LT0^Mnw^MTT^PON^PMN^LH0,0^JMA^PR2,2^LRN^CI0
^XZ
^XA
^F020,100^IME:ZEBRA.BMP^FS
^A@N,75,75,TT0003M_.TTF
^F020,400^FDZebra Technologies^FS
^XZ
```

The following file should be created, which includes all of the command in one file:

```
^XA
^LT0^Mnw^MTT^PON^PMN^LH0,0^JMA^PR2,2^LRN^CI0
^F020,100^IME:ZEBRA.BMP^FS
^A@N,75,75,TT0003M_.TTF
^F020,400^FDZebra Technologies^FS
^XZ
```

Character Substitution

The characters used for the Format Command Prefix (^), Delimiter Character (,) and Control Command Characters (~) must be substituted for their Hexadecimal equivalents. During normal operation, this is how the printer works with ZPL formats. For example, when a ZPL format is sent to the printer via a telnet, RS-232 or Ethernet connection and stored for later use, it automatically processes the file and makes these character substitutions.

When ZPL formats are sent to the printer from the "<update-root>/files" directory they are stored on the printers memory, but not processed. For this reason, it is necessary to preprocess the files so that they are ready for use.

The following character substitutions must be made to files sent from the "<update-root>/files" directory:

Original Character	Substitute Character
Command Prefix The default is the Caret (^)	HEX 1E
Delimiter Prefix The default is the comma (,)	HEX 1F
Control Prefix The default is the tilde (~)	HEX 10

For example, given the following format:

```

^XA
^F020,100^IME:ZEBRA.BMP^FS
^A@N,75,75,TT0003M_.TTF
^F020,400^FDZebra Technologies^FS
^XZ

```

It would be necessary to replace the ^ characters with a HEX 1E and the , characters with a HEX 1F. This can be done using a Text Editor. See [Example Files on page 1451](#) for more information.

Removing the ^XA and ^XZ commands

Additionally, the ^XA and ^XZ commands should be removed from the format. The printer will automatically add these commands back in to process the file. See [Example Files on page 1451](#) for more information.

Removing the ^DF command

In some cases, you might have been using files that contain the ^DF command. The purpose of the ^DF command is to instruct the printer to store everything that comes after it in a ZPL file. For example, you might have a file that contains the following:

```

^XA
^DFE:STOREFMT.ZPL^FS
^F025,25^AD,36,20^FN1^FS
^F0165,25^AD,36,20^FN2^FS
^F025,75^AB,22,14^FDBUILT BY^FS
^F025,125^AE,28,15^FN1
^XZ

```

The purpose of the above format - when sent to a printer - would be to store a file called "STOREFMT" to the E memory location on the printer. In production, the goal would be to recall and print the "STOREFMT" file using the following ZPL commands:

```

^XA
^XFE:STOREFMT.ZPL^FS
^FN1^FDZEBRA^FS
^FN2^FDPRINTER^FS
^XZ
    
```

When this is done using Mirror, the format being sent to the printer must be altered. The line with the ^DF command must be removed - this is because the Mirror process is taking care of storing the format to the E memory location. In this scenario, the original format would be edited to look like this:

```

^F025,25^AD,36,20^FN1^FS
^F0165,25^AD,36,20^FN2^FS
^F025,75^AB,22,14^FDBUILT BY^FS
^F025,125^AE,28,15^FN1
    
```

The character substitution described above must also be done on the file before it is stored in the "<update-root>/files" directory.

The "recall" format - using the **^XFE:STOREFMT.ZPL** command - does not need to be altered or edited. It can be used as it was previously.

Example Files

Example of files that have already been altered in the manner described above are available as "Mirror File Examples" at www.zebra.com.

To see an example file, right-click the paper-clip icon and select Open File or Save Embedded File to Disk.

File Naming Recommendations

- Files in the "<update-root>/files" directory and "<update-root>/commands" directory should not have the same name.
- Files in the "<update-root>/files" should not contain multiple label formats. If you need to Mirror multiple formats, the recommended method is to split the formats into separate files.

Command Use Recommendations

- Files in the "<update-root>/commands" directory should use only SGD commands or the following ZPL commands:
 - ~CC
 - ~CD
 - ~CT
 - ~JA
 - ~JL
 - ~JS
 - ~JX
 - ~RO

- Do not add a device.reset SGD command to the end of a file in the "**<update-root>/commands**" directory. Mirror will reset itself automatically after performing an update, so there is no need for this command.

Configuration

This section provides detail on the configuring the printer and FTP server for Mirror.

Mirror FTP Server Configuration

For a Zebra printer to successfully use Mirror, the Mirror FTP server must have the following:

- A client account (user name and password) for the printer to use
- A root (base) directory for Mirror updates. This root directory must have the following subdirectories:
 - /appl
 - /files
 - /commands
- A Mirror feedback folder (optional)



Important • The printer's FTP user account must have the necessary permissions to read/write files in the update and feedback root directories. The **/appl**, **/files**, and **/commands** subdirectories are read only; the Mirror feedback folder is read/write. If these permissions are not properly set, the Mirror update and feedback processes will be unsuccessful.

Mirror Printer Configuration

The following SGD commands are used to configure Mirror on the printer:

<ul style="list-style-type: none"> • ip.mirror.auto on page 1120 • ip.mirror.error_retry on page 1121 • ip.mirror.feedback.auto on page 1122 • ip.mirror.feedback.freq on page 1123 • ip.mirror.feedback.odometer on page 1124 • ip.mirror.feedback.path on page 1125 • ip.mirror.fetch on page 1126 • ip.mirror.freq on page 1127 • ip.mirror.freq_hours on page 1128 	<ul style="list-style-type: none"> • ip.mirror.last_error on page 1130 • ip.mirror.last_time on page 1131 • ip.mirror.password on page 1133 • ip.mirror.path on page 1134 • ip.mirror.reset_delay on page 1135 • ip.mirror.server on page 1136 • ip.mirror.success on page 1137 • ip.mirror.success_time on page 1138 • ip.mirror.username on page 1139 • ip.mirror.version on page 1140
---	--

The Feedback.get File

The Feedback feature is one of the key benefits of the Mirror process. During a Mirror operation, the printer can upload a file to the FTP Server that contains information about the configuration of the printer. This information can then be leveraged by the Administrator to monitor the printer's setup. Using the Feedback feature is optional.

The "**feedback.get**" file is a template file stored on the printer. It controls what content is uploaded to the "**<feedback-root>**" directory on the FTP server. The directory on the FTP server where the printer will send Feedback content to is controlled by the "**ip.mirror.feedback.path**" command.

Within the `feedback.get` file it is possible to leverage SGD commands to insert current printer status and configuration strings into the file. This feature can help make the Feedback file on the FTP server more unique and useful to the Administrator.

Additionally, the first line of the `feedback.get` file is used to control the name of the file that will be uploaded and stored on the FTP server.

For example, if first line of the "**feedback.get**" file was:

```
"zebra.<wlan.mac_raw>.<ip.mirror.feedback.odometer>"
```

That line would be evaluated by the printer and used as the Feedback destination file name to create on the FTP server.

Using the example above, if the MAC address of the wireless print server was "00a0f8ae56d7" and the Feedback odometer was currently at "33", the Feedback file created the FTP server would be named:

```
"zebra.00a0f8ae56d7.33.txt"
```

The "`feedback.get`" file can be sent to the printer using the **!CISDFCRC16** command. For additional information, see [CISDFCRC16 on page 609](#).



Note • The first line of the `feedback.get` file is not included when the Feedback data is written to FTP server.

Example Feedback.get file

Here is an example of a "feedback.get" file and its resulting uploaded file:
zebra.<wlan.mac_raw>.<ip.mirror.feedback.odometer>

Application Name = <appl.name>

Serial Number = <device.friendly_name>

Mirror Success = <ip.mirror.success>

Mirror Auto = <ip.mirror.auto>

Mirror Path = <ip.mirror.path>

Mirror Last Update = <ip.mirror.success_time>

Bootp Enable = <ip.bootp.enable>

DHCP Enable = <ip.dhcp.enable>

Data Port = <ip.port>

Associated AP = <wlan.bssid>

RF ESSID = <wlan.essid>

RF Firmware = <wlan.firmware_version>

RF Signal Strength = <wlan.signal_strength>

RF Channel Mask = <wlan.channel_mask>

Label Length = <odometer.total_print_length>

Print Length = <odometer.label_dot_length>

When this file is processed by the printer and uploaded to the FTP server, the resulting upload file on the FTP server would contain data similar to this:

```

Application Name = V53.17.2Z
Serial Number = ZBR123456

Mirror Success = Yes
Mirror Auto = on
Mirror Path = /update-root/ZM400/
Mirror Last Update = 12345678

Bootp Enable = on
DHCP Enable = on
Data Port = 9100
Associated AP = 124
RF ESSID = MyEssid
RF Firmware = 5.2.1
RF Signal Strength = 98
RF Channel Mask = FF

Label Length = 100
Print Length = 200
    
```

How to Set Up and Use Mirror

This section provides multiple scenarios which include specific examples that demonstrate how to set up and use Mirror.

Scenario One

In this scenario, the printer is configured to perform a Mirror update operation (`"ip.mirror.auto = on"`) and feedback operation (`"ip.mirror.feedback.auto = on"`) every time the printer restarts. On startup, after a network connection has been established, the printer will attempt to make a FTP connection to the server address 10.14.5.133, using the "user name" and "password" of the printer.

If the connection is successful, the printer will attempt to perform an update operation using the root directory `"/all_printers/s4m/role1"`. After the update operation is complete, the printer will attempt a Feedback operation, uploading the resulting Feedback file to the `"/all_feedback"` directory on the server.

Using the command set in the example below, the printer will not attempt any *periodic* Mirror Update or Feedback operations. It will only perform Mirror operations on startup or when explicitly instructed to using the `"ip.mirror.fetch"` command.



Note • If a file starts with `"/"` it signifies the base directory of that file system. If a file is contained in the user's account, they do not start with a `"/"`.



Example: This example shows a Mirror configuration command set. Each line item of the command set is identified with a number. For details on each line item, see the table below.

```

10 ! U1 SETVAR "ip.mirror.auto" "on"
20 ! U1 SETVAR "ip.mirror.username" "printer"
30 ! U1 SETVAR "ip.mirror.password" "printer"
40 ! U1 SETVAR "ip.mirror.server" "10.14.5.133"
50 ! U1 SETVAR "ip.mirror.path" "/all_printers/s4m/role1"
60 ! U1 SETVAR "ip.mirror.feedback.auto" "on"
70 ! U1 SETVAR "ip.mirror.feedback.path" "/all_feedback"
80 ! U1 SETVAR "ip.mirror.feedback.freq" "0"

```

1	Configures the printer to perform a Mirror Update operation at power-up.
2	Configures the FTP Server "user name" for the printer to use
3	Configures the FTP Server "password" for the printer to use
4	Configures the FTP server address the printer should make a FTP connection to.
5	If the FTP connection is successful, the printer should attempt to perform an Update operation using this root directory.
6	Configures a printer to automatically perform a Mirror Feedback operation at start-up.
7	Configures the printer to upload the resulting Feedback file to the designated directory on the server.
8	Configures a printer to repeat the Feedback operation zero times.

Scenario Two

In this scenario, the printer is configured to not perform a Mirror Update function at start-up. It is configured to perform a Mirror Feedback operation at start-up and thereafter at every 60 minutes.

When the 60 minutes elapses, the printer will attempt to make a FTP connection to the server address 10.14.5.133. If the FTP connection is successful, the printer will attempt a Feedback operation, uploading the resulting Feedback file to the "/all_feedback" directory on the server. After the initial Feedback operation, subsequent Feedback operations will occur at an interval of 60 minutes.



Important • Using the command set in the example below, for the printer to attempt any Mirror Update operation unless the "**ip.mirror.fetch**" command is sent to the printer.



Example: This example shows a Mirror configuration command set. Each line item of the command set is identified with a number. For details on each line item, see the table below.

```

10 ! U1 SETVAR "ip.mirror.auto" "off"
20 ! U1 SETVAR "ip.mirror.username" "printer"
30 ! U1 SETVAR "ip.mirror.password" "printer"
40 ! U1 SETVAR "ip.mirror.server" "10.14.5.133"
50 ! U1 SETVAR "ip.mirror.path" "/all_printers/s4m/role1"
60 ! U1 SETVAR "ip.mirror.feedback.auto" "on"
70 ! U1 SETVAR "ip.mirror.feedback.path" "/all_feedback"
80 ! U1 SETVAR "ip.mirror.feedback.freq" "60"

```

1	Configures the printer to not perform a Mirror Update operation at start-up
2	Configures the FTP Server "user name" for the printer to use
3	Configures the FTP Server "password" for the printer to use
4	Configures the FTP server address the printer should make a FTP connection to.
5	If the FTP connection is successful, the printer should attempt to perform an Update operation using this root directory.
6	Configures a printer to automatically perform a Mirror Feedback operation at start-up.
7	Configures the printer to upload the resulting Feedback file to the designated directory on the server.
8	Configures the printer to attempt a Feedback operation every 60 minutes.

Troubleshooting

If a Mirror process completes unsuccessfully, troubleshooting information can be retrieved by sending this command to the printer:

```
! U1 GETVAR "ip.mirror.last_error"
```

[Table 59](#) lists possible printer responses, an explanation of each, and resolutions. [Table 60](#) provides problem scenarios and solutions.



Important • A mirror path can have up to 50 characters.

Table 59 • Printer Response Troubleshooting

Printer Response	Explanation	Resolution
"connection failed"	The network connection to the Mirror FTP server failed while attempting to perform a printer update.	<ul style="list-style-type: none"> • Check the user name, password, and server address for the Mirror FTP server and ensure that these values are set correctly in the printer. • Ensure that the user name assigned to the printer has the proper permission to log into the Mirror FTP server. • Check that the printer has a successful network connection and is able to send and receive network data.
"Failed to get File: [filename]"	During an update operation, the printer's attempt to retrieve the file [filename] failed.	<ul style="list-style-type: none"> • Ensure that the printer's network connection has not been interrupted. If it has, re-establish network connectivity and retry the update. • Check the server's access permissions for the user name assigned to the printer. Make sure the user name is granted access to read [filename] from the server.
"feedback connection failed"	The network connection to the Mirror FTP server failed while attempting to send printer feedback.	<ul style="list-style-type: none"> • Check the user name, password, and server address for the Mirror FTP server and ensure that these values are set correctly in the printer. • Ensure that the user name assigned to the printer have the proper permission to log into the Mirror FTP server. • Check that the printer has a successful network connection and is able to send and receive network data.
"Failed getting file to parser : [filename]"	During an update operation, the printer's attempt to retrieve a file [filename] in the <mirror_path>/appl directory failed.	<ul style="list-style-type: none"> • Ensure that the printer's network connection has not been interrupted. If it has, re-establish network connectivity and retry the update. • Check the server's access permissions for the user name assigned to the printer. Make sure the user name is granted access to read [filename] from the server.
"Failed to send feedback file: <feedback_path>/<feedback_filename>"	During a feedback operation, the printer's attempt to store the feedback file in the <feedback_path> directory failed.	<ul style="list-style-type: none"> • Ensure that the printer's network connection has not been interrupted. If it has, re-establish network connectivity and retry the update. • Check the server's access permissions for the user name assigned to the printer. Make sure the user name is granted access to write to the <feedback_path> directory. • Ensure that the <feedback_path> directory exists on the remote server.
"Too many files in the firmware download directory"	The Mirror FTP server has more than one file in the <mirror_path>/appl directory.	Ensure that there is only one (1) firmware file in the <mirror_path>/appl directory.

Table 60 • blem Scenario Troubleshooting

Problem Scenario	Solution
I performed a Mirror Update and now my printer is continuously reprogramming.	<p>Ensure that the name of the firmware file in <mirror_path>/app1 matches the version of firmware contained in that file.</p> <p>Example: For firmware version V53.17.2Z, the name of the file in the <mirror_path>/app1 directory must be V53.17.2Z.ZPL to prevent the continuous reprogramming cycle.</p>
Every time a Mirror Update is run, a file is fetched even though no changes have been made to the files on the server.	<ul style="list-style-type: none"> • Check the names of the files in the <mirror_path>/files and <mirror_path>/commands directories. If the names are longer than 16 characters (minus extensions), then the printer will truncate them to 16 characters when downloading. If two filenames truncate to the same 16 characters, the printer will not be able to tell the difference between them and will re-download one of the two files during every update operation. • Check the names of the files in the <mirror_path>/files and <mirror_path>/commands directories. If any of the names are the same, then the printer will not be able to tell the difference. Therefore it will get the one in the files directory, update the timestamp file, and then it will get the one in the commands directory and update the timestamp file. Then, the next time through the one in the files directory will have a different timestamp, so it will get that file again and then check the commands directory, and so on. • Check the server's access permissions for the user name assigned to the printer. Make sure the user name is granted access to read all files in the <mirror_path>/files and <mirror_path>/commands directories.
The printer is continually rebooting.	<ul style="list-style-type: none"> • Check the /commands directory. If a file.delete command resides, then you need to remove file.delete or modify your script.



Notes • _____

Wireless Markup Language (WML)

Wireless Markup Language (WML) offers a text-based method of designing a menu structure for the display screen of selected printers. By leveraging Set/Get/Do (SGD) and files containing Zebra Programming Language (ZPL) commands, customized menus can be created.

Contents

WML Overview	1432
WML Details	1432
Supported Printers	1433
Professional Services for WML Content Creation	1434
WML Tags	1434
Using WML	1434
Send WML Content to the Printer via FTP	1436
Resetting the "ip.ftp.execute_file" setting	1436
Sending WML Content to the Printer via the CISDFCRC16 Command:	1436
Retrieving WML Content from the Printer using the file.type Command:	1437
Using .nrd Files from WML Menus	1438
Removing WML or .nrd Files from the Printer using the file.delete Command:	1438
WML Examples	1438
Example 1	1439
Example 2	1440
Example 3	1441
Example 4	1443
Example 5	1444
Troubleshooting Scenarios	1447

WML Overview

Wireless Markup Language (WML) offers a text-based method of designing customized menus on the LCD front panel of selected printers. By leveraging Set-Get-Do (SGD) and Zebra Programming Language (ZPL) commands, menus that feature both display and command features can be created. The WML “card” structure makes it possible to link from one menu screen to another, creating menus that are as many levels “deep” as desired or reduced to only those options needed by the printer operator.

For details on SGD commands, see [SGD Printer Commands on page 571](#). For details on ZPL commands, see [ZPL Commands on page 31](#).

WML Details

A WML file is made up of tags, which are similar to HTML tags. For a list of the supported WML tags, see [WML Tags on page 1466](#).

Using WML on the printer is dependent on the presence of a single `index.wml` file, stored in the printer's E: memory. The `index.wml` file can contain one or more "cards", with each card defining the content of a single menu. Everything within the card tag (`<card> </card>`) constitutes one complete front panel menu. Cards can also contain hyperlinks to other menus. If the `index.wml` has three cards, with links between the cards, that means there are three front panel menus. It is also possible to create multiple `.wml` files, with links between them and the `index.wml` file. In cases where multiple `.wml` files are used, it is recommended that each file should be structured to provide a link back to the main menu as described in the `index.wml` card.



Note • Only one `index.wml` file can reside on a printer at any time

WML defined menus can use Set-Get-Do (SGD) commands to retrieve or set printer settings. For example, a menu might display the printer's current baud rate, while also offering other potential baud rate settings for the printer selection. In more advanced uses, WML defined menus can cause ZPL command files, stored in the printer E: memory, to be injected into the printers command engine – where they will be read in and acted upon. In this use, the ZPL command file files are known as `.nrd` files.

For example, a WML defined menu could call an `.nrd` file that contains a customized set of printer configuration commands. In this way, different profiles can be created for the printer - making it possible for the printer operator to select the appropriate configuration profile needed for the task the printer is being used in.

An important concept to consider is that the WML menu completely defines what is displayed on the printers screen. If an item is not included in the WML menu definition it will not be displayed to the user.



Note • The `index.wml` file must reside on the printer's **E:** drive for the WML menu to display. If the `index.wml` file is on a drive other than **E:**, then the standard front panel menus display.



Note • When a WML menu is resident on the printer, the standard menu system can be easily be accessed by holding down the Cancel and Setup/Exit buttons (on the ZM400) or the Cancel and Setup/Exit buttons (on Xi4) or the Select button (on GX) on the front panel while the printer powers up. Hold the buttons down until the PRINT READY message displays on the front panel. To return to the WML defined menu, reset the printer again.

Supported Printers

NEEDS TO BE UPDATED FOR LINK-OS PRINTERS IN A FUTURE RELEASE (CMM 06/2015)

WML is supported on the following printers, using the indicated firmware. The buttons on the printers' front panel that are used for Navigating WML defined menus are noted.



Note • When a WML defined menu is in use, the stripes pattern found at the top of selected printers is not displayed.

Table 61 • WML-Supported Printers

Printer	Firmware	Number of "lines" available	Menu Navigation Buttons	Keys to Access Standard Menu System
105SLPlus	V53.17.15Z (or later)	5	Select + (PLUS) - (MINUS)	Hold down CANCEL & SETUP/EXIT during power-up
Xi4™ series	V53.17.5Z (or later)	5	Select + (PLUS) - (MINUS)	Hold down CANCEL & SETUP/EXIT during power-up
ZE500™	V53.17.15Z (or later)	5	Select + (PLUS) - (MINUS)	Hold down CANCEL & SETUP/EXIT during power-up
ZM400™	V53.17.5Z (or later)	5	Select + (PLUS) - (MINUS)	Hold down CANCEL & SETUP/EXIT during power-up
ZM600™	V53.17.5Z (or later)	5	NEXT/SAVE + (PLUS) - (MINUS)	Hold down CANCEL & SETUP/EXIT during power-up
G™ -series	V56.17.5Z (or later)	4	SELECT SCROLL	Hold down SELECT during power-up

Professional Services for WML Content Creation

Zebra offers a Professional Services group that can help with the creation of WML content. To inquire about Zebra's Professional Services, contact your Zebra account representative.

WML Tags

[Table 1](#) shows the WML tags and tag parameters that can be used to create a menu system. As with other tag-based languages, such as HTML and XML, ending tags should be used to indicate the end of a structure. An example of an ending tag would be `</wml>`, which indicates the end of a WML script.

Using WML



Important • Using end tags is required to create well formed and functional WML scripts.

Table 62 • WML Tag Descriptions

<code><wml> </wml></code>	indicates the beginning/end of the WML script
<code><display> </display></code>	indicates the beginning/end of the content to display on-screen
<code><card> </card></code>	indicates the beginning/end of a card
<code><p> </p></code>	indicates the beginning/end of a Paragraph
<code>
</code>	Line break
<code>Menu</code>	Hyperlink to another card
<code><timer value="xx"> </timer></code>	Controls display timer in 10 th of a second increments
<code>" ontimer="#main"</code>	Controls action to take at timer end
<code>alerts="on"</code>	Controls display of on-screen alerts
<code>\$(command.command)</code>	\$ executes a SGD "get"command
<code><do><setvar></do></code>	Controls execution of do and setvar commands

This section provides you with the necessary steps to prepare and transmit WML content to the printer. There are two methods to send WML content to the printer - via the FTP protocol or using the "CISDFCRC16" command. Both methods are detailed below.



The & (ampersand) character should not be used within the body of any Paragraph tag (<p>). If an ampersand is present within the body of a Paragraph tag, a WML-based menu may not function as expected.

The ampersand character should NEVER be used within a paragraph tag for any of the printer's soft keys (P1, P2, etc.); doing so can render the menu inoperable.

Create a Sample index.wml File:

1. Open a text editor.
2. Type (or copy/paste) the following text:

```
<wml>
<display>
  <card>
    <p>Hello World!!</p>
  </card>
</display>
</wml>
```
3. Save this file with this name: `index.wml`.

Prepare the Printer to Receive WML Content via FTP:

WML files – and any .nrd files used by a WML menu structure – must be stored in the printers E: memory location. While the files are first being transmitted to the printer, they should not be processed by the printers ZPL formatting engine. This can be done by configuring the SGD settings "ip.ftp.enable" and "ip.ftp.execute_file".

The "ip.ftp.enable" setting allows the printer to receive content via the FTP protocol. The "ip.ftp.execute_file" setting controls the printers' ability to process or not process commands received via the FTP protocol using the printers ZPL engine. By default, both settings are enabled.

1. Set "ip.ftp.enable" to "on" and the "ip.ftp.execute_file" to "off".

To do this, send these commands to the printer:

```
! U1 setvar "ip.ftp.enable" "on"  
! U1 setvar "ip.ftp.execute_file" "off"
```

2. To confirm these commands are correctly set, send the getvar command to check the settings. To do this, send these commands to the printer:

```
! U1 getvar "ip.ftp.enable"  
! U1 getvar "ip.ftp.execute_file"
```

If a terminal emulation program is being used, the following response should be returned from the printer.

```
"on""off"
```



Note • Only printers using the Internal 10/100 wired or Internal Wireless Plus & Wireless Plus print server can use the ! U1 setvar "ip.ftp.execute_file" "off" command. For other print servers, use the "CISDFCRC16" command method detailed below.

Send WML Content to the Printer via FTP

1. Go to a command prompt.
2. At the command line prompt, type "ftp xxx.xxx.xxx.xxx", where xxx.xxx.xxx.xxx is the IP Address of the printer. For example, if the IP Address of the printer is 10.3.5.34, the command would be:
ftp 10.3.5.34
3. Press Enter to connect to the printer.
4. Press Enter to log in to the printer.
5. At the FTP prompt, type "put index.wml" and press Enter. The index.wml file will be transferred to the printer's E: memory.
6. Type "quit" to disconnect from the printer and exit FTP.

7. Power cycle the printer.

Once the printer completes the power cycle the display should look similar to this:



For additional index.wml examples, see [WML Examples on page 1472](#).



Note • When a WML menu is resident on the printer, the standard menu system can be easily be accessed by holding down the Cancel and Setup/Exit buttons (on the ZM400) or the Cancel and Setup/Exit buttons (on Xi4) or the Select button (on GX) on the front panel while the printer powers up. Hold the buttons down until the PRINT READY message displays on the front panel. To return to the WML defined menu, reset the printer again.



Important • When using the "ip.ftp.execute_file" command, be sure to reset the command back to "on" for use in production processes. If the setting is left in the "off" configuration, when label formats or firmware are sent to the printer via FTP they will not be processed as intended – and the E: memory location can quickly become full.

Resetting the "ip.ftp.execute_file" setting

1. To reset the "ip.ftp.execute_file" setting to the default state, send the following command to the printer.
! U1 setvar "ip.ftp.execute_file" "on"

Sending WML Content to the Printer via the CISDFCRC16 Command:

WML files – and any .nrd files used by a WML menu structure – must be stored in the printers E: memory location. While the files are first being transmitted to the printer, they should not be processed by the printers ZPL formatting engine. This can be done by using the CISDFCRC16 command. This command allows content to be written directly to the E: memory location, without being processed by the printers ZPL formatting engine. By using the CISDFCRC16 command, WML content can be transmitted to the printer via the Serial, USB or Parallel ports.

For additional information on the CISDFCRC16 command, see [page XX](#).

1. To send the sample index.wml shown earlier, send the following commands to the printer:
! CISDFCRC16
0000
INDEX.WML
0000004E
0000
<wml>
<display>
 <card>
 <p>Hello World!!</p>
 </card>
</display>
</wml>
2. Power cycle the printer.
Once the printer completes the power cycle the display should look similar to this:



For additional index.wml examples, see [WML Examples on page 1472](#).



Note • When a WML menu is resident on the printer, the standard menu system can be easily be accessed by holding down the Cancel and Setup/Exit buttons (on the ZM400) or Cancel and Setup/Exit buttons (on Xi4) on the front panel while the printer powers up. Hold the buttons down until the PRINT READY message displays on the front panel. To return to the WML defined menu, reset the printer again.

Retrieving WML Content from the Printer using the file.type Command:

It is possible to retrieve .wml file content from the printer using the "**file.type**" SGD command. To do this, open a terminal emulation connection to the printer and issue the command. For example, to retrieve the contents of the INDEX.WML file, use the following command:

```
! U1 setvar "file.type" "E:INDEX.WML"
```



Note • The **file.type** command is case sensitive – if the file is stored on the printer as **INDEX.WML**, the command must use that same case. Additionally, you should note that **.nrd** files are treated as confidential – they cannot be retrieved from the printer.

Using .nrd Files from WML Menus

It is possible to have a WML menu send the contents of a ZPL or SGD file to the printer to be processed. In this way, the WML menu can leverage complex command scripts in response to the user pressing a single button on the printer. One possible use for this capability would be to create a series of "profile" files that contain all the settings necessary to reconfigure the printer for different uses.

The command files are known as “.nrd” files and are stored directly on the printers E: memory location. The .nrd files can be created using a standard text editor and sent to the printer via FTP or using the CISDFCRC16 command. Files should have an “.nrd” extension.

Removing WML or .nrd Files from the Printer using the file.delete Command:

It is possible to remove .wml files from the printer using the file.delete SGD command. To do this, open a terminal emulation connection to the printer and issue the command. For example, to remove the **INDEX.WML** file, use the following command:

```
! U1 do "file.delete" "E:INDEX.WML"
```

WML Examples

The examples shown below “build” from a simple, display-only, WML menu to a more complex interactive example that uses .nrd files containing ZPL commands. In the initial examples, all lines are explained in detail, in the later examples only the new concepts are covered in detail.

Indenting is used in the examples below to improve readability, it is not necessary in actual use.


Example 1

This example shows a basic WML menu structure that uses only fixed text. The content below shows the WML script plus numbered callouts and a table that identify the function of each of the WML tags.

```
1→ <wml>
2→ <display>
3→   <card>
4→     <p>Hello World!!</p>
5→   </card>
6→ </display>
7→ </wml>
```

1	Beginning of the WML file.
2	Beginning of the content to be displayed.
3	The <card> tag begins the definition of this menu.
4	The <p> beings a paragraph, here displaying Hello World! The </p> ends the paragraph
5	The </card> tag ends the definition of this menu.
6	End of the content to be displayed.
7	End of the WML file.

In use, this WML menu looks similar to this:



Example 2

This example demonstrates a WML menu structure that uses fixed text, plus two SGD commands to display the current printer settings for the Baud rate and ESSID settings on the printer.


```

1→ <wml>
2→ <display>
3→   <card>
4→     <p>Baud: $(comm.baud)</p>
5→     <br/>
6→     <p>AP: $(wlan.essid)</p>
7→   </card>
8→ </display>
9→ </wml>

```

1	Beginning of the WML file.
2	Beginning of the content to be displayed.
3	The <card> tag begins the definition of this menu.
4	The <p> begins a paragraph. ‘Baud:’ displays the text Baud: \$(comm.baud) retrieves and displays the printers’ current baud rate. The </p> ends the paragraph.
5	A line break
6	The <p> begins a paragraph. “AP:” displays the text AP: \$(wlan.essid) retrieves and displays the printers’ current ESSID setting. The </p> ends the paragraph.
7	The </card> tag ends the definition of this menu.
8	End of the content to be displayed.
9	End of the WML file

In use, this WML menu looks similar to this:



Example 3

This example demonstrates a WML menu structure with two menus. Fixed text and SGD commands are used to display the current printer settings for the Baud rate and ESSID settings on menu one and the Firmware version and ZBI State on menu two. Through use of the 'timer' setting, the menu will automatically return to a defined WML card if no buttons are pressed after a set time period. The menu is configured to allow printer alerts (such as HEAD OPEN) to be displayed.



```

1→ <wml>
2→ <display>
3→   <card id="main" title="" ontimer="#main" alerts="on">
4→     <timer value="50"></timer>
5→     <p>Baud: $(comm.baud)</p>
6→     <br/>
7→     <p>AP: $(wlan.essid)</p>
8→     <p> </p><br/>
9→     <p> </p><br/>
10→    <p>   <a href="#system">Firmware</a></p>
11→  </card>
12→  <card id="system" title="" ontimer="#main" alerts="on">
13→    <timer value="50"></timer>
14→    <p>Firmware:</p><br/>
15→    <p>$(appl.name)</p><br/>
16→    <p>ZBI State:</p><br/>
17→    <p>$(zbi.key)</p><br/>
18→    <p>   <a href="#main">Main</a></p>
19→  </card>
20→ </display>
21→ </wml>

```

3	<card id="main" - defines the card's id - "main". title="" - defines the title (not displayed on screen). ontimer="#main" - defines the WML card to display when the timer runs out. alerts="on"> - enables the alerts display feature.
4	<timer value="50"></timer> - sets the timer to 50 (in 10 th of a second increments).
10	<p> Firmware</p> - defines a link to the "system" card.
12	<card id="system" - defines the card's id - "system". title="" - defines the title (not displayed on screen). ontimer="#main" - defines the WML card to display when the timer runs out. alerts="on"> - enables the alerts display feature.
13	<timer value="50"></timer> - sets the timer to 50 (in 10 th of a second increments).
18	<p> Main</p> - defines a link to the "main" card.

In use, these two WML menus look similar to this:



Note • GX series printers can display four lines of text. If you are using a GX series printer, remove one line of text from each “card” to use this example.

Example 4

This example demonstrates a WML menu structure that creates two menu screens and a link to a command file – “config.nrd” – that contains a ZPL command that will cause the unit to print a configuration label.





```

1→ <wml>
2→ <display>
3→   <card id="main" title="" ontimer="#main" alerts="on">
4→     <timer value="50"></timer>
5→     <p>Baud: $(comm.baud)</p>
6→     <br/>
7→     <p>AP: $(wlan.essid)</p>
8→     <p> </p><br/>
9→     <p> </p><br/>
10→    <p>   <a href="#system">Firmware</a></p>
11→  </card>
12→  <card id="system" title="" ontimer="#main" alerts="on">
13→    <timer value="50"></timer>
14→    <p>Firmware:</p><br/>
15→    <p>$(appl.name)</p><br/>
16→    <p>ZBI State:</p><br/>
17→    <p>$(zbi.key)</p><br/>
18→    <p><a href="#main">Main</a>
19→    <a href="#config">Config</a></p>
20→  </card>
21→  <card id="config" title="" ontimer="#main" alerts="on">
22→    <timer value="50"></timer>
23→    <p>Printing </p><br/>
24→    <p> Config Label...</p><br/>
25→    <p></p><br/>
26→    <p>Please wait...</p><br/>
27→    <setvar name="file.run" value="e:config.nrd"/>
28→  </card>
29→ </display>
30→ </wml>

```

18	<pre><p>Main Config</p></pre> <ul style="list-style-type: none"> Defines two links, positioned next to each other - to the "main" and "config" WML cards
26	<pre><setvar name="file.run" value="e:config.nrd"/></pre> <ul style="list-style-type: none"> Defines that the SGD command "file.run" should be used on the "e:config.nrd" file. In this instance, the "e:config.nrd" file contains a single ZPL command - "~wc"

In use, these WML menus look similar to this:



Note • GX series printers can display four lines of text. If you are using a GX series printer, remove one line of text from each "card" to use this example.

Example 5

This example demonstrates a WML menu structure with three cards. The "darkness" card leverages WML and the SGD "print.tone" command to allow the user to both view and configure a setting.


```

1→ <wml>
2→ <display>
3→   <card id="main" title="" ontimer="#main" alerts="on">
4→     <timer value="50"></timer>
5→     <p>Baud: $(comm.baud)</p>
6→     <br/>
7→     <p>AP: $(wlan.essid)</p>
8→     <p> </p><br/>
9→     <p> </p><br/>
10→    <p>   <a href="#system">Firmware</a></p>
11→  </card>
12→  <card id="system" title="" ontimer="#main" alerts="on">
13→    <timer value="50"></timer>
14→    <p>Firmware:</p><br/>
15→    <p>$(appl.name)</p><br/>
16→    <p>ZBI State:</p><br/>
17→    <p>$(zbi.key)</p><br/>
18→    <p><a href="#main">Main</a>       <a
19→    href="#darkness">Darkness</a></p>
20→  </card>
21→  <card id="darkness" title="" ontimer="#main" alerts="on">
22→    <timer value="50"></timer>
23→    <p>Current: $(print.tone)</p><br/>
24→    <p>Change: </p><do type="accept" label="Up"><setvar
25→    name="print.tone" value="+1.0"/></do><br/>
26→    <p>Change: </p><do type="accept" label="Down"><setvar
27→    name="print.tone" value="-1.0"/></do><br/>
28→    <p> </p><br/>
29→    <p><a href="#main">Main</a>       <a href="#config">Config</a></p>
30→  <card id="config" title="" ontimer="#main" alerts="on">
31→    <timer value="50"></timer>
32→    <p>Printing </p><br/>
33→    <p> Config Label...</p><br/>
34→    <p></p><br/>
35→    <p>Please wait...</p><br/>
36→    <setvar name="file.run" value="e:config.nrd"/>
37→  </card>
38→ </display>
39→ </wml>

```

23	<pre><p>Change: </p></pre> <ul style="list-style-type: none"> • Defines the fixed text "Change: " <pre><do type="accept" label="Up"><setvar name="print.tone" value="+1.0"/></do>
</pre> • Defines selecting the word "Up" as equal to sending the value "+1.0" for the SGD command "print.tone". In this case, this increases the setting by 1.0.
24	<pre><p>Change: </p></pre> <ul style="list-style-type: none"> • Defines the fixed text "Change: " <pre>do type="accept" label="Down"><setvar name="print.tone" value="-1.0"/></do>
</pre> • Defines selecting the word "Down" as equal to sending the value "-1.0" for the SGD command "print.tone". In this case, this decreases the setting by 1.0.

In use, these WML menus look similar to this:



Note • GX series printers can display four lines of text. If you are using a GX series printer, remove one line of text from each "card" to use this example.

Troubleshooting Scenarios

Problem Scenario	Corrective Actions
<p>I loaded a WML menu structure on the printer, but the Factory menu structure is displaying.</p>	<ul style="list-style-type: none"> • "The WML files may have syntax errors. Reconfirm that the correct syntax has been used. When creating WML files it is recommended to start with a simple structure, validate that it's functional and build additional content onto the "known good" example • "Power cycle the printer and watch the start-up sequence - if a "WML ERROR" message displays during the start-up, the index.wml file has a syntax error that needs to be corrected. • "The index.wml file may not have been successfully transferred to the printer. Use a terminal emulation program and the following command to retrieve the index.wml file to the PC for examination: ! U1 setvar "file.type" "E:INDEX.WML" • "The index.wml file may not be present in the E: memory location. Validate that the file is present and correctly named. • "Confirm that straight quotes were used in all instances where the quote character was used (use the " character - not " or ?). SGD commands require the use of the straight quote. • "Confirm that the "WML Menu Cancel" buttons, (Setup and Cancel or Cancel and Setup/Exit or Select) were not held down during start up. These actions will cause the standard menu to display
<p>Some characters in the menu are cut off or some lines are not displaying at all.</p>	<ul style="list-style-type: none"> • Characters that extend past the width of the display are truncated, reposition the field as needed. • Check that you have not exceeded that maximum number of lines the display allows (5 lines on ZM and Xi4 series units, 4 lines on the GX series).
<p>My WML menu structure is displaying, but one of the "cards" is not displaying or is unreachable.</p>	<ul style="list-style-type: none"> • The missing "card" may not have been linked to from any of the visible "cards". Review you WML content to ensure that the correct links exist. • The WML files may have syntax errors, reconfirm that the correct syntax has been used. When creating WML files it is recommended to start with a simple structure, validate that it's functional and build additional content onto a known good example. • If the missing card content is contained in a separate .wml file, confirm that the necessary .wml files have been transferred to the printer.
<p>My WML menu structure uses SGD commands to display current settings, but the settings are not displaying.</p>	<ul style="list-style-type: none"> • Validate that the correct syntax was used for the SGD command. • Check the manual page for the command being used. Confirm that the command is supported by the printer & firmware. Use a terminal emulation program to send just the command being used to validate it functions outside the WML menu structure. • Confirm that straight quotes were used in all instances where the quote character was used (use the " character – not " or "). SGD commands require the use of the straight quote. • Characters that extend past the width of the display are truncated, reposition the field as needed. • Check that you have not exceeded that maximum number of lines the display allows (5 on ZM and Xi4 series units).

Problem Scenario	Corrective Actions
<p>My WML menu structure used SGD commands to allow the user to alter printer settings, but the settings are not getting changed as expected.</p>	<ul style="list-style-type: none"> • Validate that the value being used in the <code>value=</code> parameter of the <code><do></code> tag is supported by the SGD command. • Validate that the correct syntax was used for the SGD command. • Check the manual page for the command being used. Confirm that the command is supported by the printer & firmware. Use a terminal emulation program to send just the command being used to validate it functions outside the WML menu structure. • Confirm that straight quotes were used in all instances where the quote character was used (use the " character – not " or ?). SGD commands require the use of the straight quote.
<p>My WML menu structure uses .nrd files to send commands to the printers ZPL or SGD engine, but the commands don't seem to be getting sent when the user selects the on-screen link for the action.</p>	<ul style="list-style-type: none"> • Confirm that the .nrd files are present in E: memory and named as expected. Resend or rename the files if necessary. • Confirm that the WML menu structure is using the correct file name(s). • Confirm that the commands in the files work as expected, independently of the WML menu or .nrd file. • Validate that ZPL and SGD commands have not been interlaced.
<p>I am using the CISDFCRC16 command to transfer files, but the files are either not being transferred to the printer or are showing up with a zero (0) byte size.</p>	<ul style="list-style-type: none"> • Confirm that the Hexadecimal value used for the File Size parameter is correct. This value must be an eight digit file size specified in hexadecimal which indicates the number of bytes in the <code><data></code> section of the command. See the full manual page on the CISDFCRC16 command for additional details. • Validate that the CRC and Checksum parameters are correct (using the "0000" value for these parameters is recommended). • Confirm that the WML file name and extension are in upper case characters. • Confirm that the exclamation mark (!) was included before the command name ("! CISDFCRC16").

Using Weblink

Weblink is a feature of Zebra Link-OS™ printers. Using a secure connection, the Weblink feature allows the printer to directly connect to an internet based server, for the purpose of either sending information to the server or receiving from the server. Weblink can transport data securely through a firewall.

Contents

When Should Weblink be Used?	1483
Configuring Weblink	1484
Basic Configuration	1484
When a Proxy Server is Part of the Network Configuration	1484
When HTTP Authentication is Necessary	1485
Additional Firewall Configuration	1485
Difference Between Conn1 and Conn2	1486
Enable Logging	1486
Navigating the Log Output	1486
SSL/TLS Certificate Errors	1487
Other Typical Errors	1489
Troubleshooting	1490
HTTP Messages	1491

When Should Weblink be Used?

Weblink can transport any information related to device management, transactional data and information to be processed at a later time. It can be used as part of an overall cost reduction solution that leverages web technologies.

Typically, an application called a 'servlet' is created and run on the internet based server, waiting for printers to connect and interact with the servlet. These servlet applications can provide a variety of functions – from sending operating system updates to the printer, to receiving data from the printer and, in turn, using that data to trigger events in other systems.

For example, a solution could be created that would feature the printer consuming data from a Bluetooth® scanner connected to the printer – with that scanned data then being sent from the printer to the internet-based servlet. The servlet would then seek out additional details related to the scanned data, format a document, and then send it to the printer for printing.

Configuring Weblink

When any Weblink setting (with the exception of the logging settings) is adjusted either via SNMP, SGD, or JSON it is required that the printer be reset before the new value takes effect. The **weblink.printer_reset_required** setting will be set to "yes" if there are any settings that have been modified that require a printer reset.

Basic Configuration

To determine how much configuration is necessary the following questions should be considered:

1. Is the remote server the printer is attempting to connect to outside the corporate firewall?
2. Does the firewall require a username and password to access the remote server?
3. Does the printer require a proxy server to access the remote server?
4. Does the firewall permit HTTPS connections initially or does the printer need to connect via HTTP first?

If the answer to any of these questions is 'yes', then more than the basic configuration may be necessary. Depending upon the network environment that the printer is in, accessing the remote server may only require that a few settings be set.

The minimum requirement is that the URL for the remote server be set. For simplicity, assume that only conn1 is being used (this is the typical scenario). See also [Difference Between Conn1 and Conn2 on page 1486](#).

To configure the printer to connect to the remote server:

- a. Set **weblink.ip.conn1.location** to the URL of the remote server.

The URL must conform to the standards described in RFC3986 (<http://www.ietf.org/rfc/rfc3986.txt>). For example, if the remote servlet's full URL is <https://www.examplecorpinc.com/zebra/weblink/>

Configure the location setting as follows:

```
! U1 setvar "weblink.ip.conn1.location"  
"https://www.examplecorpinc.com/zebra/weblink/"
```

- b. Reset the printer.

When the printer has an IP address, it will attempt to connect to the remote server. In the event that the remote server does not indicate that the printer has connected, logging may need to be enabled in order to determine the failure.

When a Proxy Server is Part of the Network Configuration

If a proxy server must be used to access the remote server, the printer's proxy setting must be set to connect to the server. There are typically four properties associated with a proxy server:

- The proxy server scheme: **HTTP** or **HTTPS**
- The proxy server address
- The proxy server port (optional)
- The username and password for the proxy (optional)

To supply the address of the proxy server (assuming a default port and no username/password), configure the proxy setting as follows:

```
! U1 setvar "weblink.ip.conn1.proxy" "https://my.internal.proxy/"
```

In this scenario the proxy address is **my.internal.proxy** and the scheme is **HTTPS**. The default port (1080) will be used. No username or password will be used to authenticate with the proxy.

To specify an alternate port configure the proxy as follows:

```
! U1 setvar "weblink.ip.conn1.proxy"  
"https://my.internal.proxy:3128/"
```

To specify a username and password configure the proxy as follows:

```
! U1 setvar "weblink.ip.conn1.proxy"  
"https://user:pass@my.internal.proxy/"
```

The proxy username, password, and the rest of the URL must follow the rules specified in RFC3986 (<http://www.ietf.org/rfc/rfc3986.txt>).

When HTTP Authentication is Necessary

Use this configuration when, for example, a firewall requires a username and/or password.

It may be necessary to specify a username and password to various routers and servers along the path to the remote server. Typically when using a browser to access the server the authentication request will be presented in the form of a dialog window that asks for the username and password.

Since the printer's connection to the remote server is headless and non-interactive, the Weblink configuration allows a user to enter in a server name/username/password triplet. The triplet will be used in the event that the printer is presented with an authentication request (for example, this typically is requested via the **HTTP/1.1 401 Unauthorized** request).

To specify authentication credentials, issue the following:

```
! U1 setvar "weblink.ip.conn1.authentication.add" "servername.com username  
password"
```

In this scenario the server requesting authentication is `servername.com`. The username and password to be supplied are 'username' and 'password'. The server name can be either a DNS name or an IP address. The username and password cannot be retrieved from SGD, SNMP, or JSON once added. Only the server name will be returned.

More than one set of authentication triplets can be added. The printer will only use the credentials as they are needed. In other words, the printer will only use the credentials for `servername.com` if it receives a **HTTP/1.1 401 Unauthorized** request from `servername.com`.

To see what authentication triplets are specified issue:

```
! U1 getvar "weblink.ip.conn1.authentication.entries"
```

To remove authentication credentials issue the following:

```
! U1 setvar "weblink.ip.conn1.authentication.remove"  
"servername.com"
```

Additional Firewall Configuration

Some firewalls do not allow the first connection attempt for a device to be HTTPS or require new connections periodically to keep the initial connections intact. The weblink test branch was provided to address issues that typically arise because the printer is an unattended device.

To configure the printer to attempt an **HTTP** connection anytime the **HTTPS** connection drops :

```
! U1 setvar "weblink.ip.conn1.test.location"  
"http://www.zebra.com/apps/linktest"  
! U1 setvar "weblink.ip.conn1.test.test_on" "failure"
```

The `weblink.ip.conn1.test.location` can be any valid HTTP address. The default uses a link provided by Zebra that exists for no other purpose than to help developers test their connections to the internet. Setting `weblink.ip.conn1.test.test_on` to `interval` or `both` will force the printer to attempt a connection to the URL in location every `weblink.ip.conn1.test.retry_interval` seconds (default is 900 seconds/15 minutes).

To configure the printer to try an HTTP connection periodically, independent of the HTTPS success:

```
! U1 setvar "weblink.ip.conn1.test.location"  
"http://www.zebra.com/apps/linktest"  
! U1 setvar "weblink.ip.conn1.test.test_on" "interval"  
! U1 setvar "weblink.ip.conn1.test.retry_interval" "900"
```

Difference Between Conn1 and Conn2

The printer has the ability to connect to two different servers. Connection 1 (`conn1`) and Connection 2 (`conn2`) are identical in every way in terms of their configuration. It is expected that `conn2` will typically be left unmodified unless a user has an alternate server that they wish to use to configure the printer.

A typical scenario in which both connections would be used is if a user wishes to have the printer connect to both a configuration server and a data source.

Enable Logging

If your printer has trouble connecting, you may wish to enable logging. By default logging is not enabled in order to reduce the amount of memory consumed when the Weblink feature is enabled. It is recommended that once the Weblink feature is configured properly and is performing as expected that the logging be disabled or that a very small (less than 100) number of logging entries be permitted.

To enable logging, `weblink.logging.max_entries` needs to be modified. By default it is set to 0, which indicates that no messages are logged. When attempting to troubleshoot connection issues it is recommended that `max_entries` be set to at least 100 entries. Setting `max_entries` to 100 means that the 100 newest logging entries will be present in `weblink.logging.entries` as older entries are discarded once the maximum number of entries is reached.

```
! U1 setvar "weblink.logging.max_entries" "100"
```

The logging settings are atypical to the Weblink settings as they do not require the printer to be reset before taking effect. This does not mean that previous logging message that would have been logged will appear when the `max_entries` setting is changed from 0 to a greater value. It means that any new logging messages will be logged from that point forward.

Issue the following command to clear any log entries currently in the `weblink.logging.entries` buffer.

```
! U1 do "weblink.logging.clear" ""
```

Navigating the Log Output

The log will contain useful information, even in the scenario where the printer successfully connects to the remote server. This section explains how to read the log and highlights some of the key entries that will help to determine if the connection was successful.

A typical log entry looks as follows:

```
[12-04-2012 14:57:10.625] [conn1.1] Attempting connection to  
https://www.examplecorpinc.com/zebra/weblink/
```

The first column is the date and time that the event occurred. The format of the date and time matches the format of `rtc.date` and `rtc.time`. The time, however, also includes the milliseconds to aid in troubleshooting network latency concerns.



Note • For printers that do not have a battery to store the Real Time Clock (RTC) value, the date will be restored to the default value upon a power cycle. The default value depends upon how the `rtc.date` SGD is managed. If it has never been set then it will default to the firmware build date (the value in `appl.date`). Otherwise, the value in `rtc.date` will default to the value that it was last set to. This does not mean the value of the `rtc.date` when it was power cycled. It means that when a user sets `rtc.date` that becomes the new default value.

If the printer has a battery then the `rtc.date` is never default and continues to track the date as expected.

The second column indicates the connection name and channel that the entries are associated with. The connection name will match the weblink branch that was configured with the respective URL (for example, `conn1` or `conn2`). The channel number indicates which channel on the respective connection the entries corresponds to.




Note • Channels are additional connections that are requested by the server when the server needs to perform a specific operation that cannot be done on the channel(s) currently open. Typically only the RAW channel is open which operates similar to the RAW TCP port. It is typical to see two channels opened, the main channel and the RAW channel.





The third column is the actual message that contains information about what occurred in the printer at the corresponding time in column one. In the above example the printer was initiating the connection to the URL specified in `weblink.ip.conn1.location`.


Review the section titled [SSL/TLS Certificate Errors on page 1487](#) to understand what it means when certain logging messages/errors appear in the log.

SSL/TLS Certificate Errors

Secure connections to the remote server present the opportunity for several errors when attempting to connect. The errors typically involve the certificates used when connecting via SSL or TLS. This section highlights some of the most common issues involving the certificates.


Error	Cause / Solution
"SSL certificate problem: self signed certificate in certificate chain"	<p>One of the situations that prevent a successful connection is not having the correct Certificate Authority certificates installed on the remote server. Zebra requires that the Zebra Root Certificate Authority and the Zebra Subordinate Certificate Authority be installed on the remote server. This error typically indicates that only one of the Zebra Certificate Authority certificates is installed on the remote server.</p> <p> Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.</p>

Error	Cause / Solution
<p>"SSL certificate problem: unable to get local issuer certificate"</p>	<p>One of the situations that prevent a successful connection is not having the correct Certificate Authority certificates installed on the remote server. Zebra requires that the Zebra Root Certificate Authority and the Zebra Subordinate Certificate Authority be installed on the remote server. This error typically indicates that neither of the Zebra Certificate Authority certificates are installed on the remote server.</p> <p> Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.</p>
<p>"SSL certificate problem: certificate has expired"</p>	<p>This error indicates that the remote server's certificate has expired. This is typically an indication that the printer's date and/or time are incorrect as the Zebra certificates are typically issued for long durations. Check that rtc.date and rtc.time are set correctly.</p> <p> Note • For printers that do not have a battery to store the Real Time Clock (RTC) value, the date will be restored to the default value upon a power cycle. The default value depends upon how the rtc.date SGD is managed. If it has never been set then it will default to the firmware build date (the value in appl.date). Otherwise, the value in rtc.date will default to the value that it was last set to. This does not mean the value of the rtc.date when it was power cycled. It means that when a user sets rtc.date that becomes the new default value.</p> <p>If the printer has a battery then the rtc.date is never default and continues to track the date as expected.</p> <p> Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.</p>
<p>"SSL certificate problem: certificate is not yet valid"</p>	<p>This error indicates that the remote server's certificate was incorrectly issued or that the printer's date and/or time are incorrect. Check that the printer's date and time (rtc.date and rtc.time) are set correctly and that the certificate's start and expiration date are valid.</p> <p> Note • For printers that do not have a battery to store the Real Time Clock (RTC) value, the date will be restored to the default value upon a power cycle. The default value depends upon how the rtc.date SGD is managed. If it has never been set then it will default to the firmware build date (the value in appl.date). Otherwise, the value in rtc.date will default to the value that it was last set to. This does not mean the value of the rtc.date when it was power cycled. It means that when a user sets rtc.date that becomes the new default value.</p> <p>If the printer has a battery then the rtc.date is never default and continues to track the date as expected.</p>

Error	Cause / Solution
"subjectAltName does not match 1.2.3.4"	<p>Part of the certificate validation process involves making sure that the remote server is who it claims to be. A certificate can be created to validate against several aliases/DNS names. Typically the certificate will not contain the IP address of the server as IP addresses are subject to change. When specifying the remote server's URL via weblink.ip.conn1.location be sure to specify one of the DNS aliases listed in the certificate. The valid names will be listed either under the Common Name (CN) field and/or the subjectAltName (SAN or Subject Alternate Name) field within the certificate. For example, the certificate may have the CN set to 'examplecorpinc' and the SAN set to 'examplecorpinc.com' or 'alias.for.examplecorpinc.com'. Any of the CN or SAN names can be used, but, as the IP address is not listed in the CN or SAN it cannot. It is not recommended that the IP address be part of the SAN if a DNS name is available to avoid connection issues that may arise due to subnet change or DHCP lease expirations, etc.</p> <p> Important • When using certificate files, the time on the printer must be set correctly for the websocket connection to succeed, as the time is used in the certificate validation.</p>
"SSL certificate subject name 'examplecorpinc.com' does not match target host name '1.2.3.4'"	
"Unknown SSL protocol error in connection to ..."	When this message is seen it means that the remote server's SSL/TLS configuration is incorrect. Refer to Troubleshooting on page 1490 to ensure the server and printer are both configured correctly.
I do not see any of these errors, but the printer still does not connect.	Refer to Troubleshooting on page 1490 to ensure the server and printer are both configured correctly.

Other Typical Errors

While SSL/TLS connection errors are the most common, there are issues that can arise that prevent a successful connection. This section highlights the most common issues.

Error	Cause / Solution
"Read failed with an unexpected error"	<p>This message typically indicates that connection to the remote server was lost. The connection can either be lost due to the server powering off or resetting, the firewall or proxy server shutting down the connection, or because the remote server gracefully requests that the connection be discontinued.</p> <p> Note • After 60 seconds of inactivity on the connection the printer will attempt to contact the server via a TCP Keepalive. If the connection is still present the server will respond and the connection will remain open. After 10 successive failed attempts to contact the remote the printer will assume the connection is severed and close the connection. The printer will resume it's attempt to connect to the remote server so that when the server comes back online the printer will re-establish communication.</p>

Error	Cause / Solution
"Failed to connect (SP = #, CI = #, UW = #, AC = #, PC = #)"	<p>If this error is seen one or more of the '#' values will be set to 0. This is an indication of an incorrect configuration of the remote server. Ensure that the remote server is setup according to the Servlet configuration in the Zebra Link-OS SDK documentation.</p> <p>This typically indicates an incorrect version of the remote Application Server (for example, Apache/Tomcat version may be incorrect). If this issue persists contact Zebra Technical Support.. See <i>Contacts on page 9</i> and provide the output of the following command (ensure that logging is enabled and that this error appears within the entries).</p> <pre>! U1 getvar "weblink"</pre>

Troubleshooting

Whenever troubleshooting a connection issue, the following questions should be answered to ensure the configuration is correct.

1. Is the printer connected correctly via Wireless or Ethernet?
2. Does the printer have a valid IP address?
3. Can I ping the printer's IP address from a device on the same network as the printer?
4. Is the remote server URL in **weblink.ip.conn1.location** correct and does it point to the remote server that is configured for weblink functionality?
5. Can you connect to the location defined in the **weblink.ip.conn1.location** setting via a browser?
6. Is the remote server I am attempting to connect to outside the corporate firewall?
7. Can the URL specified in **weblink.ip.conn1.test.location** be accessed?
If this is the case, talk with your administrator about altering restrictions for accessing HTTPS connections.
8. Does the firewall require a username and password to access the remote server?
9. Do I require a proxy server to access the remote server?
10. Is the proxy server port the default (1080) or another port (for example, 3128 for the Linux Squid proxy)?



Note • If using the Linux Proxy Server Squid, and you are having trouble connecting, note that it may be configured to:

- a. disallow POST messages
- b. only operate in HTTP/1.0 mode 3
- c. disallow SSL connections.

Refer to your Linux Squid documentation for complete details.

11. Does the firewall permit HTTPS connections initially or do I need to connect via HTTP first?

12. Is the remote server configured to use SSL v3.0 or TLS 1.0?
TLS1.0 is recommended, but SSL v3.0 is also supported. Versions prior to SSL v3.0 and later than TLS v1.0 are not currently supported.
13. Are the Zebra Certificate Authority Certificates correctly installed on the remote server?
14. Was the server's certificate issued by Zebra and is it signed by the Zebra Certificate Authority?
15. Has the server's certificate expired?
16. Is the printer's date and time within the issue and expired period of the server's certificate?
17. Does the value in **weblink.ip.conn1.location** match either the Common Name or one of the names listed in the Subject Alternate Name of the remote server's certificate?
18. Is the proxy server configured correctly and does the respective proxy server allow HTTPS connections via the HTTP CONNECT method?
19. Are there any HTTP authentication attempts when trying to connect that fail?
20. Are there any HTTP/1.1 4xx messages in the log?

If your connection issues persist and the solutions in this document do not help, contact Zebra Tech Support and provide the output of the following command. Ensure that logging is enabled and that the error(s) appear within the entries)

```
! U1 getvar "weblink"
```

HTTP Messages

Message	Cause / Solution
HTTP/1.1 100 Continue	This indicates that the server and printer have begun communicating and is often seen in place of HTTP/1.1 200 OK .
HTTP/1.1 101 Switching Protocols	This indicates that the basic connection to the server worked and the protocol is being switched to a more efficient protocol for data transfer.
HTTP/1.1 200 OK	This indicates that an HTTP GET or HTTP POST was successful.
HTTP/1.1 30x Moved/Redirect/etc	This indicates that the URL specified has moved or that the firewall redirected the printer to another location (typically this is done to authenticate a user in a transparent proxy configuration).
HTTP/1.1 401 Unauthorized	This indicates that the printer either needs to authenticate with the server or failed to authenticate with the remote server (or server/router along the route to the server).
HTTP/1.1 403 Forbidden	This typically means that the authentication was provided and valid, however, the user does not have access to the requested resource.
HTTP/1.1 404 Not Found	This indicates that the remote URL provided points to an invalid location on the server. This does indicate, however, that the server name is valid. Just the path after the domain name is invalid.

HTTP POST Alerts

Link-OS printers can issue alerts to a web server that is listening for HTTP POST requests. The advantage of an HTTP POST alert over the other destinations available (for example, TCP, UDP, SNMP) is that HTTP is firewall friendly.

Contents

Configuring Alerts	
Where the Alert Destination is HTTP POST	1493
How to Parse via PHP	1495
Basic Configuration.....	1495
When a Proxy Server is Part of the Network Configuration	1496
When HTTP Authentication is Necessary	1497
Enabling Logging.....	1497
Navigating the Log Output	1498
Understanding Errors in the Alerts HTTP Log	1498
Troubleshooting	1498
HTTP Messages.....	1499

Configuring Alerts Where the Alert Destination is HTTP POST

Any setting in the **alerts.http** branch that is set will take effect for any **HTTP POST** alerts that occur from that point forward. A printer reset is not required for the settings to take effect.

If the server is configured to accept and process **HTTP POST** messages either via a CGI script or a server-side script such as PHP or ASP then the alert can be forwarded to that server from the printer. The printer will send the alert using the multipart/form-data Content-Type. This allows any type of data, including binary data, to be sent via the **POST**.

The **POST** will support two variables within the body of the **POST**:

- **alertMsg** – This is the alert details and the content follows the format of a standard alert when it is issued over one of the other alert destinations (for example, serial, USB, TCP, etc.).

- `uniqueid` – The unique id of the printer. This matches the value in `device.unique_id`. The HTTP POST request will look as follows (sent when the printer was paused)

```
POST /http_post/alert.php HTTP/1.1
Host: 10.3.4.58
Accept: */*
Connection: close
Content-Length: 281
Expect: 100-continue
Content-Type: multipart/form-data; boundary=-----
-----350c75835f46

-----350c75835f46
Content-Disposition: form-data; name="alertMsg"

ALERT%3A%20PRINTER%20PAUSED
-----350c75835f46
Content-Disposition: form-data; name="uniqueId"

XXQLJ120900310
-----350c75835f46--
```



Important • The message is using HTTP/1.1 and therefore HTTP/1.1 header fields. This is important because some older proxy servers do not handle these fields gracefully and may block the **POST** message.

It is important to note that the message is using HTTP/1.1 and therefore HTTP/1.1 header fields. This is important because some older proxy servers do not handle these fields gracefully and may block the POST message.

How to Parse via PHP

The following example shows how to parse the POST message. It does not, however, show how to use this information on other pages, store the results in a database, report this to another device on the domain, etc. The response in this example will be sent back to the printer, but it will be ignored by the printer. If you wish to see the response you can use a packet sniffing tool such as Wireshark.

```
<?php

>alertMsg = urldecode($_POST["alertMsg"]);
if (preg_match("/(\w+(\s+\w+)?):\s+(((SGD
SET)\s+([\w\d\.\_]+)\s+\-\>\s+(.+))|([\w|\s]+))/", $alertMsg,
$matches)== 1) {

>alertType = $matches[1];

if ($matches[5] === "SGD SET") {
>alertCondition = $matches[5];
>alertSgdName = htmlspecialchars($matches[6]);
>alertSgdData = htmlspecialchars($matches[7]);
} else {
>alertCondition = $matches[3];
}
}

echo "<H1>Alert Received</H1><br/>\r\n";
echo "<h2>Original Message = $alertMsg</h2><br/>\r\n";
echo "<h2>Alert Type = $alertType</h2><br/>\r\n";
echo "<h2>Alert Condition = $alertCondition</h2><br/>\r\n";
echo "<h2>SGD Name = $alertSgdName</h2><br/>\r\n";
echo"<h2>SGD Value = $alertSgdData</h2><br/>\r\n";
?>
```

Basic Configuration

To determine how much configuration is necessary, consider the following questions:

- Is the remote server that the printer is attempting to connect to outside of the corporate firewall?
- Does the firewall require a username and password to access the remote server?
- Does the printer require a proxy server to access the remote server?

If the answer to any of these questions is 'yes', then more than the basic configuration may be necessary. Depending upon the network environment that the printer is in access the remote server may only require that a few settings be set.

To configure an alert to be sent via HTTP POST to a remote server , issue the following

command:

```
! U1 setvar "alerts.add" "PRINTER PAUSED,HTTP-  
POST,Y,Y,http://www.examplecorpinc.com/alerts.php,0,N,"
```

The above command will issue an HTTP POST alert to the remote server (<http://www.examplecorpinc.com/alerts.php>) when the printer is paused or un-paused.

- The first parameter indicates the condition to monitor. A list of available alert conditions can be viewed by issuing:
! U1 getvar "alerts.conditions"
- The second parameter indicates the alert destination. For the purposes of this section HTTP-POST is the preferred destination. A list of available alert destinations can be viewed by issuing:
! U1 getvar "alerts.destinations"
- The third and fourth parameters are 'Send on Set' and 'Send on Clear', respectively. They can be either "Y" for monitor the alert or "N" for don't monitor the alert. If both are set to "N" then the alert will not be added or it will be deleted if the alert already existed. To view which alerts already exist issue:
! U1 getvar "alerts.configured"
- The fifth parameter holds the URL for the server that will be sent the HTTP POST. It holds a maximum of 255 characters for the URL and it must conform to the URI standards described in RFC3986 (<http://www.ietf.org/rfc/rfc3986.txt>).
- The sixth parameter should be set to 0 for HTTP POST alerts.
- The seventh parameter and eighth parameter will not be covered in this section and should be set as indicated in the description above. See the SGD documentation for details on these two parameters.

When a Proxy Server is Part of the Network Configuration

If a proxy server must be used to access the remote server the printer's proxy setting must be set to point to the server. There are typically four properties associated with a proxy server.

- The proxy server scheme: **HTTP** is the only supported scheme
- The proxy server address
- The proxy server port (optional)
- The username and password for the proxy (optional)

To supply the address of the proxy server, assuming a default port and no username/password, configure the proxy setting as follows:

```
! U1 setvar "alerts.http.proxy" "http://my.internal.proxy/"
```

In this scenario, the proxy address is **my.internal.proxy** and the scheme is **HTTP**. The default port (1080) will be used. No username or password will be used to authenticate with the proxy.

To specify an alternate port, configure the proxy as follows

```
! U1 setvar "alerts.http.proxy" "http://my.internal.proxy:3128/"
```

To specify a username and password, configure the proxy as follows:

```
! U1 setvar "alerts.http.proxy"  
"http://user:pass@my.internal.proxy/"
```

The proxy username, password, and the rest of the URL must follow the rules specified in RFC3986 (<http://www.ietf.org/rfc/rfc3986.txt>).

When HTTP Authentication is Necessary

Use this configuration when, for example, a firewall requires a username and/or password.

It may be necessary to specify a username and password to various routers and servers along the path to the remote server. Typically when using a browser to access the server the authentication request will be presented in the form of a dialog window that asks for the username and password.

Because the printer's connection to the remote server is headless and non-interactive, the alert http configuration allows a user to enter in a server name, username, password triplet. The triplet will be used in the event that the printer is presented with an authentication request (for example, this typically is requested via the HTTP/1.1 401 Unauthorized request).

To specify authentication credentials issue the following:

```
! U1 setvar "alerts.http.authentication.add" "servername.com username password"
```

In this scenario the server requesting authentication is servername.com. The username and password to be supplied are 'username' and 'password'. The server name can be either a DNS name or an IP address. The username and password cannot be retrieved from SGD, SNMP, or JSON once added. Only the server name will be returned.

More than one set of authentication triplets can be added. The printer will only use the credentials as they are needed. In other words, the printer will only use the credentials for servername.com if it receives a HTTP/1.1 401 Unauthorized request from servername.com.

To see what authentication triplets are specified issue:

```
! U1 getvar "alerts.http.authentication.entries"
```

To remove authentication credentials issue the following:

```
! U1 setvar "alerts.http.authentication.remove" "servername.com"
```

Enabling Logging

If your printer has trouble connecting, you may wish to enable logging. By default, logging is not enabled in order to reduce the amount of memory consumed when the HTTP alert feature is enabled. It is recommended that once the alert HTTP feature is configured properly and is performing as expected that the logging be disabled or that a very small (less than 100) number of logging entries be permitted.

To enable logging, **alerts.http.logging.max_entries** needs to be modified. By default it is set to 0, which indicates that no messages are logged. When attempting to troubleshoot connection issues it is recommended that max_entries be set to at least 100 entries. Setting max_entries to 100 means that the 100 newest logging entries will be present in alerts.http.logging.entries as older entries are discarded once the maximum number of entries is reached.

```
! U1 setvar "alerts.http.logging.max_entries" "100"
```

The logging settings do not require the printer to be reset before taking effect. This does not mean that previous logging message that would have been logged will appear when the max_entries setting is changed from 0 to a greater value. It means that any new logging messages will be logged from that point forward.

Issue the following command to clear any log entries currently in the alerts.http.logging.entries buffer.

```
! U1 do "alerts.http.logging.clear" ""
```

Navigating the Log Output

The log can contain much information, even in the scenario where the printer successfully connects to the remote server. This section explains how to read the log and highlights some of the key entries that will help to determine if the connection was successful.

A typical log entry looks as follows:

```
[12-04-2012 14:57:10.625] [http] Attempting connection to  
http://www.examplecorpinc.com/alerts.php
```

The first column is the date and time that the event occurred. The format of the date and time matches the format of `rtc.date` and `rtc.time`. The time, however, also includes the milliseconds to aid in troubleshooting network latency concerns.

The second column indicates the connection name, which is currently always set to `'http'`.

The third column is the actual message that contains information about what occurred in the printer at the corresponding time in column one. In the above example the printer was attempting to POST the alert to the connection to the URL specified in the configured alert.

Review [Understanding Errors in the Alerts HTTP Log on page 1498](#) to understand what it means when certain logging messages/errors appear in the log.

Understanding Errors in the Alerts HTTP Log

Error	Cause / Solution
Couldn't connect to host	<p>This could mean any number of things occurred that prevented the printer from connecting. This message is always present when the connection to the remote failed and is typically accompanied by an HTTP Response Code. See HTTP Messages on page 1499 for the possible HTTP Response Codes and their meaning.</p> <p>If this issue persists contact Zebra Technical Support.. See Contacts on page 9 and provide the output of the following command (ensure that logging is enabled and that this error appears within the entries).</p> <pre>! U1 getvar "alerts"</pre>

Troubleshooting

Whenever troubleshooting a connection issue, the following questions should be answered to ensure the configuration is correct.

1. Is the printer connected correctly via Wireless or Ethernet?
2. Does the printer have a valid IP address?
3. Can I ping the printer's IP address from a device on the same network as the printer?
4. Is the remote server URL listed in the output of the `alerts.configured` SGD or `~HU` command output correct, and is the URL of a server iserver that is configured to accept HTTP POST requests?
5. Can you connect to the URL via a browser?

6. Is the remote server I am attempting to connect to outside the corporate firewall?
7. Does the firewall require a username and password to access the remote server?
8. Does the printer require a proxy server to access the remote server?
9. Is the proxy server port the default (1080) or another port?
10. Is the proxy server configured to allow **HTTP POST** messages?
11. Is the proxy server HTTP 1.1 compliant and does it allow HTTP 100 Continue messages? For example, the Squid Proxy Server versions before v3.2 do not fully support HTTP 1.1 requests and may block any **HTTP POST** attempts from the printer.



Note • If using the Linux Proxy Server Squid, and you are having trouble connecting, note that it may be configured to:

- a. disallow POST messages
- b. only operate in HTTP/1.0 mode 3
- c. disallow SSL connections.

Refer to your Linux Squid documentation for complete details.

12. Are there any **HTTP** authentication attempts when trying to connect that fail?
Are there any **HTTP/1.1 4xx** messages in the log?
If your connection issues persist and the solutions in this document do not help, contact Zebra Technical Support.. See *Contacts on page 9* and provide the output of the following command (ensure that logging is enabled and that this error appears within the entries).
`! U1 getvar "alerts"`

HTTP Messages

Message	Cause / Solution
HTTP/1.1 100 Continue	This indicates that the server and printer have begun communicating and is often seen in place of HTTP/1.1 200 OK .
HTTP/1.1 200 OK	This indicates that the HTTP POST was successful.
HTTP/1.1 30x Moved/Redirect/etc	This indicates that the URL specified has moved or that the firewall redirected the printer to another location (typically this is done to authenticate a user in a transparent proxy configuration).
HTTP/1.1 401 Unauthorized	This indicates that the printer either needs to authenticate with the server or failed to authenticate with the remote server (or server/router along the route to the server).
HTTP/1.1 403 Forbidden	This typically means that the authentication was provided and valid, however, the user does not have access to the requested resource.
HTTP/1.1 404 Not Found	This indicates that the remote URL provided points to an invalid location on the server. This does indicate, however, that the server name is valid. Just the path after the domain name is invalid.

Advanced Techniques

This section presents information and commands for using advanced techniques, such as special effects, serialized data fields, control commands, program delimiters, communications, and memory cards.

Contents

Special Effects for Print Fields	1502
--	------

Serialized Data	1502
Variable Data	1503
Stored Formats	1503
Initialize/Erase Stored Formats	1503
Download Format Command	1503
Field Number Command.....	1503
Recall Stored Format Command.....	1504
Control Commands.....	1504
Test and Setup Commands	1505
Calibration and Media Feed Commands	1505
Cancel/Clear Commands	1506
Printer Control Commands.....	1506
Set Dots/Millimeter	1507
Host Status Commands.....	1508
Changing Delimiters and Command Prefixes	1508
Communication Diagnostics Commands.....	1509
Graphic Commands	1509
Image Move.....	1510
Working with Hex Graphic Images	1510
Alternative Data Compression Scheme for ~DG and ~DB Commands	1510
Recalling a Hexadecimal Graphic Image.....	1511
Reducing Download Time of Graphic Images.....	1511
Transferring Object Between Storage Devices	1512
Deleting Graphics from Memory	1512
Defining and Using the AUTOEXEC.ZPL Function	1513
Memory, Flash Cards, and Font Cards.....	1513
Shortcuts and Alternate Schemes for Writing ZPL II Scripts.....	1514

Special Effects for Print Fields

Reverse Printing a Field The **^FR** (Field Reverse Print) command allows a field to appear as white over black or black over white. When printing a field, the **^FR** command indicates that it will print the field the opposite of its background color.

Reverse Printing a Label The **^LR** (Label Reverse Print) command reverses the printing of all fields in the label format. It allows a field to appear as white over black or black over white. **^LR** functions like **^FR**, but it applies to all fields in a label. The **^LR** command remains active until turned off.

Printing a Mirror Image The **^PM** (Print Mirror Image of Label) command prints the entire printable area of the label as a mirror image. This command flips the image from left to right.

Printing a Label Inverted 180 Degrees The **^PO** (Print Orientation) command inverts the label format 180 degrees. In essence, the label is printed upside down.

Serialized Data

The **^SN** (Serialization Data) command allows the printer to index data fields by a selected increment or decrement value (that is, make the data fields increase or decrease by a specified value) each time a label is printed. This can be performed on up to 100 to 150 fields in a given format and can be performed on both alphanumeric and bar code fields. A maximum of 12 of the right-most integers are subject to indexing. The first integer found when scanning from right to left starts the indexing portion of the data field.

If the alphanumeric field to be indexed ends with an alpha character, the data will be scanned, character-by-character, from right to left until a numeric character is encountered. Serialization will take place using the value of the first number found.

Variable Data

To increase throughput, you can set up a program that uses variable data fields. Then, instead of formatting the whole label each time a label is printed, the printer will have to format only the changed data field. To use this capability, you must use the **^MC** and **^FV** commands.

Stored Formats

You can create formats and save them in the printers memory. A stored format can then be recalled and merged with downloaded data to form a complete label. This process saves data transmission time but not formatting time.

To create a format, complete these steps:

1. Design the label.
2. Replace variable data fields with field numbers.
3. Allocate space for the size of the field.
4. Give the format a name.
5. Save the format on the printer to a memory location (R, E, B, A).

You can store multiple formats on the printer, limited only by available memory. If you try to save a format that would overload memory you can confirm that the format has been successfully stored on the printer by printing the LIST FORMATS from the front panel, or by using the **^HW** command to return the directory listing to the host. For details see, [^HW on page 213](#).

If the power is turned off, all stored formats in volatile memory (R:) will be lost.

Initialize/Erased Stored Formats

Stored formats can be selectively erased using the **^ID** command.

Download Format Command

The **^DF** (Download Format) command saves the ZPL II format commands as text strings to be later merged using **^XF** with variable data. The format to be stored may contain Field Number (**^FN**) commands to be referenced when recalled.

While use of stored formats will reduce transmission time, no formatting time is saved since this command saves the ZPL II as text strings which need to be formatted at print time.

Field Number Command

The **^FN** (Field Number) command is used to number the data fields. This command is used in both Store Format and Recall Format operations.

When storing a format, the **^FN** command is used where you would normally use the **^FD** (Field Data) command. When recalling the stored format, use **^FN** in conjunction with the **^FD** (Field Data) command.

Recall Stored Format Command

The **^XF** (Recall Format) command recalls a stored format to be merged with variable data. There can be multiple **^XF** commands and they can be located anywhere in the label format.

When recalling a stored format and merging data utilizing the **^FN** (Field Number) function, the calling format must contain the **^FN** command to properly merge the data.

While use of stored formats will reduce transmission time, no formatting time is saved because the format being recalled was saved as text strings that need to be formatted at print time.



Example: These are examples of using stored format:

Working with Stored Format commands involves designing and saving a stored format, then recalling and merging the format with some variable data.

The following is an example of how to use the various Stored Format commands. First, enter the following format and send it to the printer. Notice that no label is printed. (DATA Indicator went On and Off.)

<pre>^XA^DFFORMAT^FS ^LH30,30 ^BY2,3,100 ^FO120,100^CFD^FN1^FA9^FS ^FO120,160^B3^FN2^FA6^FS ^XZ</pre>	
---	--

Second, enter the following format and send it to the printer. The label shown will be printed.

<pre>^XA^XFFORMAT^FS ^FN1^FDLABEL ONE^FS ^FN2^FDAAA001^FS ^XZ</pre>	
---	--

Control Commands

Control commands may be sent from the host at any time to elicit an immediate response from the printer. Control commands may be sent in a group or separately.

A control command is acted upon when received to perform a variety of actions, such as:

- clearing the memory

- physical action
- a combination of the above such as feeding a label and calculating and storing its length.

The basic format for using all of the control commands is:

~(2-letter command)

For example: ~DG

Test and Setup Commands

The following commands, presented in alphabetical order, are used to test various elements of the printer and its status.


Table 63 • Test and Setup Commands

Command	Function
~HM (Memory Status)	Sending this command to the printer immediately returns a memory status message to host. Use this command whenever you need to know the status of the memory.
~HS (Host Status)	Sending this command to the printer immediately returns a three-line printer status message to the host. Use this command whenever you need to know the status of the printer.
~JR (Power On Reset)	This command resets all of the printer's internal software, performs a power-on self-test, clears the buffer and DRAM, and resets communication parameters and default values. ~JR performs the same function as a manual power-on reset.
~JN (Head Test Fatal)	This command resets the printhead element error override, acting as a toggle for ~JO. The printer then goes into fault status (turns head indicator on steadily) if any subsequent execution of the printing element test detects bad printing elements. This command is only functional on certain printer platforms.
~JO (Head Test Non-Fatal)	This command overrides a failure of head element status check and allows printing to continue. The override is canceled when the printer is turned off or receives a ~JR or ~JN command. The printhead test will not produce an error if the ~JO override is active. This command is only functional on certain printer platforms.
^JT (Head Test Interval)	This command lets you change the printhead test interval from 100 to any desired interval. The printer automatically performs an internal printhead element test, which occurs every 100 labels. This takes place during formatting which minimizes a delay in printing. Therefore, the test may be performed while the printer is in PAUSE. This command is only functional on certain printer platforms.
~WC (Print Configuration Label)	The ~WC command is used to generate a printer configuration label. The printer configuration label contains information about the printer setup, such as sensor type, network ID, ZPL mode, firmware version, and descriptive data on the R:, E:, B:, and A: devices.
~HQ (Host Query)	The ~HQ command group causes the printer to send information back to the host.

Calibration and Media Feed Commands

The following commands, presented in alphabetical order, are used to perform various media and ribbon calibrations and also set the media feed mode for the printer.

Table 64 • Calibration and Media Feed Commands

Command	Function
~JC (Set Media Sensor Calibration)	Forces a label length measurement and recalibrates the media and ribbon sensors.  Note • In continuous mode, only the media and ribbon sensors are recalibrated.
~JG (Graphing Sensor Calibration)	Forces a label length measurement, recalibrates the media and ribbon sensors, and prints a graph (media sensor profile) of the sensor values.
~JL (Set Label Length)	Sets the label length. Depending on the size of the label, the printer will feed one or more blank labels.
^MF (Media Feed)	Dictates what happens to the media at power up and after an error is cleared.

Cancel/Clear Commands

The following command controls the contents of the Zebra input buffer.

Table 65 • Cancel/Clear Commands

Command	Function
~JA (Cancel All)	Cancels all format commands in the buffer. It also cancels any batches that may be printing. The printer stops printing after the current label (if one is printing) is finished printing. All internal buffers are cleared of data. The DATA LED turns off.

Printer Control Commands

The following commands control various printer operations:

Table 66 • Printer Control Commands

Command	Function
^PF (Slew Given Number of Dot Rows)	Causes the printer to slew labels (move labels at a high speed without printing) a specified number of dot rows, at the bottom of the label. This allows faster printing when the bottom portion of a label is blank.
~PH or ^PH (Slew to Home Position)	Causes the printer to feed one blank label. <ul style="list-style-type: none"> The ~PH command feeds one label after the format currently being printing is done or when the printer is placed in pause. The ^PH command feeds one blank label after the format it is in prints.
~PP (Programmable Pause)	Stops printing after the current label is printed (if one is printing) and places the printer in the Pause mode. The operation is identical to pressing the PAUSE button on the front panel of the printer. The printer will remain paused until the PAUSE button is pressed or a ~PS command is sent to the printer.

Table 66 • Printer Control Commands (Continued)

Command	Function
^PP (Programmable Pause)	<p>This command pauses the printer after the format it is in prints. Because this command is not executed immediately, several labels may be printed before the printer is paused.</p> <p>The operation is identical to pressing the PAUSE button on the front panel of the printer. The printer will remain paused until the PAUSE button is pressed or a ~PS command is sent to the printer.</p>
^PQ (Print Quantity)	<p>This command gives control over several printing operations. It controls the number of labels to print, the number of labels printed before the printer pauses, and the number of replications of each serial number.</p>
^PR (Print Rate)	<p>Determines the media speed during printing and the slew speed (feeding a blank label). The printer will operate with the selected speeds until the setting is resent in a subsequent format or the printer is turned off.</p> <p>Limitations of Higher Print Speeds</p> <p>Print speed is application specific. Because print quality is affected by media and ribbon, printing speeds, and printer operating modes, it is very important to run tests for your applications.</p> <ul style="list-style-type: none"> • With high print speeds, use thermal transfer mode only. • Horizontal bar codes with a minimum x dimension of 5 mil may be printed at print speeds of 2 in. (51mm) per second. • Rotated bar codes are limited to a minimum x dimension of 10 mil (modulus 2) at higher print speeds. At x dimension of 5 mil (modulus 1), they may be printed at 2 in. per second. • At high print speeds, Font A at a magnification of 1 is not recommended; all other fonts are acceptable.
~PS (Print Start)	<p>Causes a printer in the Pause mode to resume printing. The operation is identical to pressing the PAUSE button on the front panel of the printer when the printer is already in the Pause mode.</p>

Set Dots/Millimeter

Command	Function
^JM (Set Dots/Millimeter)	<p>Changes the number of dots printed per millimeter. Depending on the printhead, normal dots per millimeter on a Zebra printer are the following:</p> <ul style="list-style-type: none"> • 24 dots/mm (609.6 dots/inch) • 12 dots/mm (304.8 dots/inch) • 8 dots/mm (203.2 dots/inch) • 6 dots/mm (152.4 dots/inch) <p>In some applications, these high densities are not required. For these applications, a lower density of 4 dots/mm (102 dots/inch) or 3 dots/mm (77 dots/inch) can be selected.</p> <p>If used, this command must be entered before the first ^FS command.</p>

Host Status Commands

Table 67 • Host Status Commands

Command	Function
~HI (Host Identification)	This command is designed to be sent from the Host to the Zebra printer to find out the type of Zebra printer. Upon receipt, the Zebra printer will respond to the Host with a character string that gives information about the printer such as the version of firmware, dots per inch, memory, and printer options.
^SP (Start Print)	<p>This command allows a label to start printing at a specified point before the entire label has been completely formatted. On extremely complex labels, this command can increase the overall throughput of the printer.</p> <p>The command works as follows: you specify the dot row at which the ^SP command is to take affect. This then creates a label 'segment.' Once the ^SP command is processed, all information in that segment will be printed. During the printing process, all of the commands after the ^SP will continue to be received and processed by the printer.</p> <p>If the segment after the ^SP command (or the remainder of the label) is ready for printing, media motion does not stop. If the next segment is not ready, the printer will stop "mid-label" and wait for the next segment to be completed. Precise positioning of the ^SP command is somewhat of a trial-and-error process as it depends primarily on print speed and label complexity.</p> <p>The ^SP command can be effectively used to determine the worst-case print quality. You can determine if using the ^SP command is appropriate for the particular application by using the following procedure. If you send the label format up to the first ^SP command and then wait for printing to stop before sending the next segment, the printed label will be a sample of the worst case print quality. It will also drop any field that is out of order.</p>
~WC (Print Configuration Label)	This command is used to generate a printer configuration label. This command only works when the printer is idle.
~WL Print Network Configuration Label	This command is used to generate a network configuration label. This command only works when the printer is idle.

Changing Delimiters and Command Prefixes



Important • The delimiters used in the incoming ZPL script must match the delimiters set on the printer. If you change the delimiters on the printer, any ZPL script that uses the default delimiters will not work.

For some applications, you may need to change the ZPL II default delimiter (,), the format command default prefix (^), and/or the control command default prefix (~). Any ASCII character may be set as the delimiter.

You might change these characters if you are using a hand-held terminal that does not have a comma to enter the ZPL II commands, if you are working with a mainframe that has trouble processing the caret, or if you find some other character(s) easier to use.

Reasons to set an alternate delimiter include, but are not limited to:

- you are using a hand-held terminal that does not have a comma to enter the ZPL II commands;
- you are working with a host system that does not easily output the default delimiter (for example, AS/400)

- you find some other character(s) easier to use.

Communication Diagnostics Commands

Zebra printers support communication diagnostics through both hardware and software control. You can use these diagnostics to troubleshoot programs.

Table 68 • Communication Diagnostics Commands

Command	Function
~JD (Enable Communications Diagnostics)	Initiates a diagnostic mode that produces an ASCII printout (using current label length and full width of printer) of all characters received by the printer. This printout includes the ASCII Characters, the HEX value and any communication errors.
~JE (Disable Diagnostics)	Cancels the diagnostic mode and returns the printer to normal label printing.

Graphic Commands

In addition to text and bar codes, multiple types of graphics can be printed on a Zebra printer:

- boxes and lines (^GB), circles (^GC), diagonal lines (^GD), and ellipses (^GE)
- ZPL II label formats saved as graphics images
- graphic images in Hexadecimal format
- graphic symbols (^GS)
-

Table 69 • Boxes, Lines, Circles, Diagonal Lines, and Ellipses

Command	Function
^GB (Graphic Box)	The ^GB command is used to draw boxes and lines as part of a label format. Boxes and lines are used to highlight important information, divide labels into distinct areas, or to improve the appearance of a label. The same format command is used for drawing either boxes or lines.
^GC (Graphic Circle)	The ^GC command produces a circle on the printed label. The command parameters specify the diameter (width) of the circle, outline thickness, and color. Thickness extends inward from the outline.
^GD (Graphic Diagonal Line)	The ^GC command produces a circle on the printed label. The command parameters specify the diameter (width) of the circle, outline thickness, and color. Thickness extends inward from the outline.
^GE (Graphic Ellipse)	The ^GE command produces an ellipse in the label format.
^GS (Graphic Symbol)	The ^GS command enables you to generate the registered trademark, copyright symbol, and other symbols.

These label formats can also be stored as graphic images and data can be merged with them at print time. Additionally, ZPL II will permit the printing of graphic images from other sources that have been created in (or converted to) hexadecimal (HEX) format. Such graphic images can come from a variety of sources, including CAD programs, draw and paint programs, and scanned images.

Image Move

The **^IM** (Image Move) command performs a direct move of an image from a storage area into the bitmap. The command is identical to the Recall Graphic command except that there are no sizing parameters.

Working with Label Formats as Graphics

The **^IS** (Image Save) and **^IL** (Image Load) commands are used to save a ZPL label format (including text and/or bar codes) in the printer's DRAM, FLASH, or PCMCIA as a special graphic image. The **^IS** (Image Save) and **^IL** (Image Load) commands are used to save a ZPL label format (including text and/or bar codes) in the printer's DRAM, FLASH, PCMCIA, or battery backed up SRAM, as a special graphic image. This increases the throughput of a series of similar but not identical labels.

Instead of formatting each individual label completely, store the constant fields as an image (known as creating a template). Then, in subsequent label formats, commands are issued to recall that graphic image format and merge it with variable data.

Working with Hex Graphic Images

ZPL II can be used to save graphic images in HEX format in DRAM, FLASH, or PCMCIA, depending on the type of memory installed in your printer. ZPL II can be used to save graphic images in HEX format in DRAM, FLASH, PCMCIA, or battery backed up SRAM, depending on the type of memory installed in your printer. The image might be created using a CAD program, a draw or paint program, or a scanner. These images can then be printed on the label. Graphic images may be created using a program that creates files in the .PCX format. These files must then be converted to ZPL II graphic format .GRF (pure hexadecimal data without headers or other extraneous information) for use as part of a label format.

You can use ZebraDesigner or ZebraNet Bridge Enterprise to convert the .PCX graphic format into the pure hexadecimal .GRF graphic format. Hexadecimal data may also be directly input as part of a ZPL II program. Manually preparing a string of HEX code is possible but usually impractical.

Alternative Data Compression Scheme for ~DG and ~DB Commands

There is an alternative data compression scheme recognized by the Zebra printer. This scheme further reduces the actual number of data bytes and the amount of time required to download graphic images and bitmapped fonts with the **~DG** and **~DB** commands.



Note • Values start with G since 0 through 9 and A through F are already used for HEX values.)

G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19

These numbers represent the repeat counts 20, 40, 60, 80,....400 on a subsequent hexadecimal value.

g	h	i	j	k	l	m	n	o	p	q
20	40	60	80	100	120	140	160	180	200	220
r	s	t	u	v	w	x	y	z		
240	260	280	300	320	340	360	380	400		

➔ **Example 1:** Sending **M6** to the printer is identical to sending the following hexadecimal data:
6666666

The M has the value of 7. Therefore **M6** sends seven (7) hexadecimal 6's.

➔ **Example 2:** Sending **hB** to the printer is identical to sending the following hexadecimal data:
BB

The h has a value of 40. Therefore, **hB** sends 40 Hexadecimal B's.

Repeat Values Several repeat values can be used together to achieve any desired value.

Several repeat values can be used together to achieve any value desired. **vMB** or **MvB** will send 327 hexadecimal B's to the printer.

- a comma (,) fills the line, to the right, with zeros (0) until the specified line byte is filled.
- an exclamation mark (!) fills the line, to the right, with ones (1) until the specified line byte is filled.
- a colon (:) denotes repetition of the previous line.

Recalling a Hexadecimal Graphic Image

The **^XG** (Recall Graphic) command is used to recall one or more graphic images for printing. This command is used in a label format to merge pictures such as company logos and piece parts, with text data to form a complete label.

An image may be recalled and resized as many times per format as needed. Other images and data may be added to the format.

Reducing Download Time of Graphic Images

There is a method of reducing the actual number of data bytes sent to the printer when using the **~DG** command.

If the HEX string ends in an even number of zeros (0's), a single comma (,) can be substituted for ALL of the zeros. If the HEX string ends in an odd number of zeros, one zero and a single comma is required. The exclamation mark (!) and the colon (:) described under *Repeat Values on page 1511* can also be used.



Note • The text rows in your editor may not be the same as the dot rows used by ZPL II. The editor may word wrap or truncate the dot rows. ZPL II ignores the end of a text line (carriage returns and line feed characters).

Transferring Object Between Storage Devices

The **^TO** (Transfer Object) command is used to copy an object or group of objects from one storage device to another. It is quite similar to the copy function used in personal computers.

Source and destination devices must be supplied and must be different and valid for the action specified. Invalid parameters will cause the command to be ignored.

There are no defaults associated with this command. However, the asterisk (*) may be used as a wild card for Object names and extensions. For instance, ZEBRA.* or *.GRF would be acceptable forms for use with **^TO** command.

The Asterisk (*) can be used to transfer multiple object files (except *.FNT) from the DRAM to the Memory Card. For example, you have several object files that contain logos. These files are named **LOGO1.GRF**, **LOGO2.GRF**, and **LOGO3.GRF**.



Example: You want to transfer all of these files to the Memory Card using the name NEW instead of LOGO. By placing an Asterisk (*) after both LOGO and NEW in the transfer command, you can copy all of these files with one command. The format for this would be as follows:

```
^XA
^TOR:LOGO*.GRF,B:NEW*.GRF
^XZ
```



Note • If, during a multiple transfer, a file is too big to be stored on the Memory Card, it will be skipped. All remaining files will be checked to see if they can be stored. Those that can be stored, will be stored.

Deleting Graphics from Memory

The **^ID** (Item Delete) command deletes objects, images, fonts, and formats from storage areas selectively or in groups. This command can be used within a printing format to delete objects just prior to saving new ones or can be in a stand-alone type format simply to delete objects.

The object name and extension support the use of the asterisk (*) as a wildcard. This allows for easy deletion of selected groups of objects.

The following are various examples of using the **^ID** command.



Example 1: To delete just stored formats from DRAM:

```
^XA^IDR:*.ZPL^XZ
```



Example 2: To delete formats and images named SAMPLE from DRAM regardless of the extension:

```
^XA^IDR:SAMPLE.*^XZ
```


➔ **Example 3:** To delete the image SAMPLE1.GRF prior to storing SAMPLE2.GRF:

```

^XA
^F025,25^AD,18,10^FDDelete^FS
^F025,45^AD,18,10^FDthen Save^FS
^IDR: SAMPLE1.GRF^FS
^ISR: SAMPLE2.GRF^FS
^XZ
    
```

➔ **Example 4:** To delete everything from DRAM:

```

^XA^IDR:*. *^XZ
    
```

Defining and Using the AUTOEXEC.ZPL Function

An **AUTOEXEC.ZPL** file function is supported by the printer. It functions in much the same way as the **AUTOEXEC.BAT** file in MS-DOS. The **AUTOEXEC.ZPL** file function can be used for setting up various parameters at the time the printer is powered up (such as **^COY**, **^LL**, **^CWF**). The function can also be recalled at any time after power up.

This file must initially be in the extra EPROM, FLASH, or PCMCIA memory. When the printer is powered on, it looks to the extra memory site for the stored format called **AUTOEXEC.ZPL**. If found, the contents of the file are automatically executed as a stored format.

➔ **Example:** This is an example of an **autoexe.zpl** file:

```

^XA
^DFE:AUTOEXEC.ZPL^FS
^SEE:JIS.DAT^FS
^CW1,E:ANMDJ.TTF^FS
^XZ
    
```

Memory, Flash Cards, and Font Cards

Zebra printers come with a variety of memory device, including DRAM, EPROM, PCMCIA, Flash, socket Flash, and battery backed-up RAM.



Note • Not all memory options are available on all printers.

Most Zebra printers allow you to print a printer configuration label, which will show the letter designation assigned to your printer memory options. For printer models that do not support this feature, use [Table 70](#) to see how the memory IDs are assigned. Memory IDs default to these values when the printer is reset to factory defaults.

Table 70 • Letter Designations for Different Memory Options



Memory Option	Default Letter Designation
EPROM	E:
PCMCIA	B:
Flash	E:

Table 70 • Letter Designations for Different Memory Options

Memory Option	Default Letter Designation
DRAM	R:
Battery backed-up RAM	B: or E:
Socket Flash	B:
Compact Flash	A:

A few ZPL II commands directly affect the types of memory available to Zebra printers. These commands are **~JB**, **^JB** and **~HM**

Table 71 • Commands that Affect Available Memory Types

Command	Function
~JB (Reset Battery Dead)	<p>This command is sent to the printer if either of these conditions exist:</p> <ul style="list-style-type: none"> • If the B: memory card is intentionally cleared (reinitialized). • If the battery supplying power to the Battery Powered Font Card fails and is replaced. (A bad battery would show a “battery dead” condition on the printer configuration label.) <p> Note • If you replace the battery but do not send this command to the printer, the Battery Powered Font Card will not function.</p>
^JB (Initialize Flash Memory)	<p>This command is used to initialize the two types of Flash Memory available in the Zebra printers.</p> <p> Note • Link-OS printers use an automatic memory management system that eliminates the need to manually initialize the Flash Memory system.</p>
~HM (Host Memory Status)	<p>Sending this command to the printer immediately returns a memory status message to the host. Use this command whenever you need to know the status of the memory.</p> <p>When the Host Memory Status Command, ~HM, is sent to the Zebra printer, a line of data containing three numbers is sent back to the Host. The following is an example:</p> <p>1024,0780,0780</p> <ul style="list-style-type: none"> • The first value is the total amount of RAM (Random Access Memory) installed in the printer. This number is in Kilobytes. • The second value is the maximum amount of RAM available to the user. This number is in Kilobytes. • The third value is the amount of RAM currently available to the user. This number is in Kilobytes.

Shortcuts and Alternate Schemes for Writing ZPL II Scripts

ZPL II programming scripts can be written in a variety of ways. There are, however, more efficient ways to write a ZPL II script depending on the application and the commands used. The following are certain ways to write the same ZPL II script, each yielding the same result.



Example 1: The Code 39 bar code shows the ZPL II script written like this:

```
^XA^F0100,75^BY3
```

```
^B3N,N,100,Y,N
```

```
^FD123ABC^XZ
```

Since it is only one field, however, the entire command can be written as a one line entry:

```
^XA^F0100,75^BY3^B3N,N,100,Y,N^FD123ABC^XZ
```

Finally, this script can be further simplified by writing it on one line, using the comma (,) delimiter to reduce the default parameters in the **^B3** command and eliminating the default parameters at the end of the **^B3** command:

```
^XA^F0100,75^BY3^B3,,100^FD123ABC^XZ
```



Example 2: You might write your ZPL II scripts in any way that makes sense to you. Some programmers prefer to write out each format command and field on a line by line basis like this:

```
^XA
^PR2^FS
^LL935^FS
^LH30,30^FS
^F020,10^AF^FDZEBRA^FS
^F020,60^B3,,40^FDAA001^FS
^F020,180^AF^SNSERIAL NUMBER 0000000111,1,Y^FS
^PQ10^FS
^XZ
```

Although this script will print with no problems, it contains unnecessary **^FS** (Field Separator) commands which have been placed after the format commands. Some programmers feel it is required to place a **^FS** command at the end of each line, but the **^FS** command is only needed to separate specific fields. Therefore, the script would transmit more quickly written like this:

```
^XA
^PR2
^LL935
^LH30,30
^F020,10^AF^FDZEBRA^FS
^F020,60^B3,,40^FDAA001^FS
^F020,180^AF^SNSERIAL NUMBER 0000000111,1,Y^FS
^PQ10
^XZ
```

Other programmers prefer to keep the format commands on one line as an organizational preference, like this:

```
^XA^PR2^LL935^LH30,30
^F020,10^AF^FDZEBRA^FS
^F020,60^B3,,40^FDAA001^FS
^F020,180^AF^SNSERIAL NUMBER 0000000111,1,Y^FS
^PQ10^XZ
```

The label will print out the same so you should develop a scripting pattern that suits your own organizational style but one which is efficient and is concerned with keeping transmission times to a minimum.

Font Shortcuts

There are times when you might include a specific font into your script and use it repeatedly within different fields. The following is an example of one way to write this script:

```
^XA
^F0120,108^A0N,89^FDA Guide to^FS
^F0120,207^A0N,89^FDZPL II^FS
^F0120,306^A0N,89^FDProgramming^FS
^F0120,405^A0N,89^FDLanguage^FS
^XZ
```

Notice that the **^FS** command is used on the second to last line to close the field. Actually, it is unnecessary because the **^XZ** will accomplish the same thing, so we can remove it from our script. Also, since the font and font size are not changing within the fields, this script can be simplified for quicker transmission by removing the unnecessary font entries and listing the font information once using the **^CF** command (see [^CF on page 131](#)):

```
^XA
^CF0,89
^F0120,108^FDA Guide to^FS
^F0120,207^FDZPL II^FS
^F0120,306^FDProgramming^FS
^F0120,405^FDLanguage
^XZ
```

This script can be made even more efficient by including the **^FB** command to identify the left origin of the text which occurs at the same place each time. For details, see [^FB on page 163](#):

```
^XA
^CF0,89
^F0120,108
^FB800,6
^FDA Guide to\&ZPL II\&Programming\&Language
^XZ
```



Note • The entries “\&” within the text indicate a carriage return/line feed as allowed by the **^FB** command. For details, see [^FB on page 163](#).

If you wanted to change the font type or size within the script, however, you would need to include the specific font parameters within the field where the change occurs. In this case, you would not want to use the **^FB** command because the change in font size (in our example below) will affect the y-axis (up and down) position of the text.

You can still use the **^CF** command, but you will need to include the specific font information on the line where the change in the field occurs:

```
^XA
^CF0,89
^F0120,108^FDA Guide to^FS
^F0120,207^FDZPL II^FS
^F0120,306^A0N,110^FDProgramming^FS
^F0120,426^FDLanguage
^XZ
```


Glossary

ASCII American Standard Code for Information Interchange. A 7-bit character set that includes Latin characters, as well as control and punctuation characters.

bidirectional text layout The arrangement of characters with mixed directionality on a single line. For example, English and Arabic.

big-endian In the encoding, the most significant byte is stored first.

byte order mark BOM; indicates big-endian (BE) or little-endian (LE).

character The smallest component of a writing system that has understanding, refers to the abstract meaning not the specific shape.

character code Another term for code point.

character set A collection of characters.

character shaping Characters assume different glyphic forms depending on the context. They can be used with a script-based language.

code point An integral reference number assigned to a character.

coded character set An ordered collection of characters that are assigned an integral reference number.

combining semantic cluster Consists of an atomic character, a combining character sequence consisting of a base character plus one or more nonspacing marks, enclosing marks, combining word joiner, such as an Indic virama, or a sequence of Hangul jamos equivalent to a Hangul syllable.

diacritic A mark that is added to a letter or other character to change its value or meaning.

encoding The mapping of a characters code points to a sequence of bytes used to represent the data.

font An electronic collection of glyphs used for the visual representation of characters.

GB18030 A standard required by the People's Republic of China for operating systems of non-handheld computers.

GB 2312 A Chinese character set and encoding.

glyph The visual representation of a character, such as a shape or image. A default glyph character is typically used when the requested glyph is not available in the font.

grapheme cluster Consists of an atomic character, a combining character sequence consisting of a base character plus one or more nonspacing marks or enclosing marks, or a sequence of Hangul jamos equivalent to a Hangul syllable.

ISO 10646 An international standard that defines the Universal Character Set (UCS) and a character encoding. The UCS matches Unicode.

ISO 8859-1 An encoding standard for representing Western European languages using the Latin Alphabet.

language A system of sounds and scripts used to represent and communicate concepts, ideas, meanings, and thoughts.

ligature A glyph representing a combination of two or more characters.

little-endian In the encoding, the least significant byte is stored first.

open type A file format for scalable font files that extends the existing TrueType font file format used by Microsoft Windows and Apple Macintosh operating systems. OpenType tables support advanced layout features.

presentation form A pre-combined character, ligature or variant glyph that has a separate code point; used for compatibility.

rts/cts A method for a hardware handshake via the request-to-send/clear-to-send pins.

script A collection of symbols used to represent textual information in one or more writing systems.

Shift-JIS A shifted encoding of the Japanese character encoding standard, JIS X 0208, heavily deployed in PCs.

True type An outline font format that is scalable without quality loss.

Unicode The universal character set and encoding maintained by the Unicode Consortium.

UTF-8 The Unicode encoding that assigns each character code point to a sequence of one to four bytes.

UTF-16 A Unicode encoding form that represents Unicode code point values in the BMP with 16-bit code units and Unicode code point values in the supplementary planes with pairs of 16-bit code units.

UTF-16BE A Unicode encoding scheme based on UTF-16 that serializes the bytes in each code unit in big-endian order.

UTF-16LE A Unicode encoding scheme based on UTF-16 that serializes the bytes in each code unit in little-endian order.



Corporate Headquarters

Zebra Technologies Corporation
3 Overlook Point
Lincolnshire, IL 60069 USA
T: +1 847 634 6700
Toll-free +1 866 230 9494
F: +1 847 913 8766

<http://www.zebra.com>